

120 Machine Manual

© 2020 The Aagard Group, LLC



The Aagard Group, LLC



by The Aagard Group, LLC

© 2020 The Aagard Group, LLC

Products that are referred to in this document may be either trademarks and/or registered trademarks of the respective owners. The publisher and the author make no claim to these trademarks.

While every precaution has been taken in the preparation of this document, the publisher and the author assume no responsibility for errors or omissions, or for damages resulting from the use of information contained in this document.

Printed: January 2020 in Alexandria, Minnesota.

Table of Contents

Introduction, Safety, Installation and Training

| | |
|-------------------------------------------------|------|
| Introduction, Safety, Installation and Training | 1-2 |
| About This Manual | 1-3 |
| Training | 1-4 |
| Level 1 | 1-6 |
| How To Use This Manual | 1-6 |
| Navigation | 1-7 |
| Training Points | 1-8 |
| Supplemental Documentation | 1-9 |
| Search | 1-10 |
| aagardmanuals.com | 1-11 |
| Safety Recommendations | 1-12 |
| E-Stop Locations | 1-13 |
| Machine Operation | 1-14 |
| Stack Light and Warning Horn | 1-15 |
| Button Functions | 1-16 |
| Log In Screen | 1-17 |
| Keyboard | 1-18 |
| HMI Main Screen | 1-19 |
| States and Modes | 1-22 |
| Production Data Page | 1-26 |
| Continuous Running | 1-30 |
| Carton Blanks | 1-31 |
| Case Blanks | 1-33 |
| Glue | 1-34 |
| Hot Melt Adhesive | 1-35 |
| Sequence of Operation | 1-36 |
| Popups and Notices | 1-43 |
| Message Notices | 1-45 |
| Level 2 | 1-47 |
| Product Download Page | 1-47 |
| Changeover Location Drawing | 1-48 |
| Changeover Adjustments | 1-49 |
| Changeover Quick Reference Chart | 1-55 |
| Product Download Changeover Adjustments Page | 1-57 |
| Continuous Running | 1-59 |

| | |
|---------------------------------------|-------|
| Carton Blanks | 1-60 |
| Case Blanks | 1-62 |
| Glue | 1-63 |
| Log In Screen | 1-64 |
| Operator Control Panel (HMI) | 1-65 |
| HMI Main Screen | 1-66 |
| Fault History Page | 1-69 |
| Reject History Page | 1-73 |
| Production Data Page | 1-77 |
| Advanced Page | 1-81 |
| Glue Page | 1-84 |
| View Notices System Wide | 1-86 |
| Change Log Page | 1-89 |
| View Changeover Adjustments | 1-91 |
| Device List | 1-92 |
| I/O Diagnostics Page | 1-98 |
| Jog Page | 1-100 |
| Reference Page | 1-105 |
| Servo Reference Positions | 1-108 |
| Drive Function and Associated Devices | 1-126 |
| Drive Diagnostics Page | 1-130 |
| Fault Code History Page | 1-136 |
| Sercos Diagnostics Page | 1-138 |
| Member Map Diagnostics Page | 1-144 |
| Vacuum Pump Shutdown | 1-152 |
| Level 3 | 1-153 |
| Startup Page | 1-153 |
| Servo Initialize Option | 1-155 |
| Initialization Data Page | 1-156 |
| Fault History Page | 1-158 |
| Reject History Page | 1-162 |
| Edit Shifts Screen | 1-166 |
| View Notices System Wide | 1-168 |
| Misc Tags Page | 1-171 |
| Change Log Page | 1-172 |
| Glue Page | 1-174 |
| Motor Data Page | 1-176 |
| Solenoid Data Page | 1-178 |
| Servo Drive Data Page | 1-180 |
| Servo Drive Data Page - Advanced Tab | 1-183 |

| | |
|--------------------------------------------------------------|-------|
| Alternating Jog | 1-185 |
| Servo Drive Tuning | 1-186 |
| Manual SD Enabling | 1-187 |
| Edit System Product Page | 1-189 |
| Edit C40 Recipes Page | 1-191 |
| Changeover Adjustments Page | 1-193 |
| Rearrange Page | 1-194 |
| General Data Page | 1-196 |
| Servo Moves Data Page | 1-197 |
| Cam Offsets Page | 1-200 |
| Cam Data Page | 1-202 |
| Cam Generator Choose Cam Group | 1-205 |
| Cam Generator Choose Product | 1-206 |
| Cam Generator Main Screen | 1-207 |
| Maintenance | 1-210 |
| Maintenance Topics | 1-210 |
| Training Topics and Completion Sheet | 1-211 |
| Safety | 1-225 |
| Safety Recommendations | 1-226 |
| E-Stop Locations | 1-227 |
| Machine Operation | 1-228 |
| Stack Light and Warning Horn | 1-229 |
| Button Functions | 1-230 |
| Servo Motor with Brake | 1-231 |
| Installation and Power-Up | 1-232 |
| Factory Settings | 1-235 |
| Machine Description, Specifications and Operation | |
| Machine Description, Specifications and Operation | 2-2 |
| As-Built Documentation | 2-3 |
| General Terms and Conditions | 2-4 |
| Efficiency and Warranty Statement | 2-7 |
| Documentation Accuracy Statement | 2-8 |
| Floor Plan | 2-9 |
| Continuous Running | 2-10 |
| Case Blanks | 2-11 |
| Glue | 2-12 |
| Sequence of Operation | 2-13 |
| Device List | 2-20 |
| Fuse Locations | 2-26 |

| | |
|---------------------------------------|------|
| Drive Function and Associated Devices | 2-27 |
| Servo Reference Positions | 2-31 |

Operator Control Panel (HMI)

| | |
|----------------------------------------------|-------|
| Operator Control Panel (HMI) | 3-2 |
| Keyboard | 3-3 |
| Startup and Download | 3-4 |
| Startup Page | 3-5 |
| Initializing Page | 3-7 |
| Product Download Page | 3-8 |
| Edit System Products Page | 3-9 |
| Edit C40 Recipes Page | 3-11 |
| Product Download Changeover Adjustments Page | 3-13 |
| Log In Screen | 3-15 |
| HMI Main Screen | 3-16 |
| Custom Buttons | 3-19 |
| Packer Funnel / FunTucker Adjustment Page | 3-21 |
| States and Modes | 3-24 |
| Popups and Notices | 3-28 |
| Map | 3-30 |
| Info | 3-31 |
| Production Data Page | 3-32 |
| Edit Shifts Screen | 3-36 |
| Fault History Page | 3-38 |
| Reject History Page | 3-42 |
| Jog Page | 3-46 |
| Manual SD Enabling | 3-51 |
| Reference Page | 3-53 |
| Advanced Page | 3-56 |
| Glue Group | 3-59 |
| Glue Page | 3-59 |
| Data Group | 3-61 |
| View Notices System Wide | 3-61 |
| Message Notices | 3-65 |
| Change Log Page | 3-116 |
| Misc Tags Page | 3-118 |
| View Changeover Adjustments | 3-119 |
| Marquee Page | 3-120 |
| GMI Tags Page | 3-122 |
| Diagnostics Group | 3-123 |

| | |
|-------------------------------------|-------|
| Drive Diagnostics Page | 3-123 |
| Fault Code History Page | 3-129 |
| Member Map Diagnostics Page | 3-131 |
| I/O Diagnostics Page | 3-139 |
| Sercos Diagnostics Page | 3-141 |
| Setup Users Page | 3-147 |
| Data Input Page | 3-149 |
| Servo Drive Data Page | 3-150 |
| Advanced Tab | 3-153 |
| Solenoid Data Page | 3-155 |
| Motor Data Page | 3-157 |
| Cam Data Page | 3-159 |
| Cam Generator | 3-162 |
| Choose Cam Group | 3-162 |
| Choose Product | 3-163 |
| Main Screen | 3-164 |
| Add Cam | 3-166 |
| Graph View | 3-167 |
| Points View | 3-168 |
| Misc View | 3-169 |
| Editing Features | 3-170 |
| Warning Screen | 3-173 |
| Solenoid Valve Cams | 3-174 |
| Motor Cams | 3-175 |
| Servo Moves Data Page | 3-176 |
| General Data Page | 3-179 |
| Case Packer General Data Page Items | 3-180 |
| Palletizer General Data Page Items | 3-182 |
| Cam Offsets Page | 3-183 |
| Changeover Adjustments Page | 3-185 |
| Rearrange Page | 3-186 |
| About | 3-188 |
| Report Generator | 3-189 |
| Custom Configuration | 3-192 |
| | |
| Changeover Adjustments | |
| Changeover Adjustments | 4-2 |
| 2-1 to 2-5 | 4-3 |
| 2-6 to 2-24 | 4-9 |
| 2-25 to 2-31 | 4-22 |

| | |
|----------------------------------|------|
| 2-32 to 2-35 | 4-27 |
| 2-36 to 2-37 | 4-30 |
| 3-1 to 3-2, 3-4 | 4-32 |
| Changeover Quick Reference Chart | 4-34 |

Troubleshooting and Maintenance

| | |
|-------------------------------------------------------|------|
| Troubleshooting and Maintenance | 5-2 |
| Troubleshooting | 5-3 |
| Carton Quality | 5-4 |
| Side Seam | 5-5 |
| Side Seam Glue Strip Not Parallel | 5-6 |
| Warped Cartons | 5-7 |
| Incorrect Magazine Changeover Location Values | 5-8 |
| Incorrect Carton Picker Position | 5-9 |
| Vacuum Cups Wear or Damage | 5-10 |
| Incorrect Moon Nip Roller Pressure | 5-11 |
| Incorrect Nip/Metal Roller Gap | 5-13 |
| Nip Belts & Bogie Wheels Bind or Jam | 5-15 |
| Bogie Wheel Tension Against Nip Belt | 5-16 |
| Uneven Side Seams | 5-17 |
| Side Seam Fold Not on Score Line | 5-18 |
| Side Seam Not Straight | 5-19 |
| Deck Extension Fingers Damage | 5-20 |
| Side Seam Damage | 5-21 |
| Incorrect Carton Magazine Horizontal Adjustment Value | 5-22 |
| End Flaps | 5-23 |
| Out-of-Square End Flaps | 5-24 |
| Incorrect Magazine Height Adjustment Value | 5-25 |
| Incorrect Vertical Slot Guide Adjustment Value | 5-26 |
| End Flaps Damage | 5-28 |
| Cartons Not Cut Correctly | 5-29 |
| Incorrect Overhead Rail Height Adjustment Value | 5-30 |
| Incorrect Bed Plate Adjustment Values | 5-31 |
| Incorrect Tucker Disk Installed | 5-32 |
| Skewed End Flaps | 5-33 |
| Bent Dust Flap Plows | 5-34 |
| Glue Buildup - Dust Flap Plows | 5-35 |
| Glue Buildup - Major Flap Plows | 5-36 |
| Glue Buildup - Side Rails | 5-37 |
| Glue Buildup - Carton Forming | 5-38 |

| | |
|---------------------------------------------|------|
| Incorrect Overhead Brush Position | 5-39 |
| Locked Dust Flap Corners | 5-40 |
| Film | 5-41 |
| Film Not Aligned | 5-42 |
| Tracking Running Constantly or Side to Side | 5-43 |
| Films Not Aligned At Side Seal | 5-44 |
| Check Photo Eyes | 5-45 |
| Film Not Sealing Properly | 5-46 |
| Splice Tape In Side Seal | 5-47 |
| Safety Circuit | 5-48 |
| Messages on HMI Screen | 5-49 |
| Prior Safety Circuit Rewiring | 5-50 |
| Channel 1 and 2 Safety Relay Input Lights | 5-51 |
| Safety Reset Relay Malfunction | 5-52 |
| Open Monitoring Loop | 5-53 |
| Channel 1 and 2 Output Lights | 5-54 |
| Channel 1 and 2 Guard Relay Lights | 5-55 |
| SensaGuard RFID Switches | 5-56 |
| Guard Master TLS-GD2 Switches | 5-57 |
| Servo Drives | 5-58 |
| Blown Fuses | 5-59 |
| F8060 Errors | 5-61 |
| Cycle Power | 5-62 |
| Check Cabling | 5-63 |
| Replace Drive | 5-64 |
| SERCOS Communication | 5-65 |
| Ring | 5-66 |
| Opening System Manager | 5-67 |
| Which Sercos Issue? | 5-68 |
| Cannot Get Phase 0 | 5-69 |
| Inspecting Bricks | 5-70 |
| Drive type? | 5-71 |
| Inspecting Servo Drives | 5-71 |
| Inspecting KCU | 5-71 |
| Inspecting TwinCAT System Manager Settings | 5-72 |
| Eliminate Items in the Loop | 5-73 |
| SERCOS Fiber Optic Cable Assembly | 5-74 |
| Cannot Get Phase 1 | 5-76 |
| Cannot Get Phase 2 | 5-77 |
| Cannot Get Phase 3 | 5-78 |

| | |
|-----------------------------------------|-------|
| Cannot Get Phase 4 | 5-79 |
| Losing Phase 4 | 5-80 |
| Multiple Error Counts and Unstable Ring | 5-81 |
| Functional Stability | 5-83 |
| Error Counters | 5-84 |
| Drive Firmware Version | 5-85 |
| Control Voltage | 5-86 |
| Motor Temperature | 5-87 |
| Noise Measurement | 5-88 |
| Scope View 2 | 5-89 |
| What Is Scope View 2 | 5-90 |
| How To Find | 5-91 |
| Using Scope View 2 | 5-92 |
| Basic View | 5-93 |
| Location of Axes | 5-94 |
| Location of I/O | 5-96 |
| Creating a Scope | 5-98 |
| Running a Scope | 5-100 |
| Deciphering a Scope | 5-101 |
| Tips | 5-104 |
| Scope View Tutorial | 5-105 |
| Imaged 4 GB CF Card Will Not Boot | 5-106 |
| General Troubleshooting Suggestions | 5-107 |
| Call for Support | 5-110 |
| How To | 5-111 |
| Diagnostics | 5-112 |
| Barcode Scanner Diagnostics | 5-113 |
| Check I/O Device | 5-114 |
| Clear Notices | 5-115 |
| Dry Cycle | 5-116 |
| Motor Jogging | 5-117 |
| Reinitialize | 5-118 |
| Servo Axis Jogging | 5-119 |
| Servo Referencing | 5-120 |
| Solenoid Valve Jogging | 5-121 |
| HMI Operations | 5-122 |
| Clean Out | 5-123 |
| Enable Case Refeed Mode | 5-124 |
| Load Cups Cleanout | 5-125 |
| Retract Mechanism | 5-126 |

| | |
|-----------------------------------------|-------|
| Vacuum Pump Shutdown | 5-127 |
| Maintenance | 5-128 |
| General Information | 5-129 |
| Maintenance Schedule | 5-130 |
| Bolt Torque Settings | 5-132 |
| Replacing Parts | 5-133 |
| Tucker Arm | 5-134 |
| Access to Machine | 5-135 |
| Second End Seal Lift | 5-136 |
| Adhesives | 5-139 |
| Adjust Glue Head Position | 5-140 |
| Adjust Glue Head Pressure | 5-141 |
| Adjust Glue Tank Pressure & Temperature | 5-143 |
| Glue Filter Replacement | 5-145 |
| Glue Gun Replacement | 5-146 |
| Glue Hose Replacement | 5-147 |
| Glue Nozzle Jig | 5-148 |
| Glue Nozzle Replacement | 5-149 |
| Glue Solenoid Valve Replacement | 5-150 |
| Glue Tank Replacement | 5-151 |
| Hot Melt Adhesive System | 5-152 |
| Bearings, Pulleys and Shafts | 5-153 |
| Bearing and Shaft Replacement | 5-154 |
| Pulley and Idler Shaft Replacement | 5-155 |
| Rod Ends Replacement | 5-156 |
| Slip Sheet Pick Bearing Replacement | 5-157 |
| Split Linear Bearing Replacement | 5-158 |
| Belts, Chains and Rollers | 5-162 |
| Adjust Belt Tension | 5-163 |
| Adjust Chain Tension | 5-165 |
| Adjust Chain Tension - Downstackers | 5-168 |
| Adjust V-Rail Rollers | 5-169 |
| Belt Replacement | 5-170 |
| Chain Replacement | 5-171 |
| Downstacker Chain Replacement | 5-172 |
| Drive Belt Replacement | 5-173 |
| End Seal Belt Path | 5-174 |
| Infeed Flight Position | 5-175 |
| Infeed Product Belt Replacement | 5-176 |
| Matop Conveyor Belt Replacement | 5-177 |

| | |
|------------------------------------------------|-------|
| Replace Barrel Cam Chain | 5-178 |
| Side Belt Replacement | 5-184 |
| Unitizer Slip Sheet Roller Replacement | 5-185 |
| V Roller Replacement | 5-186 |
| Computer and Software | 5-187 |
| Flash Drive Replacement | 5-188 |
| Shutting Down PC | 5-192 |
| Drives | 5-193 |
| Servo Drives | 5-194 |
| Downstacker Servo Gearbox Coupling Replacement | 5-195 |
| Indradrive C Purge Assembly | 5-196 |
| MI Drive Replacement | 5-197 |
| Purchasing MI Servos Directly From Rexroth | 5-200 |
| Sealing Rexroth Servo Assemblies | 5-201 |
| Servo Cable Replacement | 5-205 |
| Servo Gearbox Replacement | 5-206 |
| Slide-Rite Gearbox Lubrication | 5-207 |
| Solenoid Valves | 5-208 |
| Glue Solenoid Valve Replacement | 5-209 |
| Motors | 5-210 |
| Motor and Gearbox Replacement | 5-211 |
| Motor and Gearbox Replacement for Side Belts | 5-212 |
| Slide-Rite Gearbox Lubrication | 5-213 |
| Knives | 5-214 |
| Knife Replacement and Setup | 5-215 |
| Knife Replacement and Setup | 5-220 |
| Knife Replacement and Setup | 5-223 |
| Taper Knife Replacement | 5-226 |
| Knife Replacement - Vertical Cartoner | 5-228 |
| Lubrication | 5-231 |
| Bundler Unitizer Lube Points | 5-232 |
| Vertical Cartoner Lube Points | 5-234 |
| Machine 200 | 5-236 |
| Pneumatics | 5-238 |
| Cylinder Replacement | 5-239 |
| Suction Cup Replacement | 5-240 |
| Valve Bank Replacement | 5-241 |
| Printers and Scanners | 5-242 |
| Create/Adjust Printer Message | 5-243 |
| Marsh Ink Head Replacement | 5-245 |

| | |
|-------------------------------------------|-------|
| Marsh Ink Supply Tank Replacement | 5-246 |
| Marsh Printer Controller Replacement | 5-247 |
| Microscan Barcode Scanner Replacement | 5-248 |
| Printer Hose Replacement | 5-251 |
| Purge Printer | 5-252 |
| SICK 400 Series Barcode Scanner | 5-253 |
| SICK 600 Series Barcode Scanner | 5-259 |
| Sanitation | 5-261 |
| Hoppers | 5-262 |
| Machine Heat Up Process | 5-270 |
| Sealing Rexroth Servo Assemblies | 5-271 |
| Washdown Considerations | 5-275 |
| Sensors, Switches and Gauges | 5-276 |
| Cognex Checker Replacement | 5-277 |
| 4G Connection and Configuration | 5-279 |
| 3G Configuration | 5-284 |
| Guard Door Switch Replacement | 5-289 |
| Light Curtain Replacement | 5-290 |
| Photo Eye Cleaning | 5-291 |
| Photo Eye Excess Wire Loops | 5-292 |
| Photo Eye Replacement | 5-293 |
| Photo Eye Setup: KT8L | 5-294 |
| Photo Eye Setup: WL12G | 5-295 |
| Pressure Regulator Gauge Replacement | 5-297 |
| Pressure Sensor Replacement and Setup | 5-298 |
| Proximity Sensor Replacement | 5-299 |
| Slip Sheet in Place Switch Replacement | 5-300 |
| Vacuum Switch Setup | 5-301 |
| Vacuum | 5-302 |
| Oil Level and Changing Oil in Vacuum Pump | 5-303 |
| Suction Cup Replacement | 5-304 |
| Vacuum Filter Replacement | 5-305 |
| Vacuum Hose Replacement | 5-306 |
| Vacuum Hub Replacement | 5-307 |
| Vacuum Sensor Replacement | 5-313 |
| Vacuum Switch Setup | 5-314 |
| Ventillation | 5-315 |
| Cooling Fan Filter - Hoffman SR1616424 | 5-316 |

Spare Parts, Drawings and Manuals

Spare Parts, Drawings and Manuals

6-2

roduction, Safety, Installation and Training



Introduction, Safety, Installation and Training

Thank You for your decision to purchase an **Aagard** automated machinery system.

We sincerely appreciate your confidence in our designs, and promise to further enhance that confidence with our technical and customer support.

We are confident our efficient designs and an emphasis on customer satisfaction will enable us to provide you with state of the art **Aagard** automated machinery systems for any of your future projects.

Again, THANK YOU for purchasing Aagard's packaging equipment. Please contact us for further assistance.

Machine Serial #120



The Aagard Group, LLC
3711 Iowa Street
Alexandria, MN 56308
www.aagard.com

Normal Business Hours:

Monday through Friday
8:00 AM to 4:30 PM

320-763-6043 (Voice)

320-763-7859 (Fax)

Parts: Option 4

Technical Service: Option 5

After-Hours Technical Service: Option 6

E-Mail:

service@aagard.com

spareparts@aagard.com

For Spare Parts and Manufacturers' components information, please see the [Spare Parts, Drawings and Manuals](#) section of this manual.

NOTE: Some items listed in this manual will not pertain to your Aagard system.

About This Manual


Training

Training Levels

Level 1, Level 2, and Level 3 training curriculums are embedded in this document. The training topics are listed, in order, in the Table of Contents of this section.

Training Navigation

Toward the upper right hand corner of this panel, use the left and right arrow topic navigation buttons to move up and down in the Table of Contents topics.



Alternately, click on each successive topic in the table of contents to navigate through the training topics

NOTE: If, during training, you follow links from a training topic, please use the browser's Back button to return to the previous topic. Then proceed by selecting the next training topic in the table of contents.

First [Level 1](#) training topic
First [Level 2](#) training topic
First [Level 3](#) training topic
[Maintenance](#) training topics

Training overview for Level 1

| |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>Pre-requisites for Training</p> <p>English language skills Ability to lift up to 50 pounds</p> <p>During Level 1 training, you will...</p> <ul style="list-style-type: none">• Load materials required to run production• Follow lock out and tag out procedures• Learn the location of the following:<ul style="list-style-type: none">○ Emergency Stop Buttons○ Air Dump○ High Voltage Disconnect○ Operator Stations• Identify the meaning of Tower Light colors• Identify the meaning of Warning Horn sounds |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

- Login to the Human Machine Interface (HMI)
- Review message notice locations and operation
- Start and stop the machine
- Clear jams
- Operate the machine in production

At the conclusion of training, you will be tested on...

- Locate and load materials
- Show location e-stop, air dump, high voltage disconnect
- Start, stop machine
- Operate machine during production

Training overview for Level 2

During Level 2 training you will...

- Jog any device on machine
- Adjust machine to different product sizes
- Adjust machine to different case sizes
- Learn to record and communicate current changeover settings before going to a new product
- Perform a product changeover
- Have a complete understanding of mechanical adjustments
- Adjust HMI glue settings
- Confirm Servo Reference Position settings

Training overview for Level 3

During Level 3 training you will...

- Initialize and reference a servo motor
- Learn how to edit shift information
- Learn about Misc Tags and General Data information
- Learn advanced glue settings
- Have a complete understanding of motor, solenoid and servo drive data
- Understand alternating jog and servo drive tuning
- Create new and edit product recipes
- Change values and rearrange changeover adjustments
- Have a complete understanding of servo moves and cam settings

Level 1

How To Use This Manual

Training

The purpose of How To Use This Manual is to demonstrate features of the electronic version of the Aagard Machine Manual.

Within these topics, you will learn:


- navigation tips and tricks
- how to use the manual with supplemental documentation
- how to use search feature
- how to access Aagard Machine Manuals over the internet

Navigation


Training

Many hyperlinks, hotspots and navigation tools are utilized in the electronic version of the Aagard Machine Manual, making navigation easy and bringing information more quickly to the user.

 This feature only applies to web version of manual

The best way to navigate through training is to use the directional buttons located in the upper right-hand corner of the topic title bar. 

Clicking the right directional button will move to the next topic listed in the table of contents, while clicking the left directional button will move to the previous topic.

During training, navigation may take the user away from the training topics. Use the browser back button to retrace your steps through the training topics. 

Of course, if you remember where you were, you may click on the topic directly in the table of contents.

Training Points

Training

 This feature only applies to web version of manual

Many topics in this manual include a [Training Points](#) link at the top of the page. When the link is clicked, a pop-up window will list training items and information specific to the current topic. These training points detail items which should be addressed during training.

Training Points

Information on these popups is intended for both trainer and trainee.

For the trainer, it can be used as a mini-syllabus for the current topic; this is particularly helpful when those who have been trained are enlisted to train others.

For the trainee, it can be referenced after training has been completed to help remember highlights of the current topic.

Supplemental Documentation

Training

Links to a number of supplemental documents may be provided in the Aagard Machine Manual at aagardmanuals.com only. Most supplemental documentation is provided in the pdf file type. These supplemental documents may include:

- Spare Parts List
- Electrical Drawings
- 3D Documentation Model (with Bill of Materials)
- As-Shipped Changeover Values
- Specification Sheet
- Aagard Equipment Standard
- Aagard Machine Control Standard

Search

Training

 This feature only applies to web version of manual

Search functionality of the Agard Machine Manual is a powerful and often overlooked tool. There are three tabs above the table of contents tree: Contents, Index, and Search.



Using Search

1) Click on Search tab above table of contents tree to display search tab

A screenshot of the search interface. It features a red header with three tabs: "Contents", "Index", and "Search". Below the tabs, there is a text input field with the placeholder text "Enter one or more keywords to search (* and ? wildcards are supported):". To the right of the input field is a "Submit" button. Below the input field, there is a "Results per page:" label followed by a dropdown menu set to "10". At the bottom, there is a "Match:" label with two radio buttons: "any search words" (unselected) and "all search words" (selected).

2) Type text for which to search into search field

3) Click 

4) View search results appear

5) Click on any link in search results to navigate to that page

There are several ways to find information about a specific device in the manual, particularly when that device might be triggering an alarm.

- Search for the device number
 - Search for the device name
 - Find it in the message notices topic of the equipment module which generated the alarm
 - Find where it is physically on the machine by using the device list
 - Read about it in the sequence of operation topic
-

aagardmanuals.com

Training


All Aagard Machinery System Manuals are posted on aagardmanuals.com.

 The latest documentation is always available at aagardmanuals.com

How to Gain Access

To obtain a username and password for aagardmanuals.com, please ask your supervisor to contact the Aagard service team at: service@aagard.com. Once logged in to the secure site, you will see the manuals to which you have been granted access.

- 1) Open a web browser
- 2) Enter <http://www.aagardmanuals.com> into the address window and press enter



The image shows a login form with the following elements:

- Username**: A text input field with the placeholder text "Enter Username".
- Password**: A text input field with the placeholder text "Enter Password".
- Forgot Password**: A blue text link located below the password field.
- Login**: A blue button located to the right of the "Forgot Password" link.

- 3) Type your username into the username field
- 4) Type your password into the password field
- 5) Click Login
 - a) For first-time login, accept the terms
- 6) Once logged in, all manuals to which you have been granted access will be available, listed by their Aagard assigned machine serial number
- 7) You may change your login credentials by clicking Edit Account, and then clicking Update My Account
- 8) When finished viewing aagardmanuals.com, click Log Out and close your browser

Safety Recommendations

At Aagard, we are committed to building quality automated machinery systems. Your new Aagard system is efficient, easy to maintain and safe to operate.

Before attempting to operate the equipment, become familiar with the safety recommendations and operational components of your Aagard system. This includes the technical information pertaining to outside vendor components used within your Aagard system. This information is located in the Manufacturer Information Binder and in other literature supplied with the equipment.

To maximize machine safety you must operate the machine correctly and comply with the described safety features!

ALWAYS follow your facility's Lockout-Tagout procedures when doing maintenance and repair work!

Prior to Lockout-Tagout, contact a Level 2 or higher Operator to properly shut down the PC.

Always follow your facility's Lockout-Tagout procedures!

Lockout/Tagout (LOTO) refers to specific practices and procedures to safeguard employees from the unexpected energization or startup of machinery and equipment, or the release of hazardous energy during service or maintenance activities.

Pay special attention to the following CAUTION, WARNING and DANGER signs below. They are used through out the manual to alert the operator to the potential of **INJURY** or **DEATH**, if the recommended procedures are not followed.

DANGER

Immediate hazards which WILL result in severe personal injury or death

WARNING

Hazards or unsafe practices which COULD result in severe personal injury or death

STAY ALERT AND REMEMBER:


Safety is the responsibility of everyone who operates or services your Aagard system

See [Servo Motor with Brake](#) for additional safety information!

E-Stop Locations

All personnel who repair, maintain, or operate Agard equipment need to know the location of the **EMERGENCY STOP** buttons:

Sample E-Stop Drawing



- **DO NOT** operate the equipment with any of the safety guards removed
- **DO NOT** wear neckties, loose clothing, or long loose-hanging hair around any equipment
- **OBSERVE** and follow the **⚠ DANGER**, **⚠ WARNING**, and **⚠ CAUTION** messages throughout this document, in vendor documentation, and displayed on the equipment
- **DO NOT** use steps or stands that allow anyone to reach over guards

[Button Functions](#)

[Stack Light and Warning Horn](#)

Machine Operation

CAUTION

Before operating equipment, see [Safety Recommendations](#)



Read and observe all safety precautions in this manual,
and in vendor literature, before proceeding

Prior to starting your packaging system

- **CHECK TO MAKE SURE ALL PERSONNEL, TOOLS AND EQUIPMENT ARE CLEAR OF THE MACHINE**
- Turn on hot melt system; allow the system time to reach normal operating temperatures
- Install and close all guard doors
- Load the magazine(s) with blanks
- Check to make sure product is available
- Once again, **CHECK TO MAKE SURE ALL PERSONNEL, TOOLS AND EQUIPMENT ARE CLEAR OF THE MACHINE**

Shutdown Warning

Failure to properly shut down the PC may void the warranty!

| | |
|-----------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Switch on | The Industrial PC does not have its own main switch. The Industrial PC will start when the equipment is switched on, or when it is connected to the power supply. |
| Shutting down and switching off | When the plant is switched off, or when it is disconnected from its power supply, the Industrial PC will be switched off. Control software such as is typically used on Industrial PCs permits various users to be given different rights. A user who may not close software may also not switch the Industrial PC off, since data can be lost from the hard disk by switching off while software is running |
|  Warning! | First shut down, then switch off the PC! If the Industrial PC is switched off as the software is writing a file to the hard disk, the file will be destroyed. Control software typically writes something to the hard disk every few seconds, so the probability of causing damage by switching off the PC while the software is running is very high! |
|  Warning! | When you have shut down the Industrial PC, you have to switch off power supply for at least 10 seconds before rebooting the system. After resetting power supply, the PC will start booting automatically. |

To properly shut down the PC, contact a Level 2 or higher Operator.

Stack Light and Warning Horn

The Stack Light consists of a stack of four (4) colored lights: **Red**, **Amber**, **Blue** and **Green** (Top to Bottom). The stack light is situated to be reasonably visible from the circumference of the machine. The warning horn will produce a sound loud enough to be heard in a production environment while standing near the circumference of the machine.

The stack lights and warning horn have following meanings:

| FOUR Stack Light definitions | | THREE Stack Light definitions | |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------|
| four light stack | Red (Top) Solid: <ul style="list-style-type: none"> An Emergency Stop condition exists A Fault condition exists | Red (Top) Solid: <ul style="list-style-type: none"> An Emergency Stop condition exists A Fault condition exists | three light stack |
| | Amber (Second from Top) Solid: <ul style="list-style-type: none"> No product coming from upstream, or an Integrated System is not ready for operation (Example: Glue System Not Ready) Downstream unable to accept product | Amber (Middle) Solid: <ul style="list-style-type: none"> No product coming from upstream, or an Integrated System is not ready for operation (Example: Glue System Not Ready) Downstream unable to accept product Flashing: <ul style="list-style-type: none"> Material status is low (Examples: Low Case Blanks, Low Adhesive Level) | |
| | Green (Third from Top) Solid: <ul style="list-style-type: none"> System Running | Green (Bottom) Solid: <ul style="list-style-type: none"> System Running | |
| | Blue (Bottom) Solid: <ul style="list-style-type: none"> Material status is low (Examples: Low Case Blanks, Low Adhesive Level) | | |

Warning Horn: The *Startup Warning* horn will sound for three seconds prior to the actual energizing or startup of a machine, which includes the enabling and recovery of servo powered systems.

The operator is required to push *and hold* the start button for the entire duration (three seconds) of the warning horn. If the operator releases the start button prior to the end of the horn, the machine will not start and the horn will cease to sound. The horn cycles on and off every ½ second for the duration of the alarm.

The *Fault Warning* alarm will sound when a fault exists and has not been acknowledged. The alarm will cycle on and off every 0.2 seconds until the fault has been acknowledged.

Button Functions

Please refer to the [E-Stop Locations](#) drawing for Emergency Stop, Cycle Stop and Start Button locations.



Emergency Stop (E-Stop) Button - Pressing this button brings all machine function to an immediate and complete stop.

Opening any safety door also triggers an E-Stop.



Cycle Stop (C-Stop) Button - Pressing this button brings all machine function to a complete stop at the end of the current cycle.

C-Stop is the preferred method to stop operation in all NON-Emergency situations.



Start Button - Pressing and holding this button for three seconds (until horn stops) starts the machine.

Start Push Button Pilot Light

Solid

- All Safety Circuits of the system are engaged (no Emergency Stop Push Buttons are depressed, all Guard Doors are closed, and Safety Relays have been reset)

Flashing

- One or more, but not all, Safety Circuits of the system are engaged

Log In Screen

General Page Information

This is what the Aagard HMI Screen will look like if the Log In Button is pressed while no one is currently logged in. If a user is currently logged in, the button will display the text "Log Out". If the button is pressed while the "Log Out" text is displayed, the current user will be logged out and the "Log In" text will be displayed. Consult your supervisor for the correct user name and password. The machine will be logged out upon power up.

SAMPLE IMAGE



| | Machine Run | Jog, Reference & Troubleshooting | Machine Data Input | Login User Information |
|-----------------------------|-------------------------------------|-------------------------------------|-------------------------------------|-------------------------------------|
| Operator Level 1 | <input checked="" type="checkbox"/> | | | |
| Operator Level 2 | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | | |
| Advanced Technician Level 3 | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | |
| Administrator Level | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |

Keyboard

General Page Information

The Keyboard and Number Pad are part of the same program, and may be toggled between each other. The Keypad program will work with any program on the PC. Launch the Keypad program by pressing on the keypad icon located on most Aagard HMI pages. If the HMI is not open, the Keyboard and Number Pad program may be opened independently of the HMI by double-clicking "AagardKeypad.exe", located inside the same folder as "AagardHMI.exe".



Hide


The Hide button will close the keyboard/number pad.

Move

The Move button will allow the user to move the keyboard/number pad around the screen. To move the keyboard/number pad, press and hold down the Move button and then drag the keyboard/number pad to any place on the screen.

NumPad

The NumPad button will open the Number Pad and the Keyboard will disappear.



Keybd Button

The Keybd Button on the Number Pad will open the Keyboard and the Number Pad will disappear.

HMI Main Screen

General Page Information

After power up and initialization of the Packaging system, the Main screen will be displayed. This Main screen is the starting point from which everything branches. All the Message Displays combined will provide information on what is happening with the machine, displaying any faults that would prevent the system from running (guard door open, low air pressure, etc.). The Aagard HMI will go straight to the Main Screen if the HMI is closed and reopened without losing power to any part of the machine.

NOTE: The system will be in the same Mode in which it was left at power down. Correct any Fault conditions which are displayed before attempting to run the machine.

NOTE: Depending on user level, not all buttons will be visible.

The screenshot displays the Aagard HMI Main Screen. At the top, it shows 'Aagard 120' and 'No Product Selected' with a 'System Rate' of 200.00. A prominent error message reads 'PC1 HMI: SERCOS Communication Error - Not In Phase 4'. Below this, two machine sections are visible: 'Case Packer' and 'Unitizer', both with 'State: Stopped' and 'Mode: EStop'. Each section includes a 'Rate: 100 %' indicator and a 'Reset' button. Control buttons for 'Automatic Mode', 'Manual Mode', 'Jog', and 'Reference' are present. A 'Production Data' table is shown below, with columns for Case Count, MTBF, MTTR, Downtime Count, Running Time Since Last Stop, Starved Time - OOP, and Efficiency. The table shows zero values for all metrics across three shifts. At the bottom, there are buttons for 'QC Case', 'Custom Buttons', 'Advanced', 'Product Change', and a yellow 'Log Out' button. The Aagard logo and 'About...' button are also visible.

| | Case Count | MTBF | MTTR | Downtime Count | Running Time Since Last Stop | Starved Time - OOP | Efficiency |
|------------|------------|------|------|----------------|------------------------------|--------------------|------------|
| Shift | 0 | 0S | 0S | 0 | 0S | 0S | 0.0% |
| Daily | 0 | 0S | 0S | 0 | 0S | 0S | 0.0% |
| Last Shift | 0 | 0S | 0S | 0 | 0S | 0S | 0.0% |

System Information

This section contains the machine name, the current downloaded product name, the current system rate and any system messages. A system is also known as the S10 level of the machine.

C40 Information

This section contains the C40 name, the [state and mode](#), and any C40 messages. An example of a C40 would be a Cartoner or a Case Packer.

Rate

This entry field will allow the machine to operate at slower speeds. 100% is equal to the maximum rate at which the machine is able to operate. 50% is half that rate and so on. This only applies while in Automatic Mode

Reset

This button will reset the selected C40. This will make the machine think that there is no product in the machine. This button is a last resort to get the machine running again. After this button is pressed, all remaining product should be cleared out of the machine and then the machine can be started again.

Fault History Button

Pressing this button will open the [Fault History Page](#) for the C40 that the button was on.

Reject History Button

Pressing this button will open the [Reject History Page](#) for the C40 that the button was on.

Data Input Button

Pressing this button will open the [Data Input Page](#) for the C40 that the button was on.

Disable/Enable

Pressing this button will Disable/Enable the selected C40. When a C40 is disabled, that section of the machine will not perform its operations. When the C40 is disabled the button will be red and the State status will be Disabled. This button can only be toggled when that C40 is in Mode: Estop.

Disable/Enable Product

Pressing this button will Disable/Enable Product on the selected C40. When a C40 has Disabled Product, the button will be red. Disabled Product is a type of a dry cycle. When the machine is started back up, that section of the machine will perform its operations as if it were receiving the amount of product per minute specified in the System Rate Display. This button can only be toggled when that C40 is in Mode: Estop.

Automatic Mode Button

When the Automatic (Run) Mode Button for the C40 is pressed, that C40 will go into Automatic Mode. Press and hold the start pushbutton for 3 seconds to begin running. If no faults are detected, the Module will continue into the Producing Mode.

Manual Mode

Pressing the Manual Mode button will put the machine in manual mode and display two additional buttons: "Jog" and "Reference".

Jog Button

Pressing this button will open the [Jog Page](#) for the C40 that the button was on.

Reference Button

Pressing this button will open the [Reference Page](#) for the C40 that the button was on.

Production Data Table

This table shows the current shift's information and the current day's information. For more on this, see the [Production Data Page](#).

Production Data Button

Pressing this button will open the [Production Data Page](#) for the machine.

QC Case

This allows the machine to reject one (1) good case for Quality Control purposes.

Custom Buttons

Pressing this button will open the [Custom Buttons Page](#) for the machine.

Advanced Button

Pressing this button will open the [Advanced Page](#) for the machine.

Product Change Button

Pressing this button will open the [Product Download Page](#) for the machine.

Log In / Log Out Button


If the button displays "Log In", then no user is currently logged in and pressing this button will open the the [Log In Screen](#).

If the button displays "Log Out", then a user is currently logged in and pressing this button will cause the current user to be logged out.

NOTE: The current user name is displayed in the upper left area of the Main Page.

About Button

This button will show version and build information, and will be useful when troubleshooting with Aagard technicians.




Aagard Logo


Pressing this button will open the Aagard Machine Operator Manual from the HMI.

- o The user may be prompted to install a documentation update

States and Modes



State Model - Automatic Mode



The following table shows a brief description of individual machine states:

| STATE | Description |
|-----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| OFF | <p>State Type: Final</p> <p>All power to machine switched off. This state is assumed if there is no response from the machine. This is an optional Final State.</p> <p>The OFF state may be reached in two ways: first, power to the machine is switched off or second, power is removed as in a power utility failure. In the OFF state, it must be assured that the machine will go at the least to the initial stopped state when power is restored either by switch or restoration of the utility power source.</p> |
| STOPPED | <p>State Type: Final</p> <p>The machine is powered and stationary. All communications with other systems are functioning (if applicable).</p> |
| STARTING | <p>State Type: Transient</p> <p>This state allows the machine to be prepared for running 1. This state could include such processes as heating, self-testing, or calibration.</p> |
| READY | <p>State Type: Quiescent</p> <p>This is a state which indicates that STARTING is complete. This state maintains the machine conditions which were achieved during the STARTING state.</p> |

| STATE | Description |
|------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| STANDBY | <p>State Type: Transient</p> <p>The machine is running at the relevant set point speed, there is no product being produced.</p> <p>This state can be reached either in response to a Start Command from READY, or any internal machine logic that would dictate a temporary transition from the PRODUCING state, such as materials run-out.</p> <p>The status of "materials run-out" could be due to a lack of materials on the machine's own infeed, or a stoppage of downstream equipment.</p> |
| PRODUCING | <p>State Type: Transient</p> <p>Once the machine is processing materials, it is deemed to be producing.</p> |
| STOPPING | <p>State Type: No Command</p> <p>This state executes the logic which brings the machine to a controlled and safe stop.</p> |
| ABORTING | <p>State Type: Transient</p> <p>The ABORTED state can be entered at any time in response to the Abort Command, or on the occurrence of a machine fault. The aborting logic will bring the machine to a rapid, controlled safe stop. Operation of the Emergency Stop, or "E-Stop", will cause the machine to be tripped by its safety system. It will also provide a signal to initiate the ABORTING state.</p> |
| ABORTED | <p>State Type: Quiescent</p> <p>This state maintains machine status information relevant to the Abort condition. The Stop Command will force transition to the STOPPED state.</p> |
| HOLDING | <p>State Type: Transient</p> <p>When the machine is in STANDBY or PRODUCING, the Hold Command can be used to start Holding logic, which brings the machine to a controlled stop.</p> |
| HELD | <p>State Type: Quiescent</p> <p>The Held state would typically be used by the operator to temporarily hold the machine's operation while material blockages are cleared, or to stop throughput while a downstream problem is being resolved.</p> |

An example State transition matrix for Automatic Mode is shown below. Note the State Model does not rigidly specify the internal machine state transition logic, which will vary depending on the application.

| Initial State | Machine Status | | | | | | Commands | | | | |
|---------------|----------------|-----------|-------------------|-----------------|---------------|----------------|----------|---------|----------|---------|----------|
| | Power On | Power Off | Materials Run-Out | Materials Ready | Machine Fault | State Complete | Prepare | Start | Stop | Held | Abort |
| Off | Stopped | | | | | | | | | | |
| Stopped | | Off | | | | | Starting | | | | |
| Starting | | | | | Aborting | Ready | | | Stopping | | Aborting |
| Ready | | | | | Aborting | | | Standby | Stopping | | Aborting |
| Standby | | | Producing | | Aborting | | | | Stopping | Holding | Aborting |
| Producing | | | | Standby | Aborting | | | | Stopping | Holding | Aborting |
| Stopping | | | | | Aborting | Stopped | | | | | Aborting |
| Holding | | | | | Aborting | Held | | | | | Aborting |

| | | | | | | | | | | | |
|----------|--|--|--|--|----------|---------|--|---------|----------|--|----------|
| Held | | | | | Aborting | | | Standby | Stopping | | Aborting |
| Aborting | | | | | | Aborted | | | | | |
| Aborted | | | | | | | | | Stopped | | |

Production Data Page

General Page Information

This page will display any production data collected by the machine. This will show how the machine is performing from day to day. The downtime tracking summary is also displayed on the page.

NOTE: The items listed and their locations on this HMI page are 100% configurable and setup by an Aagard Level user during the HMI Setup process. As such, the content on this page is a representation of a possible configuration. The items and/or their locations may change as modifications to the configuration are made on a production Aagard machine in the field. Such configuration changes may not be reflected in this machine manual.

SAMPLE IMAGE

**Time Period Drop Down Menu**

This drop down menu will allow information to be displayed for a certain selected time period.

Edit Shifts Button

This button will display the [Edit Shifts Screen](#).

Back Button

This button will display the HMI Main Screen.

Production Data Information

These items are setup by an Agard Level user during HMI Setup.

IMPORTANT! If changes are made to production data formulas, the Report Generator process *must* be restarted!

| Query Name | Short Description | Detailed Description |
|--------------------------|---------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| RunningTime | Running Time Tracking | Total amount of time the system in a producing state |
| IdleTime | Idle Time Tracking | Total amount of time the system was idle (starved or blocked) |
| UserStopsTime | User Stops Time Tracking | Total amount of downtime caused by user stops (E-Stop, Guard Door, Cycle Stop) |
| FaultTime | Fault Time Tracking | Total amount of downtime caused by faults |
| FaultAckTime | Fault Acknowledgement Time Tracking | Total amount of fault acknowledgement time |
| RunningTimeCount | Number of Running Time Occurrences | The number of instances the system went to a producing state |
| IdleTimeCount | Number of Idle Time Occurrences | Number of instances the system was not producing, caused by not receiving product or downstream not being available (starved and blocked) |
| UserStopCount | Number of User Stop Occurrences | Number of times the system was not producing, caused by a user stop (E-Stop, Guard Door, Cycle Stop) |
| FaultCount | Number of faults | Number of times the system was not producing, caused by a fault |
| DowntimeCount | # of Stops, Downtime Count | The number of instances the system was not producing, caused by a user stop or fault |
| RunningTimeSinceLastStop | Running Time Since Last User Stop Or Fault Recorded In System | Amount of time accumulated since the last time the system went into a producing or idle state |
| TargetCapacity | Target Capacity | The total number of products which could run through this machine if the machine is running at 100% for the measured time period. The machine rate is recipe-specific, as defined in the PLC program; rate changes during the measured time period are taken into account |
| UserStopLoss | Capacity Loss Due To User Stops | Capacity lost due to a user initiated downtime (E-Stop, Guard Door, Cycle Stop, and materials not available) |
| MachineStopLoss | Capacity Loss Due to Faults Or Machine Downtime | The capacity, in units, which was lost, caused by faults and idle time |
| StopLoss | Capacity Loss Due to All Stops | The capacity, in units, which was lost, caused by all stops (user stop loss and machine stop loss) |
| IdleStopLoss | Capacity Loss Due to System Being Idle | The capacity, in units, which was lost, caused by the system being idle (starved or blocked) |
| ExpectedOutput | Expected Output | The difference between Normal Production (NP) Capacity and Idle Stop Loss. NP Capacity is Target Capacity less Stop Loss |
| M(#).InfeedCount | Machine Infeed Product Count | The number of products fed into a specific machine infeed |
| M(#).UnitCount | Machine Unit Count | The number of good products discharged from a specific machine |
| M(#).RejectCount | Machine Reject Count | The number of products rejected from a specific machine |
| M(#).FaultCount | Machine Number of faults | The number of fault instances in a specific machine |
| M(#).FaultTime | Machine Fault Time | Total amount of time the system was not producing based on a specific machine's faults |
| M(#).FaultAckTime | Machine Fault Acknowledgement Time | The amount of fault acknowledgement time based on a specific machine's faults |
| M(#).MinFaultTime | Machine Minimum Fault Time | The shortest fault time length based on a specific machine's faults |

| Query Name | Short Description | Detailed Description |
|----------------------|----------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------|
| M(#)MaxFaultTime | Machine Maximum Fault Time | The longest fault time length based on a specific machine's faults |
| M(#)GDAFaultTime | Machine Greatest Deviation from Average Fault Time | The greatest deviation from average of fault time length based on a specific machine's faults |
| M(#)MinFaultAckTime | Machine Minimum Fault Ack Time | The shortest fault acknowledge time based on a specific machine's faults |
| M(#)MaxFaultAckTime | Machine Maximum Fault Ack Time | The longest fault acknowledge time based on a specific machine's faults |
| M(#)GDAFaultAckTime | Machine Greatest Deviation from Average Fault Ack Time | The greatest deviation from average fault acknowledge time based on a specific machine's faults |
| R(#)StopsCount | Number of stops based on Reason Code | Total number of instances the machine was not producing based on one specific reason code |
| R(#)StopsTime | Stops Time based on Reason Code | Total amount of time the system was not producing based on one specific reason code |
| R(#)StopsMinTime | Stops Minimum Time based on Reason Code | Shortest amount of time the system was not producing based on one specific reason code |
| R(#)StopsMaxTime | Stops Maximum Time based on Reason Code | Longest amount of time the system was not producing based on one specific reason code |
| R(#)StopsGDATime | Stops Greatest Deviation from Average Stop Time based on Reason Code | Greatest deviation from average time the system was not producing based on one specific reason code |

Continuous Running

The system will continue to run as long as new product is available, packaging supplies (carton blanks, hot melt adhesive, etc.) are replenished, and the product is removed.

[Case Blanks](#)


[Glue](#)

Carton Blanks

Carton Blanks

To replenish the magazine while the machine is running, stack the carton blanks behind the follower plate and then slide the follower plate out from the stack. Make sure the printed side of the carton blanks is facing the follower plate, with the manufacturer's flap down. Move the follower plate to the end of the stack and push against the stack, removing any gaps that may be present before resetting the follower plate onto the chain.


SAMPLE IMAGE



Top Carton Drive

When the carton magazine is empty or if there are not enough blanks to support it, the top carton drive unit will pivot downwards. To prevent the top carton drive unit from hanging down and to make it easier to load the carton blanks, hold the drive unit up slightly, remove the support pin from its vertical stored position, and insert the pin into the hole on the top of the unit as shown in the picture below. This will hold the top carton drive unit up and out of the way while carton blanks are being loaded. When sufficient carton blanks have been loaded, remove the pin and let the top carton drive unit rest on the top of the carton blanks. Return the support pin to its stored position.

SAMPLE IMAGE



Case Blanks

Case Blanks

To replenish the magazine while the machine is running, stack the case blanks behind the follower plate and then slide the follower out from the stack. Move the follower plate to the end of the stack and push against the stack, removing any gaps that may be present before resetting the follower onto the chain.



Glue

Glue Tanks


Hot melt adhesive: Replenish the hot melt adhesive in the Nordson glue system per Nordson directions as required. To load glue pellets, lift the cover of the glue tank and gently drop glue pellets into the tank. Fill to fill level line (see picture below). Close the cover.

⚠ DANGER ⚠

Under no circumstances should you reach into a hot glue tank.

Warning: Do not overfill!

SAMPLE IMAGE



Please refer to the [Nordson](#) ProBlue Adhesive System Manual for information about the hot melt applicator. The Nordson Manual contains everything from electrical wiring diagrams to operation to troubleshooting.

Hot Melt Adhesive

When a hot melt adhesive system is installed, set glue to appropriate temperatures and pressure to ensure proper pattern control and clean cutoff at glue nozzle.

NOTE: The following standard settings are for HB Fuller Advantra adhesive only!

Standard Settings (for HB Fuller Advantra adhesive)

| EQUIPMENT | TEMPERATURE | PRESSURE |
|---------------------------------|-------------|-------------|
| Tank | 335°F-350°F | 30-40 PSI |
| Hose | 335°F-350°F | N/A |
| Guns with adjustable regulators | 335°F-350°F | 65-70 PSI * |
| Guns with fixed regulators | 335°F-350°F | 65 PSI |

* Glue nozzle pressure for adjustable regulators is dependent on glue nozzle model installed on machine. If unsure of correct setting for your machine, refer to Nordson documentation or pneumatic page in electrical drawings.

Sequence of Operation

This narrative will describe, in detail, how each section of the system functions in order to help the user understand the cause and effect of each input and output. Inputs (electrical devices and signals) are discussed with references as to what occurs when they are triggered. A detailed list of each sensor and its function is located after this section. An input is a signal which informs the machine controller of an event occurring. An output is the machine controller sending the machine an instruction; outputs can be thought of as the signals and devices that do the work. A thorough understanding of the machine and how it functions will greatly aid in troubleshooting any problems that may arise.

CASE PACKER

Infeed

The Infeed Conveyor (MT1302) motor accepts the cartons from the upstream conveyor and delivers them to the side belts.



The Non-Operator Side Side Belt (MT1403) and Operator Side Side Belt (MT1406) motors launch the cartons into the downstacker flights. These side belts travel more quickly than the infeed conveyor to ensure proper gap between cartons.

Downstacker

The First Carton In Downstacker (PE31704) photo eye senses when the first carton is on the top of the downstacker flights, and the Second Carton In Downstacker (PE31703) photo eye senses when the second carton is on the top of the downstacker flights. As the side belts present a layer of cartons, the Downstacker Flights, driven by SM4 Fixed Flight 1, SM5 Fixed Flight 2, SM2 Adjustable Flight 1, and SM3 Adjustable Flight 2 servo motors, will lower by one product height, making room for the next layer. When the last layer is presented to the downstacker, the complete stack will be lowered to the bottom of the downstacker chamber, presenting the stack for the downstack pusher.

Downstack Pusher

Once the downstack pusher receives a stack complete signal from the downstacker, the downstack pusher virtual master begins its cycle.



The Downstack Pusher (SM6) then moves the stack to the loader and returns to its starting position. The Product Conditioner (SV30703) solenoid valve extends a plate down, to the top of the product, to ensure any bulged cartons will clear and enter the case.

Loader

After the product has been cross-pushed into the load station, the Loader (SM7), which is cammed to the loader virtual master, moves the product into the case. If the Case Present At Load (PE31903) photo eye does not sense a case has been properly set up at the load station, the loader will not advance. The system will stop and prompt the operator to remove the case from the load station.

As the stack is moving toward the case, the Fun/Tucker and Funnel (SM9 and SM8) servo motors start to rotate into the case. At the same time, the Fun/Tucker In/Out and Funnel In/Out (SV30406 and SV30407) solenoid valves are activated to move the funnels $\frac{3}{4}$ " toward the case. This action positions the funnel inside the score line of the case. The funnels then guide the product into the case and are retracted before the cartons are fully in the case.

Magazine

The Magazine Top Clip and the Magazine Bottom Clip (SV30705 and SV30707) solenoid valves open when the robot is moving toward the magazine. To open the case blank, rotating clips on each side of the case blank hold the back panel of the case while the robot pulls the front panel forward and down. After the robot has partially pulled the case from the magazine, the Magazine Rotate Clip (SV30306) solenoid valve opens the clips to release the case. The top clip closes sooner than the bottom and rotating clips. The bottom and rotating clips close after the case has been fully removed from the magazine. If the Case Packer Robot Vacuum (VS31806) vacuum switch from the robot is not made, a fault message is displayed.

The Magazine Advance Cylinder (SV05) will cycle if the Magazine Advance Switch (PX18) is not made and the Robot is not picking a case blank. If the cylinder cycles more than 10 times without meeting the Magazine Advance Switch, a fault message will be displayed.

The Magazine Advance (SV30401) solenoid valve activates a cylinder which moves the magazine advance chains forward with a ratcheting motion.

When the blanks in the magazine no longer block the Case Blanks Present (PE31803) photo eye, the HMI will indicate the magazine is low, a blue stack light will illuminate, and the horn will sound. If the magazine is not filled after 25 additional case blanks have been picked, the machine will stop.

Robot

The robot's cycle stop position is at the magazine.



If the robot is signaled to pick a blank, the Robot Vacuum (SV30408) solenoid valve turns on vacuum. The robot proceeds with the new case to the load station. The Case Pusher (SV30403) extends to hold the case at the load station, keeping it vertical with the flights as it moves into compression. The initial move away from the magazine is the Robot X-Axis (SM12) move, which arcs down by adding the Robot Z-Axis (SM13) to place the case in the load station. The robot then moves up and around the case being loaded and proceeds to the magazine.

Flights

The Case Flights (SM14) servo motor matches the robot x-axis movement, and advances the loaded cases through tucking, gluing, and compression.

Load Station

When an empty case blank is set up in the load station, the Load Cup Lift (SV30801) solenoid valve extends the air cylinders, and the Load Vacuum (SV30308) solenoid valve turns on the vacuum. This action holds the case in position while loading. Before the case is moved out of the load station, vacuum is turned off and the cylinders are retracted.

Fun/Tuckers

The Funnel In/Out and the Fun/Tucker In/Out (SV30407 and SV30406) solenoid valves move the funnels into the case. The Funnel and Fun/Tucker (SM8 and SM9) servos are cammed to the case packer main virtual master for funneling the cartons into the case during loading. The funnel and fun/tucker are rotated to guide the cartons into the case. As the stack is being loaded into the case, the funnels retract while the Tucker (SM10) tucks the leading flap on the operator side of the case, and the Product Stop (SM11) partially closes the trailing flap on the operator side. Closing these flaps gives the carton stacks a surface against which to square as they are loaded into the case. As the loader retracts from the case, the funnel rotates away from the case. The fun/tucker rotates away, and continues to rotate, enabling the tuckers mounted on the back side to tuck the leading flap on the non-operator side of the case. As the case moves forward out of the load station and into compression, the fun/tucker and tucker move in unison to tuck the trailing vertical flap. The Distorted Case (PE31904) photo eye looks for the trailing edge of the case to ensure flaps are properly tucked.

Glue

Glue is applied to the vertical flaps as the case moves from the load station to compression. The Lower Glue Non-Operator Side, Lower Glue Operator Side, Upper Glue Non-Operator Side and Upper Glue Operator Side (SV30805, SV30806, SV30807 and SV30808) solenoid valves are all cammed to the case packer main virtual master. Glue is applied only if vacuum is made at the Load Vacuum (VS31708).

Compression

When the case reaches the compression station, the Case Stop (SV30402) solenoid valve extends to stop the top leading edge of the case, keeping it square. The case pusher and flights ensure that the case is pushed up against the stop.



The Lower Compression Non-Operator Side, Lower Compression Operator Side, Upper Compression Non-Operator Side and Upper Compression Operator Side (SM15, SM16, SM17 and SM18) servo motors are all cammed to the case packer main virtual master.

The compression plates fold the horizontal flaps against the glue on the vertical flaps. The flights move the case out of compression and into the orienter while the next case is moved into compression.

ORIENTER

Case Tip/Reject

The case packer flights push the case out of compression onto the Tip/Reject Roller Conveyor (MT1501) in the orienter. As the case leaves the case packer, the Non-Operator Side Open Flap and Operator Side Open Flap (PE51402 and PE51401) photo eyes ensure the case flaps are closed and properly glued. The case is stopped by the Tipper Case Stop (SV50703). If either of the open flap eyes is blocked while the case passes by, the Case Tip R (SM20) retracts and the Tipper Reject Flights (SM19) pushes the case out of the machine. If the case is good, the Case Tip R catches the top, operator side, of the case while the flights push the bottom, non-operator side, out toward the operator side of the machine. This action tips the case toward the backstop (what was the non-operator side of the case is now the bottom). The flights push the case against the backstop and retract, the tipper case stop retracts, and the roller conveyor starts to move the case forward, transferring it to the Case Conveyor (MT50701).

Case Rotate

If the product requires, case rotate is enabled by default.




The Case Rotate (SM21) servo motor rotates an arm across the conveyor. The Case At Rotate (PE51505) photo eye senses when a case is approaching the arm. When sensed, the Case Rotate Vacuum (SV50201) solenoid valve is triggered and attaches the case to the arm with a vacuum cup. The arm rotates 90 degrees ($\frac{1}{4}$ turn) counter-clockwise and releases vacuum (what was the operator side of the case is now the leading side). When the case has moved past the Case Present After Rotate (PE51506) photo eye, the arm retracts and waits for the next case.

Popups and Notices

From time to time and for various reasons, certain events trigger notice popups.

These popups indicate which C40 originated the notice, device number and name, message text, message details, date and time of the notice, and number of messages currently being displayed. After the popup has been cleared, this same information is displayed in the notice history pages

SAMPLE IMAGE



NOTE: If a location is defined in the messaging database, it will be displayed between the C40 name and Device name

Edit Text Button

Users logged in Level 3 or higher may modify the message text.

Map Button

This button will appear when a location image for this device is available. [Map](#)

Info Button

Click this button to display additional PLC notice information useful when troubleshooting with Aagard personnel. [Info](#)

Clear All and Clear Buttons

There are a number of ways to clear notices from the HMI screen.

- Press the Clear button to clear an individual notice
- Press the Clear All button to clear all notices
- Energize the system by pressing the Start button once to clear all notices

NOTE: A Critical Fault will *not* be cleared by using the Clear All button or by pressing the Start button; it must be cleared individually by pressing the Clear button

Since this machine runs on a PC-based computer, other applications are running behind the HMI application. These applications also use popups, when necessary, to notify users of important information. An example of a TwinCAT error is shown below. TwinCAT is a background application required by the HMI application.



Message Notices

Sample Content

| Device | Name | Text | Cause | Remedy | Type |
|------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------|--------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------|---------|
| B1 | Bus Coupler | Read IDN Error | Unable to read the parameter from the brick | Use error id to find more details in the Beckhoff Information System | Warning |
| C20 4 | SD Reference | Probe Sensor Not Found | The probe sensor was not detected during the reference routine | Check the probe sensor and the probe setup data | Fault |
| CR40201 | Software Emergency Stop | Not Ready | A condition in the PLC is requiring a software emergency stop | Check reasons for PLC emergency stop condition | General |
| ES24305 | CP Remote System E Stop | Pulled | The emergency stop button is released | No action required | General |
| GR22401 | Sleever Guard Relay | Guard Relay Reset Failed | A check was performed after all guard doors in this circuit were closed to see if the guard relay was reset; this check failed | If problem persists, check guard circuit | Warning |
| GS22503 | Guard Door 4 | Closed | Door is closed | No action required | General |
| GT9401 | Glue System | Low Glue Level | The glue level is low | Fill glue tank | General |
| MT306 | System Vacuum Pump | Input Parameter Error | The configuration data for the motor is incorrect | Fix data configuration, check programming | Fault |
| PB41301 | CP Remote System Start | Released | Button is released | No action required | General |
| PE41705 | Manufacturer Flap | Reject Detected | Manufacturer's Flap PE was blocked in end compression station | Make sure Manufacture Glue gun is working properly and nothing is blocking the PE or Reflector | Reject |
| PS36502 | Dumped Air Pressure | Low Air Pressure | Air pressure is low | Check air pressure | General |
| SM18 SM19 SM20 SM21 SM22 SM23 SM24 SM25 SM26 SM27 SM28 SM29 SM30 | Loader Loader Z-Axis Case Setup Case Flights Flap Traps Fixed Funnel Adjustable Funnel Load Side Tucker Non Load Side Tucker Case Squaring Manufacturer Glue End Flap Compression Mfr Flap/Top Tucker | Fast Stop Failed | The drive was not able to fast stop successfully | Clear message and start system; if problem persists, review move data | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|---------|--------------------------------|-------------------------------------|----------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------|------------------|
| SR28201 | Customer Global Safety Relay | Safety Relay Reset Check Failed | A check was performed after the safety circuit was reset to see if the relay is reset; this check failed | If problem persists check safety circuit | Warning |
| SV50602 | Upper Glue Load Side | Direction A Sensor Not Made In Time | The A sensor did not make in the required time from the A direction call | Check A sensor for proper operation | Fault |
| TS37102 | Remote HMI Cabinet Temp Sensor | Above Set Point | The cabinet temperature is above the set point | Check the cabinet for excessive heat, verify cooling system is properly functioning, check temp switch for proper operation | General, Warning |
| VS36503 | System Vacuum | Low Vacuum Supply | Vacuum was lost when not expected | Check vacuum supply | Fault |

Level 2

Product Download Page

General Page Information


The Product Change screen will automatically be displayed on machine power up. It can manually be displayed by pressing the “Product Change” button on the main page while logged in at User Level 2 or higher. Click on the desired product and press the Download button. This button will download all of the new product’s information, which is now stored in the main controller, and display the [Changeover Adjustments Page](#).

NOTE: The machine must be E-Stopped to do a product change.


The [Edit Button](#) will display the page that allows System Products to be edited. A [User Level 3](#) is required for these features.

If no user is logged in when the Edit button is clicked, the log in screen will display and a user and password is required to continue.

SAMPLE IMAGE




Changeover Location Drawing



[Training Index](#)

[Next Level 2 Training](#)


Changeover Adjustments



[Training Index](#)

[Next Level 2 Training](#)

2-1



Using crank handle, adjust scale to the value shown on the View Changeover Adjustments page for this changeover location.

2-1A



Using quick handle, adjust position to the value shown on the View Changeover Adjustments page for this changeover location.

2-2



Using crank handle, adjust scale to the value shown on the View Changeover Adjustments page for this location.

2-3




Loosen quick handle and adjust the scale to the value shown on the View Changeover Adjustments page for this changeover location. Retighten quick handle!

2-4



Loosen quick handle and adjust the scale to the value shown on the View Changeover Adjustments page for this location. Retighten quick handle!

2-5



Using crank handle, adjust scale to the value shown on the View Changeover Adjustments page for this location.

Changeover Quick Reference Chart

NOTE: Please refer to the HMI for the current changeover values.

NOTE: Please refer to the HMI for the correct changeover sequence.

| Number | Name | (future products) | | |
|--------------------------------|------------------------------------------------------------|-------------------|--|--|
| CASE PACKER ADJUSTMENTS | | | | |
| 2-1 | Operator Side Magazine Width | | | |
| 2-1A | Operator Side Magazine Side Guide | | | |
| 2-2 | Non-Operator Side Magazine Width | | | |
| 2-3 | Non-Operator Side Magazine Rotate Clip | | | |
| 2-4 | Operator Side Magazine Rotate Clip | | | |
| 2-5 | Top Clip | | | |
| 2-6 | Bedplate Width | | | |
| 2-7 | Product Stop - Upper | | | |
| 2-7A | Product Stop Top Plate | | | |
| 2-8 | Product Stop - Lower | | | |
| 2-9A | Flap Tucker - Upper | | | |
| 2-9B | Flap Tucker - Lower | | | |
| 2-10 | Robot Pick Cups | | | |
| 2-11 | Robot Case Pusher Horizontal | | | |
| 2-12 | Robot Case Pusher Vertical | | | |
| 2-13 | Wide Load Vacuum Control Switch A | | | |
| 2-14 | Wide Load Vacuum Control Switch B | | | |
| 2-14A | Operator Side Load Cups On/Off | | | |
| 2-14B | RR Center Load Cups On/Off | | | |
| 2-14C | Operator Side Wide Load Cups On/Off | | | |
| 2-15 | Load Deck Transfer Plate Change Parts | | | |
| 2-16 | Top Flap Lift | | | |
| 2-17 | Product Conditioner Extension | | | |
| 2-18 | Funnel | | | |
| 2-19 | Upper Compression Height | | | |
| 2-20 | Operator Side Upper Glue Height | | | |
| 2-21 | Operator Side Tucker Rail Height | | | |
| 2-22 | Operator Side Lower Glue Height | | | |
| 2-23 | Operator Side Comp. Extension Plates | | | |
| 2-24 | Upper Compression Width | | | |
| 2-25 | Non-Operator Side Comp. Extension Plates | | | |
| 2-26 | Non-Operator Side Upper Glue Height | | | |
| 2-27 | Non-Operator Side After Tucker Rail Height | | | |
| 2-28 | Non-Operator Side Lower Glue Height | | | |
| 2-29 | Product Conditioner Height | | | |

| Number | Name | (future products) | | |
|-----------------------------|-------------------------------------------------------|-------------------|--|--|
| 2-30 | Loader Plate | | | |
| 2-31 | Fun-Tucker | | | |
| 2-32 | Dow nstacker Backstop Fixed Side | | | |
| 2-33 | Dow nstacker Backstop Adjustable Side | | | |
| 2-34 | Dow nstacker Width | | | |
| 2-35 | Dow nstack Pusher Change Part | | | |
| 2-36 | Infeed Conveyor Rail | | | |
| 2-37 | Funnel Width | | | |
| ORIENTER ADJUSTMENTS | | | | |
| 3-1 | Robot Tipper Horizontal | | | |
| 3-2 | Case Rotate Arm | | | |
| 3-4 | Conveyor Side Rail | | | |

(Print this topic as a reference when setting up new pack patterns!)

Training Index

Next Level 2 Training

Product Download Changeover Adjustments Page

General Page Information

This screen is active after a product download is initiated. It is a checklist for the changeover locations on the machine. Each changeover location is listed in the order that the adjustment should be executed. The target value for each changeover location is shown along with each changeover name and description. When an adjustment is completed, the button in the "Done" column may be pressed to indicate completion.

SAMPLE IMAGE

| <u>Done</u> | <u>Machine</u> | <u>Adj. Name</u> | <u>Description</u> | <u>Value</u> |
|-------------|---------------------|------------------|--------------------|--------------|
| Yes | Sleever Case Packer | 1-1 | Example Adjustment | 10 |
| Yes | Sleever Case Packer | 1-2 | Example Adjustment | 2 |
| Yes | Sleever Case Packer | 1-3 | Example Adjustment | 30 |
| Yes | Sleever Case Packer | 1-4 | Example Adjustment | 40 |
| No | Sleever Case Packer | 1-5 | Example Adjustment | 50 |
| No | Sleever Case Packer | 1-6 | Example Adjustment | 60 |
| No | Sleever Case Packer | 1-7 | Example Adjustment | 70 |
| No | Sleever Case Packer | 1-8 | Example Adjustment | 80 |
| No | Sleever Case Packer | 1-9 | Example Adjustment | 90 |
| No | Sleever Case Packer | 1-10 | Example Adjustment | 100 |
| No | Sleever Case Packer | 1-11A | Example Adjustment | 110 |
| No | Sleever Case Packer | 1-11B | Example Adjustment | 120 |
| No | Sleever Case Packer | 1-11C | Example Adjustment | 130 |
| No | Sleever Case Packer | 1-11D | Example Adjustment | 140 |
| No | Sleever Case Packer | 1-11E | Example Adjustment | 150 |
| No | Sleever Case Packer | 1-11F | Example Adjustment | 160 |
| No | Sleever Case Packer | 1-12A | Example Adjustment | 170 |
| No | Sleever Case Packer | 1-12B | Example Adjustment | 180 |

Print Finish

Done

This column contains a Yes/No button for each changeover adjustment. When a changeover routine is in process, the Yes/No button may be selected to show whether or not the changeover adjustment has been completed during the current changeover routine.

Machine

This column lists which machine the changeover adjustment is located in.

Adj. Name

This column lists the name of the changeover adjustment. The name is typically a number that has been assigned to that particular changeover location.

Description

This column contains the description of the item.

Value

This is the value at which the changeover adjustment should be when completed.

Print

The print button will print the machine changeover screen to the default printer set up on the HMI. This printout can then be used during the machine changeover.

It is recommended that when the changeover is completed, the printout be discarded to ensure there are no obsolete copies.

Finish Button

Press this button to continue onto the [HMI Main Screen](#) after all of the adjustments have been completed. If any of the adjustments have not been marked completed, a popup will appear after the **Finish Button** has been pressed.

This is a warning to verify that it is OK to continue onto the [HMI Main Screen](#) even though all the adjustments haven't been marked as completed.

Continuous Running

The system will continue to run as long as new product is available, packaging supplies (carton blanks, hot melt adhesive, etc.) are replenished, and the product is removed.

[Case Blanks](#)


[Glue](#)

Carton Blanks

Carton Blanks

To replenish the magazine while the machine is running, stack the carton blanks behind the follower plate and then slide the follower plate out from the stack. Make sure the printed side of the carton blanks is facing the follower plate, with the manufacturer's flap down. Move the follower plate to the end of the stack and push against the stack, removing any gaps that may be present before resetting the follower plate onto the chain.


SAMPLE IMAGE



Top Carton Drive

When the carton magazine is empty or if there are not enough blanks to support it, the top carton drive unit will pivot downwards. To prevent the top carton drive unit from hanging down and to make it easier to load the carton blanks, hold the drive unit up slightly, remove the support pin from its vertical stored position, and insert the pin into the hole on the top of the unit as shown in the picture below. This will hold the top carton drive unit up and out of the way while carton blanks are being loaded. When sufficient carton blanks have been loaded, remove the pin and let the top carton drive unit rest on the top of the carton blanks. Return the support pin to its stored position.

SAMPLE IMAGE



Case Blanks

Case Blanks

To replenish the magazine while the machine is running, stack the case blanks behind the follower plate and then slide the follower out from the stack. Move the follower plate to the end of the stack and push against the stack, removing any gaps that may be present before resetting the follower onto the chain.



Glue

Glue Tanks


Hot melt adhesive: Replenish the hot melt adhesive in the Nordson glue system per Nordson directions as required. To load glue pellets, lift the cover of the glue tank and gently drop glue pellets into the tank. Fill to fill level line (see picture below). Close the cover.

⚠ DANGER ⚠

Under no circumstances should you reach into a hot glue tank.

Warning: Do not overfill!

SAMPLE IMAGE



Please refer to the [Nordson](#) ProBlue Adhesive System Manual for information about the hot melt applicator. The Nordson Manual contains everything from electrical wiring diagrams to operation to troubleshooting.

Log In Screen

General Page Information

This is what the Aagard HMI Screen will look like if the Log In Button is pressed while no one is currently logged in. If a user is currently logged in, the button will display the text "Log Out". If the button is pressed while the "Log Out" text is displayed, the current user will be logged out and the "Log In" text will be displayed. Consult your supervisor for the correct user name and password. The machine will be logged out upon power up.

SAMPLE IMAGE



| | Machine Run | Jog, Reference & Troubleshooting | Machine Data Input | Login User Information |
|-----------------------------|-------------------------------------|-------------------------------------|-------------------------------------|-------------------------------------|
| Operator Level 1 | <input checked="" type="checkbox"/> | | | |
| Operator Level 2 | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | | |
| Advanced Technician Level 3 | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | |
| Administrator Level | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |

Operator Control Panel (HMI)

HMI Main Screen

General Page Information

After power up and initialization of the Packaging system, the Main screen will be displayed. This Main screen is the starting point from which everything branches. All the Message Displays combined will provide information on what is happening with the machine, displaying any faults that would prevent the system from running (guard door open, low air pressure, etc.). The Aagard HMI will go straight to the Main Screen if the HMI is closed and reopened without losing power to any part of the machine.

NOTE: The system will be in the same Mode in which it was left at power down. Correct any Fault conditions which are displayed before attempting to run the machine.

NOTE: Depending on user level, not all buttons will be visible.

The screenshot displays the Aagard HMI Main Screen. At the top, it shows 'Current User: Aagard', 'User Stop', and the date/time '2/28/2011 7:40:04 AM'. The main header area includes 'Aagard 120', 'No Product Selected', and 'System Rate: 200.00'. A prominent fault message reads 'PC1 HMI: SERCOS Communication Error - Not In Phase 4'. Below this, two machine sections are visible: 'Case Packer' and 'Unitizer', both with 'State: Stopped' and 'Mode: EStop'. Each section includes a 'Rate: 100 %' indicator and a 'Reset' button. Navigation buttons for 'Fault History', 'Reject History', 'Data Input', 'Disable', 'Disable Product', 'Automatic Mode', 'Manual Mode', 'Jog', and 'Reference' are present. At the bottom, a 'Production Data' table shows metrics for Case Count, MTBF, MTTR, Downtime Count, Running Time Since Last Stop, Starved Time - OOP, and Efficiency for Shift, Daily, and Last Shift periods. The table shows all values as 0 or 0S, with an efficiency of 0.0%. A footer area contains 'QC Case', 'Custom Buttons', 'Advanced', 'Product Change', and a yellow 'Log Out' button. The Aagard logo and 'About...' button are also visible.

| | Case Count | MTBF | MTTR | Downtime Count | Running Time Since Last Stop | Starved Time - OOP | Efficiency |
|------------|------------|------|------|----------------|------------------------------|--------------------|------------|
| Shift | 0 | 0S | 0S | 0 | 0S | 0S | 0.0% |
| Daily | 0 | 0S | 0S | 0 | 0S | 0S | 0.0% |
| Last Shift | 0 | 0S | 0S | 0 | 0S | 0S | 0.0% |

System Information

This section contains the machine name, the current downloaded product name, the current system rate and any system messages. A system is also known as the S10 level of the machine.

C40 Information

This section contains the C40 name, the [state and mode](#), and any C40 messages. An example of a C40 would be a Cartoner or a Case Packer.

Rate

This entry field will allow the machine to operate at slower speeds. 100% is equal to the maximum rate at which the machine is able to operate. 50% is half that rate and so on. This only applies while in Automatic Mode

Reset

This button will reset the selected C40. This will make the machine think that there is no product in the machine. This button is a last resort to get the machine running again. After this button is pressed, all remaining product should be cleared out of the machine and then the machine can be started again.

Fault History Button

Pressing this button will open the [Fault History Page](#) for the C40 that the button was on.

Reject History Button

Pressing this button will open the [Reject History Page](#) for the C40 that the button was on.

Data Input Button

Pressing this button will open the [Data Input Page](#) for the C40 that the button was on.

Disable/Enable

Pressing this button will Disable/Enable the selected C40. When a C40 is disabled, that section of the machine will not perform its operations. When the C40 is disabled the button will be red and the State status will be Disabled. This button can only be toggled when that C40 is in Mode: Estop.

Disable/Enable Product

Pressing this button will Disable/Enable Product on the selected C40. When a C40 has Disabled Product, the button will be red. Disabled Product is a type of a dry cycle. When the machine is started back up, that section of the machine will perform its operations as if it were receiving the amount of product per minute specified in the System Rate Display. This button can only be toggled when that C40 is in Mode: Estop.

Automatic Mode Button

When the Automatic (Run) Mode Button for the C40 is pressed, that C40 will go into Automatic Mode. Press and hold the start pushbutton for 3 seconds to begin running. If no faults are detected, the Module will continue into the Producing Mode.

Manual Mode

Pressing the Manual Mode button will put the machine in manual mode and display two additional buttons: "Jog" and "Reference".

Jog Button

Pressing this button will open the [Jog Page](#) for the C40 that the button was on.

Reference Button

Pressing this button will open the [Reference Page](#) for the C40 that the button was on.

Production Data Table

This table shows the current shift's information and the current day's information. For more on this, see the [Production Data Page](#).

Production Data Button

Pressing this button will open the [Production Data Page](#) for the machine.

QC Case

This allows the machine to reject one (1) good case for Quality Control purposes.

Custom Buttons

Pressing this button will open the [Custom Buttons Page](#) for the machine.

Advanced Button

Pressing this button will open the [Advanced Page](#) for the machine.

Product Change Button

Pressing this button will open the [Product Download Page](#) for the machine.

Log In / Log Out Button


If the button displays "Log In", then no user is currently logged in and pressing this button will open the the [Log In Screen](#).

If the button displays "Log Out", then a user is currently logged in and pressing this button will cause the current user to be logged out.

NOTE: The current user name is displayed in the upper left area of the Main Page.

About Button

This button will show version and build information, and will be useful when troubleshooting with Aagard technicians.



Aagard Logo

Pressing this button will open the Aagard Machine Operator Manual from the HMI.

- o The user may be prompted to install a documentation update

Fault History Page

General Page Information

This page keeps a record of all faults generated. This may help with diagnosing any major problems or possible problems. These notices will be stored in the database for three days, and then will be deleted. The information displayed on this page is also accessible on the [View Notices System Wide](#) page.

SAMPLE IMAGE

Aagard HMI - Notice History

Notice History for Cartoner

Move Column: Device [v] Left Right C40 Cartoner [v]

| Date Stamp | Device | Message | PLC Details | Notice Type | Shift | Down Time | Ack Time | Notes | Location | HMI Details |
|------------------------|-------------------|-----------------------------|--------------------|----------------|-------|-----------|----------|-------|----------|------------------|
| 11/5/2010 8:02:25 AM | IDV1 Carton ... | Bar Code Scanner Failure | Beckhoff Error ... | Fault | 1 | | | | Cartoner | |
| 1/5/2010 8:02:17 AM | IDV1 Carton ... | Bar Code Scanner Failure | Beckhoff Error ... | Fault | 1 | | | | Cartoner | |
| 12/18/2009 11:03:24 AM | SD5 Side Fil... | Motion Control Reset Error | Servo Drive E... | Fault | 1 | 00:05:53 | 00:00:07 | | Cartoner | Cleared in 7 s |
| 12/17/2009 10:54:09 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:01:21 | 00:00:01 | | Cartoner | Cleared in 1 s |
| 12/17/2009 10:49:24 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:04:07 | 00:00:02 | | Cartoner | Cleared in 2 s |
| 12/17/2009 10:35:31 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:01:13 | 00:00:02 | | Cartoner | Cleared in 2 s |
| 12/17/2009 10:25:25 AM | EN49101 Low... | Lower Film Unwind Danc... | Encoder Pos ... | Fault | 1 | 00:05:37 | 00:00:05 | | Cartoner | Cleared in 5 s |
| 12/17/2009 9:57:13 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:01:16 | 00:00:05 | | Cartoner | Cleared in 5 s |
| 12/17/2009 9:47:40 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:08:48 | 00:08:26 | | Cartoner | Cleared in 8 ... |
| 12/17/2009 9:42:22 AM | SD6 Side Fil... | Fast Stop Failed | MC_ChangeD... | Fault | 1 | 00:03:15 | 00:00:03 | | Cartoner | Cleared in 2 s |
| 12/16/2009 11:07:22 AM | IDV7 Carton ... | Checkweigher Failure | Check Check... | Fault | 1 | 00:00:13 | 00:00:07 | | Cartoner | Cleared in 7 s |
| 12/16/2009 10:43:57 AM | IDV4 Filler B ... | Metal Detected | Metal Detecte... | Critical Fault | 1 | | 00:00:32 | | Cartoner | Cleared in 31 s |
| 12/16/2009 10:43:54 AM | IDV3 Filler A ... | Metal Detected | Metal Detecte... | Critical Fault | 1 | 00:00:49 | 00:00:32 | | Cartoner | Cleared in 32 s |
| 12/16/2009 10:25:38 AM | IDV1 Carton ... | Bad Bar Code Scanned | Remove Carto... | Critical Fault | 1 | 00:02:24 | 00:01:15 | | Cartoner | Cleared in 1 ... |
| 12/16/2009 10:21:47 AM | PE48206 Cart... | Improper Carton Transfer... | Carton Did Not... | Fault | 1 | 00:03:19 | 00:00:18 | | Cartoner | Cleared in 17 s |
| 12/16/2009 9:22:37 AM | S32_4 Analo... | Function Block Failed | Channel 2 Fail... | Fault | 1 | | 00:28:34 | | Cartoner | Cleared in 28... |
| 12/16/2009 9:02:08 AM | S32_4 Analo... | Function Block Failed | Channel 1 Fail... | Fault | 1 | | 00:13:46 | | Cartoner | Cleared in 13... |
| 12/16/2009 8:57:11 AM | S32_4 Analo... | Function Block Failed | Channel 1 Fail... | Fault | 1 | 01:04:15 | 00:00:32 | | Cartoner | Cleared in 32 s |
| 12/16/2009 7:48:17 AM | IDV7 Carton ... | Checkweigher Failure | Check Check... | Fault | 1 | 00:00:35 | 00:00:15 | | Cartoner | Cleared in 15 s |
| 12/16/2009 7:45:01 AM | IDV7 Carton ... | Checkweigher Failure | Check Check... | Fault | 1 | 00:02:57 | 00:00:23 | | Cartoner | Cleared in 23 s |
| 12/16/2009 7:39:40 AM | IDV1 Carton ... | Bad Bar Code Scanned | Remove Carto... | Critical Fault | 1 | 00:00:52 | 00:00:39 | | Cartoner | Cleared in 39 s |
| 12/16/2009 7:37:31 AM | IDV1 Carton ... | Bad Bar Code Scanned | Remove Carto... | Critical Fault | 1 | 00:01:33 | 00:01:30 | | Cartoner | Cleared in 1 ... |
| 12/15/2009 6:44:58 PM | PE42306 Sec... | Blocked Too Long | Blocked For 1... | Fault | 2 | 00:05:46 | 00:05:36 | | Cartoner | Cleared in 5 ... |

C40 Filter

Click on the drop down arrow to view history for a particular C40. If a C40 is not listed, there are no messages to display.

Filter Buttons (Fault, Critical Fault, General, Warning, Reject, Debug, Utility, and Unhandled Not Shown)

These buttons represent different notice types. Press any button to filter those notices from the list. Pressing refresh will refresh the screen, displaying only those notice types selected.

- **Fault** – a message describing an unintended event which restricts the system's ability to produce
- **Critical Fault** – same as Fault, except the operator must acknowledge each Critical Fault individually
- **General** – an informational message which relays current existing conditions within the system
- **Warning** – a message describing an event which occurred, or an existing condition, which may cause a problem if not addressed
- **Reject** – a message describing why a product was rejected from the normal flow of product
- **Debug** – a message used during the debug stage of development to monitor for specific desired or undesired events
- **Utility** – a notice used to trigger a software utility
- **Unhandled Not Shown** – a message that is sent from the PLC but not defined in the Message data base
- **Production Data Not Shown** – a message used for production data collection

Individual Items

Click this button to display the items in the grid in chronological order.

NOTE: When **Individual Items** is selected, the button color will be blue

Totaled


Click this button to display the items in the grid in a totaled fashion, displaying the number of times an item occurred. The items all totaled to allow the user to more easily view which items are occurring the most frequently.

NOTE: When **Totaled** selected, the button color will be blue

| Aagard HMI - Notice History | | | | |
|-----------------------------|----------|---------------------------------|-------|--|
| Notice History for Inserter | | | | |
| Device | Location | Message | Count | |
| CS1AE Knife ... | Inserter | Cylinder Extend Switch Not M... | 1 | |
| MS1 Custom... | Inserter | VFD Faulted | 2 | |
| MS1 Custom... | Inserter | Invalid Program Call | 16 | |
| PE6 Register... | Inserter | Sensor Failure | 8 | |
| PE6 Register... | Inserter | Not Made During Startup | 1 | |
| PE2 Web Br... | Inserter | Web Break PE Not Blocked ... | 1 | |
| PE3 Loop Low | Inserter | Eye Not Blocked When Expe... | 10 | |
| SD2 Knife | Inserter | Lag Error | 1 | |
| SD1 Pirwheel | Inserter | Cam Load Failed | 1 | |
| CTRL1 HMI | Inserter | Switching To Sercos Phase 2 ... | 1 | |
| | | | | |
| | | | | |

Edit Notes Button

Select a message in the grid and the Edit Notes Button becomes available. Click on the Edit Notes button to open a dialog window to add your notes to the messages. Double-clicking on the message itself also opens this dialog. Click OK on the dialog when finished.



Delete All Button

This button will delete the entire fault log. This will make any generated reports invalid since the Report Generator uses this fault log to generate its reports.

Refresh

This button will refresh the faults on the screen to the most current log at the time the refresh button was pressed, reflected by any filters which may have been selected.

Back Button

This button will return the user to the calling page.

Filter Drop Down List

Click on the drop down arrow to view available filters to apply to the list. Select a filter from the list to apply it. Depending on the selection, additional parameters become available to enter, such as dates and hours.

| | | |
|-----------------|-----------|------------|
| From Date/Time: | 1/ 4/2010 | 5:59:00 AM |
| To Date/Time: | 1/ 4/2010 | 5:59:00 PM |
| Show Last: | 0 Hours | 0 Minutes |

Column Options

To move a column from left to right, select a column from the dropdown list, and click Left or Right to move the column in either direction.

Device Column

This column displays the name of the device which generated the notice.

Message Column

This column displays the message which appeared on the notice. A list of possible messages, causes, and actions are given on the [Message Notices](#) section.

PLC Details Column

This column displays information received from the PLC when the notice was generated.

Shift Column

This column displays the shift in which the notice was recorded.

Down Time Column

This column displays time elapsed between notice display and when the system is started.

Ack Time Column

This column displays the length of time elapsed before the notice was acknowledged.

HMI Details Column

This column displays any additional information received from the HMI when the notice was generated.

Date Stamp Column

This column displays the date and time when the notice was generated.

Notes Column

This column displays any user entered information for the selected notice.

Notice Type

This column displays the type of notice recorded.

Location Column

This column displays the notice location or area of the machine.

Reject History Page

General Page Information

This page keeps a record of all rejects generated. This may help with diagnosing any major problems or possible problems. These notices will be stored in the database for three days, and then will be deleted. The information displayed on this page is also accessible on the [View Notices System Wide](#) page.

SAMPLE IMAGE

Aagard HMI - Notice History

Notice History for Cartoner

Move Column: C40

| Date Stamp | Device | Message | PLC Details | Notice Type | Shift | Down Time | Ack Time | Notes | Location | HMI Details |
|------------------------|-------------------|-----------------------------|--------------------|----------------|-------|-----------|----------|-------|----------|------------------|
| 11/5/2010 8:02:25 AM | IDV1 Carton ... | Bar Code Scanner Failure | Beckhoff Error ... | Fault | 1 | | | | Cartoner | |
| 11/5/2010 8:02:17 AM | IDV1 Carton ... | Bar Code Scanner Failure | Beckhoff Error ... | Fault | 1 | | | | Cartoner | |
| 12/18/2009 11:03:24 AM | SD5 Side Fil... | Motion Control Reset Error | Servo Drive E... | Fault | 1 | 00:05:53 | 00:00:07 | | Cartoner | Cleared in 7 s |
| 12/17/2009 10:54:09 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:01:21 | 00:00:01 | | Cartoner | Cleared in 1 s |
| 12/17/2009 10:49:24 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:04:07 | 00:00:02 | | Cartoner | Cleared in 2 s |
| 12/17/2009 10:35:31 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:01:13 | 00:00:02 | | Cartoner | Cleared in 2 s |
| 12/17/2009 10:25:25 AM | EN49101 Low... | Lower Film Unwind Danc... | Encoder Pos ... | Fault | 1 | 00:05:37 | 00:00:05 | | Cartoner | Cleared in 5 s |
| 12/17/2009 9:57:13 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:01:16 | 00:00:05 | | Cartoner | Cleared in 5 s |
| 12/17/2009 9:47:40 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:08:48 | 00:08:26 | | Cartoner | Cleared in 8 ... |
| 12/17/2009 9:42:22 AM | SD6 Side Fil... | Fast Stop Failed | MC_ChangeD... | Fault | 1 | 00:03:15 | 00:00:03 | | Cartoner | Cleared in 2 s |
| 12/16/2009 11:07:22 AM | IDV7 Carton ... | Checkweigher Failure | Check Check... | Fault | 1 | 00:00:13 | 00:00:07 | | Cartoner | Cleared in 7 s |
| 12/16/2009 10:43:57 AM | IDV4 Filler B ... | Metal Detected | Metal Detecte... | Critical Fault | 1 | | 00:00:32 | | Cartoner | Cleared in 31 s |
| 12/16/2009 10:43:54 AM | IDV3 Filler A ... | Metal Detected | Metal Detecte... | Critical Fault | 1 | 00:00:49 | 00:00:32 | | Cartoner | Cleared in 32 s |
| 12/16/2009 10:25:38 AM | IDV1 Carton ... | Bad Bar Code Scanned | Remove Carto... | Critical Fault | 1 | 00:02:24 | 00:01:15 | | Cartoner | Cleared in 1 ... |
| 12/16/2009 10:21:47 AM | PE48206 Cart... | Improper Carton Transfer... | Carton Did Not... | Fault | 1 | 00:03:19 | 00:00:18 | | Cartoner | Cleared in 17 s |
| 12/16/2009 9:22:37 AM | S32_4 Analo... | Function Block Failed | Channel 2 Fail... | Fault | 1 | | 00:28:34 | | Cartoner | Cleared in 28... |
| 12/16/2009 9:02:08 AM | S32_4 Analo... | Function Block Failed | Channel 1 Fail... | Fault | 1 | | 00:13:46 | | Cartoner | Cleared in 13... |
| 12/16/2009 8:57:11 AM | S32_4 Analo... | Function Block Failed | Channel 1 Fail... | Fault | 1 | 01:04:15 | 00:00:32 | | Cartoner | Cleared in 32 s |
| 12/16/2009 7:48:17 AM | IDV7 Carton ... | Checkweigher Failure | Check Check... | Fault | 1 | 00:00:35 | 00:00:15 | | Cartoner | Cleared in 15 s |
| 12/16/2009 7:45:01 AM | IDV7 Carton ... | Checkweigher Failure | Check Check... | Fault | 1 | 00:02:57 | 00:00:23 | | Cartoner | Cleared in 23 s |
| 12/16/2009 7:39:40 AM | IDV1 Carton ... | Bad Bar Code Scanned | Remove Carto... | Critical Fault | 1 | 00:00:52 | 00:00:39 | | Cartoner | Cleared in 39 s |
| 12/16/2009 7:37:31 AM | IDV1 Carton ... | Bad Bar Code Scanned | Remove Carto... | Critical Fault | 1 | 00:01:33 | 00:01:30 | | Cartoner | Cleared in 1 ... |
| 12/15/2009 6:44:58 PM | PE42306 Sec... | Blocked Too Long | Blocked For 1... | Fault | 2 | 00:05:46 | 00:05:36 | | Cartoner | Cleared in 5 ... |

C40 Filter

Click on the drop down arrow to view history for a particular C40. If a C40 is not listed, there are no messages to display.

Filter Buttons (Fault, Critical Fault, General, Warning, Reject, Debug, Utility, and Unhandled Not Shown)

These buttons represent different notice types. Press any button to filter those notices from the list. Pressing refresh will refresh the screen, displaying only those notice types selected.

- **Fault** – a message describing an unintended event which restricts the system's ability to produce
- **Critical Fault** – same as Fault, except the operator must acknowledge each Critical Fault individually
- **General** – an informational message which relays current existing conditions within the system
- **Warning** – a message describing an event which occurred, or an existing condition, which may cause a problem if not addressed
- **Reject** – a message describing why a product was rejected from the normal flow of product
- **Debug** – a message used during the debug stage of development to monitor for specific desired or undesired events
- **Utility** – a notice used to trigger a software utility
- **Unhandled Not Shown** – a message that is sent from the PLC but not defined in the Message data base
- **Production Data Not Shown** – a message used for production data collection

Individual Items

Click this button to display the items in the grid in chronological order.

NOTE: When **Individual Items** is selected, the button color will be blue

Totaled


Click this button to display the items in the grid in a totaled fashion, displaying the number of times an item occurred. The items all totaled to allow the user to more easily view which items are occurring the most frequently.

NOTE: When **Totaled** selected, the button color will be blue

| Aagard HMI - Notice History | | | | |
|-----------------------------|----------|---------------------------------|-------|--|
| Notice History for Inserter | | | | |
| Device | Location | Message | Count | |
| CS1AE Knife ... | Inserter | Cylinder Extend Switch Not M... | 1 | |
| MS1 Custom... | Inserter | VFD Faulted | 2 | |
| MS1 Custom... | Inserter | Invalid Program Call | 16 | |
| PE6 Register... | Inserter | Sensor Failure | 8 | |
| PE6 Register... | Inserter | Not Made During Startup | 1 | |
| PE2 Web Br... | Inserter | Web Break PE Not Blocked ... | 1 | |
| PE3 Loop Low | Inserter | Eye Not Blocked When Expe... | 10 | |
| SD2 Knife | Inserter | Lag Error | 1 | |
| SD1 Pirwheel | Inserter | Cam Load Failed | 1 | |
| CTRL1 HMI | Inserter | Switching To Sercos Phase 2 ... | 1 | |
| | | | | |
| | | | | |

Edit Notes Button

Select a message in the grid and the Edit Notes Button becomes available. Click on the Edit Notes button to open a dialog window to add your notes to the messages. Double-clicking on the message itself also opens this dialog. Click OK on the dialog when finished.



Delete All Button

This button will delete the entire fault log. This will make any generated reports invalid since the Report Generator uses this fault log to generate its reports.

Refresh

This button will refresh the faults on the screen to the most current log at the time the refresh button was pressed, reflected by any filters which may have been selected.

Back Button

This button will return the user to the calling page.

Filter Drop Down List

Click on the drop down arrow to view available filters to apply to the list. Select a filter from the list to apply it. Depending on the selection, additional parameters become available to enter, such as dates and hours.

| | | |
|-----------------|-----------|------------|
| From Date/Time: | 1/ 4/2010 | 5:59:00 AM |
| To Date/Time: | 1/ 4/2010 | 5:59:00 PM |
| Show Last: | 0 Hours | 0 Minutes |

Column Options

To move a column from left to right, select a column from the dropdown list, and click Left or Right to move the column in either direction.

Device Column

This column displays the name of the device which generated the notice.

Message Column

This column displays the message which appeared on the notice. A list of possible messages, causes, and actions are given on the [Message Notices](#) section.

PLC Details Column

This column displays information received from the PLC when the notice was generated.

Shift Column

This column displays the shift in which the notice was recorded.

Down Time Column

This column displays time elapsed between notice display and when the system is started.

Ack Time Column

This column displays the length of time elapsed before the notice was acknowledged.

HMI Details Column

This column displays any additional information received from the HMI when the notice was generated.

Date Stamp Column

This column displays the date and time when the notice was generated.

Notes Column

This column displays any user entered information for the selected notice.

Notice Type

This column displays the type of notice recorded.

Location Column

This column displays the notice location or area of the machine.

Production Data Page

General Page Information

This page will display any production data collected by the machine. This will show how the machine is performing from day to day. The downtime tracking summary is also displayed on the page.

NOTE: The items listed and their locations on this HMI page are 100% configurable and setup by an Aagard Level user during the HMI Setup process. As such, the content on this page is a representation of a possible configuration. The items and/or their locations may change as modifications to the configuration are made on a production Aagard machine in the field. Such configuration changes may not be reflected in this machine manual.

SAMPLE IMAGE

**Time Period Drop Down Menu**

This drop down menu will allow information to be displayed for a certain selected time period.

Edit Shifts Button

This button will display the [Edit Shifts Screen](#).

Back Button

This button will display the HMI Main Screen.

Production Data Information

These items are setup by an Agard Level user during HMI Setup.

IMPORTANT! If changes are made to production data formulas, the Report Generator process *must* be restarted!

| Query Name | Short Description | Detailed Description |
|--------------------------|---------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| RunningTime | Running Time Tracking | Total amount of time the system in a producing state |
| IdleTime | Idle Time Tracking | Total amount of time the system was idle (starved or blocked) |
| UserStopsTime | User Stops Time Tracking | Total amount of downtime caused by user stops (E-Stop, Guard Door, Cycle Stop) |
| FaultTime | Fault Time Tracking | Total amount of downtime caused by faults |
| FaultAckTime | Fault Acknowledgement Time Tracking | Total amount of fault acknowledgement time |
| RunningTimeCount | Number of Running Time Occurrences | The number of instances the system went to a producing state |
| IdleTimeCount | Number of Idle Time Occurrences | Number of instances the system was not producing, caused by not receiving product or downstream not being available (starved and blocked) |
| UserStopCount | Number of User Stop Occurrences | Number of times the system was not producing, caused by a user stop (E-Stop, Guard Door, Cycle Stop) |
| FaultCount | Number of faults | Number of times the system was not producing, caused by a fault |
| DowntimeCount | # of Stops, Downtime Count | The number of instances the system was not producing, caused by a user stop or fault |
| RunningTimeSinceLastStop | Running Time Since Last User Stop Or Fault Recorded In System | Amount of time accumulated since the last time the system went into a producing or idle state |
| TargetCapacity | Target Capacity | The total number of products which could run through this machine if the machine is running at 100% for the measured time period. The machine rate is recipe-specific, as defined in the PLC program; rate changes during the measured time period are taken into account |
| UserStopLoss | Capacity Loss Due To User Stops | Capacity lost due to a user initiated downtime (E-Stop, Guard Door, Cycle Stop, and materials not available) |
| MachineStopLoss | Capacity Loss Due to Faults Or Machine Downtime | The capacity, in units, which was lost, caused by faults and idle time |
| StopLoss | Capacity Loss Due to All Stops | The capacity, in units, which was lost, caused by all stops (user stop loss and machine stop loss) |
| IdleStopLoss | Capacity Loss Due to System Being Idle | The capacity, in units, which was lost, caused by the system being idle (starved or blocked) |
| ExpectedOutput | Expected Output | The difference between Normal Production (NP) Capacity and Idle Stop Loss. NP Capacity is Target Capacity less Stop Loss |
| M(#)InfeedCount | Machine Infeed Product Count | The number of products fed into a specific machine infeed |
| M(#)UnitCount | Machine Unit Count | The number of good products discharged from a specific machine |
| M(#)RejectCount | Machine Reject Count | The number of products rejected from a specific machine |
| M(#)FaultCount | Machine Number of faults | The number of fault instances in a specific machine |
| M(#)FaultTime | Machine Fault Time | Total amount of time the system was not producing based on a specific machine's faults |
| M(#)FaultAckTime | Machine Fault Acknowledgement Time | The amount of fault acknowledgement time based on a specific machine's faults |
| M(#)MinFaultTime | Machine Minimum Fault Time | The shortest fault time length based on a specific machine's faults |


| Query Name | Short Description | Detailed Description |
|----------------------|----------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------|
| M(#)MaxFaultTime | Machine Maximum Fault Time | The longest fault time length based on a specific machine's faults |
| M(#)GDAFaultTime | Machine Greatest Deviation from Average Fault Time | The greatest deviation from average of fault time length based on a specific machine's faults |
| M(#)MinFaultAckTime | Machine Minimum Fault Ack Time | The shortest fault acknowledge time based on a specific machine's faults |
| M(#)MaxFaultAckTime | Machine Maximum Fault Ack Time | The longest fault acknowledge time based on a specific machine's faults |
| M(#)GDAFaultAckTime | Machine Greatest Deviation from Average Fault Ack Time | The greatest deviation from average fault acknowledge time based on a specific machine's faults |
| R(#)StopsCount | Number of stops based on Reason Code | Total number of instances the machine was not producing based on one specific reason code |
| R(#)StopsTime | Stops Time based on Reason Code | Total amount of time the system was not producing based on one specific reason code |
| R(#)StopsMinTime | Stops Minimum Time based on Reason Code | Shortest amount of time the system was not producing based on one specific reason code |
| R(#)StopsMaxTime | Stops Maximum Time based on Reason Code | Longest amount of time the system was not producing based on one specific reason code |
| R(#)StopsGDATime | Stops Greatest Deviation from Average Stop Time based on Reason Code | Greatest deviation from average time the system was not producing based on one specific reason code |

Advanced Page

General Page Information

This screen provides access to advanced functions on the machine.

NOTE: Depending on user level, not all buttons will be visible





Shutdown Computer

This button will activate the process of powering down the PC on which the Aagard HMI is located. Pressing this button will stop instantly any operations the machine is doing. Shutdown Warning

Failure to properly shut down the PC may void the warranty!

| | |
|------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Switch on | The Industrial PC does not have its own main switch. The Industrial PC will start when the equipment is switched on, or when it is connected to the power supply. |
|------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|

| | |
|---------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Shutting down and switching off | When the plant is switched off, or when it is disconnected from its power supply, the Industrial PC will be switched off. Control software such as is typically used on Industrial PCs permits various users to be given different rights. A user who may not close software may also not switch the Industrial PC off, since data can be lost from the hard disk by switching off while software is running |
|  Warning! | First shut down, then switch off the PC! If the Industrial PC is switched off as the software is writing a file to the hard disk, the file will be destroyed. Control software typically writes something to the hard disk every few seconds, so the probability of causing damage by switching off the PC while the software is running is very high! |
|  Warning! | When you have shut down the Industrial PC, you have to switch off power supply for at least 10 seconds before rebooting the system. After resetting power supply, the PC will start booting automatically. |

To properly shut down the PC, contact a Level 2 or higher Operator.

Restart Computer

This button will activate the process of restarting the PC on which the Aagard HMI is located. Pressing this button will stop instantly any operations the machine is doing.

ADCOMS

When ADCOMS is enabled, this button will give access to the ADCOMS pages. Full ADCOMS Documentation is available by pressing the Help button on the ADCOMS Main page.

HMI Setup

This button gives access to the Main Page tab which allows the user to choose to view the Production Data in Classic style or as an HTML page. **Level 3 access required.**

Glue Group

****Changes made on these pages will only affect the current downloaded product****

- These buttons will open the corresponding [glue pages](#).

Data Group

****Data on these pages is for information only, and should not need to be changed on these pages****

- **View Notices System Wide Button** - This button will open the [View Notices System Wide Page](#).
- **View Change Log Button** - This button will open the [Change Log Page](#).
- **Misc Tags Button** - This button will open the [Misc Tags Page](#).
- **View Changeover Adjustments Button** - This button will open the [View Changeover Adjustments Page](#).
- **Marquee Button** - This button will open the [Marquee Page](#), if installed.
- **GMI Tags Button** - This button will open the [Tags Page](#), if installed.


Diagnostics Group

****Data on these pages is for information only****

- **Servo Drive Diagnostics Button** - This button will open the [Drive Diagnostics Page](#).
- **Member Map Diagnostics Button** - This button will open the [Member Map Diagnostics Page](#).
- **I/O Diagnostics Button** - This button will open the [I/O Diagnostics Page](#).
- **Sercos Diagnostics Button** - This button will open the [Sercos Diagnostics Page](#).

Help Group

Buttons in this group will launch Help programs

- **Servo Drive Help** - This button will launch the Servo Drive Help program.
- **Beckhoff Information System** - This button will launch the Beckhoff Information System program.
- **Aagard Logo** - This button will open the Aagard Machine Operator Manual from the HMI.
 - The user may be prompted to install a documentation update
-  **Button** - When installed, this button will open the Aagard Troubleshooting Guide.
 - The user may be prompted to install a documentation update

Test Carton Qty Field

The machine will pick this number of test cartons when the Start Button is pressed during machine operation, or when the start button is held longer than three seconds when starting the machine.

Test Carton

To pick and form one empty carton, and reject it from the cartoner, press the Test Carton Button while the machine is running

Remove Aagard Available For Product

This will remove the signal sent out from the Aagard telling upstream equipment that it is available for product. Selecting this will stop upstream equipment from sending product to the Aagard system.

Ignore Downstream Available

This ignores the "Downstream Available for Product" signal coming from downstream equipment. Selecting this will allow the machine to run and produce product even when downstream equipment isn't available to take product.

Set Up Users Button

This button will open the [Setup Users Page](#). This button is only visible when logged in as Administrator Level.

Back Button

This button will close this page and go to the HMI Main Screen.

Glue Page


General Page Information

If this feature is installed, this page allows the user to easily adjust the available glue pattern. This page shows the product as it moves through the glue heads looking at it from the operator (HMI) side of the machine (*The direction of the blue arrow indicates the direction of product flow*).

Stitch Adjust Information

To display the stitch adjustment popup in the bottom center of the screen, click on any red glue stitch that needs to be adjusted. This popup will display all the adjustment information for the selected stitch.

SAMPLE IMAGE



- **On**

This is the on point of the selected stitch. **NOTE:** The ON value must be less than the OFF value!

- **Off**

This is the off point of the selected stitch. **NOTE:** The OFF value must be greater than the ON value!

- **Left Arrow**

This arrow will move the selected stitch point to the left relative to the product shown in the picture.

- **Right Arrow**

This arrow will move the selected stitch point to the right relative to the product shown in the picture.

- **Master Offset**

This will adjust the start of the cam relative to the designated servo axis. Usually the cam will relate to a position of a servo axis that is moving the product, such as flight chains.

- **Stitch Gap %**

This is the percent of glue stitch that is taken out of the center of the selected glue stitch.

NOTE: This setting applies to Case Packers only!

- **Use Gap Check Box**

This will allow the user to decide if there is to be a gap stitch applied or a full stitch applied.

NOTE: This setting applies to Case Packers only, when this feature is enabled!

Edit

This button will open the page in edit mode. **Aagard user level required!**

Back

This button will display the [Advanced Page](#).

View Notices System Wide

General Page Information

This page keeps a record of all notices generated. This may help with diagnosing any major problems or possible problems. These notices will be stored in the database for three days, and then will be deleted.

SAMPLE IMAGE

Aagard HMI - Notice History
Notice History for Cartoner
 Move Column: Device [Left] [Right] C40 [Cartoner]

| Date Stamp | Device | Message | PLC Details | Notice Type | Shift | Down Time | Ack Time | Notes | Location | HMI Details |
|------------------------|-------------------|-----------------------------|--------------------|----------------|-------|-----------|----------|-------|----------|------------------|
| 11/5/2010 8:02:25 AM | IDV1 Carton ... | Bar Code Scanner Failure | Beckhoff Error ... | Fault | 1 | | | | Cartoner | |
| 1/5/2010 8:02:17 AM | IDV1 Carton ... | Bar Code Scanner Failure | Beckhoff Error ... | Fault | 1 | | | | Cartoner | |
| 12/18/2009 11:03:24 AM | SD5 Side Fil... | Motion Control Reset Error | Servo Drive E... | Fault | 1 | 00:05:53 | 00:00:07 | | Cartoner | Cleared in 7 s |
| 12/17/2009 10:54:09 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:01:21 | 00:00:01 | | Cartoner | Cleared in 1 s |
| 12/17/2009 10:49:24 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:04:07 | 00:00:02 | | Cartoner | Cleared in 2 s |
| 12/17/2009 10:35:31 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:01:13 | 00:00:02 | | Cartoner | Cleared in 2 s |
| 12/17/2009 10:25:25 AM | EN49101 Low... | Lower Film Unwind Danc... | Encoder Pos ... | Fault | 1 | 00:05:37 | 00:00:05 | | Cartoner | Cleared in 5 s |
| 12/17/2009 9:57:13 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:01:16 | 00:00:05 | | Cartoner | Cleared in 5 s |
| 12/17/2009 9:47:40 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:08:48 | 00:08:26 | | Cartoner | Cleared in 8 ... |
| 12/17/2009 9:42:22 AM | SD6 Side Fil... | Fast Stop Failed | MC_ChangeD... | Fault | 1 | 00:03:15 | 00:00:03 | | Cartoner | Cleared in 2 s |
| 12/16/2009 11:07:22 AM | IDV7 Carton ... | Checkweigher Failure | Check Check... | Fault | 1 | 00:00:13 | 00:00:07 | | Cartoner | Cleared in 7 s |
| 12/16/2009 10:43:57 AM | IDV4 Filler B ... | Metal Detected | Metal Detecte... | Critical Fault | 1 | | 00:00:32 | | Cartoner | Cleared in 31 s |
| 12/16/2009 10:43:54 AM | IDV3 Filler A ... | Metal Detected | Metal Detecte... | Critical Fault | 1 | 00:00:49 | 00:00:32 | | Cartoner | Cleared in 32 s |
| 12/16/2009 10:25:38 AM | IDV1 Carton ... | Bad Bar Code Scanned | Remove Carto... | Critical Fault | 1 | 00:02:24 | 00:01:15 | | Cartoner | Cleared in 1 ... |
| 12/16/2009 10:21:47 AM | PE48206 Cart... | Improper Carton Transfer... | Carton Did Not... | Fault | 1 | 00:03:19 | 00:00:18 | | Cartoner | Cleared in 17 s |
| 12/16/2009 9:22:37 AM | S32_4 Analo... | Function Block Failed | Channel 2 Fail... | Fault | 1 | | 00:28:34 | | Cartoner | Cleared in 28... |
| 12/16/2009 9:02:08 AM | S32_4 Analo... | Function Block Failed | Channel 1 Fail... | Fault | 1 | | 00:13:46 | | Cartoner | Cleared in 13... |
| 12/16/2009 8:57:11 AM | S32_4 Analo... | Function Block Failed | Channel 1 Fail... | Fault | 1 | 01:04:15 | 00:00:32 | | Cartoner | Cleared in 32 s |
| 12/16/2009 7:48:17 AM | IDV7 Carton ... | Checkweigher Failure | Check Check... | Fault | 1 | 00:00:35 | 00:00:15 | | Cartoner | Cleared in 15 s |
| 12/16/2009 7:45:01 AM | IDV7 Carton ... | Checkweigher Failure | Check Check... | Fault | 1 | 00:02:57 | 00:00:23 | | Cartoner | Cleared in 23 s |
| 12/16/2009 7:39:40 AM | IDV1 Carton ... | Bad Bar Code Scanned | Remove Carto... | Critical Fault | 1 | 00:00:52 | 00:00:39 | | Cartoner | Cleared in 39 s |
| 12/16/2009 7:37:31 AM | IDV1 Carton ... | Bad Bar Code Scanned | Remove Carto... | Critical Fault | 1 | 00:01:33 | 00:01:30 | | Cartoner | Cleared in 1 ... |
| 12/15/2009 6:44:58 PM | PE42306 Sec... | Blocked Too Long | Blocked For 1... | Fault | 2 | 00:05:46 | 00:05:36 | | Cartoner | Cleared in 5 ... |

C40 Filter

Click on the drop down arrow to view history for a particular C40. If a C40 is not listed, there are no messages to display.

Filter Buttons (Fault, Critical Fault, General, Warning, Reject, Debug, Utility, and Unhandled Not Shown)

These buttons represent different notice types. Press any button to filter those notices from the list. Pressing refresh will refresh the screen, displaying only those notice types selected.

- **Fault** – a message describing an unintended event which restricts the system's ability to produce
- **Critical Fault** – same as Fault, except the operator must acknowledge each Critical Fault individually
- **General** – an informational message which relays current existing conditions within the system
- **Warning** – a message describing an event which occurred, or an existing condition, which may cause a problem if not addressed
- **Reject** – a message describing why a product was rejected from the normal flow of product
- **Debug** – a message used during the debug stage of development to monitor for specific desired or undesired events
- **Utility** – a notice used to trigger a software utility
- **Unhandled Not Shown** – a message that is sent from the PLC but not defined in the Message data base
- **Production Data Not Shown** – a message used for production data collection

Individual Items


Click this button to display the items in the grid in chronological order.

NOTE: When **Individual Items** is selected, the button color will be blue

Totaled

Click this button to display the items in the grid in a totaled fashion, displaying the number of times an item occurred. The items all totaled to allow the user to more easily view which items are occurring the most frequently.


NOTE: When **Totaled** selected, the button color will be blue



| Device | Location | Message | Count |
|-----------------|----------|---------------------------------|-------|
| CS1AE Knife ... | Inserter | Cylinder Extend Switch Not M... | 1 |
| MS1 Custom... | Inserter | VFD Faulted | 2 |
| MS1 Custom... | Inserter | Invalid Program Call | 16 |
| PE6 Register... | Inserter | Sensor Failure | 8 |
| PE6 Register... | Inserter | Not Made During Startup | 1 |
| PE2 Web Br... | Inserter | Web Break PE Not Blocked ... | 1 |
| PE3 Loop Low | Inserter | Eye Not Blocked When Expe... | 10 |
| SD2 Knife | Inserter | Lag Error | 1 |
| SD1 Pinwheel | Inserter | Cam Load Failed | 1 |
| CTRL1 HMI | Inserter | Switching To Sercos Phase 2 ... | 1 |

Edit Notes Button

Select a message in the grid and the Edit Notes Button becomes available. Click on the Edit Notes button to open a dialog window to add your notes to the messages. Double-clicking on the message itself also opens this dialog. Click OK on the dialog when finished.



Delete All Button

This button will delete the entire fault log. This will make any generated reports invalid since the Report Generator uses this fault log to generate its reports.

Refresh

This button will refresh the faults on the screen to the most current log at the time the refresh button was pressed, reflected by any filters which may have been selected.

Back Button

This button will return the user to the calling page.

Filter Drop Down List

Click on the drop down arrow to view available filters to apply to the list. Select a filter from the list to apply it. Depending on the selection, additional parameters become available to enter, such as dates and hours.

| | | |
|-----------------|-----------|------------|
| From Date/Time: | 1/ 4/2010 | 5:59:00 AM |
| To Date/Time: | 1/ 4/2010 | 5:59:00 PM |

| | | | | |
|------------|---|-------|---|---------|
| Show Last: | 0 | Hours | 0 | Minutes |
|------------|---|-------|---|---------|

Column Options

To move a column from left to right, select a column from the dropdown list, and click Left or Right to move the column in either direction.

Device Column

This column displays the name of the device which generated the notice.

Message Column

This column displays the message which appeared on the notice. A list of possible messages, causes, and actions are given on the [Message Notices](#) section.

PLC Details Column

This column displays information received from the PLC when the notice was generated.

Shift Column

This column displays the shift in which the notice was recorded.

Down Time Column

This column displays time elapsed between notice display and when the system is started.

Ack Time Column

This column displays the length of time elapsed before the notice was acknowledged.

HMI Details Column

This column displays any additional information received from the HMI when the notice was generated.

Date Stamp Column

This column displays the date and time when the notice was generated.

Notes Column

This column displays any user entered information for the selected notice.

Notice Type

This column displays the type of notice recorded.

Location Column

This column displays the notice location or area of the machine.

Change Log Page

General Page Information

This page will display any changes that have been made to the Agard HMI database. This excludes any cam changes made, which are allowable and will not be displayed here. The drop down list filter in the bottom left corner of this page will allow a specific time period to be selected. The changes logged will be deleted after three months.

SAMPLE IMAGE

| Location | Field | Old Value | New Value | Product | Notes | Who | Change... | Changed Time |
|---------------|------------------------|-----------|-----------|------------|-------|---------|-----------|--------------|
| General D... | Gen#27 | 0 | 235 | 684 Carton | | Aaga... | 11/2/2009 | 11:03:40 AM |
| Solenoid ... | SV#45405 Configuration | 0 | 2 | 356 Carton | | aaga... | 8/26/2009 | 4:01:34 PM |
| Motor Dat... | MT#503 AnalogSpeed | 0 | 1 | 356 Carton | | aaga... | 8/26/2009 | 4:01:06 PM |
| Motor Dat... | MT#516 AnalogSpeed | 0 | 1 | 356 Carton | | aaga... | 8/26/2009 | 4:01:03 PM |
| Motor Dat... | MT#603 AnalogSpeed | 0 | 1 | 356 Carton | | aaga... | 8/26/2009 | 4:01:01 PM |
| Motor Dat... | MT#616 AnalogSpeed | 0 | 1 | 356 Carton | | aaga... | 8/26/2009 | 4:00:58 PM |
| Motor Dat... | MT#1703 AnalogSpeed | 0 | 1 | 356 Carton | | aaga... | 8/26/2009 | 4:00:55 PM |
| Motor Dat... | MT#10015 ATime | 1 | 0 | 356 Carton | | aaga... | 8/26/2009 | 4:00:46 PM |
| Motor Dat... | MT#10015 OffTime | 1 | 0 | 356 Carton | | aaga... | 8/26/2009 | 4:00:44 PM |
| Motor Dat... | MT#1703 OffTime | 0 | .2 | 356 Carton | | aaga... | 8/26/2009 | 4:00:35 PM |
| Motor Dat... | MT#1703 ATime | 0 | .2 | 356 Carton | | aaga... | 8/26/2009 | 4:00:32 PM |
| Motor Dat... | MT#616 OffTime | 1 | .5 | 356 Carton | | aaga... | 8/26/2009 | 4:00:28 PM |
| Motor Dat... | MT#616 ATime | 1 | .5 | 356 Carton | | aaga... | 8/26/2009 | 4:00:26 PM |
| Motor Dat... | MT#516 OffTime | 0 | .2 | 356 Carton | | aaga... | 8/26/2009 | 4:00:15 PM |
| Motor Dat... | MT#516 ATime | 0 | .2 | 356 Carton | | aaga... | 8/26/2009 | 4:00:13 PM |
| Servo Driv... | SD#45 Move#8 Decel | 0 | 20 | 356 Carton | | aaga... | 8/26/2009 | 3:59:49 PM |
| Servo Driv... | SD#45 Move#8 Accel | 0 | 20 | 356 Carton | | aaga... | 8/26/2009 | 3:59:47 PM |
| Servo Driv... | SD#45 Move#8 Velocity | 0 | 27 | 356 Carton | | aaga... | 8/26/2009 | 3:59:44 PM |
| Servo Driv... | SD#45 Move#8 Position | 0 | 15 | 356 Carton | | aaga... | 8/26/2009 | 3:59:41 PM |
| Servo Driv... | SD#45 Move#7 Decel | 0 | 65 | 356 Carton | | aaga... | 8/26/2009 | 3:59:33 PM |
| Servo Driv... | SD#45 Move#7 Accel | 0 | 65 | 356 Carton | | aaga... | 8/26/2009 | 3:59:31 PM |
| Servo Driv... | SD#45 Move#7 Velocity | 0 | 30 | 356 Carton | | aaga... | 8/26/2009 | 3:59:29 PM |
| Servo Driv... | SD#45 Move#7 Position | 0 | 15 | 356 Carton | | aaga... | 8/26/2009 | 3:59:26 PM |
| Servo Driv... | SD#45 Move#6 Decel | 0 | 30 | 356 Carton | | aaga... | 8/26/2009 | 3:59:19 PM |
| Servo Driv... | SD#45 Move#6 Accel | 0 | 30 | 356 Carton | | aaga... | 8/26/2009 | 3:59:15 PM |
| Servo Driv... | SD#45 Move#6 Velocity | 0 | 30 | 356 Carton | | aaga... | 8/26/2009 | 3:59:13 PM |
| Servo Driv... | SD#45 Move#6 Position | 0 | 30 | 356 Carton | | aaga... | 8/26/2009 | 3:59:11 PM |

Below the table, there is a dropdown menu set to "Show Latest 50". At the bottom right, there are three buttons: "Delete All", "Refresh", and "Back".

Delete All

This button will delete the entire contents of the change log. This will make any change log section of the generated reports invalid because the report generator uses this change log to generate its reports.

Refresh

This button will refresh the changes on the screen to the most current log at the time the refresh button was pressed.

Back Button

This button will display the [Advanced Page](#).

Filter Drop Down List

Click on the drop down arrow to view available filters to apply to the list. Select a filter from the list to apply it. Depending on the selection, additional parameters become available to enter, such as dates and hours.

| | | |
|-----------------|-----------|------------|
| From Date/Time: | 1/ 4/2010 | 5:59:00 AM |
| To Date/Time: | 1/ 4/2010 | 5:59:00 PM |

| | | | | |
|------------|---|-------|---|---------|
| Show Last: | 0 | Hours | 0 | Minutes |
|------------|---|-------|---|---------|

Location Column

This column will display on which page the change was made.

Field Column

This column will display the name of the field to which the change was made.

Old Value Column

This column will record what the value was before the change was made.

New Value Column

This column will record what the value is after the change was made.

Product Column

This column will display the product downloaded when the change was made.

Notes Column

This column will display any notes that were entered by the user into the notes popup after the change was made.

Who Column

This column will display the user that was logged on at the time of the change.

Changed Date Column

This column will display the date that the change was made.

Changed Time Column

This column will display the time that the change was made.

View Changeover Adjustments

General Page Information

This page will display the changeover adjustments for the particular product selected. This page is identical to the [Product Download Changeover Adjustments Page](#) with the exception that it is for display purposes only. A popup screen will not be displayed if a changeover adjustment was not completed when exiting this page. Please go to the [Product Download Changeover Adjustments Page](#) for further details.

SAMPLE IMAGE

| <u>Done</u> | <u>Machine</u> | <u>Adj. Name</u> | <u>Description</u> | <u>Value</u> |
|-------------|------------------------|------------------|--------------------|--------------|
| Yes | Sleever Case Packer | 1-1 | Example Adjustment | 10 |
| Yes | Sleever Case Packer | 1-2 | Example Adjustment | 2 |
| Yes | Sleever Case Packer | 1-3 | Example Adjustment | 30 |
| Yes | Sleever Case Packer | 1-4 | Example Adjustment | 40 |
| No | Sleever Case Packer | 1-5 | Example Adjustment | 50 |
| No | Sleever Case Packer | 1-6 | Example Adjustment | 60 |
| No | Sleever Case Packer | 1-7 | Example Adjustment | 70 |
| No | Sleever Case Packer | 1-8 | Example Adjustment | 80 |
| No | Sleever Case Packer | 1-9 | Example Adjustment | 90 |
| No | Sleever Case Packer | 1-10 | Example Adjustment | 100 |
| No | Sleever Case Packer | 1-11A | Example Adjustment | 110 |
| No | Sleever Case Packer | 1-11B | Example Adjustment | 120 |
| No | Sleever Case Packer | 1-11C | Example Adjustment | 130 |
| No | Sleever Case Packer | 1-11D | Example Adjustment | 140 |
| No | Sleever Case Packer | 1-11E | Example Adjustment | 150 |
| No | Sleever Case Packer | 1-11F | Example Adjustment | 160 |
| No | Sleever Case Packer | 1-12A | Example Adjustment | 170 |
| No | Sleever Case Packer | 1-12B | Example Adjustment | 180 |

Print Finish

Device List

NOTE:

"CP" preceding a grid location indicates the device is in the Case Packer

"O" preceding a grid location indicates the device is in the Orienter

Device listings with no Brick Slice Point or I/O Type indicated are intentional.

By default, the table below is sorted alphabetically by device type. Click on a column heading to sort by that column.

| Type | Name | Location | Description | Aagard PN | Brick Slice Point | I/O Type | Grid |
|------------------|---------|--------------------|----------------------------------------------|-----------|-------------------|---------------|--------|
| Cylinder Sw itch | CS31606 | Case Packer Infeed | Product Conditioner | Z0123202 | B1 S14 P6 | Input-Digital | CP_D15 |
| Cylinder Sw itch | CS31901 | Case Packer | Case Packer Case Stop | Z0123236 | B1 S17 P1 | Input-Digital | CP_I19 |
| Cylinder Sw itch | CS31902 | Case Packer | Case Pusher | Z0123236 | B1 S17 P2 | Input-Digital | CP_I17 |
| Cylinder Sw itch | CS51507 | Orienter | Tipper Case Stop | Z0123236 | B5 S11 P7 | Input-Digital | O_F4 |
| Cylinder Sw itch | CS31607 | Case Packer Infeed | Product Conditioner | Z0123202 | B1 S14 P7 | Input-Digital | CP_D15 |
| Disconnect | DS501 | Main Cabinet | Main Disconnect | Z0007466 | | | CP_C4 |
| Disconnect | DS9402 | Case Packer | Glue Disconnect | Z0031001 | | | O_H14 |
| Emergency Stop | ES24301 | HMI Cabinet | System Emergency Stop | Z0004654 | B1 S11 P8 | Input-Digital | CP_N12 |
| Emergency Stop | ES24303 | Case Packer Infeed | Case Packer Non Operator Side Emergency Stop | Z0004654 | B1 S12 P5 | Input-Digital | CP_C6 |
| Emergency Stop | ES24304 | Case Packer | Case Packer Operator Side Emergency Stop | Z0004654 | B1 S12 P3 | Input-Digital | CP_L16 |
| Emergency Stop | ES26303 | Orienter Cabinet | Orienter Non Operator Side Emergency Stop | Z0004654 | B5 S7 P8 | Input-Digital | O_A13 |
| Emergency Stop | ES26304 | Orienter | Orienter Operator Side Emergency Stop | Z0004654 | B5 S7 P6 | Input-Digital | O_H12 |
| Filter Regulator | FR60201 | Case Packer | Filter Regulator | Z0067505 | | | CP_G5 |
| Guard Sw itch | GS24501 | Case Packer | Guard Door 2-1 | Z0121797 | B1 S13 P1 | Input-Digital | CP_G4 |
| Guard Sw itch | GS24502 | Case Packer | Guard Door 2-2 | Z0121797 | B1 S13 P2 | Input-Digital | CP_G8 |
| Guard Sw itch | GS24503 | Case Packer | Guard Door 2-3 | Z0121797 | B1 S13 P3 | Input-Digital | CP_L16 |
| Guard Sw itch | GS24504 | Case Packer | Guard Door 2-4 | Z0121797 | B1 S13 P4 | Input-Digital | CP_L17 |
| Guard Sw itch | GS24505 | Case Packer | Guard Door 2-5 | Z0121797 | B1 S13 P5 | Input-Digital | CP_C16 |

| Type | Name | Location | Description | Aagard PN | Brick Slice Point | I/O Type | Grid |
|---------------|---------|---------------------|------------------------------------------|-----------|-------------------|---------------|--------|
| Guard Sw itch | GS24508 | Case Packer | Guard Door 2-6 | Z0121797 | B1 S13 P6 | Input-Digital | CP_C13 |
| Guard Sw itch | GS24509 | Case Packer | Guard Door 2-7 | Z0121797 | B1 S13 P7 | Input-Digital | CP_C10 |
| Guard Sw itch | GS26501 | Orienter | Guard Door 3-1 | Z0121797 | B5 S8 P1 | Input-Digital | O_I6 |
| Servo Pow er | HCS01 | Case Packer Cabinet | Case Packer Servo Pow er Converter | Z0103625 | B1 S11 P3 | Input-Digital | CP_C6 |
| Servo Pow er | HCS01 | Case Packer Cabinet | Case Packer Servo Pow er Converter | Z0103625 | B1 S2 P4 | Output-Live | CP_C6 |
| Servo Pow er | HCS02 | Orienter Cabinet | Servo Pow er Converter | Z0103625 | B5 S1 P4 | Output-Live | O_B14 |
| Servo Pow er | HCS02 | Orienter Cabinet | Servo Pow er Converter | Z0103625 | B5 S7 P4 | Input-Digital | O_B14 |
| Motor | MT807 | Orienter | Case Conveyor | 795042 | | | O_C12 |
| Motor | MT1303 | Case Packer Infeed | Infeed Conveyor | Z0023823 | | | CP_F7 |
| Motor | MT1403 | Case Packer Infeed | Non Operator Side Side Belts | Z0023823 | | | CP_D10 |
| Motor | MT1406 | Case Packer Infeed | Operator Side Side Belts | Z0023823 | | | CP_F10 |
| Motor | MT1502 | Orienter | Tip/Reject Conveyor | 795041 | | | O_B4 |
| Push Button | PB19904 | HMI Cabinet | PC Reset | Z0129818 | | | CP_N12 |
| Push Button | PB30101 | HMI Cabinet | System Start | Z0005435 | B1 S11 P6 | Input-Digital | CP_N12 |
| Push Button | PB30101 | HMI Cabinet | System Start | Z0005435 | B1 S1 P1 | Output-Live | CP_N12 |
| Push Button | PB30205 | Case Packer Cabinet | Case Packer System Start | Z0005435 | B1 S12 P1 | Input-Digital | CP_C6 |
| Push Button | PB30205 | Case Packer Cabinet | Case Packer System Start | Z0005435 | B1 S2 P5 | Output-Live | CP_C6 |
| Push Button | PB31307 | HMI Cabinet | System Cycle Stop | Z0004653 | B1 S11 P7 | Input-Digital | CP_N12 |
| Push Button | PB31402 | Case Packer | Case Packer Non Operator Side Cycle Stop | Z0004653 | B1 S12 P2 | Input-Digital | CP_C6 |
| Push Button | PB31404 | Case Packer Infeed | Case Packer Operator Side Cycle Stop | Z0004653 | B1 S12 P4 | Input-Digital | CP_L16 |
| Push Button | PB51105 | Orienter | Orienter Operator Side Cycle Stop | Z0004653 | B5 S7 P5 | Input-Digital | O_H12 |
| Push Button | PB51107 | Orienter Cabinet | Orienter Non Operator Side Cycle Stop | Z0004653 | B5 S7 P7 | Input-Digital | O_A13 |
| Photo Eye | PE31002 | Case Packer Infeed | Non Op Side Lower Dow nstacker Reference | Z0123440 | B1 S8 P2 | Input-Digital | CP_D13 |
| Photo Eye | PE31003 | Case Packer Infeed | Non Op Side Upper Dow nstacker | Z0123440 | B1 S8 P3 | Input-Digital | CP_D11 |

| Type | Name | Location | Description | Aagard PN | Brick Slice Point | I/O Type | Grid |
|-----------------|---------|----------------------|-------------------------------------------|-----------|-------------------|---------------|--------|
| | | | Reference | | | | |
| Photo Eye | PE31004 | Case Packer Infeed | Operator Side Lower Downstacker Reference | Z0123440 | B1 S8 P4 | Input-Digital | CP_G13 |
| Photo Eye | PE31005 | Case Packer Infeed | Operator Side Upper Downstacker Reference | Z0123440 | B1 S8 P5 | Input-Digital | CP_G11 |
| Photo Eye | PE31104 | Case Packer Infeed | Case Packer Flights | Z0123440 | B1 S9 P4 | Input-Digital | CP_H13 |
| Photo Eye | PE31702 | Case Packer Infeed | Product in Side Belts | Z0123440 | B1 S15 P2 | Input-Digital | CP_G10 |
| Photo Eye | PE31703 | Case Packer Infeed | 2nd Carton At Downstacker | Z0097847 | B1 S15 P3 | Input-Digital | CP_D11 |
| Photo Eye | PE31704 | Case Packer Infeed | 1st Carton At Downstacker | Z0096984 | B1 S15 P4 | Input-Digital | CP_E12 |
| Photo Eye | PE31707 | Case Packer Infeed | Product At Downstack Pusher | Z0123440 | B1 S15 P7 | Input-Digital | CP_D12 |
| Photo Eye | PE31803 | Case Packer Magazine | Case Blanks Present | Z0096984 | B1 S16 P3 | Input-Digital | CP_H11 |
| Photo Eye | PE31903 | Case Packer | Case Present at Load | Z0123715 | B1 S17 P3 | Input-Digital | CP_H15 |
| Photo Eye | PE31904 | Case Packer | Distorted Case | Z0123440 | B1 S17 P4 | Input-Digital | CP_H16 |
| Photo Eye | PE31905 | Case Packer Infeed | Product At Loader | Z0123440 | B1 S15 P1 | Input-Digital | CP_F15 |
| Photo Eye | PE51401 | Orienter | Operator Side Open Case Flap | Z0123440 | B5 S10 P1 | Input-Digital | CP_I19 |
| Photo Eye | PE51402 | Orienter | Non Operator Side Open Case Flap | Z0123440 | B5 S10 P2 | Input-Digital | CP_H19 |
| Photo Eye | PE51503 | Orienter | Case At Tip | Z0123440 | B5 S11 P3 | Input-Digital | O_D1 |
| Photo Eye | PE51504 | Orienter | Lower Case Reject Chute | Z0123440 | B5 S11 P4 | Input-Digital | O_J5 |
| Photo Eye | PE51505 | Orienter | Case At Rotate | Z0123440 | B5 S11 P5 | Input-Digital | O_D8 |
| Photo Eye | PE51506 | Orienter | Case Present After Rotate | Z0123440 | B5 S11 P6 | Input-Digital | O_D10 |
| Photo Eye | PE51508 | Orienter | Upper Case Reject Chute | Z0123440 | B5 S11 P8 | Input-Digital | O_J5 |
| Pressure Switch | PS31201 | Case Packer | System Air Pressure | Z0064191 | B1 S10 P1 | Input-Digital | CP_G5 |
| Prox | PX31001 | Case Packer Infeed | Spatula Reference | Z0098920 | B1 S8 P1 | Input-Digital | CP_F9 |
| Prox | PX31006 | Case Packer Infeed | Downstack Pusher Reference | Z0098920 | B1 S8 P6 | Input-Digital | CP_E4 |
| Prox | PX31007 | Case Packer | Loader Probe | Z0098920 | B1 S8 P7 | Input-Digital | CP_B15 |
| Prox | PX31102 | Case Packer | Case Packer Robot X | Z0098920 | B1 S9 P2 | Input-Digital | CP_G14 |

| Type | Name | Location | Description | Aagard PN | Brick Slice Point | I/O Type | Grid |
|-------------|----------|----------------------|----------------------------------|-----------|-------------------|---------------|--------|
| Prox | PX31103 | Case Packer | Z Axis Probe | Z0098920 | B1 S9 P3 | Input-Digital | CP_I16 |
| Prox | PX31908 | Case Packer | Load Gate Closed | Z0098920 | B1 S17 P8 | Input-Digital | CP_D16 |
| Prox | PX31804 | Case Packer Magazine | Case Magazine Advance | Z0098920 | B1 S16 P4 | Input-Digital | CP_H13 |
| Prox | PX51001 | Orienter | Case Tip Y Reference | Z0098920 | B5 S6 P1 | Input-Digital | O_C4 |
| Prox | PX51002 | Orienter | Case Tipper Reference | Z0098920 | B2 S5 P2 | Input-Digital | O_G3 |
| Regulator | Reg30401 | Case Packer Magazine | Magazine Advance | Z0016121 | | | CP_G12 |
| Regulator | Reg30805 | Case Packer | Lower Fixed Glue Regulator | Z0016121 | | | CP_F17 |
| Regulator | Reg30806 | Case Packer | Lower Adjustable Glue Regulator | Z0016121 | | | CP_J16 |
| Regulator | Reg30807 | Case Packer | Upper Fixed Glue Regulator | Z0016121 | | | CP_H16 |
| Regulator | Reg30808 | Case Packer | Upper Adjustable Glue Regulator | Z0016121 | | | CP_K17 |
| Servo Motor | SM01 | Case Packer Infeed | Transfer Spatula | Z0103609 | | | CP_F9 |
| Servo Motor | SM02 | Case Packer Infeed | Non Op Side Lower Dow nstacker | Z0103609 | | | CP_D9 |
| Servo Motor | SM03 | Case Packer Infeed | Non Op Side Upper Dow nstacker | Z0103609 | | | CP_D14 |
| Servo Motor | SM04 | Case Packer Infeed | Operator Side Lower Dow nstacker | Z0103609 | | | CP_F9 |
| Servo Motor | SM05 | Case Packer Infeed | Operator Side Upper Dow nstacker | Z0103609 | | | CP_F14 |
| Servo Motor | SM06 | Case Packer Infeed | Dow n Stack Pusher | Z0103609 | | | CP_E3 |
| Servo Motor | SM07 | Case Packer Infeed | Loader | Z0103609 | | | CP_A15 |
| Servo Motor | SM08 | Case Packer Infeed | Funnel | Z0103607 | | | CP_F15 |
| Servo Motor | SM09 | Case Packer Infeed | Fun Tucker | Z0103607 | | | CP_F16 |
| Servo Motor | SM10 | Case Packer | Tucker | Z0103607 | | | CP_K15 |
| Servo Motor | SM11 | Case Packer | Product Stop | Z0103607 | | | CP_J15 |
| Servo Motor | SM12 | Case Packer | Case Packer Robot X Axis | Z0103609 | | | CP_H18 |
| Servo Motor | SM13 | Case Packer | Case Packer Robot Z Axis | Z0103610 | | | CP_I17 |
| Servo Motor | SM14 | Case Packer | Case Packer | Z0103607 | | | CP_G18 |

| Type | Name | Location | Description | Aagard PN | Brick Slice Point | I/O Type | Grid |
|----------------|---------|----------------------|--------------------------------------|-----------|-------------------|---------------|--------|
| | | | Flights | | | | |
| Servo Motor | SM15 | Case Packer | Low er Compression Non Operator Side | Z0103607 | | | CP_G17 |
| Servo Motor | SM16 | Case Packer | Low er Compression Operator Side | Z0103607 | | | CP_J17 |
| Servo Motor | SM17 | Case Packer | Upper Compression Non Operator Side | Z0103607 | | | CP_G18 |
| Servo Motor | SM18 | Case Packer | Upper Compression Operator Side | Z0103607 | | | CP_J17 |
| Servo Motor | SM19 | Orienter | Case Tip Y | Z0103607 | | | O_D6 |
| Servo Motor | SM20 | Orienter | Case Tipper | Z0103610 | | | O_E4 |
| Servo Motor | SM21 | Orienter | Case Rotate | Z0103607 | | | O_D8 |
| Solenoid Valve | SV24223 | Case Packer | Manual Dump Valve | Z0067506 | | | CP_G5 |
| Solenoid Valve | SV24223 | Case Packer | System Air Dump | Z0036804 | | | CP_G5 |
| Solenoid Valve | SV30306 | Case Packer Magazine | Magazine Rotate Clips | Z0023954 | B1 S3 P6 | Output-Live | CP_G11 |
| Solenoid Valve | SV30307 | Case Packer | Load Cups Blow back | Z0023954 | B1 S3 P7 | Output-Live | CP_G18 |
| Solenoid Valve | SV30308 | Case Packer | Load Vacuum | Z0014917 | B1 S3 P8 | Output-Live | CP_H13 |
| Solenoid Valve | SV30401 | Case Packer Magazine | Magazine Advance | Z0023954 | B1 S4 P1 | Output-Live | CP_G11 |
| Solenoid Valve | SV30402 | Case Packer | Case Packer Case Stop | Z0024215 | B1 S4 P2 | Output-Live | CP_G18 |
| Solenoid Valve | SV30403 | Case Packer | Case Pusher | Z0024215 | B1 S4 P3 | Output-Live | CP_I15 |
| Solenoid Valve | SV30406 | Case Packer Infeed | Fun Tucker | Z0023954 | B1 S4 P6 | Output-Live | CP_G18 |
| Solenoid Valve | SV30407 | Case Packer Infeed | Funnel In/Out | Z0023954 | B1 S4 P7 | Output-Live | CP_G18 |
| Solenoid Valve | SV30408 | Case Packer | Case Packer Robot Vacuum | Z0014917 | B1 S4 P8 | Output-Live | CP_I6 |
| Solenoid Valve | SV30703 | Case Packer Infeed | Product Conditioner | Z0029339 | B1 S6 P3 | Output-E-Stop | CP_D15 |
| Solenoid Valve | SV30703 | Case Packer Infeed | Product Conditioner | Z0029339 | B1 S6 P4 | Output-E-Stop | CP_D15 |
| Solenoid Valve | SV30705 | Case Packer Magazine | Magazine Top Clip | Z0029339 | B1 S6 P5 | Output-E-Stop | CP_G11 |
| Solenoid Valve | SV30705 | Case Packer Magazine | Magazine Top Clip | Z0029339 | B1 S6 P6 | Output-E-Stop | CP_G11 |
| Solenoid Valve | SV30707 | Case Packer Magazine | Magazine Bottom Clip | Z0029339 | B1 S6 P8 | Output-E-Stop | CP_G11 |
| Solenoid Valve | SV30707 | Case Packer Magazine | Magazine Bottom Clip | Z0029339 | B1 S6 P7 | Output-E-Stop | CP_G11 |

| Type | Name | Location | Description | Aagard PN | Brick Slice Point | I/O Type | Grid |
|----------------|---------|-------------|-------------------------------|-----------|-------------------|---------------|--------|
| Solenoid Valve | SV30801 | Case Packer | Load Cups Lift | Z0029339 | B1 S7 P2 | Output-E-Stop | CP_G18 |
| Solenoid Valve | SV30801 | Case Packer | Load Cups Lift | Z0029339 | B1 S7 P1 | Output-E-Stop | CP_G18 |
| Solenoid Valve | SV30805 | Case Packer | Low er Glue Non Operator Side | Z0004483 | B1 S7 P5 | Output-E-Stop | CP_H16 |
| Solenoid Valve | SV30806 | Case Packer | Low er Glue Operator Side | Z0004483 | B1 S7 P6 | Output-E-Stop | CP_J16 |
| Solenoid Valve | SV30807 | Case Packer | Upper Glue Non Operator Side | Z0004483 | B1 S7 P7 | Output-E-Stop | CP_H16 |
| Solenoid Valve | SV30808 | Case Packer | Upper Glue Operator Side | Z0004483 | B1 S7 P8 | Output-E-Stop | CP_J16 |
| Solenoid Valve | SV50201 | Orienter | Case Rotate Vacuum | Z0014917 | B5 S2 P1 | Output-Live | O_C8 |
| Solenoid Valve | SV50703 | Orienter | Tipper Case Stop | Z0024214 | B5 S4 P4 | Output-E-Stop | O_C7 |
| Solenoid Valve | SV50703 | Orienter | Tipper Case Stop | Z0024214 | B5 S4 P3 | Output-E-Stop | O_C7 |
| Vacuum Sw itch | VS31202 | Case Packer | System Vacuum | Z0089514 | B1 S10 P2 | Input-Digital | O_A4 |
| Vacuum Sw itch | VS31708 | Case Packer | Load Vacuum | Z0089514 | B1 S15 P8 | Input-Digital | CP_G13 |
| Vacuum Sw itch | VS31806 | Case Packer | Case Packer Robot Vacuum | Z0089514 | B1 S16 P6 | Input-Digital | CP_I16 |
| Vacuum Sw itch | VS51305 | Orienter | Case Rotate Vacuum Present | Z0089514 | B5 S9 P5 | Input-Digital | O_D8 |
| Transformer | XF10002 | Case Packer | 480 VAC - 120 VAC | 794578 | | | CP_D3 |

I/O Diagnostics Page


General Page Information

This page is only for status information. It shows the user whether or not an I/O point is energized on an I/O Brick and Slice. If an I/O point is energized the status dot will be red. This page will display all the I/O points on the machine. Through I/O points, the controller communicates to the devices on the machine or anything in the physical world. This is mainly a troubleshooting feature.

Hover over a point with the mouse and a tool tip will display brick, slice, and point.

Click on the + (plus symbol) to expand a node, or click on the - (minus symbol) to minimize a node.

SAMPLE IMAGE



Search

Type text into the box and click search. If what you are searching for is found, the first instance of the searched-for text is highlighted in the tree. If it is not found, the search box will turn red. Clicking search repeatedly acts as "Next".

Collapse Tree

Clicking this button collapses all nodes in the tree.

Add

Click to add an IO node.

Delete

Click to delete the selected IO node.

Back Button

This button will display the [Advanced Page](#).

Jog Page

SAMPLE IMAGE


Aagard HMI - Jog Page
 Joq Page for Cartoner
 Servo: Actual Position: 0.000
24 - Metering Conveyor
 Jog Fwd Jog Rev Jog Velocity = 10
 To Go Target Position: 0 Go To Position
 Tuning: Velocity Prop. Gain (Kp): 0 0, Velocity Integral Action Time (TN): 0 0, Position Prop. Gain (Kv): 0 0, Rejection Frequency: 0 0, Rejection Bandwidth: 0 0. Default, Apply Tuning Settings, Set To Default.
 Alternating Jog: Position 1: 0, Position 2: 0, Alt Dwell: 0, Velocity: 0, Accel: 0, Torque: 0, Pos Err Limit: 0. Start Alternating, Stop Alternating, Diagnose, Disable Servo Drive.
 Solenoid Valve: **2 - Reflector Blow Off**
 Left Right, A Coil, B Coil.
 Motor: **5 - Overhead Adjustment**
 Left Center Right, Speed: 2 FPM.
 24 Drive Status: Act Pos: 0.000, Max Pos. Err: 0.000, Max Torq: 0.000. Disabled, Stopped EStop, Manual SD Enabling, SD Data Input, SV Data Input, MT Data Input, Drive Diagnostics, Member Map Diag., I/O Diagnostics, Back.

From here, the machine user is able to manually jog the prime movers that power the actions of this machine. This screen also contains the status of the selected servo drive, including Actual Position, Max Position Error, Max Torque and State – Enabled, Disabled, or Faulted. All Jogging functions are made in a manual mode, which means that no automatic functions govern their movements.

Servo Axis Jogging

To manually move a component that is driven by a servo motor, the user must define which servo axis they want to jog and select it from the servo axis drop down list. Once the machine is started and in the ready state and manual mode, the user may jog the servo axis in the desired direction. The State and Mode is displayed in the bottom left hand corner next to the Drive Status Display. Other servo jogging features include velocity, Go To Position (which sends the axis to that position), and an alternating jog function. Unlike non servo controlled motors and solenoid valves, a servo axis will only travel while the button is depressed. Once the button is released the axis will stop.

Warning: Jogging should be done very carefully and at a low velocity. This will eliminate damage to any obstructed machine parts. Use the jog velocity sliding bar to adjust velocity.

SAMPLE IMAGE**Servo Drive**

To access different servo drives, use the servo drive drop down list.

Actual Position

This display will show the actual position of the Servo.

Jog Button

This button will jog the Servo Axis in the direction the button states.

Left Arrow

This button will adjust the Velocity Adjustor Bar to the left.

Jog Velocity

This bar can be dragged or moved via the Arrow buttons on the right or left of the bar to select the velocity of the Servo Axis selected in the servo drive drop down menu.

Right Arrow

This button will adjust the Velocity Adjustor Bar to the right.

Go To Target Position

This entry field will allow a position to be specified and, when the Go To Position button is pressed, the Servo Axis will move in the shortest direction to get to the specified position.

Go To Position

This button moves the Servo Axis to the position specified in the Go To Target Position entry field via the shortest way possible.

Tuning Box

The information contained in the Servo Drive Tuning Box is explained in further detail in the Servo Drive Tuning section.

Alternating Jog Box

The information contained in the Servo Drive Alternating Jog Box is explained in further detail in the Alternating Jog section.

Diagnose

This button will display a diagnostic popup for the currently selected Servo Drive. This diagnostic popup is described in further detail on the [Drive Diagnostics Page](#).

Enable/Disable Servo Drive Button

Click this button to enable or disable this servo drive. If the drive is currently enabled, the button color will be green and the text will read Disable Servo Drive. If the drive is currently disabled, the button color will be red and the text will read Enable Servo Drive.


NOTE: This feature is only available with the correct PLC framework version in place

NOTE: This button will only be enabled when Manual Enabling is activated

Solenoid Valve Jogging

To manually move a component that is driven by a Solenoid Valve, the user must find which solenoid valve controls the component and select it from the solenoid valve drop down list. Once the machine is started and in the ready state and manual mode, the user may jog the solenoid valve in the desired direction. The State and Mode is displayed in the bottom left hand corner next to the Drive Status Display. Once a solenoid valve jog button is depressed, the valve will move in that direction until another direction button or a stop button is depressed.

SAMPLE IMAGE



Solenoid Valve

To access different solenoid valves, use the solenoid valve drop down list.

Left Jog Button

This button will jog the Solenoid Valve in the direction the button states. This button will energize the A Coil.

Center Jog Button

This button will jog the Solenoid Valve in the direction the button states. This button will d-energize the A and B Coils.


Right Jog Button

This button will jog the Solenoid Valve in the direction the button states. This button will energize the B Coil. Not all Solenoid Valves have this button.

Motor Jogging

To manually move a component that is driven by a non servo motor, the user must define which motor they want to jog and select it from the motor drop down list. Once the machine is started and in the ready state and manual mode, the user may jog the motor in the desired direction. The State and Mode is displayed in the bottom left hand corner next to the Drive Status Display. Once a motor jog button is depressed, the motor will continue to run in that direction until the "Stop" button is depressed or the machine is externally stopped (Cycle Stop or Emergency Stop).

SAMPLE IMAGE



Motor

To access different motors, use the motor drop down list.

Left Jog

This button will jog the Motor in the direction that the button states.

Center Jog

This button will shut off the Motor.

Right Jog

This button will jog the Motor in the direction the button states. Not all Motors have this button.

Speed

This entry field will set the speed at which the Motor will be jogged. Not all Motors have this entry field.

Drive Status Box

This box is located in the bottom left corner of this page. Information that is given is Actual Position, Max Position Error, Max Torque, and State of the Servo Drive. More information can be found on the [Drive Diagnostics Page](#).

Servo Drive Diagnostics Button

This button will display the [Drive Diagnostics Page](#).

Member Map Diag. Button

This button will display the [Member Map Diagnostics Page](#).

I/O Diagnostics Button

This button will display the [I/O Diagnostics Page](#).

Manual SD Enabling Button

This button will display the [Manual SD Enabling Page](#).

NOTE: This feature is only available with the correct PLC framework version in place

Back Button

This button will close this page and go to the HMI Main Screen.

Reference Page

General Page Information


Referencing is the process of setting a Servo Axis position in reference to a stationary object such as a sensor or a hard stop (travel limit). Any time the mechanical link between the servo motor and the object that the servo motor is moving has been violated (disconnected, jumped teeth), the servo motor will need to be referenced. If a servo motor is not working correctly, it may need to be replaced (please see the **Replacing an MI Drive** topic in the Troubleshooting Guide for more information).

The referencing process begins by moving the servo axis towards the stationary object used for determining the servo axis position. When the object is located, the servo motor will then move to the reference end position based on the capture position of the stationary object. When the servo axis reaches the reference end position, the motor will disable and the servo axis' position will be set. Once the position has been set, the servo axis will enable and reposition itself to the reference end position completing the reference process.

Settings for referencing each servo axis can be found on the [Servo Drive Data Page](#).

A summary of all servos and their reference positions can be viewed in the [Servo Reference Positions](#) topic in this manual.

SAMPLE IMAGE



Servo Drive

To access different servo drives, use the servo drive drop down list.

Do Reference Routine

This button will initiate the reference routine for the selected Servo Axis or Group of Servo Axis. The display in the bottom left hand corner of the page must display Ready and Manual in order to initiate the reference routine. If the start button is pressed until the top display changes to Starting, the machine will then get to Ready and the reference routine will be able to be initiated. Once the reference routine is finished, a window will popup which contains a picture of the servo correctly referenced. **NOTE:** If multiple servos are referenced in one routine, the window will popup after the complete routine is finished and it will contain tabs for each picture.

View Image Button

This button will open a window that displays the servo in the referenced position. This image is also displayed following the completion of a reference routine. To close window, click on the red X in right corner, click outside the popup, or press Esc.

NOTE: This button will not be visible if no image has been associated with the selected servo drive.

**Actual Position**

This display will show the actual position of the Servo.

Home Position

This display shows the position of the selected Servo's sensor or hard stop.

Home End Position

This display shows the actual position when the reference routine of the selected Servo is complete.

Reference Mark Position

The Reference Mark Position is the position the servo reads when lined up with the reference mark.

Reference Mark Location

The Reference Mark Location is a precise description of the reference mark placement in relation to a fixed member of the machine.

Direction of Positive Movement

The Direction of Positive Movement is the direction of movement which causes a positive change in the position read out.

Reference Done

This display will show "Reference Done" when the reference routine has completed successfully.

Reference Pos. Difference

This display will show the difference between the old reference position and the new reference position.

SD Data Input Button

This button will display the [Servo Drive Data Page](#).

SV Data Input Button

This button will display the [Solenoid Data Page](#).

MT Data Input Button

This button will display the [Motor Data Page](#).

Diagnose Button

This button will display a diagnostic popup for the currently selected Servo Drive. This diagnostic popup is described in further detail on the [Drive Diagnostics Page](#).

Servo Drive Diagnostics Button

This button will display the [Drive Diagnostics Page](#).

Member Map Diag. Button

This button will display the [Member Map Diagnostics Page](#).

I/O Diagnostics Button

This button will display the [I/O Diagnostics Page](#).

Back Button


This button will close this page and go to the HMI Main Screen.

Servo Reference Positions


This section of the Aagard Machine Manual provides a pictorial and written description of each servo reference point on the machine. For each section of the machine, a table lists the servo number, name and values for each servo. Each servo drive is shown pictured in its referenced position with a visible mark or reference indicator for a quick visual check. When the servo drive has been referenced, this mark/indicator should give the operator a quick visual confirmation that the drive has been referenced properly. This is not intended to replace the use of a tape measure, squares, or other means to check reference positions. It is intended to allow operators to quickly check the reference position of a drive without the use of any tools, and continue on with minimal downtime. See the [Reference](#) page on the HMI for more information regarding servo reference positions.

| Servo # | Servo Name | Direction of Positive Movement | Reference Position | End Position | Reference Mark Location |
|---------|------------------------------------------------------|--------------------------------|--------------------|--------------|-------------------------------------------------------------------------------------------------|
| 1 | Spatula | Tow ard dow nstacker flights | 0.25 | 0 | Dow nstream edge of spatula is at the shear point. (Dow nstream edge of side belt bottom rails) |
| 2 | Adjustable Dow nstacker 1 | Dow n w ith product | -24.375 | 0 | Top of flight 1/4" below sheer point |
| 3 | Adjustable Dow nstacker 2 | Dow n w ith product | -24.375 | 30.95 | Top of flight in line w ith the top of upper drive shaft |
| 4 | Fixed Dow nstacker 1 | Dow n w ith product | -19 | 0 | Top of flight 1/4" below sheer point |
| 5 | Fixed Dow nstacker 2 | Dow n w ith product | -18.875 | 30.827 | Top of flight in line w ith the top of upper drive shaft |
| 6 | Dow nstack Pusher | Moving product dow nstream | -1 | 0 | 1" off of upstream hardstop (Located on upstream end of v-rail) |
| 7 | Loader | Moving product dow nstream | -1 | 0 | 1" from the mechanical stop in the retracted position |
| 8 | Funnel | Funnel moving out of case | -10 | 0 | Funnel is 90 degrees to flight chain |
| 9 | Fun Tucker | Funnel moving out of case | -15 | 0 | Funnel is 90 degrees to flight chain |
| 10 | Tucker | Tucking trailing flap | -5 | 0 | Tucker arm is 90 degrees to flight chain |
| 11 | Product Stop | Tucking leading flap | 140 | 0 | Tucker arm is 90 degrees to flight chain |
| 12 | Casepacker Robot X-Axis | Tow ard palletizer | 34.53 | 32 | 2.5" f from the dow nstream mechanical stop |
| 13 | Casepacker Robot Z-Axis | Dow n | -1 | 0 | 1" from the mechanical stop in the retracted position |
| 14 | Casepacker Flights | Tow ard palletizer | 0.675 | 0 | Leading edge of flight is aligned w ith fixed side of load chamber |
| 15 | Low er Compression Non Operator Side | From horizontal to vertical | -4 | 0 | Compression plate is horizontal (open) |
| 16 | Low er Compression Operator Side | From horizontal to vertical | -2 | 0 | Compression plate is horizontal (open) |
| 17 | Upper Compression Non Operator Side | From horizontal to vertical | -8 | 0 | Compression plate is horizontal (open) |
| 18 | Upper Compression Operator Side | From horizontal to vertical | -3 | 0 | Compression plate is horizontal (open) |
| 19 | Case Tip Y | Moving tow ards operator side | -7.625 | 0 | Operator side face of flight is aligned w ith operator side of sheet metal backstop |
| 20 | Case Tip R | Tipping product | -1 | 0 | 1 inch from the "up" mechanical stop |
| 21 | Case Rotate | Turning case | 130 | 0 | Vacuum cup arm is 90 degrees to conveyor |


1 - Spatula



2 - Adjustable Downstacker 1




3 - Adjustable Downstacker 2




4 - Fixed Downstacker 1



5 - Fixed Downstacker 2



6 - Downstack Pusher



7 - Loader




8 - Funnel




Vertical
marks are
aligned

Funnel is at a
90 degree
angle to flight
chain


9 - Fun Tucker




10 - Tucker



11 - Product Stop




12 - Casepacker Robot X-Axis



13 - Casepacker Robot Z-Axis




14 - Casepacker Flights



**Vertical
marks are
aligned**


15 - 18 Compression Plates




**Compression
Plates**

**Compression
plates are
horizontal/flat**


19 - Case Tip Y



20 - Case Tip R



21 - Case Rotate



Drive Function and Associated Devices

The following table indicates how devices are related to drives, and the function of the particular device.

| Drive | Device | Function | |
|--------------------|--------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------|
| Case Packer | | | |
| Infeed | | | |
| SD1 | Spatula | Guides the product into the correct position in the downstacker | |
| | PE31704 | 1st Carton At Downstacker Photo Eye | Senses when the 1st carton is at the top of the downstack chamber |
| | PE31703 | 2nd Carton At Downstacker Photo Eye | Senses when the 2nd carton is at the top of the downstack chamber |
| | PX31001 | Spatula Reference Proximity Switch | Senses when the spatula is in its reference position |
| MT1 | Infeed Conveyor | Advances product into the machine and up to the side belts | |
| | VFD1302 | Infeed Conveyor VFD | Controls the speed of the infeed conveyor |
| MT2 | Side Belts | Collates the incoming product and sends it into the Downstacker | |
| | PE31702 | Product In Side Belts | Senses when product is present in the side belts |
| | VFD1402 | Side Belts VFD | Controls the speed of the side belts |
| Downstacker | | | |
| SD2 | Adjustable Downstacker 1 | Accepts incoming products from the side belts and indexes allowing a specified number of products to accumulate prior to lowering the products onto the accumulation deck | |
| | PE31704 | 1st Carton At Downstacker Photo Eye | Senses when the 1st carton is at the top of the downstack chamber |
| | PE31703 | 2nd Carton At Downstacker Photo Eye | Senses when the 2nd carton is at the top of the downstack chamber |
| | PE31002 | Non Operator Side Lower Downstacker Reference Photo Eye | Senses when the non operator side lower downstacker is in its reference position |
| SD3 | Adjustable Downstacker 2 | Accepts incoming products from the side belts and indexes allowing a specified number of products to accumulate prior to lowering the products onto the accumulation deck | |
| | PE31704 | 1st Carton At Downstacker Photo Eye | Senses when the 1st carton is at the top of the downstack chamber |
| | PE31703 | 2nd Carton At Downstacker Photo Eye | Senses when the 2nd carton is at the top of the downstack chamber |
| | PE31003 | Non Operator Side Upper Downstacker Reference Photo Eye | Senses when the non operator side upper downstacker is in its reference position |
| SD4 | Fixed Downstacker 1 | Accepts incoming products from the side belts and indexes allowing a specified number of products to accumulate prior to lowering the products onto the accumulation deck | |
| | PE31704 | 1st Carton At Downstacker Photo Eye | Senses when the 1st carton is at the top of the downstack chamber |
| | PE31703 | 2nd Carton At Downstacker Photo Eye | Senses when the 2nd carton is at the top of the downstack chamber |
| | PE31004 | Operator Side Lower Downstacker Reference Photo Eye | Senses when the operator side lower downstacker is in its reference position |
| SD5 | Fixed Downstacker 2 | Accepts incoming products from the side belts and indexes allowing a specified number of products to accumulate prior to lowering the products onto the accumulation deck | |

| Drive | Device | | Function |
|-------------------------|--------------------------|------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|
| | PE31704 | 1st Carton At Dow nstacker Photo Eye | Senses w hen the 1st carton is at the top of the dow nstack chamber |
| | PE31703 | 2nd Carton At Dow nstacker Photo Eye | Senses w hen the 2nd carton is at the top of the dow nstack chamber |
| | PE31005 | Operator Side Upper Dow nstacker Reference Photo Eye | Senses w hen the operator side upper dow nstacker is in its reference position |
| Downstack Pusher | | | |
| SD6 | Dow nstack Pusher | | Pushes the accumulated product out of the dow nstack chamber delivering it to the loader |
| | PX31006 | Dow nstack Pusher Reference Proximity Sw itch | Senses w hen the dow nstack pusher is in its reference position |
| SD24 | Dow nstack Pusher Master | | This is the virtual axis that the dow nstack pusher follow s |
| | PE31707 | Product At Dow nstack Pusher Photo Eye | Senses w hen product is present at the dow nstack pusher |
| SV30703 | Product Conditioner | | Applies dow nward pressure on the stacked product ensuring that it w ill fit into the case during loading |
| | CS31606 | Product Conditioner Extended Cylinder Sw itch | Senses w hen the cylinder is extended |
| | CS31607 | Product Conditioner Retracted Cylinder Sw itch | Senses w hen the cylinder is retracted |
| Loader | | | |
| SD7 | Loader | | Pushes the accumulated product out of the loader accumulation and into the partially formed case |
| | PX31007 | Loader Probe Proximity Sw itch | Senses w hen the loader is in its reference position |
| SD25 | Loader Master | | This is the virtual axis that the loader follow s |
| | PE31905 | Product At Loader Photo Eye | Senses w hen product is present at the loader |
| | PX31908 | Load Gate Closed Proximity Sw itch | Senses w hen the load gate is closed to allow the loader to cycle |
| Magazine | | | |
| SV30401 | Magazine Advance | | Advances the case blanks dow nstream tow ard the case former robot, maintaining sufficient pressure to pick |
| | PE31803 | Case Blanks Present Photo Eye | Senses w hen case blanks are present on the magazine advance chains |
| | PX31804 | Case Magazine Advance | Senses w hen cases are ready to be picked |
| Case Former | | | |
| SD8 | Funnel | | Opens the upstream minor flap and helps guide the product into the case |
| SD9 | Fun Tucker | | Opens the dow nstream minor flap and helps guide the product into the case, then tucks the trailing minor flap prior to compression |
| SD10 | Tucker | | Provides support for the case during loading and tucks the operator side trailing minor |
| SD11 | Product Stop | | Provides support for the case during loading and a backstop for incoming product to ensure it does not pass the operator side scoreline |
| SD12 | Case Packer Robot X Axis | | Moves the case packer robot upstream and dow nstream along the machines X axis |
| | PX31102 | Case Packer Robot X Axis Probe Proximity Sw itch | Senses w hen the case packer robot X is in its reference position |
| SD13 | Case Packer Robot Z Axis | | Moves the case packer robot up and dow n along the machines Z axis |

| Drive | Device | | Function |
|---------|--------------------------------------|----------------------------------------------------|-------------------------------------------------------------------------------------------------------------------|
| | PX31103 | Case Packer Robot Z Axis Probe Proximity Sw itch | Senses w hen case packer robot Z is in its reference position |
| SD14 | Case Packer Flights | | Advance the base of the case through the loading and compression areas of the machine |
| | PE31104 | Case Packer Flights Reference Photo Eye | Senses w hen the case packer flights are in their reference position |
| SD15 | Low er Compression Non Operator Side | | Compresses the low er non operator side major flap ensuring good adhesion and completing the case forming process |
| SD16 | Low er Compression Operator Side | | Compresses the low er operator side major flap ensuring good adhesion and completing the case forming process |
| SD17 | Upper Compression Non Operator Side | | Compresses the upper non operator side major flap ensuring good adhesion and completing the case forming process |
| SD18 | Upper Compression Operator Side | | Compresses the upper operator side major flap ensuring good adhesion and completing the case forming process |
| SD26 | Packer Main Master | | This is the virtual drive that all of the servo drives in the case former follow |
| | PE31903 | Case Present At Load Photo Eye | Senses w hen a case is present at the load station |
| | PE31904 | Distorted Case Present Photo Eye | Senses w hen a distorted case is present at the load station |
| | PE51402 | Non Operator Side Open Case Flap Present Photo Eye | Senses w hen a non operator side open case flap exists |
| | PE51401 | Operator Side Open Case Flap Present Photo Eye | Senses w hen a operator side open case flap exists |
| SV30306 | Magazine Rotate Clips | | Controls the sides of the cases in the magazine ensuring they are released at the proper time |
| SV30705 | Magazine Top Clip | | Controls the top of the cases in the magazine ensuring they are released at the proper time |
| SV30707 | Magazine Bottom Clip | | Controls the bottom of the cases in the magazine ensuring they are released at the proper time |
| SV30408 | Case Packer Robot Vacuum | | This valve controls the vacuum to the vacuum cups on the case packer robot head |
| | VS 31806 | Case Packer Robot Vacuum Present Vacuum Sw itch | Senses w hen the case packer robot has sufficient vacuum for operation |
| SV30403 | Case Pusher | | raises and low ers the case pusher, pushing the loaded case into the compression station |
| | CS31902 | Case Pusher Pushed Cylinder Sw itch | Senses w hen the case pusher cylinder is extended |
| SV30407 | Fun Tucker In / Out | | Moves the fun tucker in and out of the case to provide clearance for the case forming |
| SV30407 | Funnel In / Out | | Moves the funnel in and out of the case to provide clearance for the case forming |
| SV30308 | Load Vacuum | | This valve controls the vacuum supply to the vacuum cups at the case load station |
| | VS31708 | Load Vacuum Present Vacuum Sw itch | Senses w hen the load vacuum has sufficient vacuum for operation |
| SV30801 | Load Cups Lift | | Raises and low ers the load cups in order for the cases to clear as they travel dow nstream |
| SV30307 | Load Cups Blow back | | This valve controls the blow back to the vacuum cups at the case load station causing the case to be released |
| SV30402 | Case Stop | | Low ers stopping cases coming in to the compression station from advancing to far dow nstream |
| | CS31901 | Case Stop Retracted Cylinder Sw itch | Senses w hen the case stop cylinder is retracted |


| Drive | Device | Function | |
|---------------------------------|-------------------------------|----------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------|
| SV30805 | Low er Glue Non Operator Side | Fires glue onto the formed case prior to compression | |
| SV30806 | Low er Glue Operator Side | Fires glue onto the formed case prior to compression | |
| SV30807 | Upper Glue Non Operator Side | Fires glue onto the formed case prior to compression | |
| SV30808 | Upper Glue Operator Side | Fires glue onto the formed case prior to compression | |
| Orienter | | | |
| Case Tip / Reject | | | |
| SD19 | Tip / Reject Flights | Drives the case against the Tip Axis for tipping or out the Case Reject Chute for rejecting | |
| | PE51503 | Case At Tip Present Photo Eye | Senses w hen a case is present in the tip / reject station |
| | PX51001 | Tip Reject Flights Reference Proximity Sw itch | Senses w hen the tip / reject flights are in their reference position |
| SD20 | Case Tip R | Stops the operator side of the case during the tipping process to help it roll over the flights | |
| | PE51503 | Case At Tip Present Photo Eye | Senses w hen a case is present in the tip / reject station |
| SV50703 | Tipper Case Stop | Stops the advancing case on the tip reject conveyor in order for the tip / reject flights to perform the appropriate cycle | |
| | CS51507 | Case Stop Retracted Cylinder Sw itch | Senses w hen the case stop cylinder is retracted |
| MT9 | Tip / Reject Conveyor | Advances the completed case from the compression station through the tip reject station and onto the case conveyor | |
| | VFD1501 | Tip / Reject Conveyor VFD | Controls the speed of the tip / reject conveyor |
| Case Rotate Accumulation | | | |
| SD21 | Case Rotate | Rotates the completed case 90 degrees to orient it correctly for the dow nstream equipment | |
| | PE51505 | Case At Rotate Present Photo Eye | Senses w hen a case is present at the rotate station |
| | PE51506 | Case Present After Rotate Photo Eye | Senses w hen a case has cleared the rotate station |
| SV50201 | Case Rotate Vacuum | This valve controls the vacuum supply to the vacuum cup on the case rotate head | |
| | VS51305 | Case Rotate Vacuum Present Vacuum Sw itch | Senses w hen the case rotate has sufficient vacuum for operation |
| MT10 | Case Conveyor | Advances the completed cases dow nstream from the tip / reject station to the case accumulation area | |
| | OL806 | Case Conveyor Overload | Senses w hen the case conveyor has been overloaded |
| System | | | |
| SV24223 | System Air Dump | Supplies air pressure to the machine w hen the safety circuit is engaged | |
| | PS31201 | System Air Pressure Present Pressure Sw itch | Senses w hen the system air pressure is sufficient for machine operation |

Drive Diagnostics Page

General Page Information - Servo Drives

This page will display information about the Servo Drives on the machine. This is mainly a troubleshooting feature.

SAMPLE IMAGE



Servo Drive Diagnostic, Solenoid Valve, and Motor Selection Tabs

Each of these tabs will display a list of the possible Servo Drives, Solenoid Valves and Motors that can be selected to display the Diagnostic Box for the selected device.

Popup Button

This button will display a diagnostic popup window for the currently selected device. This diagnostic popup window will always be displayed regardless of which HMI page is open. This diagnostic popup window will show exactly what is shown in the diagnostic box for the selected device.

Display >> Button

This button will display device diagnostics for the selected device. For servo drives (types 2, 3, and 4 only), fault and diagnostic codes are displayed.

Drive Diagnostics Tab

| SD#2 - Linear Drive | | Close |
|---------------------------------|--------------------|-------------------------------------------|
| Drive Diagnostics | Fault Codes (P192) | Diagnostic Codes (S375) |
| <input type="radio"/> Not Used | C15: 0 | Act Pos: 0.014 |
| <input type="radio"/> Enabled | | Max Pos. Err. 0.000 Reset |
| <input type="radio"/> Ready | | Act Pos. Err. 0.000 |
| <input type="radio"/> Active | | Max Torq. 5 Reset |
| <input type="radio"/> Done | CW = Positive | Act Torq. -1 |
| <input type="radio"/> Faulted | CCW = Negative | |
| A0013 Ready for power on | | |

Not Used Status

This status will signal if the Servo Drive is not used

Enabled Status

This status will signal if the Servo Drive is enabled

Ready Status

This status will signal if the Servo Drive is ready

Active Status

This status will signal if the Servo Drive is active

Done Status

This status will signal if the Servo Drive is done

Faulted Status

This status will signal if the Servo Drive is faulted

Servo Drive Display Status

This will display what the Servo Drive Display is currently displaying. This will be displayed below the faulted status on the screen.

Location Status

This status will tell by what the Servo Drive is controlled in the program.

Positive Direction

This label communicates which direction makes the Servo Drive move in a positive direction.

Negative Direction

This label communicates which direction makes the Servo Drive move in a negative direction.

Act Pos Status

This status will display the actual position of the Servo Drive.

Max Pos Err Status

This status will display the maximum position error that has occurred on that Servo Drive. Maximum Position Error is the largest position error that has occurred since the last time the machine had been stopped.

Act Pos Err Status

This status will display the actual position error of the Servo Drive.

Max Torq Status

This status will display the maximum torque that the Servo Drive has used. Maximum Torque is the highest torque that has been used since the last time the machine had been stopped.

Act Torq Status

This status will display the actual torque that the Servo Drive is using.

Reset Features

These features will reset the Max Pos. Err. or Max Torq. values to zero and start recording the new max values of each of these statuses.

Close Button

This button will close the Servo Drive Diagnostic Box for this Servo Drive.

Fault Codes (P192) Tab

| SD#1 - Rotary Drive | | | | | Close |
|---------------------|--------------------------------------------|------------------------|-------------------------|--|-------|
| Drive Diagnostics | | Fault Codes (P192) | Diagnostic Codes (S375) | | |
| Code | Description | Date/Time | Operating Hours | | |
| F2174 | Loss of motor encoder reference | 11/16/2010 12:10:22 PM | 6675:55:53 | | |
| F2174 | Loss of motor encoder reference | 11/16/2010 10:23:18 AM | 6674:09:14 | | |
| F8022 | Enc. 1: enc. signals incorr. (can be cl... | 11/16/2010 10:18:57 AM | 6674:04:53 | | |
| F2174 | Loss of motor encoder reference | | 6430:19:46 | | |
| F2174 | Loss of motor encoder reference | | 6430:19:39 | | |
| F2174 | Loss of motor encoder reference | | 6430:19:35 | | |
| F2174 | Loss of motor encoder reference | | 6430:19:30 | | |
| F2008 | RL The motor type has changed. | | 6430:19:30 | | |

Code

This column displays the code received from the selected servo drive.

Description

This column contains the description of the item.

Date/Time

This column displays the date and time the code was received.

Operating Hours

This value represents the current operating hours for this servo drive at the time the code was received, in hours:minutes:seconds.

Close Button

This button will close this Servo Drive Diagnostic Box.


NOTE: This button does not appear on the Sercos Diagnostics Page

NOTE: The Drive Diagnostics tab does not appear on the Sercos Diagnostics Page

NOTE: A missing description or date/time stamp may indicate either the correct PLC framework version is not in place, the error occurred prior to startup operating hours being logged, or the code is not listed in the reference

table

Diagnostic Codes (S375) Tab



| Code | Description | Date/Time | Operating Hours |
|-------|----------------------------------------|------------------------|-----------------|
| C0500 | Reset class 1 diagnostics | 11/16/2010 12:10:23 PM | 6675:55:54 |
| F2174 | Loss of motor encoder reference | 11/16/2010 12:10:22 PM | 6675:55:53 |
| C5200 | Communication phase 4 transition ch... | 11/16/2010 12:10:20 PM | 6675:55:51 |
| A0003 | Communication phase 3 | 11/16/2010 12:10:17 PM | 6675:55:48 |
| A0002 | Communication phase 2 | 11/16/2010 12:10:16 PM | 6675:55:48 |
| C0100 | Communication phase 3 transition ch... | 11/16/2010 12:10:16 PM | 6675:55:48 |
| A0002 | Communication phase 2 | 11/16/2010 12:10:16 PM | 6675:55:48 |
| C0500 | Reset class 1 diagnostics | 11/16/2010 12:10:16 PM | 6675:55:47 |

Code

This column displays the code received from the selected servo drive.

Description

This column contains the description of the item.

Date/Time

This column displays the date and time the code was received.

Operating Hours

This value represents the current operating hours for this servo drive at the time the code was received, in hours:minutes:seconds.

Close Button

This button will close this Servo Drive Diagnostic Box.

NOTE: This button does not appear on the Sercos Diagnostics Page

NOTE: The Drive Diagnostics tab does not appear on the Sercos Diagnostics Page

NOTE: A missing description or date/time stamp may indicate either the correct PLC framework version is not in place, the error occurred prior to startup operating hours being logged, or the code is not listed in the reference table

Clear All Button

This button will clear all the displayed diagnostic boxes off the screen.

Fault Code History Button

This button will display the [Fault Code History Page](#).

NOTE: This feature is only available with the correct PLC framework version in place


Back Button

This button will display the [Advanced Page](#).

General Page Information - Solenoid Valves

This page will display information about the Solenoid Valves on the machine. This is mainly a troubleshooting feature.

SAMPLE IMAGE



Solenoid Valve Diagnostic Box

Close Button - This button will close the Solenoid Valve Member Map Diagnostic Box for that Solenoid Valve

Internal Group

Not Used Status - This status will signal if the Solenoid Valve is not used.

Ready Status - This status will signal if the Solenoid Valve is ready.

Active Status - This status will signal if the Solenoid Valve is active.

Done Status - This status will signal if the Solenoid Valve is done.

Faulted Status - This status will signal if the Solenoid Valve is faulted.

Location Status - This status will tell by what the Solenoid Valve is controlled in the program.

Output Group

A Coil - This status will signal if the Solenoid Valve should have the A Coil energized.

B Coil - This status will signal if the Solenoid Valve should have the B Coil energized.


Input Group

A Switch - This status will signal if the Solenoid Valve's A Switch is energized.

B Switch - This status will signal if the Solenoid Valve's B Switch is energized.

General Page Information - Motors

This page will display information about the Motors on the machine. This is mainly a troubleshooting feature.

SAMPLE IMAGE**Motor Diagnostic Box**

Close Button - This button will close the Motor Member Map Diagnostic Box for that Motor.

Speed - This status will display the speed at which the motor should be traveling.

Internal Group

Not Used Status - This status will signal if the Motor is not used.

Ready Status - This status will signal if the Motor is ready.

Active Status - This status will signal if the Motor is active.

Done Status - This status will signal if the Motor is done.

Faulted Status - This status will signal if the Motor is faulted.

Location Status - This status will tell by what the Motor is controlled in the program.

Output Group

Enable - This status will signal if the Motor is enabled.

Forward - This status will signal if the Motor should have the forward signal energized.

Reverse - This status will signal if the Motor should have the reverse signal energized.

Input Group

Forward - This status will signal if the Motor's forward switch is energized.

Reverse - This status will signal if the Motor's reverse switch is energized.

Fault Code History Page

SAMPLE IMAGE

Aagard HMI – Drive Diagnostics - Fault Code History

Servo Drive: All Servo Drives

| SD# | Servo Drive Name | Type | Code | Description | Date/Time | Operating Hours |
|-----|------------------|------|-------|------------------------------------------------|--------------------|-----------------|
| 1 | Rotary Drive | A | A0013 | Ready for power on | 11/23/2010 7:07 AM | 6823:52:14 |
| 1 | Rotary Drive | A | A0012 | Control and power sections ready for operation | 11/23/2010 7:07 AM | 6823:52:14 |
| 2 | Linear Drive | A | A0012 | Control and power sections ready for operation | 11/23/2010 7:07 AM | 6823:56:42 |
| 2 | Linear Drive | A | A0012 | Control and power sections ready for operation | 11/23/2010 7:07 AM | 6823:56:42 |
| 2 | Linear Drive | A | A0012 | Control and power sections ready for operation | 11/23/2010 7:07 AM | 6823:56:42 |
| 2 | Linear Drive | A | A0013 | Ready for power on | 11/23/2010 7:07 AM | 6823:56:42 |
| 2 | Linear Drive | A | A0012 | Control and power sections ready for operation | 11/23/2010 7:07 AM | 6823:56:41 |
| 2 | Linear Drive | A | A0012 | Control and power sections ready for operation | 11/23/2010 7:06 AM | 6823:56:05 |
| 1 | Rotary Drive | A | A0012 | Control and power sections ready for operation | 11/23/2010 7:06 AM | 6823:51:35 |
| 1 | Rotary Drive | A | A0104 | Position mode lagless | 11/23/2010 7:06 AM | 6823:51:35 |
| 2 | Linear Drive | E | E8260 | Torque/force command value limit active | 11/23/2010 7:06 AM | 6823:56:03 |
| 1 | Rotary Drive | E | E8260 | Torque/force command value limit active | 11/23/2010 7:06 AM | 6823:51:33 |
| 1 | Rotary Drive | A | A0104 | Position mode lagless | 11/23/2010 7:05 AM | 6823:50:32 |
| 2 | Linear Drive | A | A0104 | Position mode lagless | 11/23/2010 7:05 AM | 6823:55:01 |
| 2 | Linear Drive | A | A0012 | Control and power sections ready for operation | 11/23/2010 7:05 AM | 6823:54:57 |
| 1 | Rotary Drive | A | A0012 | Control and power sections ready for operation | 11/23/2010 7:05 AM | 6823:50:29 |
| 1 | Rotary Drive | A | A0013 | Ready for power on | 11/23/2010 7:02 AM | 6823:48:07 |
| 2 | Linear Drive | C | C0500 | Reset class 1 diagnostics | 11/23/2010 7:02 AM | 6823:52:36 |
| 1 | Rotary Drive | C | C0500 | Reset class 1 diagnostics | 11/23/2010 7:02 AM | 6823:48:07 |
| 2 | Linear Drive | A | A0013 | Ready for power on | 11/23/2010 7:02 AM | 6823:52:36 |
| 2 | Linear Drive | A | A0013 | Ready for power on | 11/23/2010 7:02 AM | 6823:52:35 |
| 1 | Rotary Drive | F | F2174 | Loss of motor encoder reference | 11/23/2010 7:02 AM | 6823:48:05 |
| 2 | Linear Drive | A | A0051 | Operating mode | 11/23/2010 7:02 AM | 6823:52:34 |

Time Period: Last hour

Individual Items | Totaled | Refresh | Back

Filters Applied: Reset Filters | Refresh | Back




NOTE: Fault and Diagnostic codes displayed on the Sercos Diagnostics Page are read directly from the servo drive, whereas errors displayed on the Fault Code History page are read from a database

Servo Drive

To access different servo drives, use the servo drive drop down list.

Column Headings and Filters

Optionally click on a column to sort the column in ascending order; click it again to sort in descending order.

Optionally click  in the column header to apply filters to a column. When filters are defined, the  will change to .

NOTE: Any filters applied will be used until Reset Defaults is clicked

SD#

This column displays the servo drive number.

Servo Drive Name

This column displays the servo drive name.

Type

This column displays the type of code received.

Code

This column displays the code received from the selected servo drive.

Description

This column displays the description of the code.

Date/Time

This column displays the date and time the code was received.


Operating Hours

This value represents the current operating hours for this servo drive at the time the code was received, in hours:minutes:seconds.

Time Period Selection

Click on the drop down arrow to view available time period filters to apply to the list. Select a filter from the list to apply it.

When selecting the custom date/range filter, additional date and time parameters become available to enter. After entering date and time parameters, click Apply.



NOTE: Any filters applied will be used until Reset Defaults is clicked

Individual Items

Click this button to display the items in the grid in chronological order.

NOTE: When **Individual Items** is selected, the button color will be blue

Totaled

Click this button to display the items in the grid in a totaled fashion, displaying the number of times an item occurred. The items all totaled to allow the user to more easily view which items are occurring the most frequently.

NOTE: When **Totaled** selected, the button color will be blue

Refresh Button

Click this button to update the database with the latest information from the servo drives, and then display that information on this page.

Reset Filters Button

Click this button to reset the screen to default sort and filter settings.

NOTE: This button will only appear when filters have been applied to this page

NOTE: When filters are applied, text indicating so will be displayed above the Reset Filters button

Back

This button will display the [Drive Diagnostics Page](#).

Sercos Diagnostics Page

General Page Information

This page is only for information and used primarily during troubleshooting.

NOTE: Fault and Diagnostic codes displayed on the Sercos Diagnostics Page are read directly from the servo drive, whereas errors displayed on the Fault Code History page are read from a database

SAMPLE IMAGE

Aagard HMI - Sercos Diagnostics

Sercos Ring: 1

Master Status

- Actual Phase: 4
- System State: Phase 4
- System Error: No error
- TimingErrorCnt1: 0
- TimingErrorCnt2: 0
- RDistErrorCnt: 0
- FibBrErrorCnt: 0
- RErrErrorCount: 0
- MstLateErrorCnt: 0
- MstEarlyErrorCnt: 0

Sercos Control

Init

E-Stop Mode

Reinitialize System

Servo Drive Data

Request Phase 1

Request Phase 2

Request Phase 3

Request Phase 4

Node Selection

- 1 - Rotary Drive
- 2 - Linear Drive
- 1 - Slice 1

Node Status

MST error counter (S28): 0 IDN S28 & S29 will only refresh while in phase 4.

MDT error counter (S29): 0

Diagnostic message (S95): A0013 Ready for power on

List of invalid operation data for CP2 (S21):

List of invalid operation data for CP3 (S22):

| Error Code | Description | Date/Time | Operating Hours |
|------------|-------------------------------------------------------|-------------------------|-----------------|
| F2174 | Loss of motor encoder reference | 11/16/2010 12:10:22 ... | 6675:55:53 |
| F2174 | Loss of motor encoder reference | 11/16/2010 10:23:18 ... | 6674:09:14 |
| F8022 | Enc. 1: enc. signals incorr. (can be cleared in ph... | 11/16/2010 10:18:57 ... | 6674:04:53 |
| F2174 | Loss of motor encoder reference | | 6430:19:46 |
| F2174 | Loss of motor encoder reference | | 6430:19:39 |
| F2174 | Loss of motor encoder reference | | 6430:19:35 |
| F2174 | Loss of motor encoder reference | | 6430:19:30 |

Manufacturer Version: FWA-INDRV[®]-MPB-04V24-D5-1-NNN-NN

Startup Operating Hours: 6675:56:05

Refresh Status

Fault Code History Back

Sercos Ring

This is a drop down list containing a list of the Sercos rings. Select a ring from the list to view the diagnostics for that ring.

Master Status

This is a list of the ring status and error counts from the currently selected ring.

Sercos Control Buttons and Mode

Init / E-Stop Mode

This displays the current mode of the machine.



Button

Click this button to view all C40 modes.

NOTE: This button will be visible when more than one C40 exists

E-Stop Mode / Initialize Mode

Click the Initialize Mode button to request Init Mode. How To Reinitialize

These steps are done via the Sercos Diagnostics Page in the HMI

- 1) E-Stop the machine
- 2) Go to the Sercos Diagnostic Page
- 3) Click on Initialize
- 4) The text on the Initialize Button changes to E-Stop
- 5) Click on "Reinitialize System", and wait for the machine to reinitialize the sercos ring
NOTE: Although no physical adjustments need to be made, you will need to download the correct product size and Inserter recipe, if installed, and initialize the Barcode Scanner, if installed
 - a) If you downloaded a product other than what was previously downloaded, the Product Download Changeover Adjustments Page will be displayed
- 6) When complete, the Sercos Diagnostics Page will be displayed
- 7) Click on E-Stop on the HMI screen
 - a) The text on the button returns to "Initialize"
CAUTION: If you downloaded the wrong product during the Sercos Ring re-initialization routine, you must go to the Main Page and download the correct product
- 8) Pull the E-Stop button, and restart the machine

A simple but more time consuming alternative to these steps is to restart the HMI from the Advanced Page.

NOTE: If the system is already in Init mode, this button will read **E-Stop Mode**. Click this button to take the system out of Init mode

NOTE: When in Init Mode, these additional buttons become available

Reinitialize System

This button will perform an initialization function when all major sections of the system are in Init mode. This button is only available when the system is in Init mode.

Servo Drive Data

This button will open the Servo Drive Data page

Request Phase 1

This button, when pressed, will force the current selected ring to phase 1.

Request Phase 2

This button, when pressed, will force the current selected ring to phase 2.

Request Phase 3

This button, when pressed, will force the current selected ring to phase 3.

Request Phase 4

This button, when pressed, will force the current selected ring to phase 4.

Node Selection

This is a list of available nodes from the currently selected Ring.

Node Status

Node Status and error counts from the currently selected Node of the currently selected Ring.

IDN 28 – MST Error Count

IDN 29 – MDT Error Count

IDN 95 – Node Display Status

IDN 21 – List of IDN with invalid values for change of phase form 2 to 3

IDN 22 – List of IDN with invalid values for change of phase form 3 to 4

IDN P-192 – List of up to 50 error codes

IDN S-375 – List of up to 50 diagnostic codes

Fault Codes (P192) Tab

| Code | Description | Date/Time | Operating Hours |
|-------|--------------------------------------------|------------------------|-----------------|
| F2174 | Loss of motor encoder reference | 11/16/2010 12:10:22 PM | 6675:55:53 |
| F2174 | Loss of motor encoder reference | 11/16/2010 10:23:18 AM | 6674:09:14 |
| F8022 | Enc. 1: enc. signals incorr. (can be cl... | 11/16/2010 10:18:57 AM | 6674:04:53 |
| F2174 | Loss of motor encoder reference | | 6430:19:46 |
| F2174 | Loss of motor encoder reference | | 6430:19:39 |
| F2174 | Loss of motor encoder reference | | 6430:19:35 |
| F2174 | Loss of motor encoder reference | | 6430:19:30 |
| F2008 | RL The motor type has changed. | | 6430:19:30 |

Code

This column displays the code received from the selected servo drive.

Description

This column contains the description of the item.

Date/Time

This column displays the date and time the code was received.

Operating Hours

This value represents the current operating hours for this servo drive at the time the code was received, in hours:minutes:seconds.

Close Button

This button will close this Servo Drive Diagnostic Box.

NOTE: This button does not appear on the Sercos Diagnostics Page

NOTE: The Drive Diagnostics tab does not appear on the Sercos Diagnostics Page

NOTE: A missing description or date/time stamp may indicate either the correct PLC framework version is not in place, the error occurred prior to startup operating hours being logged, or the code is not listed in the reference table

Diagnostic Codes (S375) Tab

| SD#1 - Rotary Drive | | | | |
|---------------------|----------------------------------------|------------------------|-------------------------|--|
| Close | | | | |
| Drive Diagnostics | | Fault Codes (P192) | Diagnostic Codes (S375) | |
| Code | Description | Date/Time | Operating Hours | |
| C0500 | Reset class 1 diagnostics | 11/16/2010 12:10:23 PM | 6675:55:54 | |
| F2174 | Loss of motor encoder reference | 11/16/2010 12:10:22 PM | 6675:55:53 | |
| C5200 | Communication phase 4 transition ch... | 11/16/2010 12:10:20 PM | 6675:55:51 | |
| A0003 | Communication phase 3 | 11/16/2010 12:10:17 PM | 6675:55:48 | |
| A0002 | Communication phase 2 | 11/16/2010 12:10:16 PM | 6675:55:48 | |
| C0100 | Communication phase 3 transition ch... | 11/16/2010 12:10:16 PM | 6675:55:48 | |
| A0002 | Communication phase 2 | 11/16/2010 12:10:16 PM | 6675:55:48 | |
| C0500 | Reset class 1 diagnostics | 11/16/2010 12:10:16 PM | 6675:55:47 | |

Code

This column displays the code received from the selected servo drive.

Description

This column contains the description of the item.

Date/Time

This column displays the date and time the code was received.

Operating Hours

This value represents the current operating hours for this servo drive at the time the code was received, in hours:minutes:seconds.

Close Button

This button will close this Servo Drive Diagnostic Box.

NOTE: This button does not appear on the Sercos Diagnostics Page

NOTE: The Drive Diagnostics tab does not appear on the Sercos Diagnostics Page

NOTE: A missing description or date/time stamp may indicate either the correct PLC framework version is not in place, the error occurred prior to startup operating hours being logged, or the code is not listed in the reference table

Manufacturer Version

This label displays the current firmware version of the selected servo drive node.

Startup Operating Hours

This label displays the total operating hours of the selected servo drive node.

Refresh Status

When this button is pressed, the Node Status values are updated for the currently selected Node of the currently selected Ring.

Fault Code History Button

This button will display the [Fault Code History Page](#).

NOTE: This feature is only available with the correct PLC framework version in place

Back

This button will open the previous page.

Member Map Diagnostics Page

General Page Information

This screen displays the status information for different drives and sections of the machine. This is mainly a troubleshooting function.

SAMPLE IMAGE

SD#1 - Rotary Drive Close

Drive Diagnostics | Fault Codes (P192) | Diagnostic Codes (S375)

Not Used C15: 0 Act Pos: 142.638
 Enabled
 Ready Max Pos. Err. 0.000 [Reset](#)
 Active Act Pos. Err. 0.000
 Done CW = Positive Max Torq. 1.462 [Reset](#)
 Faulted CCW = Negative Act Torq. 2
A0013 Ready for power on

SV#30702 - Cylinder Close

Internal: Not Used C15: 0 A Coil A Switch
 Ready B Coil B Switch
 Active
 Done
 Faulted

MT#207 - Carton Discharge Conveyor Close

Internal: Not Used C15: 0 Speed: 0
 Ready Enable
 Active Forward
 Done Reverse
 Faulted

Buttons: **Popup** **Display >>** **Clear All** **Back**

Member Map Diagnostic Selection Tree

This will display a list of the possible devices that can be displayed in a diagnostic box. Double click an item to open the diagnostic box.

Popup Button

This button will display a diagnostic popup window for the currently selected device. This diagnostic popup window will always be displayed regardless of which HMI page is open. This diagnostic popup window will show exactly what is shown in the diagnostic box for the selected device.

Display >> Button

This button will display device diagnostics for the selected device. For servo drives (types 2, 3, and 4 only), fault and diagnostic codes are displayed.

Drive Diagnostics Tab

| SD#2 - Linear Drive | | Close |
|---------------------------------|--------------------|-------------------------------------------|
| Drive Diagnostics | Fault Codes (P192) | Diagnostic Codes (S375) |
| <input type="radio"/> Not Used | C15: 0 | Act Pos: 0.014 |
| <input type="radio"/> Enabled | | Max Pos. Err. 0.000 Reset |
| <input type="radio"/> Ready | | Act Pos. Err. 0.000 |
| <input type="radio"/> Active | | Max Torq. 5 Reset |
| <input type="radio"/> Done | CW = Positive | Act Torq. -1 |
| <input type="radio"/> Faulted | CCW = Negative | |
| A0013 Ready for power on | | |

Not Used Status

This status will signal if the Servo Drive is not used

Enabled Status

This status will signal if the Servo Drive is enabled

Ready Status

This status will signal if the Servo Drive is ready

Active Status

This status will signal if the Servo Drive is active

Done Status

This status will signal if the Servo Drive is done

Faulted Status

This status will signal if the Servo Drive is faulted

Servo Drive Display Status

This will display what the Servo Drive Display is currently displaying. This will be displayed below the faulted status on the screen.

Location Status

This status will tell by what the Servo Drive is controlled in the program.

Positive Direction

This label communicates which direction makes the Servo Drive move in a positive direction.

Negative Direction

This label communicates which direction makes the Servo Drive move in a negative direction.

Act Pos Status

This status will display the actual position of the Servo Drive.

Max Pos Err Status

This status will display the maximum position error that has occurred on that Servo Drive. Maximum Position Error is the largest position error that has occurred since the last time the machine had been stopped.

Act Pos Err Status

This status will display the actual position error of the Servo Drive.

Max Torq Status

This status will display the maximum torque that the Servo Drive has used. Maximum Torque is the highest torque that has been used since the last time the machine had been stopped.

Act Torq Status


This status will display the actual torque that the Servo Drive is using.

Reset Features

These features will reset the Max Pos. Err. or Max Torq. values to zero and start recording the new max values of each of these statuses.

Close Button

This button will close the Servo Drive Diagnostic Box for this Servo Drive.

Fault Codes (P192) Tab


| SD#1 - Rotary Drive | | | | |
|---------------------|--------------------------------------------|------------------------|-------------------------|--|
| Close | | | | |
| Drive Diagnostics | | Fault Codes (P192) | Diagnostic Codes (S375) | |
| Code | Description | Date/Time | Operating Hours | |
| F2174 | Loss of motor encoder reference | 11/16/2010 12:10:22 PM | 6675:55:53 | |
| F2174 | Loss of motor encoder reference | 11/16/2010 10:23:18 AM | 6674:09:14 | |
| F8022 | Enc. 1: enc. signals incorr. (can be cl... | 11/16/2010 10:18:57 AM | 6674:04:53 | |
| F2174 | Loss of motor encoder reference | | 6430:19:46 | |
| F2174 | Loss of motor encoder reference | | 6430:19:39 | |
| F2174 | Loss of motor encoder reference | | 6430:19:35 | |
| F2174 | Loss of motor encoder reference | | 6430:19:30 | |
| F2008 | RL The motor type has changed. | | 6430:19:30 | |

Code

This column displays the code received from the selected servo drive.

Description

This column contains the description of the item.

Date/Time

This column displays the date and time the code was received.

Operating Hours

This value represents the current operating hours for this servo drive at the time the code was received, in hours:minutes:seconds.

Close Button

This button will close this Servo Drive Diagnostic Box.

NOTE: This button does not appear on the Sercos Diagnostics Page

NOTE: The Drive Diagnostics tab does not appear on the Sercos Diagnostics Page

NOTE: A missing description or date/time stamp may indicate either the correct PLC framework version is not in place, the error occurred prior to startup operating hours being logged, or the code is not listed in the reference

table

Diagnostic Codes (S375) Tab

| SD#1 - Rotary Drive | | | | |
|---------------------|----------------------------------------|------------------------|-------------------------|--|
| Close | | | | |
| Drive Diagnostics | | Fault Codes (P192) | Diagnostic Codes (S375) | |
| Code | Description | Date/Time | Operating Hours | |
| C0500 | Reset class 1 diagnostics | 11/16/2010 12:10:23 PM | 6675:55:54 | |
| F2174 | Loss of motor encoder reference | 11/16/2010 12:10:22 PM | 6675:55:53 | |
| C5200 | Communication phase 4 transition ch... | 11/16/2010 12:10:20 PM | 6675:55:51 | |
| A0003 | Communication phase 3 | 11/16/2010 12:10:17 PM | 6675:55:48 | |
| A0002 | Communication phase 2 | 11/16/2010 12:10:16 PM | 6675:55:48 | |
| C0100 | Communication phase 3 transition ch... | 11/16/2010 12:10:16 PM | 6675:55:48 | |
| A0002 | Communication phase 2 | 11/16/2010 12:10:16 PM | 6675:55:48 | |
| C0500 | Reset class 1 diagnostics | 11/16/2010 12:10:16 PM | 6675:55:47 | |

Code

This column displays the code received from the selected servo drive.

Description

This column contains the description of the item.

Date/Time

This column displays the date and time the code was received.

Operating Hours

This value represents the current operating hours for this servo drive at the time the code was received, in hours:minutes:seconds.

Close Button

This button will close this Servo Drive Diagnostic Box.

NOTE: This button does not appear on the Sercos Diagnostics Page

NOTE: The Drive Diagnostics tab does not appear on the Sercos Diagnostics Page

NOTE: A missing description or date/time stamp may indicate either the correct PLC framework version is not in place, the error occurred prior to startup operating hours being logged, or the code is not listed in the reference table

Clear All Button

This button will clear all the displayed diagnostic boxes off the screen.

Back Button

This button will display the [Advanced Page](#).

Motor Diagnostic Box

Close Button - This button will close the Motor Member Map Diagnostic Box for that Motor.

Speed - This status will display the speed at which the motor should be traveling.

Internal Group

Not Used Status - This status will signal if the Motor is not used.

Ready Status - This status will signal if the Motor is ready.

Active Status - This status will signal if the Motor is active.

Done Status - This status will signal if the Motor is done.

Faulted Status - This status will signal if the Motor is faulted.

Location Status - This status will tell by what the Motor is controlled in the program.

Output Group

Enable - This status will signal if the Motor is enabled.

Forward - This status will signal if the Motor should have the forward signal energized.

Reverse - This status will signal if the Motor should have the reverse signal energized.

Input Group

Forward - This status will signal if the Motor's forward switch is energized.

Reverse - This status will signal if the Motor's reverse switch is energized.

Solenoid Valve Diagnostic Box

Close Button - This button will close the Solenoid Valve Member Map Diagnostic Box for that Solenoid Valve

Internal Group

Not Used Status - This status will signal if the Solenoid Valve is not used.

Ready Status - This status will signal if the Solenoid Valve is ready.

Active Status - This status will signal if the Solenoid Valve is active.

Done Status - This status will signal if the Solenoid Valve is done.

Faulted Status - This status will signal if the Solenoid Valve is faulted.

Location Status - This status will tell by what the Solenoid Valve is controlled in the program.

Output Group

A Coil - This status will signal if the Solenoid Valve should have the A Coil energized.


B Coil - This status will signal if the Solenoid Valve should have the B Coil energized.

Input Group

A Switch - This status will signal if the Solenoid Valve's A Switch is energized.

B Switch - This status will signal if the Solenoid Valve's B Switch is energized.

SAMPLE IMAGE

**C40 Member Map Diagnostic Box**

This diagnostic box is displayed when a motor is added to the display side of the screen.

E-Stopped Status - This status will signal if the C40 is E-stopped.

Power Status - This status will signal if the C40 has power.

State Status - This status will display the state of the C40.

Mode Status - This status will display the mode of the C40.

Rate Status - This status will tell the rate of the C40.

Close Button - This button will close the C40 Member Map Diagnostic Box for that C40.

C20 Member Map Diagnostic Box

In Use Status - This status will signal if the C20 is not used.

State Complete Status - This status will signal if the C20 is state complete.

Ready Status - This status will signal if the C20 is ready.

Active Status - This status will signal if the C20 is active.

Done Status - This status will signal if the C20 is done.

Faulted Status - This status will signal if the C20 is faulted.

Sequence Step Status - This status will indicate in which sequence step the C20 is in the program.

Close Button - This button will close the C20 Member Map Diagnostic Box for that C20.

C15 Member Map Diagnostic Box

In Use Status - This status will signal if the C15 is not used.

Fault Response Complete Status - This status will signal if the C15 fault response is complete.

Recovery Complete Status - This status will signal if the C15 recovery is complete.

Ready Status - This status will signal if the C15 is ready.

Active Status - This status will signal if the C15 is active.

Done Status - This status will signal if the C15 is done.

F-Stopped Status - This status will signal if the C15 is fault stopped.

Use Sync Recovery Status - This status will signal if the C15 is using sync recovery.

Wait For Sync Status - This status will signal if the C15 is waiting to be in sync.

Faulted Status - This status will signal if the C15 is faulted.

E-Stop Recovery Step Status - This status will tell what E-stop recovery step the C15 is in the program.

Close Button - This button will close the C15 Member Map Diagnostic Box for that C15.

Vacuum Pump Shutdown

From time to time, it may be necessary or desirable to turn off the vacuum pump.

On machines with standard System Start and System Cycle Stop buttons, follow these instructions:

- 1) Cycle-stop machine
 - 2) Depress system E-Stop button
 - 3) After machine is E-Stopped, simultaneously press System Start and System Cycle Stop buttons on the HMI panel
-

On machines which have an additional physical Reset button, follow these instructions instead:

- 1) Cycle-stop machine
 - 2) Depress system E-Stop button
 - 3) After machine is E-Stopped, simultaneously press Reset and System Cycle Stop buttons on the HMI panel
-


If machine has been E-stopped for one hour, the vacuum pump will automatically turn off. When machine is started, vacuum pump will turn on automatically and no further action is required.

Level 3

Startup Page

General Page Information

This page is the first page that will be shown after the HMI is powered up. Two buttons will be displayed on the screen. One button is the Servo Initialization Option button and the other is the Continue button. The initialization process will start automatically if no buttons are pressed by the time the timer in the bottom right hand corner of the screen has expired. After the initialization process is complete and successful, the [Product Download Page](#) will be displayed.



Servo Initialization Options Button

Pressing this button will deactivate the automatic download feature for the current initialization and display the Servo Initialization Options Page (shown below).



Sercos Diagnostics Button

This button displays the [Sercos Diagnostics Page](#). This page is only for information and is used primarily during troubleshooting.

Initialization Data Button

This button will display the **Initialization Data Page**. This page shows Servo Drive Data for each Servo Drive on the machine. This page is identical to the [Servo Drive Data Page](#), with the addition of one check mark box in the bottom left hand corner of the screen labeled "Include This Servo In Initialization". Checking this box will do a full initialization to the Servo Drive that is currently selected the next time an initialization is done. A full initialization will load all the parameters specified under the Initialization Column on the [Servo Drive Data Page](#). Information about the parameters on this page can be found under the [Servo Drive Data Page](#). Accessing the Initialization Data Page requires a [User Level 3](#) log in.

Continue Button

The **Continue Button** does the same on either of the pages, the **Startup Page** and the **Servo Initialization Option Page**. This button will start the initialization process as soon as it is pressed.

Servo Initialize Option



Initialization Data Page

General Page Information

This page shows Servo Drive Data for each Servo Drive on the machine. This page is identical to the [Servo Drive Data Page](#), with the addition of one check mark box in the bottom left hand corner of the screen labeled "Include This Servo In Initialization". Checking this box will do a full initialization to the Servo Drive that is currently selected the next time an initialization is done. A full initialization will load all the parameters specified under the Initialization Column on the [Servo Drive Data Page](#). Information about the parameters on this page can be found under the [Servo Drive Data Page](#).

User Level 3 required!

Initialize Data Section

Initialize Data Category

The machine controller uses this data in the machine start up to configure each servo axis. This data will require a full initialize on that servo axis before the changes will take effect. More information on how to do a full initialize on a servo axis can be found on the [Start Up Page](#).

Referencing Data Section

Referencing Data Category

This data is for machine referencing of the currently selected servo axis. Data changed in this category will take effect immediately after entering the data.

Jog Data Section

Jog Data Category

This data is used while in manual mode and jogging the currently selected servo axis. Data changed in this category will take effect immediately after entering the data.

Motion Data Section

Motion Data Category

This data is used as default variables and starting speeds for the currently selected servo axis. Data changed in this category will take effect immediately after entering the data.

Cam Data Section

Cam Data Category

This data is used when the axis is cam coupled to a master. If zero is specified, the default value in the Motion Data Category will be used. Data changed in this category will take effect immediately after entering the data.

Torque Monitoring Section

Torque Monitoring Category

This data is used as default variables and starting speeds for the currently selected servo axis. Data changed in this category will take effect immediately after entering the data.

SAMPLE IMAGE

Aagard HMI - Data Input - Servo Drive

Servo Drive: **(5) 5 - Carton Picker**

Standard | **Advanced**

Initialize Data

Motion Type: Rotary

Unit: Inches

Feed Forward:

Negate Feedback:

Inches Per Revolution: 0

Input Revolutions: 10

Output Revolutions: 1

Feedback Reference: Load

Modulo: 0

Velocity Limit: 1500

Max Velocity Limit: 3,476.772

Accel Limit: 100000000

Max Accel Limit: 116,889,663.063

In Position Bandwidth: 1

In Position Monitor Time: 0

Disable Drive Loop Monitoring: **(WARNING! This also disables runaway detection!)**

Enable Probe:

Probe Direction: Bi-Directional

Referencing Data

Standard Referencing:

Referencing Type: Switch Rev

Referencing Direction: Positive

Ref Verification Type: None

Torque: 50

Reference Velocity: 30

Low Velocity: 20

Accel: 720

Decel: 720

End Position: 0

Reference Position: -12

Sensor Clear Dist: 30

Sensor Compare Pos.: 0

Sensor Bandwidth: 0

Lag Limit: 0

Move #: 1

Motion Data

Default Velocity: 30

Default Accel: 250

Default Decel: 250

Default Torque: 180

Default Lag Limit: 5

E-Stop Recovery Accel: 250

E-Stop Fast Decel: 500

Cam Data

Master Offset Step: 0.01

Slave Offset Step: 0.1

Torque Limit: 0

Lag Limit: 0

Torque Monitoring

Torq. Averaging Count: 2

Torq. Warning Threshold %: 100

Jog Data

Move #: 2

Accel: 250

Decel: 250

Torque Limit: 50

Lag Limit: 0

Notes

11 Drive Status

Act Pos: 0.000

Max Pos. Err: 0.000 [Reset](#)

Max Torq: 0.000 [Reset](#)

Disabled

Include This Servo In Initialization

Init All

Init None

Diagnose

Copy From...

Back

Fault History Page

General Page Information

This page keeps a record of all faults generated. This may help with diagnosing any major problems or possible problems. These notices will be stored in the database for three days, and then will be deleted. The information displayed on this page is also accessible on the [View Notices System Wide](#) page.

SAMPLE IMAGE

Aagard HMI - Notice History

Notice History for Cartoner

Move Column: C40

| Date Stamp | Device | Message | PLC Details | Notice Type | Shift | Down Time | Ack Time | Notes | Location | HMI Details |
|------------------------|-------------------|-----------------------------|--------------------|----------------|-------|-----------|----------|-------|----------|------------------|
| 11/5/2010 8:02:25 AM | IDV1 Carton ... | Bar Code Scanner Failure | Beckhoff Error ... | Fault | 1 | | | | Cartoner | |
| 11/5/2010 8:02:17 AM | IDV1 Carton ... | Bar Code Scanner Failure | Beckhoff Error ... | Fault | 1 | | | | Cartoner | |
| 12/18/2009 11:03:24 AM | SD5 Side Fil... | Motion Control Reset Error | Servo Drive E... | Fault | 1 | 00:05:53 | 00:00:07 | | Cartoner | Cleared in 7 s |
| 12/17/2009 10:54:09 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:01:21 | 00:00:01 | | Cartoner | Cleared in 1 s |
| 12/17/2009 10:49:24 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:04:07 | 00:00:02 | | Cartoner | Cleared in 2 s |
| 12/17/2009 10:35:31 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:01:13 | 00:00:02 | | Cartoner | Cleared in 2 s |
| 12/17/2009 10:25:25 AM | EN49101 Low... | Lower Film Unwind Danc... | Encoder Pos ... | Fault | 1 | 00:05:37 | 00:00:05 | | Cartoner | Cleared in 5 s |
| 12/17/2009 9:57:13 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:01:16 | 00:00:05 | | Cartoner | Cleared in 5 s |
| 12/17/2009 9:47:40 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:08:48 | 00:08:26 | | Cartoner | Cleared in 8 ... |
| 12/17/2009 9:42:22 AM | SD6 Side Fil... | Fast Stop Failed | MC_ChangeD... | Fault | 1 | 00:03:15 | 00:00:03 | | Cartoner | Cleared in 2 s |
| 12/16/2009 11:07:22 AM | IDV7 Carton ... | Checkweigher Failure | Check Check... | Fault | 1 | 00:00:13 | 00:00:07 | | Cartoner | Cleared in 7 s |
| 12/16/2009 10:43:57 AM | IDV4 Filler B ... | Metal Detected | Metal Detecte... | Critical Fault | 1 | | 00:00:32 | | Cartoner | Cleared in 31 s |
| 12/16/2009 10:43:54 AM | IDV3 Filler A ... | Metal Detected | Metal Detecte... | Critical Fault | 1 | 00:00:49 | 00:00:32 | | Cartoner | Cleared in 32 s |
| 12/16/2009 10:25:38 AM | IDV1 Carton ... | Bad Bar Code Scanned | Remove Carto... | Critical Fault | 1 | 00:02:24 | 00:01:15 | | Cartoner | Cleared in 1 ... |
| 12/16/2009 10:21:47 AM | PE48206 Cart... | Improper Carton Transfer... | Carton Did Not... | Fault | 1 | 00:03:19 | 00:00:18 | | Cartoner | Cleared in 17 s |
| 12/16/2009 9:22:37 AM | S32_4 Analo... | Function Block Failed | Channel 2 Fail... | Fault | 1 | | 00:28:34 | | Cartoner | Cleared in 28... |
| 12/16/2009 9:02:08 AM | S32_4 Analo... | Function Block Failed | Channel 1 Fail... | Fault | 1 | | 00:13:46 | | Cartoner | Cleared in 13... |
| 12/16/2009 8:57:11 AM | S32_4 Analo... | Function Block Failed | Channel 1 Fail... | Fault | 1 | 01:04:15 | 00:00:32 | | Cartoner | Cleared in 32 s |
| 12/16/2009 7:48:17 AM | IDV7 Carton ... | Checkweigher Failure | Check Check... | Fault | 1 | 00:00:35 | 00:00:15 | | Cartoner | Cleared in 15 s |
| 12/16/2009 7:45:01 AM | IDV7 Carton ... | Checkweigher Failure | Check Check... | Fault | 1 | 00:02:57 | 00:00:23 | | Cartoner | Cleared in 23 s |
| 12/16/2009 7:39:40 AM | IDV1 Carton ... | Bad Bar Code Scanned | Remove Carto... | Critical Fault | 1 | 00:00:52 | 00:00:39 | | Cartoner | Cleared in 39 s |
| 12/16/2009 7:37:31 AM | IDV1 Carton ... | Bad Bar Code Scanned | Remove Carto... | Critical Fault | 1 | 00:01:33 | 00:01:30 | | Cartoner | Cleared in 1 ... |
| 12/15/2009 6:44:58 PM | PE42306 Sec... | Blocked Too Long | Blocked For 1... | Fault | 2 | 00:05:46 | 00:05:36 | | Cartoner | Cleared in 5 ... |

C40 Filter

Click on the drop down arrow to view history for a particular C40. If a C40 is not listed, there are no messages to display.

Filter Buttons (Fault, Critical Fault, General, Warning, Reject, Debug, Utility, and Unhandled Not Shown)

These buttons represent different notice types. Press any button to filter those notices from the list. Pressing refresh will refresh the screen, displaying only those notice types selected.

- **Fault** – a message describing an unintended event which restricts the system's ability to produce
- **Critical Fault** – same as Fault, except the operator must acknowledge each Critical Fault individually
- **General** – an informational message which relays current existing conditions within the system
- **Warning** – a message describing an event which occurred, or an existing condition, which may cause a problem if not addressed
- **Reject** – a message describing why a product was rejected from the normal flow of product
- **Debug** – a message used during the debug stage of development to monitor for specific desired or undesired events
- **Utility** – a notice used to trigger a software utility
- **Unhandled Not Shown** – a message that is sent from the PLC but not defined in the Message data base
- **Production Data Not Shown** – a message used for production data collection

Individual Items

Click this button to display the items in the grid in chronological order.

NOTE: When **Individual Items** is selected, the button color will be blue

Totaled


Click this button to display the items in the grid in a totaled fashion, displaying the number of times an item occurred. The items all totaled to allow the user to more easily view which items are occurring the most frequently.

NOTE: When **Totaled** selected, the button color will be blue

| Aagard HMI - Notice History | | | | |
|-----------------------------|----------|---------------------------------|-------|--|
| Notice History for Inserter | | | | |
| Device | Location | Message | Count | |
| CS1AE Knife ... | Inserter | Cylinder Extend Switch Not M... | 1 | |
| MS1 Custom... | Inserter | VFD Faulted | 2 | |
| MS1 Custom... | Inserter | Invalid Program Call | 16 | |
| PE6 Register... | Inserter | Sensor Failure | 8 | |
| PE6 Register... | Inserter | Not Made During Startup | 1 | |
| PE2 Web Br... | Inserter | Web Break PE Not Blocked ... | 1 | |
| PE3 Loop Low | Inserter | Eye Not Blocked When Expe... | 10 | |
| SD2 Knife | Inserter | Lag Error | 1 | |
| SD1 Pinwheel | Inserter | Cam Load Failed | 1 | |
| CTRL1 HMI | Inserter | Switching To Sercos Phase 2 ... | 1 | |
| | | | | |
| | | | | |

Edit Notes Button

Select a message in the grid and the Edit Notes Button becomes available. Click on the Edit Notes button to open a dialog window to add your notes to the messages. Double-clicking on the message itself also opens this dialog. Click OK on the dialog when finished.

**Delete All Button**

This button will delete the entire fault log. This will make any generated reports invalid since the Report Generator uses this fault log to generate its reports.

Refresh

This button will refresh the faults on the screen to the most current log at the time the refresh button was pressed, reflected by any filters which may have been selected.

Back Button

This button will return the user to the calling page.

Filter Drop Down List

Click on the drop down arrow to view available filters to apply to the list. Select a filter from the list to apply it. Depending on the selection, additional parameters become available to enter, such as dates and hours.

| | | |
|-----------------|-----------|------------|
| From Date/Time: | 1/ 4/2010 | 5:59:00 AM |
| To Date/Time: | 1/ 4/2010 | 5:59:00 PM |
| Show Last: | 0 Hours | 0 Minutes |

Column Options

To move a column from left to right, select a column from the dropdown list, and click Left or Right to move the column in either direction.

Device Column

This column displays the name of the device which generated the notice.

Message Column

This column displays the message which appeared on the notice. A list of possible messages, causes, and actions are given on the [Message Notices](#) section.

PLC Details Column

This column displays information received from the PLC when the notice was generated.

Shift Column

This column displays the shift in which the notice was recorded.

Down Time Column

This column displays time elapsed between notice display and when the system is started.

Ack Time Column

This column displays the length of time elapsed before the notice was acknowledged.

HMI Details Column

This column displays any additional information received from the HMI when the notice was generated.

Date Stamp Column

This column displays the date and time when the notice was generated.

Notes Column

This column displays any user entered information for the selected notice.

Notice Type

This column displays the type of notice recorded.

Location Column

This column displays the notice location or area of the machine.

Reject History Page

General Page Information

This page keeps a record of all rejects generated. This may help with diagnosing any major problems or possible problems. These notices will be stored in the database for three days, and then will be deleted. The information displayed on this page is also accessible on the [View Notices System Wide](#) page.

SAMPLE IMAGE

Aagard HMI - Notice History

Notice History for Cartoner

Move Column: Device C40 Cartoner

| Date Stamp | Device | Message | PLC Details | Notice Type | Shift | Down Time | Ack Time | Notes | Location | HMI Details |
|------------------------|-------------------|-----------------------------|--------------------|----------------|-------|-----------|----------|-------|----------|------------------|
| 11/5/2010 8:02:25 AM | IDV1 Carton ... | Bar Code Scanner Failure | Beckhoff Error ... | Fault | 1 | | | | Cartoner | |
| 11/5/2010 8:02:17 AM | IDV1 Carton ... | Bar Code Scanner Failure | Beckhoff Error ... | Fault | 1 | | | | Cartoner | |
| 12/18/2009 11:03:24 AM | SD5 Side Fil... | Motion Control Reset Error | Servo Drive E... | Fault | 1 | 00:05:53 | 00:00:07 | | Cartoner | Cleared in 7 s |
| 12/17/2009 10:54:09 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:01:21 | 00:00:01 | | Cartoner | Cleared in 1 s |
| 12/17/2009 10:49:24 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:04:07 | 00:00:02 | | Cartoner | Cleared in 2 s |
| 12/17/2009 10:35:31 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:01:13 | 00:00:02 | | Cartoner | Cleared in 2 s |
| 12/17/2009 10:25:25 AM | EN49101 Low... | Lower Film Unwind Danc... | Encoder Pos ... | Fault | 1 | 00:05:37 | 00:00:05 | | Cartoner | Cleared in 5 s |
| 12/17/2009 9:57:13 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:01:16 | 00:00:05 | | Cartoner | Cleared in 5 s |
| 12/17/2009 9:47:40 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:08:48 | 00:08:26 | | Cartoner | Cleared in 8 ... |
| 12/17/2009 9:42:22 AM | SD6 Side Fil... | Fast Stop Failed | MC_ChangeD... | Fault | 1 | 00:03:15 | 00:00:03 | | Cartoner | Cleared in 2 s |
| 12/16/2009 11:07:22 AM | IDV7 Carton ... | Checkweigher Failure | Check Check... | Fault | 1 | 00:00:13 | 00:00:07 | | Cartoner | Cleared in 7 s |
| 12/16/2009 10:43:57 AM | IDV4 Filler B ... | Metal Detected | Metal Detecte... | Critical Fault | 1 | | 00:00:32 | | Cartoner | Cleared in 31 s |
| 12/16/2009 10:43:54 AM | IDV3 Filler A ... | Metal Detected | Metal Detecte... | Critical Fault | 1 | 00:00:49 | 00:00:32 | | Cartoner | Cleared in 32 s |
| 12/16/2009 10:25:38 AM | IDV1 Carton ... | Bad Bar Code Scanned | Remove Carto... | Critical Fault | 1 | 00:02:24 | 00:01:15 | | Cartoner | Cleared in 1 ... |
| 12/16/2009 10:21:47 AM | PE48206 Cart... | Improper Carton Transfer... | Carton Did Not... | Fault | 1 | 00:03:19 | 00:00:18 | | Cartoner | Cleared in 17 s |
| 12/16/2009 9:22:37 AM | S32_4 Analo... | Function Block Failed | Channel 2 Fail... | Fault | 1 | | 00:28:34 | | Cartoner | Cleared in 28... |
| 12/16/2009 9:02:08 AM | S32_4 Analo... | Function Block Failed | Channel 1 Fail... | Fault | 1 | | 00:13:46 | | Cartoner | Cleared in 13... |
| 12/16/2009 8:57:11 AM | S32_4 Analo... | Function Block Failed | Channel 1 Fail... | Fault | 1 | 01:04:15 | 00:00:32 | | Cartoner | Cleared in 32 s |
| 12/16/2009 7:48:17 AM | IDV7 Carton ... | Checkweigher Failure | Check Check... | Fault | 1 | 00:00:35 | 00:00:15 | | Cartoner | Cleared in 15 s |
| 12/16/2009 7:45:01 AM | IDV7 Carton ... | Checkweigher Failure | Check Check... | Fault | 1 | 00:02:57 | 00:00:23 | | Cartoner | Cleared in 23 s |
| 12/16/2009 7:39:40 AM | IDV1 Carton ... | Bad Bar Code Scanned | Remove Carto... | Critical Fault | 1 | 00:00:52 | 00:00:39 | | Cartoner | Cleared in 39 s |
| 12/16/2009 7:37:31 AM | IDV1 Carton ... | Bad Bar Code Scanned | Remove Carto... | Critical Fault | 1 | 00:01:33 | 00:01:30 | | Cartoner | Cleared in 1 ... |
| 12/15/2009 6:44:58 PM | PE42306 Sec... | Blocked Too Long | Blocked For 1... | Fault | 2 | 00:05:46 | 00:05:36 | | Cartoner | Cleared in 5 ... |

C40 Filter

Click on the drop down arrow to view history for a particular C40. If a C40 is not listed, there are no messages to display.

Filter Buttons (Fault, Critical Fault, General, Warning, Reject, Debug, Utility, and Unhandled Not Shown)

These buttons represent different notice types. Press any button to filter those notices from the list. Pressing refresh will refresh the screen, displaying only those notice types selected.

- **Fault** – a message describing an unintended event which restricts the system's ability to produce
- **Critical Fault** – same as Fault, except the operator must acknowledge each Critical Fault individually
- **General** – an informational message which relays current existing conditions within the system
- **Warning** – a message describing an event which occurred, or an existing condition, which may cause a problem if not addressed
- **Reject** – a message describing why a product was rejected from the normal flow of product
- **Debug** – a message used during the debug stage of development to monitor for specific desired or undesired events
- **Utility** – a notice used to trigger a software utility
- **Unhandled Not Shown** – a message that is sent from the PLC but not defined in the Message data base
- **Production Data Not Shown** – a message used for production data collection

Individual Items

Click this button to display the items in the grid in chronological order.

NOTE: When **Individual Items** is selected, the button color will be blue

Totaled


Click this button to display the items in the grid in a totaled fashion, displaying the number of times an item occurred. The items all totaled to allow the user to more easily view which items are occurring the most frequently.

NOTE: When **Totaled** selected, the button color will be blue

| Aagard HMI - Notice History | | | | |
|-----------------------------|----------|---------------------------------|-------|--|
| Notice History for Inserter | | | | |
| Device | Location | Message | Count | |
| CS1AE Knife ... | Inserter | Cylinder Extend Switch Not M... | 1 | |
| MS1 Custom... | Inserter | VFD Faulted | 2 | |
| MS1 Custom... | Inserter | Invalid Program Call | 16 | |
| PE6 Register... | Inserter | Sensor Failure | 8 | |
| PE6 Register... | Inserter | Not Made During Startup | 1 | |
| PE2 Web Br... | Inserter | Web Break PE Not Blocked ... | 1 | |
| PE3 Loop Low | Inserter | Eye Not Blocked When Expe... | 10 | |
| SD2 Knife | Inserter | Lag Error | 1 | |
| SD1 Pinwheel | Inserter | Cam Load Failed | 1 | |
| CTRL1 HMI | Inserter | Switching To Sercos Phase 2 ... | 1 | |
| | | | | |
| | | | | |

Edit Notes Button

Select a message in the grid and the Edit Notes Button becomes available. Click on the Edit Notes button to open a dialog window to add your notes to the messages. Double-clicking on the message itself also opens this dialog. Click OK on the dialog when finished.

**Delete All Button**

This button will delete the entire fault log. This will make any generated reports invalid since the Report Generator uses this fault log to generate its reports.

Refresh

This button will refresh the faults on the screen to the most current log at the time the refresh button was pressed, reflected by any filters which may have been selected.

Back Button

This button will return the user to the calling page.

Filter Drop Down List

Click on the drop down arrow to view available filters to apply to the list. Select a filter from the list to apply it. Depending on the selection, additional parameters become available to enter, such as dates and hours.

| | | |
|-----------------|-----------|------------|
| From Date/Time: | 1/ 4/2010 | 5:59:00 AM |
| To Date/Time: | 1/ 4/2010 | 5:59:00 PM |
| Show Last: | 0 Hours | 0 Minutes |

Column Options

To move a column from left to right, select a column from the dropdown list, and click Left or Right to move the column in either direction.

Device Column

This column displays the name of the device which generated the notice.

Message Column

This column displays the message which appeared on the notice. A list of possible messages, causes, and actions are given on the [Message Notices](#) section.

PLC Details Column

This column displays information received from the PLC when the notice was generated.

Shift Column

This column displays the shift in which the notice was recorded.

Down Time Column

This column displays time elapsed between notice display and when the system is started.

Ack Time Column

This column displays the length of time elapsed before the notice was acknowledged.

HMI Details Column

This column displays any additional information received from the HMI when the notice was generated.

Date Stamp Column

This column displays the date and time when the notice was generated.

Notes Column

This column displays any user entered information for the selected notice.

Notice Type

This column displays the type of notice recorded.

Location Column

This column displays the notice location or area of the machine.

Edit Shifts Screen

General Page Information

This screen will display the edit shifts popup section. This will allow the user to edit the shift information for that machine. This will adjust anywhere the shift feature is used, such as the time period drop down menu as described on the [Production Data Page](#). This will also affect the reports that are generated by the Report Generator. The Aagard Report Generator also uses the given shifts to generate the summary reports broken down by shift. More information about the Aagard Report Generator can be found in the Report Generator section.

NOTE: For proper recording and display of production data, the total of all shifts in one day *must* equal 24 hours

SAMPLE IMAGE

The screenshot displays the 'Aagard HMI - Production Data' window. At the top, there is a dropdown menu for 'Shift 1' and a 'Refresh' button. Below this is a 'Shift Start Date' dropdown set to '2/26/2010'. The main area is divided into two columns. The left column lists various performance metrics for the selected shift, such as System Efficiency (0.0%), Reliability (0.0%), MTBF (0S), MTR (0S), Time Since Last Stop (0S), Total Downtime (2H 35M), Total Uptime (0S), Running Time (0S), Idle Time (0S), Fault Count (0), Fault Time (0S), Fault Ack Time (0S), # Of Stops (0), User Stops Time (2H 35M), Starved Time - OOP (0S), Carton Count (0), Case Count (0), Case Reject Count (0), Cube Count (0), and Partial Cube Count (0). The right column is titled 'Edit Shifts' and contains five shift entries. Each entry has a checkbox, a 'Begin' time, and an 'End' time. Shift 1 is checked and has a begin time of 7:00:00 AM and an end time of 3:00:00 PM. Shift 2 is checked with a begin time of 3:00:00 PM and an end time of 11:00:00 PM. Shift 3 is checked with a begin time of 11:00:00 PM and an end time of 7:00:00 AM. Shift 4 is unchecked with a begin time of 9:35:08 AM and an end time of 9:35:08 AM. Shift 5 is unchecked with a begin time of 9:35:08 AM and an end time of 9:35:08 AM. At the bottom of the 'Edit Shifts' panel are 'Save' and 'Cancel' buttons. Below the entire panel are a printer icon and a 'Back' button.

Check Box

This will allow the correct number of shifts to be used to be selected. If a shift is to be used, this box should be checked.

Begin Entry

This will be the begin time for the shift under this entry field.

End Entry

This will be the end time for the shift under this entry field.

NOTE: For proper recording and display of production data, the total of all shifts in one day **must** equal 24 hours.

Save

This button will save the Edit Shifts information and display the [Production Data Page](#).

Cancel

This button will not save any changes made to the Edit Shifts information and display the [Production Data Page](#).

View Notices System Wide

General Page Information

This page keeps a record of all notices generated. This may help with diagnosing any major problems or possible problems. These notices will be stored in the database for three days, and then will be deleted.

SAMPLE IMAGE

| Date Stamp | Device | Message | PLC Details | Notice Type | Shift | Down Time | Ack Time | Notes | Location | HMI Details |
|------------------------|-------------------|-----------------------------|--------------------|----------------|-------|-----------|----------|-------|----------|------------------|
| 11/5/2010 8:02:25 AM | IDV1 Carton ... | Bar Code Scanner Failure | Beckhoff Error ... | Fault | 1 | | | | Cartoner | |
| 1/5/2010 8:02:17 AM | IDV1 Carton ... | Bar Code Scanner Failure | Beckhoff Error ... | Fault | 1 | | | | Cartoner | |
| 12/18/2009 11:03:24 AM | SD5 Side Fil... | Motion Control Reset Error | Servo Drive E... | Fault | 1 | 00:05:53 | 00:00:07 | | Cartoner | Cleared in 7 s |
| 12/17/2009 10:54:09 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:01:21 | 00:00:01 | | Cartoner | Cleared in 1 s |
| 12/17/2009 10:49:24 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:04:07 | 00:00:02 | | Cartoner | Cleared in 2 s |
| 12/17/2009 10:35:31 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:01:13 | 00:00:02 | | Cartoner | Cleared in 2 s |
| 12/17/2009 10:25:25 AM | EN49101 Low... | Lower Film Unwind Danc... | Encoder Pos ... | Fault | 1 | 00:05:37 | 00:00:05 | | Cartoner | Cleared in 5 s |
| 12/17/2009 9:57:13 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:01:16 | 00:00:05 | | Cartoner | Cleared in 5 s |
| 12/17/2009 9:47:40 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:08:48 | 00:08:26 | | Cartoner | Cleared in 8 ... |
| 12/17/2009 9:42:22 AM | SD6 Side Fil... | Fast Stop Failed | MC_ChangeD... | Fault | 1 | 00:03:15 | 00:00:03 | | Cartoner | Cleared in 2 s |
| 12/16/2009 11:07:22 AM | IDV7 Carton ... | Checkweigher Failure | Check Check... | Fault | 1 | 00:00:13 | 00:00:07 | | Cartoner | Cleared in 7 s |
| 12/16/2009 10:43:57 AM | IDV4 Filler B ... | Metal Detected | Metal Detecte... | Critical Fault | 1 | | 00:00:32 | | Cartoner | Cleared in 31 s |
| 12/16/2009 10:43:54 AM | IDV3 Filler A ... | Metal Detected | Metal Detecte... | Critical Fault | 1 | 00:00:49 | 00:00:32 | | Cartoner | Cleared in 32 s |
| 12/16/2009 10:25:38 AM | IDV1 Carton ... | Bad Bar Code Scanned | Remove Carto... | Critical Fault | 1 | 00:02:24 | 00:01:15 | | Cartoner | Cleared in 1 ... |
| 12/16/2009 10:21:47 AM | PE48206 Cart... | Improper Carton Transfer... | Carton Did Not... | Fault | 1 | 00:03:19 | 00:00:18 | | Cartoner | Cleared in 17 s |
| 12/16/2009 9:22:37 AM | S32_4 Analo... | Function Block Failed | Channel 2 Fail... | Fault | 1 | | 00:28:34 | | Cartoner | Cleared in 28... |
| 12/16/2009 9:02:08 AM | S32_4 Analo... | Function Block Failed | Channel 1 Fail... | Fault | 1 | | 00:13:46 | | Cartoner | Cleared in 13... |
| 12/16/2009 8:57:11 AM | S32_4 Analo... | Function Block Failed | Channel 1 Fail... | Fault | 1 | 01:04:15 | 00:00:32 | | Cartoner | Cleared in 32 s |
| 12/16/2009 7:48:17 AM | IDV7 Carton ... | Checkweigher Failure | Check Check... | Fault | 1 | 00:00:35 | 00:00:15 | | Cartoner | Cleared in 15 s |
| 12/16/2009 7:45:01 AM | IDV7 Carton ... | Checkweigher Failure | Check Check... | Fault | 1 | 00:02:57 | 00:00:23 | | Cartoner | Cleared in 23 s |
| 12/16/2009 7:39:40 AM | IDV1 Carton ... | Bad Bar Code Scanned | Remove Carto... | Critical Fault | 1 | 00:00:52 | 00:00:39 | | Cartoner | Cleared in 39 s |
| 12/16/2009 7:37:31 AM | IDV1 Carton ... | Bad Bar Code Scanned | Remove Carto... | Critical Fault | 1 | 00:01:33 | 00:01:30 | | Cartoner | Cleared in 1 ... |
| 12/15/2009 6:44:58 PM | PE42306 Sec... | Blocked Too Long | Blocked For 1... | Fault | 2 | 00:05:46 | 00:05:36 | | Cartoner | Cleared in 5 ... |

C40 Filter

Click on the drop down arrow to view history for a particular C40. If a C40 is not listed, there are no messages to display.

Filter Buttons (Fault, Critical Fault, General, Warning, Reject, Debug, Utility, and Unhandled Not Shown)

These buttons represent different notice types. Press any button to filter those notices from the list. Pressing refresh will refresh the screen, displaying only those notice types selected.

- **Fault** – a message describing an unintended event which restricts the system's ability to produce
- **Critical Fault** – same as Fault, except the operator must acknowledge each Critical Fault individually
- **General** – an informational message which relays current existing conditions within the system
- **Warning** – a message describing an event which occurred, or an existing condition, which may cause a problem if not addressed
- **Reject** – a message describing why a product was rejected from the normal flow of product
- **Debug** – a message used during the debug stage of development to monitor for specific desired or undesired events
- **Utility** – a notice used to trigger a software utility
- **Unhandled Not Shown** – a message that is sent from the PLC but not defined in the Message data base
- **Production Data Not Shown** – a message used for production data collection

Individual Items


Click this button to display the items in the grid in chronological order.

NOTE: When **Individual Items** is selected, the button color will be blue

Totaled

Click this button to display the items in the grid in a totaled fashion, displaying the number of times an item occurred. The items all totaled to allow the user to more easily view which items are occurring the most frequently.


NOTE: When **Totaled** selected, the button color will be blue



| Device | Location | Message | Count |
|-----------------|----------|---------------------------------|-------|
| CS1AE Knife ... | Inserter | Cylinder Extend Switch Not M... | 1 |
| MS1 Custom... | Inserter | VFD Faulted | 2 |
| MS1 Custom... | Inserter | Invalid Program Call | 16 |
| PE6 Register... | Inserter | Sensor Failure | 8 |
| PE6 Register... | Inserter | Not Made During Startup | 1 |
| PE2 Web Br... | Inserter | Web Break PE Not Blocked ... | 1 |
| PE3 Loop Low | Inserter | Eye Not Blocked When Expe... | 10 |
| SD2 Knife | Inserter | Lag Error | 1 |
| SD1 Pinwheel | Inserter | Cam Load Failed | 1 |
| CTRL1 HMI | Inserter | Switching To Sercos Phase 2 ... | 1 |

Edit Notes Button

Select a message in the grid and the Edit Notes Button becomes available. Click on the Edit Notes button to open a dialog window to add your notes to the messages. Double-clicking on the message itself also opens this dialog. Click OK on the dialog when finished.



Delete All Button

This button will delete the entire fault log. This will make any generated reports invalid since the Report Generator uses this fault log to generate its reports.

Refresh

This button will refresh the faults on the screen to the most current log at the time the refresh button was pressed, reflected by any filters which may have been selected.

Back Button

This button will return the user to the calling page.

Filter Drop Down List

Click on the drop down arrow to view available filters to apply to the list. Select a filter from the list to apply it. Depending on the selection, additional parameters become available to enter, such as dates and hours.

| | | |
|-----------------|-----------|------------|
| From Date/Time: | 1/ 4/2010 | 5:59:00 AM |
| To Date/Time: | 1/ 4/2010 | 5:59:00 PM |

| | | | | |
|------------|---|-------|---|---------|
| Show Last: | 0 | Hours | 0 | Minutes |
|------------|---|-------|---|---------|

Column Options

To move a column from left to right, select a column from the dropdown list, and click Left or Right to move the column in either direction.

Device Column

This column displays the name of the device which generated the notice.

Message Column

This column displays the message which appeared on the notice. A list of possible messages, causes, and actions are given on the [Message Notices](#) section.

PLC Details Column

This column displays information received from the PLC when the notice was generated.

Shift Column

This column displays the shift in which the notice was recorded.

Down Time Column

This column displays time elapsed between notice display and when the system is started.

Ack Time Column

This column displays the length of time elapsed before the notice was acknowledged.

HMI Details Column

This column displays any additional information received from the HMI when the notice was generated.

Date Stamp Column

This column displays the date and time when the notice was generated.

Notes Column

This column displays any user entered information for the selected notice.

Notice Type

This column displays the type of notice recorded.

Location Column

This column displays the notice location or area of the machine.

Misc Tags Page

General Page Information


This page is where the HMI stores information needed to operate the machine. Information used here is only temporary and is not retained for the next product change.

| Booleans: | | |
|--------------------------|----|-------------------------------------|
| <input type="checkbox"/> | 1 | Ignore Upstream Sending Product |
| <input type="checkbox"/> | 2 | Ignore Downstream Available |
| <input type="checkbox"/> | 3 | Remove Aagard Available For Product |
| <input type="checkbox"/> | 4 | Force Aagard Sending Product |
| <input type="checkbox"/> | 5 | Ignore Glue System Status |
| <input type="checkbox"/> | 6 | Ignore Vacuum Supply Status |
| <input type="checkbox"/> | 7 | Ignore Multiple Rejects |
| <input type="checkbox"/> | 8 | Clean Out |
| <input type="checkbox"/> | 10 | Enable Case Refeed |
| <input type="checkbox"/> | 11 | QC Case |
| <input type="checkbox"/> | 23 | Load Cups Clean Out |

? Button

This button will display the **Misc Data Definition Popup**. This popup contains the definition for the related Misc Tag. To close the popup, click the red X in right corner, click outside the popup, or press Esc. **NOTE:** If logged in at Aagard level, this definition is editable.

SAMPLE IMAGE



Back Button

This button will display the [Advanced Page](#).

Change Log Page

General Page Information

This page will display any changes that have been made to the Aagard HMI database. This excludes any cam changes made, which are allowable and will not be displayed here. The drop down list filter in the bottom left corner of this page will allow a specific time period to be selected. The changes logged will be deleted after three months.

SAMPLE IMAGE

| Location | Field | Old Value | New Value | Product | Notes | Who | Change... | Changed Time |
|---------------|------------------------|-----------|-----------|------------|-------|---------|-----------|--------------|
| General D... | Gen#27 | 0 | 235 | 684 Carton | | Aaga... | 11/2/2009 | 11:03:40 AM |
| Solenoid ... | SV#45405 Configuration | 0 | 2 | 356 Carton | | aaga... | 8/26/2009 | 4:01:34 PM |
| Motor Dat... | MT#503 AnalogSpeed | 0 | 1 | 356 Carton | | aaga... | 8/26/2009 | 4:01:06 PM |
| Motor Dat... | MT#516 AnalogSpeed | 0 | 1 | 356 Carton | | aaga... | 8/26/2009 | 4:01:03 PM |
| Motor Dat... | MT#603 AnalogSpeed | 0 | 1 | 356 Carton | | aaga... | 8/26/2009 | 4:01:01 PM |
| Motor Dat... | MT#616 AnalogSpeed | 0 | 1 | 356 Carton | | aaga... | 8/26/2009 | 4:00:58 PM |
| Motor Dat... | MT#1703 AnalogSpeed | 0 | 1 | 356 Carton | | aaga... | 8/26/2009 | 4:00:55 PM |
| Motor Dat... | MT#10015 ATime | 1 | 0 | 356 Carton | | aaga... | 8/26/2009 | 4:00:46 PM |
| Motor Dat... | MT#10015 OffTime | 1 | 0 | 356 Carton | | aaga... | 8/26/2009 | 4:00:44 PM |
| Motor Dat... | MT#1703 OffTime | 0 | .2 | 356 Carton | | aaga... | 8/26/2009 | 4:00:35 PM |
| Motor Dat... | MT#1703 ATime | 0 | .2 | 356 Carton | | aaga... | 8/26/2009 | 4:00:32 PM |
| Motor Dat... | MT#616 OffTime | 1 | .5 | 356 Carton | | aaga... | 8/26/2009 | 4:00:28 PM |
| Motor Dat... | MT#616 ATime | 1 | .5 | 356 Carton | | aaga... | 8/26/2009 | 4:00:26 PM |
| Motor Dat... | MT#516 OffTime | 0 | .2 | 356 Carton | | aaga... | 8/26/2009 | 4:00:15 PM |
| Motor Dat... | MT#516 ATime | 0 | .2 | 356 Carton | | aaga... | 8/26/2009 | 4:00:13 PM |
| Servo Driv... | SD#45 Move#8 Decel | 0 | 20 | 356 Carton | | aaga... | 8/26/2009 | 3:59:49 PM |
| Servo Driv... | SD#45 Move#8 Accel | 0 | 20 | 356 Carton | | aaga... | 8/26/2009 | 3:59:47 PM |
| Servo Driv... | SD#45 Move#8 Velocity | 0 | 27 | 356 Carton | | aaga... | 8/26/2009 | 3:59:44 PM |
| Servo Driv... | SD#45 Move#8 Position | 0 | 15 | 356 Carton | | aaga... | 8/26/2009 | 3:59:41 PM |
| Servo Driv... | SD#45 Move#7 Decel | 0 | 65 | 356 Carton | | aaga... | 8/26/2009 | 3:59:33 PM |
| Servo Driv... | SD#45 Move#7 Accel | 0 | 65 | 356 Carton | | aaga... | 8/26/2009 | 3:59:31 PM |
| Servo Driv... | SD#45 Move#7 Velocity | 0 | 30 | 356 Carton | | aaga... | 8/26/2009 | 3:59:29 PM |
| Servo Driv... | SD#45 Move#7 Position | 0 | 15 | 356 Carton | | aaga... | 8/26/2009 | 3:59:26 PM |
| Servo Driv... | SD#45 Move#6 Decel | 0 | 30 | 356 Carton | | aaga... | 8/26/2009 | 3:59:19 PM |
| Servo Driv... | SD#45 Move#6 Accel | 0 | 30 | 356 Carton | | aaga... | 8/26/2009 | 3:59:15 PM |
| Servo Driv... | SD#45 Move#6 Velocity | 0 | 30 | 356 Carton | | aaga... | 8/26/2009 | 3:59:13 PM |
| Servo Driv... | SD#45 Move#6 Position | 0 | 30 | 356 Carton | | aaga... | 8/26/2009 | 3:59:11 PM |

Below the table, there is a dropdown menu set to "Show Latest 50". At the bottom right, there are three buttons: "Delete All", "Refresh", and "Back".

Delete All

This button will delete the entire contents of the change log. This will make any change log section of the generated reports invalid because the report generator uses this change log to generate its reports.

Refresh

This button will refresh the changes on the screen to the most current log at the time the refresh button was pressed.

Back Button

This button will display the [Advanced Page](#).

Filter Drop Down List

Click on the drop down arrow to view available filters to apply to the list. Select a filter from the list to apply it. Depending on the selection, additional parameters become available to enter, such as dates and hours.



From Date/Time: 1/ 4/2010 5:59:00 AM
To Date/Time: 1/ 4/2010 5:59:00 PM



Show Last: 0 Hours 0 Minutes

Location Column

This column will display on which page the change was made.

Field Column

This column will display the name of the field to which the change was made.

Old Value Column

This column will record what the value was before the change was made.

New Value Column

This column will record what the value is after the change was made.

Product Column

This column will display the product downloaded when the change was made.

Notes Column

This column will display any notes that were entered by the user into the notes popup after the change was made.

Who Column

This column will display the user that was logged on at the time of the change.

Changed Date Column

This column will display the date that the change was made.

Changed Time Column

This column will display the time that the change was made.

Glue Page


General Page Information

If this feature is installed, this page allows the user to easily adjust the available glue pattern. This page shows the product as it moves through the glue heads looking at it from the operator (HMI) side of the machine (*The direction of the blue arrow indicates the direction of product flow*).

Stitch Adjust Information

To display the stitch adjustment popup in the bottom center of the screen, click on any red glue stitch that needs to be adjusted. This popup will display all the adjustment information for the selected stitch.

SAMPLE IMAGE



- **On**

This is the on point of the selected stitch. **NOTE:** The ON value must be less than the OFF value!

- **Off**

This is the off point of the selected stitch. **NOTE:** The OFF value must be greater than the ON value!

- **Left Arrow**

This arrow will move the selected stitch point to the left relative to the product shown in the picture.

- **Right Arrow**

This arrow will move the selected stitch point to the right relative to the product shown in the picture.

- **Master Offset**

This will adjust the start of the cam relative to the designated servo axis. Usually the cam will relate to a position of a servo axis that is moving the product, such as flight chains.

- **Stitch Gap %**

This is the percent of glue stitch that is taken out of the center of the selected glue stitch.

NOTE: This setting applies to Case Packers only!

- **Use Gap Check Box**

This will allow the user to decide if there is to be a gap stitch applied or a full stitch applied.

NOTE: This setting applies to Case Packers only, when this feature is enabled!

Edit

This button will open the page in edit mode. **Aagard user level required!**

Back

This button will display the [Advanced Page](#).

Motor Data Page

General Page Information

The configuration of each non servo motor is contained in this screen. Changing the configuration of any motor can greatly affect how the machine functions.

Motor Parameter Fields

Motor Parameter Entry Fields

These parameters are described in further detail in the Motor Data Page Items topic.

SAMPLE IMAGE

Aagard HMI - Data Input - Motor

Motor:
 (3) 1115 - Layer Pad Magazine

Configuration: 3) VFD

"Forward" Time: 0 Seconds

"Reverse" Time: 0 Seconds

Change Director Delay: 0 Seconds

"Forward" Sensor:

"Reverse" Sensor:

Notes: **Edit**

This motor advances the Layer Pad blanks in the Layer Pad Magazine.
 (0.599 FPM @ 60 Htz)

Copy From... **Back**

Motor


To access different motors, use the motor drop down list.

Notes

These notes can be edited by pressing the **Edit Button** located to the bottom right of the SD Notes Box. Once the Edit Button has been pressed, the text on the Edit Button will change to "Save" and the notes are now able to be edited. After the notes are edited, the **Save Button** will have to be pressed in order for the notes to be saved.

Copy From Button

This button will allow all the data from another motor to be copied and replace all of the data for the currently selected motor. This feature may be useful when setting up a new motor. Pressing this button will display the **Copy From Popup**.

**Back Button**

This button will close and save any changes and go to the [Data Input Page](#).

Solenoid Data Page

General Page Information

The configuration of each solenoid valve controlled actuator is contained on this screen. Changing the configuration of a valve can greatly affect how the machine functions. For instance, a solenoid valve controlling vacuum must have the configuration data of a vacuum valve. A vacuum controlling solenoid valve must also have the A Sensor activated because a vacuum sensor is connected to this input. Thus, the "A" Time is the time allowed for a vacuum to be made. If a cylinder is slowed via the flow controls and the cylinder does not make the cylinder switch in the time displayed in 'sensor time', then the cylinder will give a "Jam" fault. If it is desired to slow a cylinder, make sure that the time for that direction is raised to accommodate the slower action time.

Solenoid Valve Parameters Fields

Solenoid Valve Parameter Entry Fields

The solenoid valve parameters that can be specified for a specific solenoid valve are Configuration, "A" Time, "B" Time, "DeBounce" Time, "Jam" Time, "A" Sensor, and "B" Sensor. View the Solenoid Data Page Items page for more information on each field.

SAMPLE IMAGE

Solenoid Valve


To access different solenoid valves, use the solenoid valve drop down list.

Notes

These notes can be edited by pressing the **Edit Button** located to the bottom right of the SD Notes Box. Once the Edit Button has been pressed, the text on the Edit Button will change to "Save" and the notes are now able to be edited. After the notes are edited, the **Save Button** will have to be pressed in order for the notes to be saved.

Copy From Button

This button will allow all the data from another solenoid valve to be copied and replace all of the currently selected solenoid valve data. This feature may be useful when setting up a new solenoid valve. Pressing this button will display the **Copy From Popup**.

**Back Button**

This button will close and save any changes and go to the [Data Input Page](#).

Servo Drive Data Page

General Page Information

This page shows Servo Drive Data for each Servo Drive on the machine. This page is identical to the [Servo Drive Data Page](#), with the addition of one check mark box in the bottom left hand corner of the screen labeled "Include This Servo In Initialization". Checking this box will do a full initialization to the Servo Drive that is currently selected the next time an initialization is done. A full initialization will load all the parameters specified under the Initialization Column on the [Servo Drive Data Page](#). Information about the parameters on this page can be found under the [Servo Drive Data Page](#).

User Level 3 required!

Initialize Data Section

Initialize Data Category

The machine controller uses this data in the machine start up to configure each servo axis. This data will require a full initialize on that servo axis before the changes will take effect. More information on how to do a full initialize on a servo axis can be found on the [Start Up Page](#).

Referencing Data Section

Referencing Data Category

This data is for machine referencing of the currently selected servo axis. Data changed in this category will take effect immediately after entering the data.

Jog Data Section

Jog Data Category

This data is used while in manual mode and jogging the currently selected servo axis. Data changed in this category will take effect immediately after entering the data.

Motion Data Section

Motion Data Category

This data is used as default variables and starting speeds for the currently selected servo axis. Data changed in this category will take effect immediately after entering the data.

Cam Data Section

Cam Data Category

This data is used when the axis is cam coupled to a master. If zero is specified, the default value in the Motion Data Category will be used. Data changed in this category will take effect immediately after entering the data.

Torque Monitoring Section

Torque Monitoring Category

This data is used as default variables and starting speeds for the currently selected servo axis. Data changed in this category will take effect immediately after entering the data.

SAMPLE IMAGE

Servo Drive: (5) 5 - Carton Picker

Standard | **Advanced**

Initialize Data

Motion Type: Rotary
Unit: Inches
Feed Forward:
Negate Feedback:
Inches Per Revolution: 0
Input Revolutions: 10
Output Revolutions: 1
Feedback Reference: Load
Modulo: 0
Velocity Limit: 1500
Max Velocity Limit: 3,476.772
Accel Limit: 100000000
Max Accel Limit: 116,889,663.063
In Position Bandwidth: 1
In Position Monitor Time: 0
Disable Drive Loop Monitoring: (WARNING! This also disables runaway detection!)
Enable Probe:
Probe Direction: Bi-Directional

Referencing Data

Standard Referencing:
Referencing Type: Switch Rev
Referencing Direction: Positive
Ref Verification Type: None
Torque: 50
Reference Velocity: 30
Low Velocity: 20
Accel: 720
Decel: 720
End Position: 0
Reference Position: -12
Sensor Clear Dist: 30
Sensor Compare Pos.: 0
Sensor Bandwidth: 0
Lag Limit: 0
Move #: 1

Motion Data

Default Velocity: 30
Default Accel: 250
Default Decel: 250
Default Torque: 180
Default Lag Limit: 5
E-Stop Recovery Accel: 250
E-Stop Fast Decel: 500

Cam Data

Master Offset Step: 0.01
Slave Offset Step: 0.1
Torque Limit: 0
Lag Limit: 0

Torque Monitoring

Torq. Averaging Count: 2
Torq. Warning Threshold %: 100

Jog Data

Move #: 2
Accel: 250
Decel: 250
Torque Limit: 50
Lag Limit: 0

Notes

Edit

11 Drive Status
Act Pos: 0.000
Max Pos. Err: 0.000 [Reset](#)
Max Torq: 0.000 [Reset](#)
Disabled

Diagnose Copy From... Back

Servo Drive

To access different servo drives, use the servo drive drop down list.

Notes

These notes can be edited by pressing the **Edit Button** located to the bottom right of the SD Notes Box. Once the Edit Button has been pressed, the text on the Edit Button will change to "Save" and the notes are now able to be edited. After the notes are edited, the **Save Button** will have to be pressed in order for the notes to be saved.

Drive Status Box


This box is located in the bottom left corner of this page. Information that is given is Actual Position, Max Position Error, Max Torque, and State of the Servo Drive. More information can be found on the [Drive Diagnostics Page](#).

Diagnose

This button will display a diagnostic popup for the currently selected Servo Drive. This diagnostic popup is described in further detail on the [Drive Diagnostics Page](#).

Copy From Button


This button will allow all the data from another servo axis to be copied, replacing all of the data for the currently selected servo axis. This feature may be useful when setting up a new servo axis. Pressing this button will display the **Copy From Popup**.

**Back Button**

This button will close and save any changes and go to the [Data Input Page](#).

Servo Drive Data Page - Advanced Tab

SAMPLE IMAGE



Reference Mark Location

The Reference Mark Location is a precise description of the reference mark placement in relation to a fixed member of the machine.

Direction of Positive Movement

The Direction of Positive Movement is the direction of movement which causes a positive change in the position read out.


Reference Mark Position

The Reference Mark Position is the position the servo reads when lined up with the reference mark.

Precision

Change the precision setting for the selected drive. **WARNING: Data loss will occur when going from higher precision to lower!**

Reference Image

The Reference Image is the image that will display at the end of the reference routine. Push the  button to browse to the image file location.

Note: The image can only be 640 x 480 max.

Drive Status Box


This box is located in the bottom left corner of this page. Information that is given is Actual Position, Max Position Error, Max Torque, and State of the Servo Drive. More information can be found on the [Drive Diagnostics Page](#).

Diagnose

This button will display a diagnostic popup for the currently selected Servo Drive. This diagnostic popup is described in further detail on the [Drive Diagnostics Page](#).

Copy From Button

This button will allow all the data from another servo axis to be copied, replacing all of the data for the currently selected servo axis. This feature may be useful when setting up a new servo axis. Pressing this button will display the **Copy From Popup**.

**Back Button**

This button will close and save any changes and go to the [Data Input Page](#).

Alternating Jog

SAMPLE IMAGE

| Alternating Jog | |
|--------------------------------------------------|-------------------------------------------------|
| Position 1: | 0 |
| Position 2: | 0 |
| Alt Dwell: | 0 |
| Velocity: | 0 |
| Accel: | 0 |
| Torque: | 0 |
| Pos Err Limit: | 0 |
| <input type="button" value="Start Alternating"/> | <input type="button" value="Stop Alternating"/> |

Position 1 Entry Field

This entry field should specify the first position at which the axis should stop.

Position 2 Entry Field

This entry field should specify the second position at which the axis should stop.

Alt Dwell Entry Field

This entry field should specify how long the axis should stop at each position entered in the Position 1 and Position 2 entry fields.

Velocity Entry Field

This entry field should specify the max velocity at which the axis should be allowed to travel. If 0 is specified, then the Default Velocity specified on the [Servo Drive Data Page](#) will be used.

Accel Entry Field

This entry field should specify the acceleration rate the axis should use to accel to the specified velocity. This value will also be used for the deceleration rate. If 0 is specified, then the Default Accel specified on the [Servo Drive Data Page](#) will be used.

Torque Entry Field

This entry field should specify the torque limit the axis should use while executing the alternating jog moves. If 0 is specified, then the Default Torque specified on the [Servo Drive Data Page](#) will be used.

Pos Err Limit Entry Field

This entry field should specify the position error limit the axis should use while executing the alternating jog moves. If 0 is specified, then the Default Lag Limit specified on the [Servo Drive Data Page](#) will be used.

Start Alternating Button

Pressing this button will start the alternating jog moves as long the mode is manual and the state is ready. Getting the machine to the correct mode and state can be accomplished by starting the machine as if in automatic mode and product was going to be cycled through the machine.

Stop Alternating Button

Pressing this button will stop the axis from executing the alternating jog moves.

Servo Drive Tuning

SAMPLE IMAGE

| Tuning | | Default | |
|-------------------------------------|----------------------------------|---------|-----------------------|
| Velocity Prop. Gain (Kp): | <input type="text" value="1"/> | 1 | Apply Tuning Settings |
| Velocity Integral Action Time (TN): | <input type="text" value="5"/> | 5 | |
| Position Prop. Gain (Kv): | <input type="text" value="1"/> | 1 | Set To Default |
| Rejection Frequency: | <input type="text" value="600"/> | 600 | |
| Rejection Bandwidth: | <input type="text" value="0"/> | 0 | |

Velocity Prop. Gain (Kp) Entry Field

This entry field should specify the proportional gain of the velocity loop of the servo.

Velocity Integral Action Time (TN) Entry Field

This entry field should specify the integral action time of the velocity loop of the servo.

Position Prop. Gain (Kv) Entry Field

This entry field should specify the proportional gain of the position loop of the servo.

Rejection Frequency Entry Field

This entry field should specify the rejection frequency of the servo.

Rejection Bandwidth Entry Field

This entry field should specify the rejection bandwidth of the servo.

Default Column

This column displays the default values for all the tuning entry fields listed above.

Apply Tuning Settings Button

Pressing this button will apply the settings entered into the entry fields listed above.

Set To Default Button

Pressing this button will set all the tuning entry fields listed above to the values displayed in the Default Column.

Manual SD Enabling

This page is used to activate the manual servo enabling feature. When activated, individual servos may be enabled on this page or on the jog page.

| Servo Drive Name | Status | Action |
|-----------------------------------------|--------|---------------------|
| SD: 24 - Metering Conveyor | Green | Disable Servo Drive |
| SD: 25 - Upstream Correction Conveyor | Red | Enable Servo Drive |
| SD: 26 - Downstream Correction Conveyor | Red | Enable Servo Drive |
| SD: 27 - Launch Conveyor | Red | Enable Servo Drive |
| SD: 28 - Fixed Fan Feeder | Red | Enable Servo Drive |
| SD: 29 - Adjustable Fan Feeder | Red | Enable Servo Drive |
| SD: 30 - Overhead Sweep | Red | Enable Servo Drive |
| SD: 31 - Carton Picker | Red | Enable Servo Drive |
| SD: 33 - Barrel Cam | Red | Enable Servo Drive |
| SD: 34 - Side Flap Tucker | Red | Enable Servo Drive |
| SD: 35 - Side Compression | Red | Enable Servo Drive |
| SD: 36 - Upstream End Tuck | Red | Enable Servo Drive |
| SD: 37 - Downstream End Tuck | Red | Enable Servo Drive |
| SD: 39 - Discharge / Reject | Red | Enable Servo Drive |
| SD: 45 - Moon Nip | Red | Enable Servo Drive |
| SD: 46 - Cartoner Master | Red | Enable Servo Drive |
| SD: 32 - Nip Belt | Red | Enable Servo Drive |
| SD: 38 - Carton Flights | Red | Enable Servo Drive |

Pressing the Activate Manual Enabling button will cause all of the servo drives in this machine/C40 to be disabled!

Deactivate Manual Enabling Back

Servo Drive Name and ID

This label represents the name of the servo drive and its ID

Status Light

This light represents the actual enabled or disabled status of the servo drive. When the drive is enabled, the status light will be green. When the drive is disabled, the status light will be red.

Enable/Disable Servo Drive Button

Click this button to enable or disable this servo drive. If the drive is currently enabled, the button color will be green and the text will read Disable Servo Drive. If the drive is currently disabled, the button color will be red and the text will read Enable Servo Drive.

NOTE: This feature is only available with the correct PLC framework version in place

NOTE: This button will only be enabled when Manual Enabling is activated

Up/Down Navigation Buttons

Up and down navigation buttons will appear when not all servo drives fit onto one screen. When drives exist above the first drive shown at the top of the screen, a button with an up arrow will be displayed. When drives exist below

the last drive shown on the bottom of the screen, a button with a down arrow will be displayed.

Activate/Deactivate Manual Enabling

Press this button to activate or deactivate manual enabling of servo drives. When activated, the button color will be green and the text will read Deactivate Manual Enabling. When deactivated, the button color will be red and the text will read Activate Manual Enabling.


NOTE: When activating manual enabling, all currently enabled servo drives will become disabled

Back Button

Click here to return to the page which called this page.

Edit System Product Page

SAMPLE IMAGE




This list contains all the currently available System Products to be edited. When a System Product is selected, the appropriate C40 Recipes will be shown in the C40 Recipes Drop Down Menus to the right of the System Products List.

Cartoner Recipe

The Cartoner Recipe drop down menu contains the name of the recipe used for the currently selected product. If the machine includes a Cartoner, Case Packer, and Palletizer there will be three different Recipe drop down menus.

New Button

If the New Button is pressed, the S10 Product Name Popup will appear. This is where the new product's name will be declared for the first time.




Product Name

This entry field is where the name of the new product will be defined. The text that is entered here will be exactly what is displayed on the [Product Download Page](#).

The **OK Button** can then be pressed if the information is to be saved, or the **Cancel Button** will close the popup and save nothing new.

Rename Button

This button will allow the currently selected product to be renamed. When this button is pressed, a popup will appear. Replace the old name with the new name. The **OK Button** can then be pressed if the information is to be saved, or the **Cancel Button** will close the popup and save nothing new.



Delete

If this button is pressed, the current selected product will be deleted from the System Products list.

Edit C40 Recipes Button


This button will display the [Edit C40 Recipes Page](#).

Import Recipes

This button will display the Import Recipes Page. **Aagard level required!**

Copy Changeover Data From

The Copy Changeover Data From button allows a particular system product to be selected and have changeover data product values copied over to it.




Back Button

This button will close and save any changes and go to the [Product Download Page](#).

Edit C40 Recipes Page


SAMPLE IMAGE



C40s Selection Tabs

The selection tabs will display the list of recipes for each C40 selectable by the selection tabs.


- **C40 Recipes List** - This list contains all the currently created recipes for the C40 selected by the C40s Selection Tab.
- **New Button** - If the New Button is pressed, the C40 Recipe Name Popup will appear. This is where the new recipe's name will be declared for the first time.



- **Recipe Name Entry Field** - This entry field is where the name of the new recipe will be defined. The **OK Button** can then be pressed if the information is to be saved, or the **Cancel Button** will close the popup and save nothing new.
- **Rename Button** - This button will allow the currently selected recipe to be renamed. When this button is pressed, a popup will appear. Replace the old name with the new name. The **OK Button** can then be pressed if the information is to be saved, or the **Cancel Button** will close the popup and save nothing new.



- **Delete Button** - This button will delete the current recipe selected.
- **Copy Data From Button** - This button, when pressed, will go through the process of copying the recipe information from another recipe to the current recipe selected. This will prompt for a previously created recipe to be selected from the Copy Recipe From Popup. If no recipes have been previously created, nothing will be available in the drop down menu. After a recipe has been selected, the **OK Button** will complete the operation and the **Cancel Button** will close the popup and save nothing new.



Back Button

This button will close and save any changes and go to the [Edit System Products Page](#).

Changeover Adjustments Page


General Page Information

This page provides a list of adjustments and values for the currently downloaded product. Values are adjustable from this page.

Columns indicate the Adjustment Name, Value, and Description.

SAMPLE IMAGE

| Current Product: | | |
|------------------|---------------|----------------------------------------|
| 2-1 | 88 | Operator Side Magazine Width |
| 2-2 | 21 | Non-Operator Side Magazine Width |
| 2-3 | 180 | Non-Operator Side Magazine Rotate Clip |
| 2-4 | 205 | Operator Side Magazine Rotate Clip |
| 2-5 | 380 | Top Clip |
| 2-6 | 42 | Bedplate Width |
| 2-7 | 100 EXTEND | Product Stop - Upper |
| 2-8 | EXTEND | Product Stop - Lower |
| 2-9A | 1/4" DOWN FRO | Flap Tucker - Upper |
| 2-9B | 145 | Flap Tucker - Lower |
| 2-10 | LOWER | Robot Pick Cups |
| 2-11 | 185 | Robot Case Pusher Horizontal |
| 2-12 | 330 | Robot Case Pusher Vertical |
| 2-13 | ON | 5th Cup Vacuum Control Valve |
| 2-14 | OFF | 4th Cups Vacuum Control Valve |

Buttons:  **Export List Of All Values For All Products** **ReArrange** **Back**

Export List Of All Values For All Products Button

This button will export a list of all values for all products in default order to a Microsoft Excel file, which may also be opened by other application programs.

ReArrange Button

This button will display the [ReArrange Page](#).

Rearrange Page

General Page Information

This will allow the changeover order be adjusted when changing from one product to another. Having the changeover adjustments in the correct order for all the different size changes may eliminate any possible interferences that may occur.


SAMPLE IMAGE

Agard HMI - Data Input - Adjustment Order

Product Combination: From: 684 Carton To: 699 Carton

| Number | Default Order | Modified Ord | Name |
|--------|---------------|--------------|----------------------------------|
| 1-1 | 1 | -1 | Infeed Conveyor Width |
| 1-2 | 2 | -1 | Blank Backstop Width |
| 1-3 | 3 | -1 | Bucket Changeout |
| 1-4 | 4 | -1 | Backstop Offset |
| 1-5 | 5 | -1 | Side Seam Compression |
| 1-6 | 6 | -1 | Nip Belt Height |
| 1-7 | 7 | -1 | Picker Arm-Change Part |
| 1-8 | 8 | -1 | Magazine Height |
| 1-9 | 9 | -1 | Top Carton Drive Height |
| 1-10 | 10 | -1 | Carton Blank Width |
| 1-11 | 11 | -1 | Magazine Horizontal Adjustment |
| 1-12 | 12 | -1 | Carton Slot Guide |
| 1-13 | 13 | -1 | Upper Carton Clamp |
| 1-14 | 14 | -1 | Lower Carton Clamp |
| 1-15 | 15 | -1 | Upper Flite Chain Width |
| 1-16 | 16 | -1 | Lower Flite Chain Width |
| 1-17 | 17 | -1 | Tucker Height |
| 1-18 | 18 | -1 | Operator Upstream Glue Height |
| 1-19 | 19 | -1 | Operator Lower Compression Plate |
| 1-20 | 20 | -1 | Operator Downstream Glue Height |
| 1-21 | 21 | -1 | Operator Upper Compression Plate |
| 1-22 | 22 | -1 | Discharge Conveyor Width |
| 1-23 | 23 | -1 | Domino Laser Position |
| 1-24 | 24 | -1 | After Tuck Rail |

If the Modified Order Value = "-1" then the Default Order Value will be used in its place.
 Changing The Default Order will change it for all Product Combinations.

 **Back**

Product Combination Drop Down List

This list will allow the correct product combination to be selected when going from a particular product to another product.

Number Column

This column will show the different adjustment changeover numbers.

Default Order Column

This column will show the changeover adjustment's default order that is displayed on the [Adjustments Page](#). This order can be changed from this page. This will change the default order on all sizes.

Modified Order Column

This will show the changeover adjustment's modified order. This column can be different depending on what Product Combination is selected. If the order needs to be modified, change the -1(Default Order) in the Modified Order Column to the appropriate number that will place it correctly in the Default Order.

Name Column

This column will display the changeover adjustment names.

General Data Page

General Page Information

The data contained on this page is provided as a means to adjust certain running parameters. These values pertain to the current downloaded product only. If changes are desired on any other products, a product download will have to be performed and then changes made to that specific downloaded product.

[Case Packer General Data Page Items](#)

[Palletizer General Data Page Items](#)

? Button

This button will display the **General Data Definition Popup**. This popup contains the definition for the related General Data item. To close the popup, click the red X in top right corner, click outside the popup, or press Esc.

NOTE: If logged in at Aagard level, this definition is editable.



Back Button

This button will display the [Data Input Page](#).

Servo Moves Data Page

General Page Information

This screen provides a means to adjust servo axis move parameters. Most servo-controlled motions use this move data.

SAMPLE IMAGE

Aagard HMI - Data Input - Servo Drive Moves
Current Recipe: #1 (684 Carton)

Servo Drive: 5 - Carton Picker

Move: 3 - Alt Jog 1 (Auto Calc)

Position: 0 (Default)

Velocity: 0 (Default 360)

Accel: 0 (Default 720)

Decel: 0 (Default 720)

Torque: 0 (Default 150)

Position Error Limit: 0 (Default 4.000)

Servo Modulo: 0.000

Notes: This is Designated As The Alternate Jog 1 Move (Go To the Jog Page To Change).

5 Drive Status
Act Pos: 0.000
Max Pos. Err. 0.000
Max Torq. 0.000
Disabled

Smoothest Triangle Move (Dist, Time)

| Time | Dist | Time into 1st Seg |
|---------|------|----------------------|
| Seg1: | | Dist: Vel: |
| Seg2: | | Dist into 1st Seg: 0 |
| Totals: | | Time: Vel: |

Diagnose
Back

Servo Drive

To access different servo drives, use the servo drive drop down list.

Move

Each servo axis has a collection of moves accessible via the drop down menu. Some of these are auto calculated by the controller and values don't need to be entered for these moves. Move numbers 1 through 5 are always auto calculated. Any move numbers higher than 5 will be labeled if they are auto calculated.

New

This button will display a **New Move Popup** window. This feature will allow a new move to be created.



SD # Entry Field - This number should be the same as the Servo Drive number for which the move needs to be created.

Number - This number is equal to the move number that is specified in the controller program for this move.

Name - This is where the name of the move should be specified.

OK Button - This button will save any new information and close the popup window.

Cancel Button - This button will not save any new information and close the popup window.

Rename Button

This button will display a **Rename Move Popup** window. This feature will allow an existing move to be renamed.



Name - This is where the name of the move should be specified.

OK Button - This button will save any new information and close the popup window.

Cancel Button - This button will not save any new information and close the popup window.

Delete Button

This button will delete the currently selected move for the currently selected servo drive.

Servo Axis Move Parameters Entry Field Column

The move parameters that can be specified for a specific move are Position, Velocity, Accel, Decel, Torque, and Position Error Limit. These parameters are described in further detail on the [Servo Modes Data Page Items](#) topic.

Default Fields

This column will display the default parameters set in the [Servo Drive Data Page](#) for the selected servo drive.

Notes

These notes can be edited by pressing the **Edit Button** located to the bottom right of the SD Notes Box. Once the Edit Button has been pressed, the text on the Edit Button will change to "Save" and the notes are now able to be edited. After the notes are edited, the **Save Button** will have to be pressed in order for the notes to be saved.

Drive Status Box

This box is located in the bottom left corner of this page. Information that is given is Actual Position, Max Position Error, Max Torque, and State of the Servo Drive. More information can be found on the [Drive Diagnostics Page](#).

Servo Move Calculator Box

This box will display different types of possible move calculators depending on what is selected in the Servo Move Calculator Drop Down Menu. This tool will allow information about a move to be calculated once the required information is entered.

Diagnose

This button will display a diagnostic popup for the currently selected Servo Drive. This diagnostic popup is described in further detail on the [Drive Diagnostics Page](#).

Back Button


This button will close and save any changes and go to the [Data Input Page](#).

Cam Offsets Page

General Page Information

This screen allows the user to slightly adjust a complete cam while the machine is operating. It may be convenient to make slight adjustments to a cam while the machine is still in operation. Individual parts of the cam can't be adjusted from this page, but the whole cam can be adjusted slightly earlier or later. The servo drive start position of the cam can also be adjusted slightly from this page. CAUTION! Changes made here may greatly affect the performance of this machine.

SAMPLE IMAGE



Servo Drive

To access different servo drives, use the servo drive drop down list.

Solenoid Valve

To access different solenoid valves, use the solenoid valve drop down list.

Master Offset

This entry field will adjust the master offset of the cam for the selected device. This will offset the cam for the selected device by the Master Distance. For example: At 0 the cam and master will both start at the same time. If 5 is entered in the Master Offset Entry Field the cam will now be advanced by a Master Position of 5. If -5 is entered in the Master Offset Entry Field the cam will now be delayed by a Master Position of 5.

Slave Offset Entry Field

This entry field will adjust the slave offset of the cam for the selected drive. For example: At 0 the slave will start at the position specified by the cam in cam generator. If 5 is entered in the Slave Offset Entry Field the slave will now start the cam at the position specified in the cam plus 5 units. If -5 is entered in the Slave Offset Entry Field the slave will now start the cam at the position specified in the cam minus 5 units. The units will vary depending on how the drive is configured. The units of the drive are specified on the Servo Drive Data Page.

Diagnose

This button will display a diagnostic popup for the currently selected Servo Drive. This diagnostic popup is described in further detail on the [Drive Diagnostics Page](#).

Back Button

This button will close and save any changes and go to the [Data Input Page](#).

Cam Data Page

General Page Information

A device cam is an electronic coupling of one or more devices to a master. The Cam Data Input Page contains the master/slave positions for each device. The slave is electronically coupled to the master by position, and the table contains those position to position couplings. The points in the table are also shown on a graph. The cams are very tightly coupled with the master and even a slight position change can greatly affect machine function.

SAMPLE IMAGE

Cam Table: Current Recipe: #1 (684 Carton)

16 - Magazine Vacuum (SV)

Cam Table Length: 3 Currently Looking at #: 0

Remove From Cam Generator New Rename Delete

| | 1 | 2 | 3 |
|-------------|---|-----|------|
| Master Pos: | 0 | 400 | 1050 |
| Slave Pos: | 0 | 1 | 0 |

Notes: Edit

Slave Pos of -1 = OFF (B Coil)
 Slave Pos of 0 = OFF (B Coil)
 Slave Pos of 1 = ON (A Coil)
 Magazine Master is the master for this cam.

Refresh Graph Graph All (Slow) Graph Current Slope Graph Square Wave Graph

Position (Max: 1.00000, Min: 0.00000)

Depending on the type of cam you have selected, some of these fields could have different definitions. Click a button below to view more information on that specific cam type.

Servo Drive Solenoid Valve Motor

Cam Generator Back

Cam Table

This is a drop down menu to allow any solenoid valve or motor cam to be selected. The data being displayed on the page pertains to the selected cam.


Remove From Cam Generator

Press this button to remove the selected cam from Cam Generator. **Use with caution!**

Aagard level required!

New


This button will display the **New Cam Popup** which will create a new cam.



- **Number Entry Field** - This entry field is for the new cam ID number.
- **Name Entry Field** - This entry field is for the new cam name.
- **OK Button** - This button will close and save the information entered.
- **Cancel Button** - This button will close but not save the information entered.

Rename

This button will display the **Rename Cam Popup** which will allow the currently selected cam to be renamed.



- **Name Entry Field** - This entry field is where the cam name can be edited.
- **OK Button** - This button will close and save the information entered.
- **Cancel Button** - This button will close but not save the information entered.

Delete

This button allow the currently selected cam to be deleted.

Cam Table Length

This field will allow the cam to be setup to have as many points needed to make the proper cam. The previous example screen has 4 cam points.

Currently Looking at

This field will allow the cam point entered to be viewed on the cam table right below this entry field.

Notes

These notes can be edited by pressing the **Edit Button** located to the bottom right of the SD Notes Box. Once the Edit Button has been pressed, the text on the Edit Button will change to "Save" and the notes are now able to be edited. After the notes are edited, the **Save Button** will have to be pressed in order for the notes to be saved.

Refresh Graph

This button will refresh the graph shown.

Graph Selection

This feature displays cams in different graph formats.

- Graph All (Slow) uses all of the points in the cam to generate the graph
- Graph Current uses the points currently displayed on the screen to generate the graph
- Slope Graph displays the points in a slope (best suited for servo drives)
- Square Wave Graph displays the points in a square wave (best suited for solenoid valves)

Cam Generator Button

This button will open the Cam Generator Program. This program is used to create Servo Drive Cams. The Cam Generator is an Aagard developed application that generates cam tables. Opening the cam generator application allows the user to manipulate cam tables generated with the Aagard Cam Generator.

Back Button

This button will close and save any changes and go to the [Data Input Page](#).

Servo Drive Cams

The servo drive cams should be altered through the [Cam Generator](#). These cams are described in further detail in the [Cam Generator](#) help section.

Solenoid Valve Cams

The solenoid valve cams should be altered on the [Cam Data Page](#). These cams are described in further detail in the [Solenoid Valve Cams](#) topic.

Motor Cams

The motor cams should be altered on the [Cam Data Page](#). These cams are described in further detail in the [Motor Cams](#) topic.

Cam Generator Choose Cam Group

General Page Information

The first screen to popup after the cam generator button is pressed is the Cam Generator Choose Cam Group Screen. The cam group is a group of servo axes that may have related functions.



Existing Cam Group Option

The user is prompted to select a cam group from the existing cam groups available that contains all the information needed to build the cam table wanted.

New Cam Group Option

If a new cam group is wanted, the New Option Button will have to be pressed.

- **Name Entry Field** - A name will have to be entered in the Name Entry Field.
- **C40 Drop Down Menu** - A C40 will have to be selected from the C40 Drop Down Menu. The C40 that should be selected from this menu is the C40 in which the Servo Drive(s) are located.

OK Button

This button will save any new Cam Groups and go to the Choose Product Screen (see below).


Cancel Button

This button will exit the Cam Generator and not save any changes.

Cam Generator Choose Product

General Page Information

The next screen to pop up after the OK button on the Cam Generator Choose Cam Group Screen is pressed is the Choose Product screen. The product to choose is the one to which you would like the changes applied.



Existing Drop Down Menu

The user is prompted to select a product from the existing list of products available that contains all the information needed to build the cam table wanted.

OK Button

This button will go to the [Cam Generator Main Screen](#).

Cancel Button

This button will exit the Cam Generator.


Cam Generator Main Screen

General Page Information

This is the Cam Generator Main Screen. This is where all Servo Drive Cams are made and edited. Once changes are complete, the generated positions are placed into the HMI database. A product download will be needed for the modifications to take effect. The Product Download will then load the generated positions to create the new cam.

Cam Generator has different ways the created cam can be viewed, if desired. The Cam Generator will default to the Setup Viewing Feature shown on the Cam Generator Main Screen. Other possible viewing features are [Graph](#) and [Points](#). There is also a [Misc](#) Viewing Feature, which allows notes to be assigned to each cam.

SAMPLE IMAGE




Cam Group Information

MDist Multiplier

This entry field makes the MDist displayed in the different information blocks relate to something such as time or distance of another axis. Keep in mind that the MDist is only equal to time when operating at 100% rate.

Add Cam Button - This button will display the Choose Cam Popup. This popup will allow a new cam to be added to or created in the cam generator. If the cam exists already, select the Existing Option and select the cam from the drop down menu. If the cam doesn't exist, select the New Option and specify the cam number in the left entry field and put the name of the cam in the right entry field. The OK Button will save the information, and the Cancel Button will close the popup and go to the Cam Generator Main Screen.



Remove Button - This button will remove the currently selected cam.

Rename Cam - A cam can be renamed by clicking on the cam name at the top of the cam.

Number of Points to Use

This field defines the maximum number of points that the cam generator program uses to generate the table for the drive data for this cam.

NOTE: Using more points will produce smoother motion

Add Data Type Button - This button will display the [Select Type of Data Popup](#).

Remove

This button will remove the currently selected cam data type

Move>>

This button will move the currently selected Cam Data Type to the right.

<<Move

This button will move the currently selected Cam Data Type to the left.

Master Start

This is the Master Position at which the cam should start.

Slave Start

This is the Slave (Servo Drive) Position at which the cam should start.

Velocity Start

This is the velocity at which the Servo Drive should start its cam.

Calculate

This button will calculate the Master End, Slave End, and all the status information generated in each Cam Data Type for the cam.

Master End Status

This position will be generated after the Calculate Button has been pressed. This status is the position at which the master currently ends. This should always equal the length of the master's travel after all changes have been made.

Slave End Status

This position will be generated after the Calculate Button has been pressed. The status is the position at which the slave (Servo Drive) currently ends. This position should usually equal the slave start unless the axis rolls its position over to zero at some point.

Quit Button - This button will ask if any changes want to be saved and start the process to exit cam generator and display the [Cam Generator Warning Screen](#).

Save Button - This button will save any changes made to the cams.

Load Button - This button will ask if any changes want to be saved and go to the [Cam Generator Choose Cam Group Screen](#) to load another group of cams.

View Timing Graph

This feature displays the relationship (in time) between each segment of the cam to the overall length of the cam.

View Overlay Graph

This feature displays the position of the axis (Show Slave selection) as well as the velocity of the axis (Show Velocity selection) over the length of the cam.

View 2 Axis Graph

This feature displays the profile of a two-axis cam, graphing the position of one axis over the position of another.

Maintenance

Maintenance Topics

The following maintenance items, when applicable, will be addressed:

- Review panel layout and devices
- Remove and install knives
- Remove servo motor, disassemble, and reinstall
- Remove servo drive, swap with another drive, set switches and restart
- Review electrical spare parts lists
- Review mechanical spare parts lists
- Review electrical drawings
- Review entire maintenance section of this manual
- Adjust HMI glue settings
- Confirm servo reference position settings

Training Topics and Completion Sheet

| | | |
|-------------------------------|-----------------|-----------------------------------------------|
| Please print copies as needed | Instructor: | * = Full Understanding Required! |
| | Training Group: | |
| Name: | Machine #: | 1=Fully Comprehend 2=More Training Desired |
| Job Title/Role: | Date: | |
| | Shift: | |

NOTE: Not all items listed here pertain to your Aagard system.

To go to [Level 2 Training overview, click here.](#)

To go to [Level 3 Training overview, click here.](#)

| | |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----|
| How To Use This Manual * | 1 2 |
| Safety Recommendations * training points Training Points for this page (10 Mins) <ul style="list-style-type: none"> • Please follow this facility's Lockout-Tagout procedures! <ul style="list-style-type: none"> ○ During lockout, ensure all disconnects are locked out • Learn the location of the following items for each safety zone (C40) of the machine <ul style="list-style-type: none"> ○ High voltage disconnect (removes high voltage from the machine) ○ Air dump (removes air pressure supply to the machine) ○ Separate high voltage disconnect for each Glue tank ○ Standard AC voltage to HMI not connected to any disconnects • Pay special attention to the following signs and placards that might be on this machine <ul style="list-style-type: none"> ○ CAUTION ○ WARNING ○ DANGER ○ HOT ○ Do Not Step • Learn of any any vertical applications which might have counter balance or brake • Aagard machines are divided into zones: power can be removed from one zone while the other zone still has power | 1 2 |
| E-Stop Locations * training points Training Points for this page (10 Mins) <ul style="list-style-type: none"> • Learn how to read the E-Stop floor plan for this machine <ul style="list-style-type: none"> ○ Perform safety check (open guard doors, depress E-Stops, etc., and view HMI notices) ○ Recall that C40 is a safety zone; safety check must be performed for each C40 ○ Attempt to start the machine with a guard door open • Using E-Stop or opening of a guard door has the same effect on the safety system <p>With this topic, the <i>Introduction and Safety</i> section is complete. Please fill out Topic Completion Sheets at this time.</p> | 1 2 |
| Machine Operation - training points Training Points for this page (10 Mins) <ul style="list-style-type: none"> • Reinforce items on this page! | 1 2 |
| Stack Light and Warning Horn * training points Training Points for this page (10 Mins) <ul style="list-style-type: none"> • Reinforce items on this page! | 1 2 |

| | |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|
| <ul style="list-style-type: none"> • Learn what each color of the stack light represents • Learn what the horn sounds mean | |
| <p><u>Button Functions</u> * training points</p> <p>Training Points for this page (10 Mins)</p> <ul style="list-style-type: none"> • Definitions <ul style="list-style-type: none"> ○ HMI = Human Machine Interface ○ E-Stop = Emergency Stop ○ C-Stop = Cycle Stop • E-Stop: Brings machine to “fast stop” (some machines have time delay on stop) <ul style="list-style-type: none"> ○ NOTE: This is NOT the preferred method for stopping the machine ○ Button is illuminated when depressed • Cycle Stop: Stops machine at the next position available for stopping <ul style="list-style-type: none"> ○ NOTE: This IS the preferred method for stopping the machine • Start <ul style="list-style-type: none"> ○ Hard wire reset on safety circuit ○ Reset faults ○ Starts machine if held on for full three seconds ○ Learn to determine meaning of flashing vs. solid green start button light | <p>1 2</p> |
| <p><u>Log In Screen</u> * training points</p> <p>Training Points for this page (10 Mins)</p> <ul style="list-style-type: none"> • Login with the keyboard • Learn location of login status • Automatic log out after a predetermined amount of time • Learn of User Level 1, 2, 3 and Admin concept | <p>1 2</p> |
| <p><u>Keyboard / Number Pad</u> * training points</p> <p>Training Points for this page</p> <ul style="list-style-type: none"> • Learn how to access on-board keyboard and number pad • Login using the HMI keyboard | <p>1 2</p> |
| <p><u>HMI Main Screen</u> * training points</p> <p>Training Points for this page (40 Mins)</p> <p>Level 1</p> <ul style="list-style-type: none"> • This main screen will be displayed 95% of time machine is in production • Learn the function of each available button for User Level 1 <ul style="list-style-type: none"> ○ Login Button ○ Reset Button ○ Production Data Button • Review available buttons for each C40 • Learn the location of state and mode status pilot lights <ul style="list-style-type: none"> ○ Three basic colors <ul style="list-style-type: none"> ▪ Red ▪ Blue ▪ Green ○ Demonstrate <ul style="list-style-type: none"> ▪ Starting ▪ Stopping ▪ E-Stopping ○ C40 Reset <ul style="list-style-type: none"> ▪ Learn code reset ▪ Some machines will need product cleaned/cleared ▪ Some machines might need additional special functions ▪ Sequence code is reset (start over from beginning) | <p>1 2</p> |

| | |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|
| <p>Level 2</p> <ul style="list-style-type: none"> • Review message notice display locations • Review Safety Zone (C40) concepts • Review States and Modes • Learn button functions • Level 2 and above users have access to considerable information <p>When in Manual Mode, Jog and Reference buttons are available</p> | |
| <p><u>States and Modes</u></p> | <p>1 2</p> |
| <p><u>Production Data Page</u> - training points</p> <p>Training Points for this page (20 Mins)</p> <ul style="list-style-type: none"> • This page displays up time and down time, and product number count • Machine keeps track of three days of production • This information is useful when determining how previous shift ran | <p>1 2</p> |
| <p><u>Continuous Running</u> * training points</p> <p>Training Points for this page (20 Mins)</p> <ul style="list-style-type: none"> • Learn how to use Materials-related notices on the HMI • Learn what warnings are sounded if materials are low • Learn how to load materials • Learn how changes in materials affect the machine <ul style="list-style-type: none"> ○ Change in glue manufacturer ○ New cardboard supplier ○ Size variations ○ Defective supplies | <p>1 2</p> |
| <p><u>Hot Melt Adhesive System</u> - training points</p> <p>Training Points for this page (10 Mins)</p> <ul style="list-style-type: none"> • Learn location of glue guns • Contact with heated glue components will burn skin instantly and severely | <p>1 2</p> |
| <p><u>Sequence of Operation</u> - training points</p> <p>Training Points for this page (20 Mins)</p> <ul style="list-style-type: none"> • Learn how product moves through the machine • Learn how to put machine in dry cycle and startup • Read each paragraph of the Sequence of Operation and, working with Message Notices, identify possible notices generated by the devices referenced in the Sequence of Operation <p>Level 1 Training is complete Please fill out Topic Completion Sheets at this time</p> | <p>1 2</p> |
| <p><u>Popups and Notices</u></p> | <p>1 2</p> |
| <p><u>Message Notices</u> - training points</p> <p>Training Points for this page (10 Mins)</p> <ul style="list-style-type: none"> • Learn message display locations • Learn how to decode and use this information <ul style="list-style-type: none"> ○ Device ○ Displayed Message ○ Cause ○ Action • Review each notice | <p>1 2</p> |

| Level 2 | |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------|
| <p><u>Product Download Page</u> * training points</p> <p>Training Points for this page (10 Mins)</p> <ul style="list-style-type: none"> • Become familiar with every changeover point on this machine • Learn how changeover settings affect product flow through the machine • Learn how to setup the machine based on product size • Learn how to test the machine for following a product changeover | 1 2 |
| <p><u>Changeover Location Drawings</u> * training points</p> <p>Training Points for this page (50 Mins)</p> <ul style="list-style-type: none"> • This floor plan shows the location for changeover point locations • Note that the numbering sequence does not always correspond with the changeover order • The changeover order is dependent upon FROM which, and TO which, sizes you are changing! • The HMI will always show the correct changeover order • Have the class find each changeover on the Machine using the drawings | 1 2 |
| <p><u>Changeover Adjustments</u> * training points</p> <p>Training Points for this page (20 Mins)</p> <ul style="list-style-type: none"> • Learn how to use Changeover Adjustment Pages | 1 2 |
| <p><u>Changeover Quick Reference Chart</u> * training points</p> <p>Training Points for this page (10 Mins)</p> <ul style="list-style-type: none"> • Learn how to document and communicate any changes from the values in the Changeover Quick Reference Chart • Learn how to use Changeover Quick Reference Chart • Learn how each adjustment point works, and how it affects the machine • Learn how to test machine after a changeover has been completed | 1 2 |
| <p><u>Product Download Changeover Adjustments</u> * training points</p> <p>Training Points for this page (10 Mins)</p> <ul style="list-style-type: none"> • Use this page to verify all changeovers have been completed for the current product | 1 2 |
| <p><u>Continuous Running</u> * training points</p> <p>Training Points for this page (20 Mins)</p> <ul style="list-style-type: none"> • Learn how to use Materials-related notices on the HMI • Learn what warnings are sounded if materials are low • Learn how to load materials • Learn how changes in materials affect the machine <ul style="list-style-type: none"> ○ Change in glue manufacturer ○ New cardboard supplier ○ Size variations ○ Defective supplies | 1 2 |
| <p><u>Log In Screen</u> * training points</p> <p>Training Points for this page (10 Mins)</p> <ul style="list-style-type: none"> • Login with the keyboard • Learn location of login status • Automatic log out after a predetermined amount of time • Learn of User Level 1, 2, 3 and Admin concept | 1 2 |
| <p><u>Operator Control Panel</u></p> | 1 2 |
| <p><u>HMI Main Screen</u> - training points</p> <p>Training Points for this page (40 Mins)</p> | 1 2 |

Level 2**Level 1**

- This main screen will be displayed 95% of time machine is in production
- Learn the function of each available button for User Level 1
 - Login Button
 - Reset Button
 - Production Data Button
- Review available buttons for each C40
- Learn the location of state and mode status pilot lights
 - Three basic colors
 - Red
 - Blue
 - Green
 - Demonstrate
 - Starting
 - Stopping
 - E-Stopping
 - C40 Reset
 - Learn code reset
 - Some machines will need product cleaned/cleared
 - Some machines might need additional special functions
 - Sequence code is reset (start over from beginning)

Level 2

- Review message notice display locations
- Review Safety Zone (C40) concepts
- Review States and Modes
- Learn button functions
- Level 2 and above users have access to considerable information

When in Manual Mode, **Jog** and **Reference** buttons are available

[Fault History Page](#) - training points

1 2

Training Points for this page

Level 2 (20 Mins)

- The information on this page is an excellent tool for determining problem spots or how other shifts have run
- Determine the location of problem spots other shifts may have had

Level 3 (2 Mins)

- Learn about Move column
- Learn about Delete All button

[Reject History Page](#) - training points

1 2

Training Points for this page

Level 2 (20 Mins)

- The information on this page is an excellent tool for determining problem spots or how other shifts have run
- Determine the location of problem spots other shifts may have had

Level 3 (2 Mins)

| Level 2 | |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----|
| <ul style="list-style-type: none"> Learn about Move column Learn about Delete All button | |
| <p>Production Data Page - training points</p> <p>Training Points for this page (20 Mins)</p> <ul style="list-style-type: none"> This page displays up time and down time, and product number count Machine keeps track of three days of production This information is useful when determining how previous shift ran | 1 2 |
| <p>Advanced Page - training points</p> <p>Training Points for this page (30 Mins)</p> <p>The items on this page are the most powerful tools available for troubleshooting.</p> <ul style="list-style-type: none"> Learn how to use the information behind the available buttons on this page through explanation, demonstration and review Learn how to access online manuals Open other manufacturers' E-Manuals <p>Note regarding Shutdown</p> <ul style="list-style-type: none"> This is the preferred method for proper power down on this PC-based machine If customer requires power to be off during changeover procedure, follow shutdown procedure and use hard copy of this manual for changeover training If shutdown is not required, follow Begin Changeovers at the bottom of this topic <p>Note regarding Restart</p> <ul style="list-style-type: none"> Pressing this button Restarts PC, and will stop production! | 1 2 |
| <p>Glue Page * training points</p> <p>Training Points for this page</p> <p>Level 2 (20 Mins)</p> <ul style="list-style-type: none"> Learn how to change settings NOTE: Changes made here are <u>not</u> recorded in the change log! NOTE: You must press "Enter" for changed values to be accepted <p>Level 3 (3 Mins)</p> <ul style="list-style-type: none"> Learn about Offset Position | 1 2 |
| <p>View Notices System Wide - training points</p> <p>Training Points for this page</p> <ul style="list-style-type: none"> Learn how to use this information Learn expand/collapse features Learn about time stamp Learn how to perform a custom sort Learn how to sort by shift | 1 2 |
| <p>Change Log Page - training points</p> <p>Training Points for this page (5 Mins)</p> <p>Level 2</p> | 1 2 |

| Level 2 | |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----|
| <ul style="list-style-type: none"> Learn how to use this information Learn sort features The information on this page is an excellent tool for viewing changes made to the machine | |
| <p>Level 3</p> <ul style="list-style-type: none"> WARNING! Do not use the "Delete All" button! Learn about values and demonstrate how it works | |
| <p>View Changeover Adjustments Page - training points</p> <p>Training Points for this page (20 Mins)</p> <ul style="list-style-type: none"> This screen is for information purposes, showing changeover settings | 1 2 |
| <p>Device List * training points</p> <p>Training Points for this page (2 Hours)</p> <ul style="list-style-type: none"> Learn how to use this information Learn how to find a device on the machine Review Device List Key (device abbreviations) Learn how to locate identifying labels on devices Have the class find each device on the machine using the list and map | 1 2 |
| <p>I/O Diagnostics Page * training points</p> <p>Training Points for this page (10 Mins)</p> <ul style="list-style-type: none"> Learn how to use this information Review of how devices are labeled Review of how to look for a device | 1 2 |
| <p>Jog Page * training points</p> <p>Training Points for this page</p> <p>Level 2 (40 Mins)</p> <ul style="list-style-type: none"> Learn how Aagard labels devices in the machine Device labels are referenced in message notices Learn meaning of machine mode and state pilot lights Pilot lights must be blue in order to jog a device Learn how to jog a device on this machine with the touch screen and the mouse BEWARE: Jogging initiates a direct link to the device – if something is obstructing the device, it WILL crash. Learn through demonstration that all jog pages have the same layout <p><u>Servo Drive Jog</u></p> <ul style="list-style-type: none"> Learn about the location velocity bar and how to adjust it BEWARE: Ensure velocity bar is set to slow rate Learn about GoTo position feature Learn about Alternating Jog feature <p><u>Solenoid Valve</u></p> <ul style="list-style-type: none"> Learn how to jog a solenoid valve <p><u>Motor</u></p> <ul style="list-style-type: none"> Learn how to jog a motor NOTE: If motor is VFD-controlled, speed number must be entered <p>Level 3</p> | 1 2 |

| Level 2 | |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----|
| <p><i>Alternating Jog (15-30 Mins)</i></p> <ul style="list-style-type: none"> Review Alternating Jog features Learn how to use the Alternating Jog information Demonstrate how to use the Alternating Jog page <p><i>Servo Drive Tuning (2 Mins)</i></p> <ul style="list-style-type: none"> These values are set at Aagard! Do not adjust them! | |
| <p>Reference Page * training points</p> <p>Training Points for this page (60 Mins)</p> <p>Many servo-controlled axes utilize an overload referencing technique. This means that they travel at a slow velocity until an elevated torque level is seen, indicating that the axis has hit a hard stop. If it contacts an obstruction and needs elevated torque to continue its motion, it is possible that the axis could reference against this obstruction and give the axis a false reference position.</p> <ul style="list-style-type: none"> Learn how to reference a servo motor Have the class reference every servo NOTE: It is important to always be in the correct position | 1 2 |
| <p>Servo Reference Positions * training points</p> <p>Training Points for this page (20 Mins)</p> <ul style="list-style-type: none"> Learn how to interpret the information on this page Hands-on application with at least two servo drives | 1 2 |
| <p>Drive Function and Associated Devices - training points</p> <p>Training Points for this page (20 Mins)</p> <ul style="list-style-type: none"> Learn how to use this information Learn the relationship of the drive to the work it performs, and to associated devices Hands-on application with at least two drives This information may be helpful when troubleshooting machine problems | 1 2 |
| <p>Drive Diagnostics Page - training points</p> <p>Training Points for this page (10 Mins)</p> <ul style="list-style-type: none"> Learn about Aagard Control Structure View Add and Popup features | 1 2 |
| <p>Fault Code History Page</p> | 1 2 |
| <p>Sercos Diagnostics Page - training points</p> <p>Training Points for this page (20 Mins)</p> <ul style="list-style-type: none"> This page is for information only to the Level 2 Operator Learn how to use the information on this page This page provides an on-board tool for troubleshooting fiber optic and related components | 1 2 |
| <p>Member Map Diagnostics Page - training points</p> <p>Training Points for this page (10 Mins)</p> <ul style="list-style-type: none"> Learn about Aagard Control Structure View Add and Popup features | 1 2 |
| <p>Vacuum Pump Shutdown</p> | 1 2 |

| Level 3 | |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------|
| <p><u>Start Up Page</u> * training points</p> <p>Training Points for this page (15 Mins) <i>Servo Initialize Options >> Initialize Data Button</i></p> <ul style="list-style-type: none"> • Only available on power up or PC restart • 8 seconds to select Servo Initialization Options button or initialize process will start automatically • Used when servo motor (or drive) is replaced • Hands-on: Do power up and select servo to initialize (Remember to reference that servo!) | 1 2 |
| <u>Servo Initialize Option</u> * | 1 2 |
| <u>Initialization Data Page</u> * | 1 2 |
| <p><u>Fault History Page</u> * training points</p> <p>Training Points for this page</p> <p>Level 2 (20 Mins)</p> <ul style="list-style-type: none"> • The information on this page is an excellent tool for determining problem spots or how other shifts have run • Determine the location of problem spots other shifts may have had <p>Level 3 (2 Mins)</p> <ul style="list-style-type: none"> • Learn about Move column • Learn about Delete All button | 1 2 |
| <p><u>Reject History Page</u> * training points</p> <p>Training Points for this page</p> <p>Level 2 (20 Mins)</p> <ul style="list-style-type: none"> • The information on this page is an excellent tool for determining problem spots or how other shifts have run • Determine the location of problem spots other shifts may have had <p>Level 3 (2 Mins)</p> <ul style="list-style-type: none"> • Learn about Move column • Learn about Delete All button | 1 2 |
| <p><u>Edit Shifts Screen</u> * training points</p> <p>Training Points for this page (2 Mins)</p> <ul style="list-style-type: none"> • Learn how to adjust shifts from the Production Data page | 1 2 |
| <p><u>View Notices System Wide</u> * training points</p> <p>Training Points for this page</p> <p>Level 2 (20 Mins)</p> <ul style="list-style-type: none"> • The information on this page is an excellent tool for determining problem spots or how other shifts have run • Determine the location of problem spots other shifts may have had <p>Level 3 (2 Mins)</p> <ul style="list-style-type: none"> • Learn about Move column • Learn about Delete All button | 1 2 |

| Level 3 | |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----|
| <p>Misc Tags Page * training points</p> <p>Training Points for this page (4 Mins)</p> <ul style="list-style-type: none"> Learn brief explanation of what this information represents Learn about the "?" information box Learn how this information is used | 1 2 |
| <p>Change Log Page * training points</p> <p>Training Points for this page (5 Mins)</p> <p>Level 2</p> <ul style="list-style-type: none"> Learn how to use this information Learn sort features The information on this page is an excellent tool for viewing changes made to the machine <p>Level 3</p> <ul style="list-style-type: none"> WARNING! Do not use the "Delete All" button! Learn about values and demonstrate how it works | 1 2 |
| <p>Glue Page * training points</p> <p>Training Points for this page</p> <p>Level 2 (20 Mins)</p> <ul style="list-style-type: none"> Learn how to change settings NOTE: Changes made here are <u>not</u> recorded in the change log! NOTE: You must press "Enter" for changed values to be accepted <p>Level 3 (3 Mins)</p> <ul style="list-style-type: none"> Learn about Offset Position | 1 2 |
| <p>Motor Data Page * training points</p> <p>Training Points for this page (15 Mins+)</p> <ul style="list-style-type: none"> Learn about Framework Learn about each feature when selected and when not selected Notice how layout of Solenoid & Motor pages are similar Have the class move around and ask questions Important! This information should be well understood! | 1 2 |
| <p>Solenoid Data Page * training points</p> <p>Training Points for this page (15 Mins+)</p> <ul style="list-style-type: none"> Learn about Framework Learn about each feature when selected and when not selected Notice how layout of Solenoid & Motor pages are similar Have the class move around and ask questions Important! This information should be well understood! | 1 2 |
| <p>Servo Drive Data Page * training points</p> <p>Training Points for this page (10-20 Mins)</p> <ul style="list-style-type: none"> This page is intended for Aagard use only (because it is accessible at Level 3, provide a brief explanation) | 1 2 |

| Level 3 | |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----|
| <ul style="list-style-type: none"> This page is used for the configuration of servos Explain each section briefly Have the class move around and ask questions Important! This information should be well understood! | |
| <p><u>Servo Drive Data Page - Advanced tab</u> * training points</p> <p>Training Points for this page (3 Mins)</p> <ul style="list-style-type: none"> Learn about reference picture paths and descriptions | 1 2 |
| <p><u>Alternating Jog</u> * training points</p> <p>Training Points for this page</p> <p>Level 2 (40 Mins)</p> <ul style="list-style-type: none"> Learn how Aagard labels devices in the machine Device labels are referenced in message notices Learn meaning of machine mode and state pilot lights Pilot lights must be blue in order to jog a device Learn how to jog a device on this machine with the touch screen and the mouse BEWARE: Jogging initiates a direct link to the device – if something is obstructing the device, it WILL crash. Learn through demonstration that all jog pages have the same layout <p><u>Servo Drive Jog</u></p> <ul style="list-style-type: none"> Learn about the location velocity bar and how to adjust it BEWARE: Ensure velocity bar is set to slow rate Learn about GoTo position feature Learn about Alternating Jog feature <p><u>Solenoid Valve</u></p> <ul style="list-style-type: none"> Learn how to jog a solenoid valve <p><u>Motor</u></p> <ul style="list-style-type: none"> Learn how to jog a motor NOTE: If motor is VFD-controlled, speed number must be entered <p>Level 3</p> <p><i>Alternating Jog (15-30 Mins)</i></p> <ul style="list-style-type: none"> Review Alternating Jog features Learn how to use the Alternating Jog information Demonstrate how to use the Alternating Jog page <p><i>Servo Drive Tuning (2 Mins)</i></p> <ul style="list-style-type: none"> These values are set at Aagard! Do not adjust them! | 1 2 |
| <p><u>Servo Drive Tuning</u> * training points</p> <p>Training Points for this page</p> <p>Level 2 (40 Mins)</p> <ul style="list-style-type: none"> Learn how Aagard labels devices in the machine Device labels are referenced in message notices Learn meaning of machine mode and state pilot lights Pilot lights must be blue in order to jog a device Learn how to jog a device on this machine with the touch screen and the mouse BEWARE: Jogging initiates a direct link to the device – if something is obstructing the device, it WILL crash. Learn through demonstration that all jog pages have the same layout | 1 2 |

| Level 3 | |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------|
| <p><u>Servo Drive Jog</u></p> <ul style="list-style-type: none"> Learn about the location velocity bar and how to adjust it BEWARE: Ensure velocity bar is set to slow rate Learn about GoTo position feature Learn about Alternating Jog feature <p><u>Solenoid Valve</u></p> <ul style="list-style-type: none"> Learn how to jog a solenoid valve <p><u>Motor</u></p> <ul style="list-style-type: none"> Learn how to jog a motor NOTE: If motor is VFD-controlled, speed number must be entered <p>Level 3</p> <p><i>Alternating Jog (15-30 Mins)</i></p> <ul style="list-style-type: none"> Review Alternating Jog features Learn how to use the Alternating Jog information Demonstrate how to use the Alternating Jog page <p><i>Servo Drive Tuning (2 Mins)</i></p> <ul style="list-style-type: none"> These values are set at Aagard! Do not adjust them! | |
| <u>Manual SD Enabling</u> | 1 2 |
| <p><u>Edit System Products Page</u> * training points</p> <p>Training Points for this page (20 Mins) - from Product Download Page</p> <ul style="list-style-type: none"> Learn how to create a new recipe It's important to understand how we alias systems to a C40 and how the copy function works | 1 2 |
| <p><u>Edit C40 Recipes Page</u> * training points</p> <p>Training Points for this page (20 Mins) - from Product Download Page</p> <ul style="list-style-type: none"> Learn how to create a new recipe It's important to understand how we alias systems to a C40 and how the copy function works | 1 2 |
| <p><u>Changeover Adjustments Page</u> * training points</p> <p>Training Points for this page (3 Mins)</p> <ul style="list-style-type: none"> Learn how to edit changeover values | 1 2 |
| <p><u>Rearrange Page</u> * training points</p> <p>Training Points for this page (3 Mins)</p> <ul style="list-style-type: none"> Learn how to rearrange the order in which changeover are completed | 1 2 |
| <p><u>General Data Page</u> * training points</p> <p>Training Points for this page (10 Mins)</p> <ul style="list-style-type: none"> Learn about each General Data item on this page Learn about the "?" information box Learn how this information is used | 1 2 |

| Level 3 | |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------|
| <p><u>Servo Moves Data Page</u> * training points</p> <p>Training Points for this page (30 Mins)</p> <ul style="list-style-type: none"> Learn about move numbers #2, 3, 4 and 5 Learn about Auto-Calc Learn about default info | 1 2 |
| <p><u>Cam Offsets Page</u> * training points</p> <p>Training Points for this page (15-30 Mins)</p> <ul style="list-style-type: none"> Learn about Master / Slave Learn about old mechanical line shaft and how cam could be advanced with slotted part or connecting rod Learn through demonstration how to adjust cam offsets Learn how cam offsets affect the machine Hands On: Have the class make some adjustments Remember! Stop and restart machine for changes to work! | 1 2 |
| <p><u>Cam Data Page</u> * training points</p> <p>Training Points for this page (15-30 Mins)</p> <ul style="list-style-type: none"> Learn about drop-down selection: servo drive / solenoid valve / motor function of cam Select square wave plot Select SV cam and learn about how it works Learn basic concept of cams: Most Masters are in time and Slave can be almost any value, so if making an adjustment, go to Servo Setup page to see what the values are before changing. Sometimes we have to just change it and see what happens | 1 2 |
| <p><u>Cam Generator Choose Cam Group</u> * training points</p> <p>Training Points for this page</p> <ul style="list-style-type: none"> Learn about Master and Group | 1 2 |
| <p><u>Cam Generator Choose Product</u> * training points</p> <p>Training Points for this page</p> <ul style="list-style-type: none"> Each group has its own information for each recipe | 1 2 |
| <p><u>Cam Generator Main Screen</u> * training points</p> <p>Training Points for this page (1-2 Hours)</p> <ul style="list-style-type: none"> Learn all about the Cam Generator (detailed explanation) Remember! If end users think that they need to make a change in this area, they should call Aagard first! This area is sometimes very complex and can have effects on other areas of the machine or servos in the same group. | 1 2 |

| Maintenance Topics (when applicable) | |
|-----------------------------------------------------------------------|-----|
| Review panel layout and devices | 1 2 |
| Remove and install knives | 1 2 |
| Remove servo motor, disassemble, and reinstall | 1 2 |
| Remove servo drive, swap with another drive, set switches and restart | 1 2 |
| Review Electrical Spare Parts Lists | 1 2 |
| Review Mechanical Spare Parts Lists | 1 2 |

Maintenance Topics (when applicable)

| | | |
|--------------------------------------------------|---|---|
| Review Electrical Drawings | 1 | 2 |
| Review entire Maintenance Section of this manual | 1 | 2 |
| Adjust HMI glue settings | 1 | 2 |
| Confirm Servo Reference Position settings | 1 | 2 |

Safety

 **DANGER**

 **CAUTION**

Lockout power during maintenance

Do not operate without guards

Do not remove guards, clean, lubricate, or repair machinery while machine is in motion

Before operating equipment, see [Safety Recommendations](#)

Read and observe all safety precautions in this manual, and in vendor literature, before proceeding

Prior to Lockout-Tagout, contact a Level 2 or higher Operator to properly shut down the PC.

Safety Recommendations

At Aagard, we are committed to building quality automated machinery systems. Your new Aagard system is efficient, easy to maintain and safe to operate.

Before attempting to operate the equipment, become familiar with the safety recommendations and operational components of your Aagard system. This includes the technical information pertaining to outside vendor components used within your Aagard system. This information is located in the Manufacturer Information Binder and in other literature supplied with the equipment.

To maximize machine safety you must operate the machine correctly and comply with the described safety features!

ALWAYS follow your facility's Lockout-Tagout procedures when doing maintenance and repair work!

Prior to Lockout-Tagout, contact a Level 2 or higher Operator to properly shut down the PC.

Always follow your facility's Lockout-Tagout procedures!

Lockout/Tagout (LOTO) refers to specific practices and procedures to safeguard employees from the unexpected energization or startup of machinery and equipment, or the release of hazardous energy during service or maintenance activities.

Pay special attention to the following CAUTION, WARNING and DANGER signs below. They are used throughout the manual to alert the operator to the potential of **INJURY** or **DEATH**, if the recommended procedures are not followed.

 **DANGER**

Immediate hazards which WILL result in severe personal injury or death

 **WARNING**

Hazards or unsafe practices which COULD result in severe personal injury or death

STAY ALERT AND REMEMBER:


Safety is the responsibility of everyone who operates or services your Aagard system

See [Servo Motor with Brake](#) for additional safety information!

E-Stop Locations

All personnel who repair, maintain, or operate Aagard equipment need to know the location of the **EMERGENCY STOP** buttons:

Sample E-Stop Drawing



- **DO NOT** operate the equipment with any of the safety guards removed
- **DO NOT** wear neckties, loose clothing, or long loose-hanging hair around any equipment
- **OBSERVE** and follow the **⚠ DANGER**, **⚠ WARNING**, and **⚠ CAUTION** messages throughout this document, in vendor documentation, and displayed on the equipment
- **DO NOT** use steps or stands that allow anyone to reach over guards

[Button Functions](#)

[Stack Light and Warning Horn](#)

Machine Operation

CAUTION

Before operating equipment, see [Safety Recommendations](#)



Read and observe all safety precautions in this manual,
and in vendor literature, before proceeding

Prior to starting your packaging system

- **CHECK TO MAKE SURE ALL PERSONNEL, TOOLS AND EQUIPMENT ARE CLEAR OF THE MACHINE**
- Turn on hot melt system; allow the system time to reach normal operating temperatures
- Install and close all guard doors
- Load the magazine(s) with blanks
- Check to make sure product is available
- Once again, **CHECK TO MAKE SURE ALL PERSONNEL, TOOLS AND EQUIPMENT ARE CLEAR OF THE MACHINE**

Shutdown Warning

Failure to properly shut down the PC may void the warranty!

| | |
|-----------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Switch on | The Industrial PC does not have its own main switch. The Industrial PC will start when the equipment is switched on, or when it is connected to the power supply. |
| Shutting down and switching off | When the plant is switched off, or when it is disconnected from its power supply, the Industrial PC will be switched off. Control software such as is typically used on Industrial PCs permits various users to be given different rights. A user who may not close software may also not switch the Industrial PC off, since data can be lost from the hard disk by switching off while software is running |
|  Warning! | First shut down, then switch off the PC! If the Industrial PC is switched off as the software is writing a file to the hard disk, the file will be destroyed. Control software typically writes something to the hard disk every few seconds, so the probability of causing damage by switching off the PC while the software is running is very high! |
|  Warning! | When you have shut down the Industrial PC, you have to switch off power supply for at least 10 seconds before rebooting the system. After resetting power supply, the PC will start booting automatically. |

To properly shut down the PC, contact a Level 2 or higher Operator.

Stack Light and Warning Horn

The Stack Light consists of a stack of four (4) colored lights: **Red**, **Amber**, **Blue** and **Green** (Top to Bottom). The stack light is situated to be reasonably visible from the circumference of the machine. The warning horn will produce a sound loud enough to be heard in a production environment while standing near the circumference of the machine.

The stack lights and warning horn have following meanings:

| FOUR Stack Light definitions | | THREE Stack Light definitions | |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------|
| four light stack | Red (Top) Solid: <ul style="list-style-type: none"> An Emergency Stop condition exists A Fault condition exists | Red (Top) Solid: <ul style="list-style-type: none"> An Emergency Stop condition exists A Fault condition exists | three light stack |
| | Amber (Second from Top) Solid: <ul style="list-style-type: none"> No product coming from upstream, or an Integrated System is not ready for operation (Example: Glue System Not Ready) Downstream unable to accept product | Amber (Middle) Solid: <ul style="list-style-type: none"> No product coming from upstream, or an Integrated System is not ready for operation (Example: Glue System Not Ready) Downstream unable to accept product Flashing: <ul style="list-style-type: none"> Material status is low (Examples: Low Case Blanks, Low Adhesive Level) | |
| | Green (Third from Top) Solid: <ul style="list-style-type: none"> System Running | Green (Bottom) Solid: <ul style="list-style-type: none"> System Running | |
| | Blue (Bottom) Solid: <ul style="list-style-type: none"> Material status is low (Examples: Low Case Blanks, Low Adhesive Level) | | |

Warning Horn: The *Startup Warning* horn will sound for three seconds prior to the actual energizing or startup of a machine, which includes the enabling and recovery of servo powered systems.

The operator is required to push *and hold* the start button for the entire duration (three seconds) of the warning horn. If the operator releases the start button prior to the end of the horn, the machine will not start and the horn will cease to sound. The horn cycles on and off every ½ second for the duration of the alarm.

The *Fault Warning* alarm will sound when a fault exists and has not been acknowledged. The alarm will cycle on and off every 0.2 seconds until the fault has been acknowledged.

Button Functions

Please refer to the [E-Stop Locations](#) drawing for Emergency Stop, Cycle Stop and Start Button locations.



Emergency Stop (E-Stop) Button - Pressing this button brings all machine function to an immediate and complete stop.

Opening any safety door also triggers an E-Stop.



Cycle Stop (C-Stop) Button - Pressing this button brings all machine function to a complete stop at the end of the current cycle.

C-Stop is the preferred method to stop operation in all NON-Emergency situations.



Start Button - Pressing and holding this button for three seconds (until horn stops) starts the machine.

Start Push Button Pilot Light

Solid

- All Safety Circuits of the system are engaged (no Emergency Stop Push Buttons are depressed, all Guard Doors are closed, and Safety Relays have been reset)

Flashing

- One or more, but not all, Safety Circuits of the system are engaged

Servo Motor with Brake

DANGER

If you begin maintenance on any servo motor which has a brake without securing it, a vertical axis may fall and cause severe personal injury or death, as well as mechanical damage!

Before performing maintenance on any servo motor with a brake, jog the vertical axis which the servo motor controls to a safe position. Place supportive material to protect both the axis and the area onto which it is being placed before jogging the servo to a safe position.

If you are unable to jog the servo motor to safely position the vertical axis, use straps to secure it. The following image is for reference only:



Installation and Power-Up

The **Aagard Group, LLC** employs skilled technicians to assist our customers with installation and startup of new equipment, as well as provide continuous technical support.

CAUTION

Before operating equipment, see [Safety Recommendations](#)

Read and observe all safety precautions in this manual and in vendor literature before proceeding!

DANGER

IMPORTANT!

Do not switch on the main power-disconnect!
The Aagard technician will perform the initial power-up

Lifting and Unloading Equipment – Aagard recommends you use qualified riggers to unload and locate machine components to avoid possible damage. Care must be taken when removing the machine and skid from the truck. Lifting on one end may bow the skid and attached machine, and is not recommended. Lift in sufficient locations to support the weight of the machine to prevent bowing, flexing and twisting. Excessive bowing and flexing will damage components within the machine and may be difficult to see.

CAUTION

Bowing in excess of 2 inches over a 40 foot span (1 inch over a 20 foot span) is unacceptable.

Twisting in excess of 1 inch over a 20 foot of length, and greater than 1/2 inch over an 8 foot width span, is unacceptable.

Damage that occurs while lifting and unloading may be undetectable, and can cause premature fatigue and extensive wear. Damage that occurs from improper lifting or unloading practices as noted in these guidelines may void the machine's warranty.

Machines Shipped With Steel Skids

- These skids have side lift points which should be used when lifting from the trailer, or when placing machine rollers beneath the skid. Never lift the machine and/or skid only from the ends, or from a single location along the side.
- Use machine rollers in sufficient quantities placed beneath the skid, under the machine, when moving the machine. Use a minimum of three rollers on each side of the machine.
- These skids have pull points that should be used when dragging from the trailer onto the loading dock or maneuvering to the desired location. The machine with the skids still attached should be moved to the final machine position prior to removing the skid.

- If it is not possible to leave the skid fastened to the machine frame base for maneuvering, it is important to locate additional rollers to support the frame. These rollers, when the skid is not used, should be located at approximately 6 foot intervals, and not further than 8 foot intervals. Extra care must also be taken when making corners while moving into position.
- Once the machine has been removed from the steel skid, the skid and all components of the skid are to be returned to The Aagard Group in a timely manner.

Machines Shipped With Wood Skids

- These systems are generally shipped in smaller sections. However, they should never be lifted from the ends. Even though they are shorter, the wood skids do not render as much support to the base framework as do tubular steel skids.
- Use machine rollers in sufficient quantities placed beneath the skid under the machine, when moving the machine. Use a minimum of three rollers on each side of the machine.
- Place a strap around the skid and base of the machine frame, when dragging from the trailer onto the loading dock.

Skid Removal – Use caution when removing the skids. Aagard recommends you use qualified riggers to uncrate and spot machine components to avoid possible damage. In addition, place floor pads under all legs to help eliminate floor damage and provide surface support.

- **Remove clamps** - Use caution when removing the clamps between the machine frame and the skid. Adjust the leveling legs on the frame to lift the machine from the skid. ***DO NOT LIFT THE MACHINE FROM ONE END WHEN ATTEMPTING TO REMOVE SKID. THE MACHINE SHOULD BE LIFTED UNIFORMLY.*** Remove the fasteners from the skid cross members on each side. The skid can then be removed from the sides of the machine; some of the legs may need to be left out until after the skid has been removed. Install the remainder of the leveling legs and, once in the proper location, begin the procedure to level your machine.

Certain items may have been removed from the system that will require reassembly once the system is in position. Standard wrenches are required for this reassembly.

NOTE!

Leveling the machine eliminates twisting and binding of assembled components

Leveling the Aagard Machine

- Level the machine in both the length and cross-machine dimensions.
- Perform an initial level check throughout the machine at both ends and sides when checking level using a 30 to 36 inch level. The use of a laser level will produce the best results, however, and is recommended. Use the lower horizontal frame members for leveling. Do not use the vertical supports for leveling.
- Adjust the 1" threaded legs, located in multi-support positions around the lower frame section, to level and adjust the height.
- We also recommend using silicone to seal the pads to the floor and the legs to the pads to help prevent contamination. Some components may require fastening to the floor.
- **For final leveling, use a laser level.** Start at the end of the machine, leveling side-to-side, and then along the length of the machine.
- After the leveling process is complete, use a laser level to ensure the framework is straight and free of bows along the length of the framework.

Power and Air Supply

- Prior to installation, **verify** that your incoming electrical service meets all local safety and building codes. Check to ensure you are internally set up to meet the system's power requirements. See the machine Specification Chart for power requirements.
- **Check** to ensure you are able to meet the air pressure requirements. See the machine Specification Chart for air pressure requirements.
- "Clean/Dry" is defined as air filtered to five microns or less and with a pressure dew point of 40°F or lower.
- This machine is equipped with a filter regulator at the location shown on the floor layout.

Miscellaneous

- Wire power and air to glue tank, if equipped. Wires and wiring points are clearly marked.

Prior to Aagard Technician Arrival

- Plumb in air and electrical systems.
- Mount **ALL** guards.

 **DANGER**

The initial electrical system hook-up, operational-check and inspection must be done by qualified electricians

USE EXTREME CAUTION when working at any electrical panel

The high voltage, 3-phase service enters at the main electrical cabinet

AFTER ALL OF THE ABOVE HAS BEEN COMPLETED:

- Switch **OFF** the main power-disconnect for incoming power. Open the main electrical-control cabinet.
- Connect the wires for the 3-phase power service and ground (earth) wire.
- At the main power disconnect input, use an accurate meter to check the incoming line voltage to ensure it meets operating specifications.

Factory Settings


Parts that are adjusted in the initial setup of the machine are pre-set in a factory determined default position. These are the factory default settings with which the machine is shipped. These factory default settings are scribed or painted and visible on slotted or moveable parts to which default settings apply.

NOTE: Factory default settings may be adjusted as part of the machine setup process as determined by appropriate personnel.

SAMPLE IMAGE



SAMPLE IMAGE



Description, Specifications and Operation



Machine Description, Specifications and Operation

| | |
|-----------------------------------|---------------------------------------|
| AAGARD SYSTEM SERIAL #120 | RH KD Case Packer with Orienter |
| MACHINE DIMENSIONS | 25' x 10' 5" |
| ADHESIVE SYSTEM | Nordson ProBlue 240V-3-PH-60Hz |
| PRODUCT DESCRIPTION | Sealed cartons of dry cereal |
| | |
| CASE STYLE | RSC knock down case |
| CASE FLAP FOLDING SEQUENCE | Vertical flaps, then horizontal flaps |

As-Built Documentation

Please view following documents and topics for as-built documentation.

[Specification Sheet](#)

[General Terms and Conditions](#)

[Efficiency and Warranty Statement](#)

[Bill of Materials](#)

These documents are considered as-built documentation at the time of machine shipment and will not be updated.

General Terms and Conditions

This topic is considered as-built documentation at the time of machine shipment and will not be updated

All sales, agreements for sale, offers to sell, quotations, acknowledgments and contracts of sale, including but not limited to purchase orders, installment sale contracts, leases and subsequent purchases of spare parts or change parts for the item of sale (herein IOS) shall be subject to the following terms and conditions; in addition the terms of Installment sale contracts and leases shall prevail when such terms conflict with the terms herein. Whenever the term Aagard is used, it is understood and agreed to include the corporate entity of The Aagard Group, LLC its employees, agents and representatives.

1. **PRICES:** All prices are subject to change without notice except those written quotations which shall expire without notice at Midnight CST sixty (60) calendar days from the date issued except such quotations can be terminated by prior written notice.
2. **PAYMENT:** Terms of payment are set forth herein. No discount. In the event machinery is the IOS and Aagard cannot demonstrate that the machine performs according to specifications herein, Aagard shall have the right to adjust the IOS so that the same shall perform to specifications. Purchaser shall, at Aagard's option, have the right to withhold ten (10%) percent of the purchase price without interest until such adjustments are completed. Any delinquent payment shall bear interest at the highest legal rate. If shipment is delayed by the purchaser or by anyone not a party hereto, payment shall become due on the date Aagard is prepared to make shipment. If the work covered by the purchase is delayed by the purchaser, payment shall be made forthwith based on the full purchase price or the percentage of completion to be determined at Aagard's option. If the purchaser defaults in any payment when due, then the full contract price shall become due and payable upon demand, or Aagard may, without prejudice to other lawful remedies, defer delivery or cancel the agreement and seek damages. Products held for the purchaser shall be at the risk and expense of the purchaser. If the financial condition of the purchaser at any time does not, in the judgment of Aagard, justify continuance of the work to be performed, Aagard may require full or partial payment in advance, and in the event of bankruptcy or insolvency of the purchaser or in the event any proceeding is brought by or against the purchaser under the bankruptcy or insolvency laws, Aagard shall be entitled to cancel any agreement then outstanding, and Aagard shall receive reimbursement for its damages.
3. **ACCEPTANCE:** No order, sale, agreement for sale, accepted quotation, offer to sell and/or contract of sale, shall be binding upon Aagard unless accepted by an Officer of Aagard at its office in the city of Alexandria, Douglas County, Minnesota, on Aagard's standard "Order Acknowledgment" form.
4. **TAXES:** Any taxes, including but not limited to turnover taxes, duties, fees, or other specific assessments which may be levied against the IOS shall be extra and borne by the purchaser. If Aagard is required to pay any of the above, purchaser shall reimburse Aagard upon notice, or furnish documents with the order, which exempts such payment.
5. **CHANGES:** No change of the agreement shall be binding without the written consent of all parties.
6. **SHIPMENT:** Shipments are made F.O.B. Aagard's plant of manufacture.
7. **CANCELLATION:** Orders acknowledged per paragraph 3 above are not cancelable by purchaser.
8. **ERRORS:** Stenographical and clerical errors are subject to correction.
9. **DELIVERY:** Shipping dates submitted are approximate. Aagard will use its best efforts to meet the approximated shipping date provided the purchaser supplies all necessary information, but Aagard shall not be held responsible for failure to do so. Shipping date is based upon construction to normal Aagard standards (unless otherwise specified herein) and further dependent upon vendor's and subcontractor's delivery commitments. Any delays due to Department of Defense priorities, shortages of labor and/or materials may change the shipment date herein set forth. Aagard shall be subject to no penalty or liability for failure to meet a shipping date and shall in no event be held responsible for loss of profits, damages incurred by the purchaser, its customers, or other consequential damages that may result there from.
10. **TESTING MATERIALS:** Purchaser shall furnish to point of manufacture at its expense sufficient product, sample packages, packaging materials, complete manufacturing data and other material necessary for full testing of IOS.

11. **DAMAGE OR LOSS IN SHIPMENT:** Aagard shall not be responsible for damage or loss in transit and all claims must be made by the purchaser direct to the carrier. Claims for shortages or incorrect IOS must be made in writing within fifteen (15) days after receipt of the shipment by the purchaser, and failure to give Aagard written notice within that period shall be unqualified acceptance of the IOS and a waiver of all claims.

12. **WARRANTY:** Aagard warrants that the IOS will be constructed in accordance with normal Aagard methods of manufacture and attached specifications. The IOS is warranted to be free from defects in material and workmanship for a period of one (1) year or 7,500 operating hours, whichever occurs first, from the date of shipment. The Aagard Group will repair or replace defective components covered by outside manufacturers' warranties according to the provisions of each respective manufacturer's warranty. Freight, labor, expenses, and service rates related to replacement parts under warranty are invoiced at applicable standard rates. All equipment a part of the IOS but not manufactured by Aagard is limited in warranty and guarantee to the warranty and/or guarantee of the manufacturer and expires upon the expiration of such warranty. If the purchaser within the warranty period gives Aagard written notice of any alleged defect, Aagard will, at its option, repair or replace the same free of charge F.O.B. its manufacturing plant, installation extra. Equipment replaced under the warranty shall have the same warranty as equipment, but does not extend the warranty of the original IOS. No warranty is made with respect to: (A) Consumable items within IOS, such as vacuum cups, plastic wear guides, etc., (B) Failures not reported to Aagard within the warranty period, (C) Failures or damage due to misapplication, lack of proper maintenance, abuse, improper installation or abnormal conditions of temperature, moisture, dirt, or corrosive matter, etc., (D) Failures due to operation, either intentional or otherwise, above the rated capacities, or in an otherwise improper manner, (E) Any IOS which has been altered by anyone other than an authorized representative of Aagard, (F) Any IOS damaged without fault of Aagard. Aagard shall not be liable for any expenses incurred by the purchaser in an attempt to correct any allegedly defective IOS.

13. **PURCHASER'S PRODUCT:** Purchaser shall hold Aagard harmless from any action arising by reason of alleged design and construction of the products handled by the IOS or the method or process carried out thereon.

14. **PURCHASER'S OPERATION:** It is understood that Aagard has no special knowledge of the purchaser's operation or requirements and purchaser agrees that the IOS is purchased because of the independent determination by the purchaser of its suitability for intended use.

15. **LIABILITY:** The use of all guards, interlocks, electrical devices, and other safety devices on the IOS and the operation of the IOS in accordance with Aagard operating instructions is essential to the safe use of the machine, and, therefore, the purchaser agrees that it will keep in legible condition all warnings or operating instructions affixed to the IOS or parts of the IOS by Aagard, and that it will not remove or render inoperable any guards, interlocks, electrical devices, or other safety devices, that are part of the IOS, and that it will not add any devices that will render the machine unsafe and that it will operate the machine in accordance with Aagard operating instructions. The purchaser agrees to pay in behalf of Aagard all sums which Aagard becomes legally obligated to pay because of bodily injury or property damage caused by or resulting from the use or misuse of the IOS, including reasonable attorney's fees and legal expenses. The purchaser agrees to indemnify and hold Aagard harmless from all actions, claims or demands by any person, firm or corporation arising out of or in any way connected with the IOS, its operation, use or misuse, or the design, construction or composition of any product made or handled by the IOS, including all such actions, claims or demands based in whole or in part on the default or negligence of Aagard. If the purchaser allows the IOS to be used by any other party, then the purchaser agrees to indemnify and hold Aagard harmless from any and all claims, actions or demands whatsoever arising thereafter by reason of the use or misuse of the IOS.

16. **LIMITATIONS:** Aagard shall not be liable for any losses, costs, forfeitures and all other consequential damages (including loss of profits, liabilities of the purchaser to its customers or third persons) whether direct or indirect, and whether or not resulting from or contributed to by the default or negligence of Aagard, its agents, employees and subcontractors, which might be claimed as the result of the use or failure of the IOS. THERE IS NO FURTHER WARRANTY EITHER EXPRESS OR IMPLIED IN CONNECTION WITH THE DESIGN, SALE, MERCHANTABILITY OR USE OF THE IOS AND/OR SERVICES EXCEPT AS TO TITLE; AND AAGARD'S LIABILITY ON ITS WARRANTY SHALL IN NO EVENT EXCEED THE COST OF THE IOS.

17. **PATENT INDEMNITY:** Aagard agrees that it shall defend any suits that may be instituted by any party against purchaser for an alleged infringement of any U.S. patent relating to the structure of the IOS as originally furnished, provided purchaser shall have made all payments due and gives to Aagard immediate written notice of the institution of such suits, and permits Aagard, through its counsel, to defend the same, and gives all needed information, assistance and authority to enable Aagard to do so. Aagard's obligation to meet the expenses of defending such suit and for payment of any award for infringement is expressly limited to an amount no greater than the purchase price of the IOS. Subject to the foregoing and in case of final award or damages in such suit. Aagard, at its option, may pay such award or remove said IOS and refund the purchase price so that Aagard's total liability shall not exceed the purchase price of the IOS. In case the structure of the IOS in suite is held to infringe any U.S. patent and its use thereof is enjoined, Aagard may at its option: (A) Obtain for the purchaser the right to continue using the IOS, or (B) Replace the same with non-infringing equipment, or (C) Modify the IOS so that it is non-infringing or (D) Remove the IOS and refund the purchase price reduced by a factor of use allowance of twenty (20%) percent per year. Because Aagard cannot know or control the use or nature and character of products produced on the IOS, Aagard assumes no responsibility for any damages or expenses which may be incurred in the defense of infringement actions brought by third parties against the purchaser and/or his customers for infringement of patent claims directed to: (1) the package manufactured by the IOS, (2) the design and construction of the products handled by the IOS, and (3) the method or process carried out on the IOS, including, but not limited to, all infringement actions against Aagard for patent infringement or as a contributory infringer.

18. **COPYING:** Purchaser recognizes that the IOS has been designed and built through expenditure of substantial time and money by Aagard, and purchaser agrees not to make drawings of the IOS or any portions thereof, or permit others to do so, and will not duplicate or conspire in the duplication of the IOS.

19. **DAMAGES:** Aagard shall not be liable for any actual or consequential damages resulting to the purchaser by reason of this sale.

20. **LOCAL LAW AND CONDITIONS:** If national or local laws, regulations, orders, etc. or unusual climate conditions require modification of the IOS not within the Aagard standard specifications, the purchaser shall specify in detail and pay for such modifications according to Aagard's normal pricing policy in addition to the purchase price stated. If such modifications alter the performance or prevent the IOS from performing according to specifications, Aagard shall not be liable therefore and shall not be required to meet these specifications to the extent the performance may be adversely affected.

21. **PERFORMANCE:** The IOS will be deemed acceptable under the terms and conditions of this contract if the purchaser has not given written notification to Aagard to the contrary within sixty (60) days from the date of shipment or in the event the purchaser continues to use the IOS.

22. **LAW:** The rights and duties of all persons and the construction and effect of all provisions hereof shall be governed by and construed according to the laws of Minnesota.

23. **ENTIRE AGREEMENT:** This document constitutes the entire agreement between the purchaser and Aagard for the IOS and is not an acceptance of Purchaser's purchase order or subject to purchaser's delivery order, and inures only to the benefit of the purchaser. Should any of the Terms and Conditions of the purchaser's order be at variance with any of the Terms and Conditions contained herein, it is understood and agreed that Aagard Terms and Conditions will prevail.

24. **COMPLIANCE WITH EXECUTIVE ORDER OF PRESIDENT:** Aagard agrees to comply with the provisions of Section 202 of the President's Executive Order 11246 and any amendments thereto and the Rules and Regulations issued pursuant to Section 201 thereof and, Aagard warrants that it will comply with such Executive Order and Rules and Regulations to the extent the same are applicable to the manufacture of the IOS.

Efficiency and Warranty Statement

This topic is considered as-built documentation at the time of machine shipment and will not be updated

The Aagard Group, LLC guarantees 97% efficiency. The guarantee ensures that Aagard machines will perform as specified. All Aagard machinery is thoroughly tested to the highest standards.

The system running efficiency
defined as follows:

Total Machine Run Time
Total Machine Available Time

$$466/480 = 0.97 \times 100 = 97\% \text{ efficiency}$$

Total machine available time does not include time lost because of the following:

- Failure to supply products to the pre-defined quality standards
- No operators available to start the machine
- No cartons, trays and/or cases or out of specification cartons, trays and/or cases
- Upstream or downstream line stoppages
- Cleaning, preventative maintenance and scheduled downtime stoppages
- Machine ramp up/ramp down time (from stop situation – caused by line ramp up/down time)

Total machine available time does include time lost because of the following:

- Machinery adjustments
- Product jams or placement issues
- Carton, tray and/or case jams
- Adhesive faults
- Mechanical faults
- Electrical faults

Equipment covered for defects in material and/or workmanship for a period of one year, or 7500 operating hours. This warranty excludes consumables, such as plastic wear guides, vacuum cups, etc. Changes to the programmable controller logic program or mechanical modifications without written approval of The Aagard Group may result in undesirable machine operations and will void the warranty.


Outside components are covered by outside manufacturers' warranties according to the provisions of each respective manufacturer's warranty.

Documentation Accuracy Statement

While every precaution has been taken in the preparation of this document, the publisher and the author assume no responsibility for errors or omissions, or for damages resulting from the use of information contained in this document.

NOTE: Screen shots displayed within this documentation may appear slightly differently due to differences in operating system platforms and user screen settings

Floor Plan



Continuous Running

The system will continue to run as long as new product is available, packaging supplies (carton blanks, hot melt adhesive, etc.) are replenished, and the product is removed.

[Case Blanks](#)

[Glue](#)

Case Blanks

Case Blanks

To replenish the magazine while the machine is running, stack the case blanks behind the follower plate and then slide the follower out from the stack. Move the follower plate to the end of the stack and push against the stack, removing any gaps that may be present before resetting the follower onto the chain.



Glue

Glue Tanks


Hot melt adhesive: Replenish the hot melt adhesive in the Nordson glue system per Nordson directions as required. To load glue pellets, lift the cover of the glue tank and gently drop glue pellets into the tank. Fill to fill level line (see picture below). Close the cover.

⚠ DANGER ⚠

Under no circumstances should you reach into a hot glue tank.

Warning: Do not overfill!

SAMPLE IMAGE



Please refer to the [Nordson ProBlue Adhesive System Manual](#) for information about the hot melt applicator. The Nordson Manual contains everything from electrical wiring diagrams to operation to troubleshooting.

Sequence of Operation

This narrative will describe, in detail, how each section of the system functions in order to help the user understand the cause and effect of each input and output. Inputs (electrical devices and signals) are discussed with references as to what occurs when they are triggered. A detailed list of each sensor and its function is located after this section. An input is a signal which informs the machine controller of an event occurring. An output is the machine controller sending the machine an instruction; outputs can be thought of as the signals and devices that do the work. A thorough understanding of the machine and how it functions will greatly aid in troubleshooting any problems that may arise.

CASE PACKER

Infeed

The Infeed Conveyor (MT1302) motor accepts the cartons from the upstream conveyor and delivers them to the side belts.



The Non-Operator Side Side Belt (MT1403) and Operator Side Side Belt (MT1406) motors launch the cartons into the downstacker flights. These side belts travel more quickly than the infeed conveyor to ensure proper gap between cartons.

Downstacker

The First Carton In Downstacker (PE31704) photo eye senses when the first carton is on the top of the downstacker flights, and the Second Carton In Downstacker (PE31703) photo eye senses when the second carton is on the top of the downstacker flights. As the side belts present a layer of cartons, the Downstacker Flights, driven by SM4 Fixed Flight 1, SM5 Fixed Flight 2, SM2 Adjustable Flight 1, and SM3 Adjustable Flight 2 servo motors, will lower by one product height, making room for the next layer. When the last layer is presented to the downstacker, the complete stack will be lowered to the bottom of the downstacker chamber, presenting the stack for the downstack pusher.

Downstack Pusher

Once the downstack pusher receives a stack complete signal from the downstacker, the downstack pusher virtual master begins its cycle.



The Downstack Pusher (SM6) then moves the stack to the loader and returns to its starting position. The Product Conditioner (SV30703) solenoid valve extends a plate down, to the top of the product, to ensure any bulged cartons will clear and enter the case.

Loader

After the product has been cross-pushed into the load station, the Loader (SM7), which is cammed to the loader virtual master, moves the product into the case. If the Case Present At Load (PE31903) photo eye does not sense a case has been properly set up at the load station, the loader will not advance. The system will stop and prompt the operator to remove the case from the load station.

As the stack is moving toward the case, the Fun/Tucker and Funnel (SM9 and SM8) servo motors start to rotate into the case. At the same time, the Fun/Tucker In/Out and Funnel In/Out (SV30406 and SV30407) solenoid valves are activated to move the funnels $\frac{3}{4}$ " toward the case. This action positions the funnel inside the score line of the case. The funnels then guide the product into the case and are retracted before the cartons are fully in the case.

Magazine

The Magazine Top Clip and the Magazine Bottom Clip (SV30705 and SV30707) solenoid valves open when the robot is moving toward the magazine. To open the case blank, rotating clips on each side of the case blank hold the back panel of the case while the robot pulls the front panel forward and down. After the robot has partially pulled the case from the magazine, the Magazine Rotate Clip (SV30306) solenoid valve opens the clips to release the case. The top clip closes sooner than the bottom and rotating clips. The bottom and rotating clips close after the case has been fully removed from the magazine. If the Case Packer Robot Vacuum (VS31806) vacuum switch from the robot is not made, a fault message is displayed.

The Magazine Advance Cylinder (SV05) will cycle if the Magazine Advance Switch (PX18) is not made and the Robot is not picking a case blank. If the cylinder cycles more than 10 times without meeting the Magazine Advance Switch, a fault message will be displayed.

The Magazine Advance (SV30401) solenoid valve activates a cylinder which moves the magazine advance chains forward with a ratcheting motion.

When the blanks in the magazine no longer block the Case Blanks Present (PE31803) photo eye, the HMI will indicate the magazine is low, a blue stack light will illuminate, and the horn will sound. If the magazine is not filled after 25 additional case blanks have been picked, the machine will stop.

Robot

The robot's cycle stop position is at the magazine.



If the robot is signaled to pick a blank, the Robot Vacuum (SV30408) solenoid valve turns on vacuum. The robot proceeds with the new case to the load station. The Case Pusher (SV30403) extends to hold the case at the load station, keeping it vertical with the flights as it moves into compression. The initial move away from the magazine is the Robot X-Axis (SM12) move, which arcs down by adding the Robot Z-Axis (SM13) to place the case in the load station. The robot then moves up and around the case being loaded and proceeds to the magazine.

Flights

The Case Flights (SM14) servo motor matches the robot x-axis movement, and advances the loaded cases through tucking, gluing, and compression.

Load Station

When an empty case blank is set up in the load station, the Load Cup Lift (SV30801) solenoid valve extends the air cylinders, and the Load Vacuum (SV30308) solenoid valve turns on the vacuum. This action holds the case in position while loading. Before the case is moved out of the load station, vacuum is turned off and the cylinders are retracted.

Fun/Tuckers

The Funnel In/Out and the Fun/Tucker In/Out (SV30407 and SV30406) solenoid valves move the funnels into the case. The Funnel and Fun/Tucker (SM8 and SM9) servos are cammed to the case packer main virtual master for funneling the cartons into the case during loading. The funnel and fun/tucker are rotated to guide the cartons into the case. As the stack is being loaded into the case, the funnels retract while the Tucker (SM10) tucks the leading flap on the operator side of the case, and the Product Stop (SM11) partially closes the trailing flap on the operator side. Closing these flaps gives the carton stacks a surface against which to square as they are loaded into the case. As the loader retracts from the case, the funnel rotates away from the case. The fun/tucker rotates away, and continues to rotate, enabling the tuckers mounted on the back side to tuck the leading flap on the non-operator side of the case. As the case moves forward out of the load station and into compression, the fun/tucker and tucker move in unison to tuck the trailing vertical flap. The Distorted Case (PE31904) photo eye looks for the trailing edge of the case to ensure flaps are properly tucked.

Glue

Glue is applied to the vertical flaps as the case moves from the load station to compression. The Lower Glue Non-Operator Side, Lower Glue Operator Side, Upper Glue Non-Operator Side and Upper Glue Operator Side (SV30805, SV30806, SV30807 and SV30808) solenoid valves are all cammed to the case packer main virtual master. Glue is applied only if vacuum is made at the Load Vacuum (VS31708).

Compression

When the case reaches the compression station, the Case Stop (SV30402) solenoid valve extends to stop the top leading edge of the case, keeping it square. The case pusher and flights ensure that the case is pushed up against the stop.



The Lower Compression Non-Operator Side, Lower Compression Operator Side, Upper Compression Non-Operator Side and Upper Compression Operator Side (SM15, SM16, SM17 and SM18) servo motors are all cammed to the case packer main virtual master.

The compression plates fold the horizontal flaps against the glue on the vertical flaps. The flights move the case out of compression and into the orienter while the next case is moved into compression.

ORIENTER

Case Tip/Reject

The case packer flights push the case out of compression onto the Tip/Reject Roller Conveyor (MT1501) in the orienter. As the case leaves the case packer, the Non-Operator Side Open Flap and Operator Side Open Flap (PE51402 and PE51401) photo eyes ensure the case flaps are closed and properly glued. The case is stopped by the Tipper Case Stop (SV50703). If either of the open flap eyes is blocked while the case passes by, the Case Tip R (SM20) retracts and the Tipper Reject Flights (SM19) pushes the case out of the machine. If the case is good, the Case Tip R catches the top, operator side, of the case while the flights push the bottom, non-operator side, out toward the operator side of the machine. This action tips the case toward the backstop (what was the non-operator side of the case is now the bottom). The flights push the case against the backstop and retract, the tipper case stop retracts, and the roller conveyor starts to move the case forward, transferring it to the Case Conveyor (MT50701).

Case Rotate

If the product requires, case rotate is enabled by default.



The Case Rotate (SM21) servo motor rotates an arm across the conveyor. The Case At Rotate (PE51505) photo eye senses when a case is approaching the arm. When sensed, the Case Rotate Vacuum (SV50201) solenoid valve is triggered and attaches the case to the arm with a vacuum cup. The arm rotates 90 degrees ($\frac{1}{4}$ turn) counter-clockwise and releases vacuum (what was the operator side of the case is now the leading side). When the case has moved past the Case Present After Rotate (PE51506) photo eye, the arm retracts and waits for the next case.

Device List

NOTE:

"CP" preceding a grid location indicates the device is in the Case Packer

"O" preceding a grid location indicates the device is in the Orienter

Device listings with no Brick Slice Point or I/O Type indicated are intentional.

By default, the table below is sorted alphabetically by device type. Click on a column heading to sort by that column.

| Type | Name | Location | Description | Aagard PN | Brick Slice Point | I/O Type | Grid |
|------------------|---------|--------------------|----------------------------------------------|-----------|-------------------|---------------|--------|
| Cylinder Switch | CS31606 | Case Packer Infeed | Product Conditioner | Z0123202 | B1 S14 P6 | Input-Digital | CP_D15 |
| Cylinder Switch | CS31901 | Case Packer | Case Packer Case Stop | Z0123236 | B1 S17 P1 | Input-Digital | CP_I19 |
| Cylinder Switch | CS31902 | Case Packer | Case Pusher | Z0123236 | B1 S17 P2 | Input-Digital | CP_I17 |
| Cylinder Switch | CS51507 | Orienter | Tipper Case Stop | Z0123236 | B5 S11 P7 | Input-Digital | O_F4 |
| Cylinder Switch | CS31607 | Case Packer Infeed | Product Conditioner | Z0123202 | B1 S14 P7 | Input-Digital | CP_D15 |
| Disconnect | DS501 | Main Cabinet | Main Disconnect | Z0007466 | | | CP_C4 |
| Disconnect | DS9402 | Case Packer | Glue Disconnect | Z0031001 | | | O_H14 |
| Emergency Stop | ES24301 | HMI Cabinet | System Emergency Stop | Z0004654 | B1 S11 P8 | Input-Digital | CP_N12 |
| Emergency Stop | ES24303 | Case Packer Infeed | Case Packer Non Operator Side Emergency Stop | Z0004654 | B1 S12 P5 | Input-Digital | CP_C6 |
| Emergency Stop | ES24304 | Case Packer | Case Packer Operator Side Emergency Stop | Z0004654 | B1 S12 P3 | Input-Digital | CP_L16 |
| Emergency Stop | ES26303 | Orienter Cabinet | Orienter Non Operator Side Emergency Stop | Z0004654 | B5 S7 P8 | Input-Digital | O_A13 |
| Emergency Stop | ES26304 | Orienter | Orienter Operator Side Emergency Stop | Z0004654 | B5 S7 P6 | Input-Digital | O_H12 |
| Filter Regulator | FR60201 | Case Packer | Filter Regulator | Z0067505 | | | CP_G5 |
| Guard Switch | GS24501 | Case Packer | Guard Door 2-1 | Z0121797 | B1 S13 P1 | Input-Digital | CP_G4 |
| Guard Switch | GS24502 | Case Packer | Guard Door 2-2 | Z0121797 | B1 S13 P2 | Input-Digital | CP_G8 |
| Guard Switch | GS24503 | Case Packer | Guard Door 2-3 | Z0121797 | B1 S13 P3 | Input-Digital | CP_L16 |
| Guard Switch | GS24504 | Case Packer | Guard Door 2-4 | Z0121797 | B1 S13 P4 | Input-Digital | CP_L17 |
| Guard Switch | GS24505 | Case Packer | Guard Door 2-5 | Z0121797 | B1 S13 P5 | Input-Digital | CP_C16 |

| Type | Name | Location | Description | Aagard PN | Brick Slice Point | I/O Type | Grid |
|---------------|---------|---------------------|------------------------------------------|-----------|-------------------|---------------|--------|
| Guard Sw itch | GS24508 | Case Packer | Guard Door 2-6 | Z0121797 | B1 S13 P6 | Input-Digital | CP_C13 |
| Guard Sw itch | GS24509 | Case Packer | Guard Door 2-7 | Z0121797 | B1 S13 P7 | Input-Digital | CP_C10 |
| Guard Sw itch | GS26501 | Orienter | Guard Door 3-1 | Z0121797 | B5 S8 P1 | Input-Digital | O_I6 |
| Servo Pow er | HCS01 | Case Packer Cabinet | Case Packer Servo Pow er Converter | Z0103625 | B1 S11 P3 | Input-Digital | CP_C6 |
| Servo Pow er | HCS01 | Case Packer Cabinet | Case Packer Servo Pow er Converter | Z0103625 | B1 S2 P4 | Output-Live | CP_C6 |
| Servo Pow er | HCS02 | Orienter Cabinet | Servo Pow er Converter | Z0103625 | B5 S1 P4 | Output-Live | O_B14 |
| Servo Pow er | HCS02 | Orienter Cabinet | Servo Pow er Converter | Z0103625 | B5 S7 P4 | Input-Digital | O_B14 |
| Motor | MT807 | Orienter | Case Conveyor | 795042 | | | O_C12 |
| Motor | MT1303 | Case Packer Infeed | Infeed Conveyor | Z0023823 | | | CP_F7 |
| Motor | MT1403 | Case Packer Infeed | Non Operator Side Side Belts | Z0023823 | | | CP_D10 |
| Motor | MT1406 | Case Packer Infeed | Operator Side Side Belts | Z0023823 | | | CP_F10 |
| Motor | MT1502 | Orienter | Tip/Reject Conveyor | 795041 | | | O_B4 |
| Push Button | PB19904 | HMI Cabinet | PC Reset | Z0129818 | | | CP_N12 |
| Push Button | PB30101 | HMI Cabinet | System Start | Z0005435 | B1 S11 P6 | Input-Digital | CP_N12 |
| Push Button | PB30101 | HMI Cabinet | System Start | Z0005435 | B1 S1 P1 | Output-Live | CP_N12 |
| Push Button | PB30205 | Case Packer Cabinet | Case Packer System Start | Z0005435 | B1 S12 P1 | Input-Digital | CP_C6 |
| Push Button | PB30205 | Case Packer Cabinet | Case Packer System Start | Z0005435 | B1 S2 P5 | Output-Live | CP_C6 |
| Push Button | PB31307 | HMI Cabinet | System Cycle Stop | Z0004653 | B1 S11 P7 | Input-Digital | CP_N12 |
| Push Button | PB31402 | Case Packer | Case Packer Non Operator Side Cycle Stop | Z0004653 | B1 S12 P2 | Input-Digital | CP_C6 |
| Push Button | PB31404 | Case Packer Infeed | Case Packer Operator Side Cycle Stop | Z0004653 | B1 S12 P4 | Input-Digital | CP_L16 |
| Push Button | PB51105 | Orienter | Orienter Operator Side Cycle Stop | Z0004653 | B5 S7 P5 | Input-Digital | O_H12 |
| Push Button | PB51107 | Orienter Cabinet | Orienter Non Operator Side Cycle Stop | Z0004653 | B5 S7 P7 | Input-Digital | O_A13 |
| Photo Eye | PE31002 | Case Packer Infeed | Non Op Side Lower Downstacker Reference | Z0123440 | B1 S8 P2 | Input-Digital | CP_D13 |
| Photo Eye | PE31003 | Case Packer Infeed | Non Op Side Upper | Z0123440 | B1 S8 P3 | Input-Digital | CP_D11 |

| Type | Name | Location | Description | Aagard PN | Brick Slice Point | I/O Type | Grid |
|------------------|---------|----------------------|---------------------------------------------|-----------|-------------------|---------------|--------|
| | | | Dow nstacker Reference | | | | |
| Photo Eye | PE31004 | Case Packer Infeed | Operator Side Low er Dow nstacker Reference | Z0123440 | B1 S8 P4 | Input-Digital | CP_G13 |
| Photo Eye | PE31005 | Case Packer Infeed | Operator Side Upper Dow nstacker Reference | Z0123440 | B1 S8 P5 | Input-Digital | CP_G11 |
| Photo Eye | PE31104 | Case Packer Infeed | Case Packer Flights | Z0123440 | B1 S9 P4 | Input-Digital | CP_H13 |
| Photo Eye | PE31702 | Case Packer Infeed | Product in Side Belts | Z0123440 | B1 S15 P2 | Input-Digital | CP_G10 |
| Photo Eye | PE31703 | Case Packer Infeed | 2nd Carton At Dow nstacker | Z0097847 | B1 S15 P3 | Input-Digital | CP_D11 |
| Photo Eye | PE31704 | Case Packer Infeed | 1st Carton At Dow nstacker | Z0096984 | B1 S15 P4 | Input-Digital | CP_E12 |
| Photo Eye | PE31707 | Case Packer Infeed | Product At Dow nstack Pusher | Z0123440 | B1 S15 P7 | Input-Digital | CP_D12 |
| Photo Eye | PE31803 | Case Packer Magazine | Case Blanks Present | Z0096984 | B1 S16 P3 | Input-Digital | CP_H11 |
| Photo Eye | PE31903 | Case Packer | Case Present at Load | Z0123715 | B1 S17 P3 | Input-Digital | CP_H15 |
| Photo Eye | PE31904 | Case Packer | Distorted Case | Z0123440 | B1 S17 P4 | Input-Digital | CP_H16 |
| Photo Eye | PE31905 | Case Packer Infeed | Product At Loader | Z0123440 | B1 S15 P1 | Input-Digital | CP_F15 |
| Photo Eye | PE51401 | Orienter | Operator Side Open Case Flap | Z0123440 | B5 S10 P1 | Input-Digital | CP_I19 |
| Photo Eye | PE51402 | Orienter | Non Operator Side Open Case Flap | Z0123440 | B5 S10 P2 | Input-Digital | CP_H19 |
| Photo Eye | PE51503 | Orienter | Case At Tip | Z0123440 | B5 S11 P3 | Input-Digital | O_D1 |
| Photo Eye | PE51504 | Orienter | Low er Case Reject Chute | Z0123440 | B5 S11 P4 | Input-Digital | O_J5 |
| Photo Eye | PE51505 | Orienter | Case At Rotate | Z0123440 | B5 S11 P5 | Input-Digital | O_D8 |
| Photo Eye | PE51506 | Orienter | Case Present After Rotate | Z0123440 | B5 S11 P6 | Input-Digital | O_D10 |
| Photo Eye | PE51508 | Orienter | Upper Case Reject Chute | Z0123440 | B5 S11 P8 | Input-Digital | O_J5 |
| Pressure Sw itch | PS31201 | Case Packer | System Air Pressure | Z0064191 | B1 S10 P1 | Input-Digital | CP_G5 |
| Prox | PX31001 | Case Packer Infeed | Spatula Reference | Z0098920 | B1 S8 P1 | Input-Digital | CP_F9 |
| Prox | PX31006 | Case Packer Infeed | Dow nstack Pusher Reference | Z0098920 | B1 S8 P6 | Input-Digital | CP_E4 |
| Prox | PX31007 | Case Packer | Loader Probe | Z0098920 | B1 S8 P7 | Input-Digital | CP_B15 |

| Type | Name | Location | Description | Aagard PN | Brick Slice Point | I/O Type | Grid |
|-------------|----------|----------------------|---------------------------------|-----------|-------------------|---------------|--------|
| Prox | PX31102 | Case Packer | Case Packer Robot X | Z0098920 | B1 S9 P2 | Input-Digital | CP_G14 |
| Prox | PX31103 | Case Packer | Z Axis Probe | Z0098920 | B1 S9 P3 | Input-Digital | CP_I16 |
| Prox | PX31908 | Case Packer | Load Gate Closed | Z0098920 | B1 S17 P8 | Input-Digital | CP_D16 |
| Prox | PX31804 | Case Packer Magazine | Case Magazine Advance | Z0098920 | B1 S16 P4 | Input-Digital | CP_H13 |
| Prox | PX51001 | Orienter | Case Tip Y Reference | Z0098920 | B5 S6 P1 | Input-Digital | O_C4 |
| Prox | PX51002 | Orienter | Case Tipper Reference | Z0098920 | B2 S5 P2 | Input-Digital | O_G3 |
| Regulator | Reg30401 | Case Packer Magazine | Magazine Advance | Z0016121 | | | CP_G12 |
| Regulator | Reg30805 | Case Packer | Lower Fixed Glue Regulator | Z0016121 | | | CP_F17 |
| Regulator | Reg30806 | Case Packer | Lower Adjustable Glue Regulator | Z0016121 | | | CP_J16 |
| Regulator | Reg30807 | Case Packer | Upper Fixed Glue Regulator | Z0016121 | | | CP_H16 |
| Regulator | Reg30808 | Case Packer | Upper Adjustable Glue Regulator | Z0016121 | | | CP_K17 |
| Servo Motor | SM01 | Case Packer Infeed | Transfer Spatula | Z0103609 | | | CP_F9 |
| Servo Motor | SM02 | Case Packer Infeed | Non Op Side Lower Downstacker | Z0103609 | | | CP_D9 |
| Servo Motor | SM03 | Case Packer Infeed | Non Op Side Upper Downstacker | Z0103609 | | | CP_D14 |
| Servo Motor | SM04 | Case Packer Infeed | Operator Side Lower Downstacker | Z0103609 | | | CP_F9 |
| Servo Motor | SM05 | Case Packer Infeed | Operator Side Upper Downstacker | Z0103609 | | | CP_F14 |
| Servo Motor | SM06 | Case Packer Infeed | Down Stack Pusher | Z0103609 | | | CP_E3 |
| Servo Motor | SM07 | Case Packer Infeed | Loader | Z0103609 | | | CP_A15 |
| Servo Motor | SM08 | Case Packer Infeed | Funnel | Z0103607 | | | CP_F15 |
| Servo Motor | SM09 | Case Packer Infeed | Fun Tucker | Z0103607 | | | CP_F16 |
| Servo Motor | SM10 | Case Packer | Tucker | Z0103607 | | | CP_K15 |
| Servo Motor | SM11 | Case Packer | Product Stop | Z0103607 | | | CP_J15 |
| Servo Motor | SM12 | Case Packer | Case Packer Robot X Axis | Z0103609 | | | CP_H18 |

| Type | Name | Location | Description | Aagard PN | Brick Slice Point | I/O Type | Grid |
|----------------|---------|----------------------|--------------------------------------|-----------|-------------------|---------------|--------|
| Servo Motor | SM13 | Case Packer | Case Packer Robot Z Axis | Z0103610 | | | CP_I17 |
| Servo Motor | SM14 | Case Packer | Case Packer Flights | Z0103607 | | | CP_G18 |
| Servo Motor | SM15 | Case Packer | Low er Compression Non Operator Side | Z0103607 | | | CP_G17 |
| Servo Motor | SM16 | Case Packer | Low er Compression Operator Side | Z0103607 | | | CP_J17 |
| Servo Motor | SM17 | Case Packer | Upper Compression Non Operator Side | Z0103607 | | | CP_G18 |
| Servo Motor | SM18 | Case Packer | Upper Compression Operator Side | Z0103607 | | | CP_J17 |
| Servo Motor | SM19 | Orienter | Case Tip Y | Z0103607 | | | O_D6 |
| Servo Motor | SM20 | Orienter | Case Tipper | Z0103610 | | | O_E4 |
| Servo Motor | SM21 | Orienter | Case Rotate | Z0103607 | | | O_D8 |
| Solenoid Valve | SV24223 | Case Packer | Manual Dump Valve | Z0067506 | | | CP_G5 |
| Solenoid Valve | SV24223 | Case Packer | System Air Dump | Z0036804 | | | CP_G5 |
| Solenoid Valve | SV30306 | Case Packer Magazine | Magazine Rotate Clips | Z0023954 | B1 S3 P6 | Output-Live | CP_G11 |
| Solenoid Valve | SV30307 | Case Packer | Load Cups Blow back | Z0023954 | B1 S3 P7 | Output-Live | CP_G18 |
| Solenoid Valve | SV30308 | Case Packer | Load Vacuum | Z0014917 | B1 S3 P8 | Output-Live | CP_H13 |
| Solenoid Valve | SV30401 | Case Packer Magazine | Magazine Advance | Z0023954 | B1 S4 P1 | Output-Live | CP_G11 |
| Solenoid Valve | SV30402 | Case Packer | Case Packer Case Stop | Z0024215 | B1 S4 P2 | Output-Live | CP_G18 |
| Solenoid Valve | SV30403 | Case Packer | Case Pusher | Z0024215 | B1 S4 P3 | Output-Live | CP_I15 |
| Solenoid Valve | SV30406 | Case Packer Infeed | Fun Tucker | Z0023954 | B1 S4 P6 | Output-Live | CP_G18 |
| Solenoid Valve | SV30407 | Case Packer Infeed | Funnel In/Out | Z0023954 | B1 S4 P7 | Output-Live | CP_G18 |
| Solenoid Valve | SV30408 | Case Packer | Case Packer Robot Vacuum | Z0014917 | B1 S4 P8 | Output-Live | CP_I6 |
| Solenoid Valve | SV30703 | Case Packer Infeed | Product Conditioner | Z0029339 | B1 S6 P3 | Output-E-Stop | CP_D15 |
| Solenoid Valve | SV30703 | Case Packer Infeed | Product Conditioner | Z0029339 | B1 S6 P4 | Output-E-Stop | CP_D15 |
| Solenoid Valve | SV30705 | Case Packer Magazine | Magazine Top Clip | Z0029339 | B1 S6 P5 | Output-E-Stop | CP_G11 |
| Solenoid Valve | SV30705 | Case Packer Magazine | Magazine Top Clip | Z0029339 | B1 S6 P6 | Output-E-Stop | CP_G11 |

| Type | Name | Location | Description | Aagard PN | Brick Slice Point | I/O Type | Grid |
|----------------|---------|----------------------|-------------------------------|-----------|-------------------|---------------|--------|
| Solenoid Valve | SV30707 | Case Packer Magazine | Magazine Bottom Clip | Z0029339 | B1 S6 P8 | Output-E-Stop | CP_G11 |
| Solenoid Valve | SV30707 | Case Packer Magazine | Magazine Bottom Clip | Z0029339 | B1 S6 P7 | Output-E-Stop | CP_G11 |
| Solenoid Valve | SV30801 | Case Packer | Load Cups Lift | Z0029339 | B1 S7 P2 | Output-E-Stop | CP_G18 |
| Solenoid Valve | SV30801 | Case Packer | Load Cups Lift | Z0029339 | B1 S7 P1 | Output-E-Stop | CP_G18 |
| Solenoid Valve | SV30805 | Case Packer | Low er Glue Non Operator Side | Z0004483 | B1 S7 P5 | Output-E-Stop | CP_H16 |
| Solenoid Valve | SV30806 | Case Packer | Low er Glue Operator Side | Z0004483 | B1 S7 P6 | Output-E-Stop | CP_J16 |
| Solenoid Valve | SV30807 | Case Packer | Upper Glue Non Operator Side | Z0004483 | B1 S7 P7 | Output-E-Stop | CP_H16 |
| Solenoid Valve | SV30808 | Case Packer | Upper Glue Operator Side | Z0004483 | B1 S7 P8 | Output-E-Stop | CP_J16 |
| Solenoid Valve | SV50201 | Orienter | Case Rotate Vacuum | Z0014917 | B5 S2 P1 | Output-Live | O_C8 |
| Solenoid Valve | SV50703 | Orienter | Tipper Case Stop | Z0024214 | B5 S4 P4 | Output-E-Stop | O_C7 |
| Solenoid Valve | SV50703 | Orienter | Tipper Case Stop | Z0024214 | B5 S4 P3 | Output-E-Stop | O_C7 |
| Vacuum Sw itch | VS31202 | Case Packer | System Vacuum | Z0089514 | B1 S10 P2 | Input-Digital | O_A4 |
| Vacuum Sw itch | VS31708 | Case Packer | Load Vacuum | Z0089514 | B1 S15 P8 | Input-Digital | CP_G13 |
| Vacuum Sw itch | VS31806 | Case Packer | Case Packer Robot Vacuum | Z0089514 | B1 S16 P6 | Input-Digital | CP_I16 |
| Vacuum Sw itch | VS51305 | Orienter | Case Rotate Vacuum Present | Z0089514 | B5 S9 P5 | Input-Digital | O_D8 |
| Transformer | XF10002 | Case Packer | 480 VAC - 120 VAC | 794578 | | | CP_D3 |

Fuse Locations

A fuse location label is located inside each electrical panel.

SAMPLE IMAGE



Sample Fuse Location Label

| Number | Location | Name | Partnum | PartDesc | Bin# |
|---------|----------|--------|----------|------------------------------------------------------------|------|
| FU304 | CP2 | KTKR10 | Z0128852 | Class CC 10 amps 600 VAC 300 VDC fast-acting fuse | |
| FU321 | CP2 | FNQR30 | Z0128844 | Class CC 30 amps; 600 VAC; 300 VDC; Time Delay fuses | |
| FU406 | CP2 | LPCC3 | Z0005681 | Class CC 3 amps 600VAC 250VDC dual-element time-delay fuse | |
| FU410 | CP2 | LPCC3 | Z0005681 | Class CC 3 amps 600VAC 250VDC dual-element time-delay fuse | |
| FU1101 | CP2 | LPCC6 | Z0128811 | Class CC 6 amps 600VAC 250VDC dual-element time-delay fuse | |
| FU10113 | CP2 | KTKR5 | Z0128849 | Class CC 5 amps 600 VAC 300 VDC fast-acting fuse | |
| FU22008 | CP2 | ATC5 | Z0128799 | ATC series 5 amps 32 Volts Automotive fuse | |
| FU22009 | CP2 | ATC10 | Z0128800 | ATC series 10 amps 32 Volts Automotive fuse | |
| FU22010 | CP2 | ATC5 | Z0128799 | ATC series 5 amps 32 Volts Automotive fuse | |
| FU22011 | CP2 | ATC5 | Z0128799 | ATC series 5 amps 32 Volts Automotive fuse | |
| FU22012 | CP2 | ATC5 | Z0128799 | ATC series 5 amps 32 Volts Automotive fuse | |
| FU22013 | CP2 | ATC5 | Z0128799 | ATC series 5 amps 32 Volts Automotive fuse | |
| FU22014 | CP2 | ATC1 | Z0128798 | ATC series 1 amps 32 Volts Automotive fuse | |

Drive Function and Associated Devices

The following table indicates how devices are related to drives, and the function of the particular device.

| Drive | Device | Function | |
|--------------------|--------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------|
| Case Packer | | | |
| Infeed | | | |
| SD1 | Spatula | Guides the product into the correct position in the downstacker | |
| | PE31704 | 1st Carton At Downstacker Photo Eye | Senses when the 1st carton is at the top of the downstack chamber |
| | PE31703 | 2nd Carton At Downstacker Photo Eye | Senses when the 2nd carton is at the top of the downstack chamber |
| | PX31001 | Spatula Reference Proximity Switch | Senses when the spatula is in its reference position |
| MT1 | Infeed Conveyor | Advances product into the machine and up to the side belts | |
| | VFD1302 | Infeed Conveyor VFD | Controls the speed of the infeed conveyor |
| MT2 | Side Belts | Collates the incoming product and sends it into the Downstacker | |
| | PE31702 | Product In Side Belts | Senses when product is present in the side belts |
| | VFD1402 | Side Belts VFD | Controls the speed of the side belts |
| Downstacker | | | |
| SD2 | Adjustable Downstacker 1 | Accepts incoming products from the side belts and indexes allowing a specified number of products to accumulate prior to lowering the products onto the accumulation deck | |
| | PE31704 | 1st Carton At Downstacker Photo Eye | Senses when the 1st carton is at the top of the downstack chamber |
| | PE31703 | 2nd Carton At Downstacker Photo Eye | Senses when the 2nd carton is at the top of the downstack chamber |
| | PE31002 | Non Operator Side Lower Downstacker Reference Photo Eye | Senses when the non operator side lower downstacker is in its reference position |
| SD3 | Adjustable Downstacker 2 | Accepts incoming products from the side belts and indexes allowing a specified number of products to accumulate prior to lowering the products onto the accumulation deck | |
| | PE31704 | 1st Carton At Downstacker Photo Eye | Senses when the 1st carton is at the top of the downstack chamber |
| | PE31703 | 2nd Carton At Downstacker Photo Eye | Senses when the 2nd carton is at the top of the downstack chamber |
| | PE31003 | Non Operator Side Upper Downstacker Reference Photo Eye | Senses when the non operator side upper downstacker is in its reference position |
| SD4 | Fixed Downstacker 1 | Accepts incoming products from the side belts and indexes allowing a specified number of products to accumulate prior to lowering the products onto the accumulation deck | |
| | PE31704 | 1st Carton At Downstacker Photo Eye | Senses when the 1st carton is at the top of the downstack chamber |
| | PE31703 | 2nd Carton At Downstacker Photo Eye | Senses when the 2nd carton is at the top of the downstack chamber |
| | PE31004 | Operator Side Lower Downstacker Reference Photo Eye | Senses when the operator side lower downstacker is in its reference position |
| SD5 | Fixed Downstacker 2 | Accepts incoming products from the side belts and indexes allowing a specified number of products to accumulate prior to lowering the products onto the accumulation deck | |

| Drive | Device | | Function |
|-------------------------|--------------------------|------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|
| | PE31704 | 1st Carton At Dow nstacker Photo Eye | Senses w hen the 1st carton is at the top of the dow nstack chamber |
| | PE31703 | 2nd Carton At Dow nstacker Photo Eye | Senses w hen the 2nd carton is at the top of the dow nstack chamber |
| | PE31005 | Operator Side Upper Dow nstacker Reference Photo Eye | Senses w hen the operator side upper dow nstacker is in its reference position |
| Downstack Pusher | | | |
| SD6 | Dow nstack Pusher | | Pushes the accumulated product out of the dow nstack chamber delivering it to the loader |
| | PX31006 | Dow nstack Pusher Reference Proximity Sw itch | Senses w hen the dow nstack pusher is in its reference position |
| SD24 | Dow nstack Pusher Master | | This is the virtual axis that the dow nstack pusher follow s |
| | PE31707 | Product At Dow nstack Pusher Photo Eye | Senses w hen product is present at the dow nstack pusher |
| SV30703 | Product Conditioner | | Applies dow nward pressure on the stacked product ensuring that it w ill fit into the case during loading |
| | CS31606 | Product Conditioner Extended Cylinder Sw itch | Senses w hen the cylinder is extended |
| | CS31607 | Product Conditioner Retracted Cylinder Sw itch | Senses w hen the cylinder is retracted |
| Loader | | | |
| SD7 | Loader | | Pushes the accumulated product out of the loader accumulation and into the partially formed case |
| | PX31007 | Loader Probe Proximity Sw itch | Senses w hen the loader is in its reference position |
| SD25 | Loader Master | | This is the virtual axis that the loader follow s |
| | PE31905 | Product At Loader Photo Eye | Senses w hen product is present at the loader |
| | PX31908 | Load Gate Closed Proximity Sw itch | Senses w hen the load gate is closed to allow the loader to cycle |
| Magazine | | | |
| SV30401 | Magazine Advance | | Advances the case blanks dow nstream tow ard the case former robot, maintaining sufficient pressure to pick |
| | PE31803 | Case Blanks Present Photo Eye | Senses w hen case blanks are present on the magazine advance chains |
| | PX31804 | Case Magazine Advance | Senses w hen cases are ready to be picked |
| Case Former | | | |
| SD8 | Funnel | | Opens the upstream minor flap and helps guide the product into the case |
| SD9 | Fun Tucker | | Opens the dow nstream minor flap and helps guide the product into the case, then tucks the trailing minor flap prior to compression |
| SD10 | Tucker | | Provides support for the case during loading and tucks the operator side trailing minor |
| SD11 | Product Stop | | Provides support for the case during loading and a backstop for incoming product to ensure it does not pass the operator side scoreline |
| SD12 | Case Packer Robot X Axis | | Moves the case packer robot upstream and dow nstream along the machines X axis |
| | PX31102 | Case Packer Robot X Axis Probe Proximity Sw itch | Senses w hen the case packer robot X is in its reference position |
| SD13 | Case Packer Robot Z Axis | | Moves the case packer robot up and dow n along the machines Z axis |

| Drive | Device | | Function |
|---------|--------------------------------------|----------------------------------------------------|-------------------------------------------------------------------------------------------------------------------|
| | PX31103 | Case Packer Robot Z Axis Probe Proximity Sw itch | Senses w hen case packer robot Z is in its reference position |
| SD14 | Case Packer Flights | | Advance the base of the case through the loading and compression areas of the machine |
| | PE31104 | Case Packer Flights Reference Photo Eye | Senses w hen the case packer flights are in their reference position |
| SD15 | Low er Compression Non Operator Side | | Compresses the low er non operator side major flap ensuring good adhesion and completing the case forming process |
| SD16 | Low er Compression Operator Side | | Compresses the low er operator side major flap ensuring good adhesion and completing the case forming process |
| SD17 | Upper Compression Non Operator Side | | Compresses the upper non operator side major flap ensuring good adhesion and completing the case forming process |
| SD18 | Upper Compression Operator Side | | Compresses the upper operator side major flap ensuring good adhesion and completing the case forming process |
| SD26 | Packer Main Master | | This is the virtual drive that all of the servo drives in the case former follow |
| | PE31903 | Case Present At Load Photo Eye | Senses w hen a case is present at the load station |
| | PE31904 | Distorted Case Present Photo Eye | Senses w hen a distorted case is present at the load station |
| | PE51402 | Non Operator Side Open Case Flap Present Photo Eye | Senses w hen a non operator side open case flap exists |
| | PE51401 | Operator Side Open Case Flap Present Photo Eye | Senses w hen a operator side open case flap exists |
| SV30306 | Magazine Rotate Clips | | Controls the sides of the cases in the magazine ensuring they are released at the proper time |
| SV30705 | Magazine Top Clip | | Controls the top of the cases in the magazine ensuring they are released at the proper time |
| SV30707 | Magazine Bottom Clip | | Controls the bottom of the cases in the magazine ensuring they are released at the proper time |
| SV30408 | Case Packer Robot Vacuum | | This valve controls the vacuum to the vacuum cups on the case packer robot head |
| | VS 31806 | Case Packer Robot Vacuum Present Vacuum Sw itch | Senses w hen the case packer robot has sufficient vacuum for operation |
| SV30403 | Case Pusher | | raises and low ers the case pusher, pushing the loaded case into the compression station |
| | CS31902 | Case Pusher Pushed Cylinder Sw itch | Senses w hen the case pusher cylinder is extended |
| SV30407 | Fun Tucker In / Out | | Moves the fun tucker in and out of the case to provide clearance for the case forming |
| SV30407 | Funnel In / Out | | Moves the funnel in and out of the case to provide clearance for the case forming |
| SV30308 | Load Vacuum | | This valve controls the vacuum supply to the vacuum cups at the case load station |
| | VS31708 | Load Vacuum Present Vacuum Sw itch | Senses w hen the load vacuum has sufficient vacuum for operation |
| SV30801 | Load Cups Lift | | Raises and low ers the load cups in order for the cases to clear as they travel dow nstream |
| SV30307 | Load Cups Blow back | | This valve controls the blow back to the vacuum cups at the case load station causing the case to be released |
| SV30402 | Case Stop | | Low ers stopping cases coming in to the compression station from advancing to far dow nstream |
| | CS31901 | Case Stop Retracted Cylinder Sw itch | Senses w hen the case stop cylinder is retracted |


| Drive | Device | Function | |
|---------------------------------|-------------------------------|----------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------|
| SV30805 | Low er Glue Non Operator Side | Fires glue onto the formed case prior to compression | |
| SV30806 | Low er Glue Operator Side | Fires glue onto the formed case prior to compression | |
| SV30807 | Upper Glue Non Operator Side | Fires glue onto the formed case prior to compression | |
| SV30808 | Upper Glue Operator Side | Fires glue onto the formed case prior to compression | |
| Orienter | | | |
| Case Tip / Reject | | | |
| SD19 | Tip / Reject Flights | Drives the case against the Tip Axis for tipping or out the Case Reject Chute for rejecting | |
| | PE51503 | Case At Tip Present Photo Eye | Senses w hen a case is present in the tip / reject station |
| | PX51001 | Tip Reject Flights Reference Proximity Sw itch | Senses w hen the tip / reject flights are in their reference position |
| SD20 | Case Tip R | Stops the operator side of the case during the tipping process to help it roll over the flights | |
| | PE51503 | Case At Tip Present Photo Eye | Senses w hen a case is present in the tip / reject station |
| SV50703 | Tipper Case Stop | Stops the advancing case on the tip reject conveyor in order for the tip / reject flights to perform the appropriate cycle | |
| | CS51507 | Case Stop Retracted Cylinder Sw itch | Senses w hen the case stop cylinder is retracted |
| MT9 | Tip / Reject Conveyor | Advances the completed case from the compression station through the tip reject station and onto the case conveyor | |
| | VFD1501 | Tip / Reject Conveyor VFD | Controls the speed of the tip / reject conveyor |
| Case Rotate Accumulation | | | |
| SD21 | Case Rotate | Rotates the completed case 90 degrees to orient it correctly for the dow nstream equipment | |
| | PE51505 | Case At Rotate Present Photo Eye | Senses w hen a case is present at the rotate station |
| | PE51506 | Case Present After Rotate Photo Eye | Senses w hen a case has cleared the rotate station |
| SV50201 | Case Rotate Vacuum | This valve controls the vacuum supply to the vacuum cup on the case rotate head | |
| | VS51305 | Case Rotate Vacuum Present Vacuum Sw itch | Senses w hen the case rotate has sufficient vacuum for operation |
| MT10 | Case Conveyor | Advances the completed cases dow nstream from the tip / reject station to the case accumulation area | |
| | OL806 | Case Conveyor Overload | Senses w hen the case conveyor has been overloaded |
| System | | | |
| SV24223 | System Air Dump | Supplies air pressure to the machine w hen the safety circuit is engaged | |
| | PS31201 | System Air Pressure Present Pressure Sw itch | Senses w hen the system air pressure is sufficient for machine operation |

Servo Reference Positions

This section of the Aagard Machine Manual provides a pictorial and written description of each servo reference point on the machine. For each section of the machine, a table lists the servo number, name and values for each servo. Each servo drive is shown pictured in its referenced position with a visible mark or reference indicator for a quick visual check. When the servo drive has been referenced, this mark/indicator should give the operator a quick visual confirmation that the drive has been referenced properly. This is not intended to replace the use of a tape measure, squares, or other means to check reference positions. It is intended to allow operators to quickly check the reference position of a drive without the use of any tools, and continue on with minimal downtime. See the [Reference](#) page on the HMI for more information regarding servo reference positions.

| Servo # | Servo Name | Direction of Positive Movement | Reference Position | End Position | Reference Mark Location |
|---------|-----------------------------------------------------|--------------------------------|--------------------|--------------|-----------------------------------------------------------------------------------------------|
| 1 | Spatula | Toward downstream flights | 0.25 | 0 | Downstream edge of spatula is at the shear point. (Downstream edge of side belt bottom rails) |
| 2 | Adjustable Downstacker 1 | Down with product | -24.375 | 0 | Top of flight 1/4" below shear point |
| 3 | Adjustable Downstacker 2 | Down with product | -24.375 | 30.95 | Top of flight in line with the top of upper drive shaft |
| 4 | Fixed Downstacker 1 | Down with product | -19 | 0 | Top of flight 1/4" below shear point |
| 5 | Fixed Downstacker 2 | Down with product | -18.875 | 30.827 | Top of flight in line with the top of upper drive shaft |
| 6 | Downstack Pusher | Moving product downstream | -1 | 0 | 1" off of upstream hardstop (Located on upstream end of v-rail) |
| 7 | Loader | Moving product downstream | -1 | 0 | 1" from the mechanical stop in the retracted position |
| 8 | Funnel | Funnel moving out of case | -10 | 0 | Funnel is 90 degrees to flight chain |
| 9 | Fun Tucker | Funnel moving out of case | -15 | 0 | Funnel is 90 degrees to flight chain |
| 10 | Tucker | Tucking trailing flap | -5 | 0 | Tucker arm is 90 degrees to flight chain |
| 11 | Product Stop | Tucking leading flap | 140 | 0 | Tucker arm is 90 degrees to flight chain |
| 12 | Casepacker Robot X-Axis | Toward palletizer | 34.53 | 32 | 2.5" from the downstream mechanical stop |
| 13 | Casepacker Robot Z-Axis | Down | -1 | 0 | 1" from the mechanical stop in the retracted position |
| 14 | Casepacker Flights | Toward palletizer | 0.675 | 0 | Leading edge of flight is aligned with fixed side of load chamber |
| 15 | Lower Compression Non Operator Side | From horizontal to vertical | -4 | 0 | Compression plate is horizontal (open) |
| 16 | Lower Compression Operator Side | From horizontal to vertical | -2 | 0 | Compression plate is horizontal (open) |
| 17 | Upper Compression Non Operator Side | From horizontal to vertical | -8 | 0 | Compression plate is horizontal (open) |
| 18 | Upper Compression Operator Side | From horizontal to vertical | -3 | 0 | Compression plate is horizontal (open) |
| 19 | Case Tip Y | Moving towards operator side | -7.625 | 0 | Operator side face of flight is aligned with operator side of sheet metal backstop |
| 20 | Case Tip R | Tipping product | -1 | 0 | 1 inch from the "up" mechanical stop |
| 21 | Case Rotate | Turning case | 130 | 0 | Vacuum cup arm is 90 degrees to conveyor |


1 - Spatula



2 - Adjustable Downstacker 1




3 - Adjustable Downstacker 2




4 - Fixed Downstacker 1




5 - Fixed Downstacker 2



6 - Downstack Pusher



7 - Loader




8 - Funnel




Vertical
marks are
aligned

Funnel is at a
90 degree
angle to flight
chain


9 - Fun Tucker




10 - Tucker



11 - Product Stop




12 - Casepacker Robot X-Axis




13 - Casepacker Robot Z-Axis




14 - Casepacker Flights




15 - 18 Compression Plates




19 - Case Tip Y



20 - Case Tip R



21 - Case Rotate



Operator Control Panel (HMI)



Operator Control Panel (HMI)

Keyboard

General Page Information

The Keyboard and Number Pad are part of the same program, and may be toggled between each other. The Keypad program will work with any program on the PC. Launch the Keypad program by pressing on the keypad icon located on most Aagard HMI pages. If the HMI is not open, the Keyboard and Number Pad program may be opened independently of the HMI by double-clicking "AagardKeypad.exe", located inside the same folder as "AagardHMI.exe".



Hide


The Hide button will close the keyboard/number pad.

Move

The Move button will allow the user to move the keyboard/number pad around the screen. To move the keyboard/number pad, press and hold down the Move button and then drag the keyboard/number pad to any place on the screen.

NumPad

The NumPad button will open the Number Pad and the Keyboard will disappear.



Keybd Button

The Keybd Button on the Number Pad will open the Keyboard and the Number Pad will disappear.


Startup and Download

When the HMI is powered up, several screens will display as part of the startup process. This section of the manual details the HMI startup sequence.

Startup Page

General Page Information

This page is the first page that will be shown after the HMI is powered up. Two buttons will be displayed on the screen. One button is the Servo Initialization Option button and the other is the Continue button. The initialization process will start automatically if no buttons are pressed by the time the timer in the bottom right hand corner of the screen has expired. After the initialization process is complete and successful, the [Product Download Page](#) will be displayed.



Servo Initialization Options Button

Pressing this button will deactivate the automatic download feature for the current initialization and display the Servo Initialization Options Page (shown below).



Sercos Diagnostics Button

This button displays the [Sercos Diagnostics Page](#). This page is only for information and is used primarily during troubleshooting.

Initialization Data Button

This button will display the **Initialization Data Page**. This page shows Servo Drive Data for each Servo Drive on the machine. This page is identical to the [Servo Drive Data Page](#), with the addition of one check mark box in the bottom left hand corner of the screen labeled "Include This Servo In Initialization". Checking this box will do a full initialization to the Servo Drive that is currently selected the next time an initialization is done. A full initialization will load all the parameters specified under the Initialization Column on the [Servo Drive Data Page](#). Information about the parameters on this page can be found under the [Servo Drive Data Page](#). Accessing the Initialization Data Page requires a [User Level 3](#) log in.


Continue Button

The **Continue Button** does the same on either of the pages, the **Startup Page** and the **Servo Initialization Option Page**. This button will start the initialization process as soon as it is pressed.

Initializing Page

General Page Information

The machine will only have to go through the Initialize Process if the machine is powered down or the TwinCAT Program is restarted. This is the process of initializing the servo drives and getting the Sercos Ring to Phase 4. Once all the servo drives have been initialized, the [Product Download](#) page will appear.



Product Download Page

General Page Information


The Product Change screen will automatically be displayed on machine power up. It can manually be displayed by pressing the “Product Change” button on the main page while logged in at User Level 2 or higher. Click on the desired product and press the Download button. This button will download all of the new product’s information, which is now stored in the main controller, and display the [Changeover Adjustments Page](#).

NOTE: The machine must be E-Stopped to do a product change.

The [Edit Button](#) will display the page that allows System Products to be edited. A [User Level 3](#) is required for these features.


If no user is logged in when the Edit button is clicked, the log in screen will display and a user and password is required to continue.

SAMPLE IMAGE



Edit System Products Page

SAMPLE IMAGE




This list contains all the currently available System Products to be edited. When a System Product is selected, the appropriate C40 Recipes will be shown in the C40 Recipes Drop Down Menus to the right of the System Products List.

Cartoner Recipe

The Cartoner Recipe drop down menu contains the name of the recipe used for the currently selected product. If the machine includes a Cartoner, Case Packer, and Palletizer there will be three different Recipe drop down menus.

New Button

If the New Button is pressed, the S10 Product Name Popup will appear. This is where the new product's name will be declared for the first time.




Product Name

This entry field is where the name of the new product will be defined. The text that is entered here will be exactly what is displayed on the [Product Download Page](#).

The **OK Button** can then be pressed if the information is to be saved, or the **Cancel Button** will close the popup and save nothing new.

Rename Button

This button will allow the currently selected product to be renamed. When this button is pressed, a popup will appear. Replace the old name with the new name. The **OK Button** can then be pressed if the information is to be saved, or the **Cancel Button** will close the popup and save nothing new.



Delete

If this button is pressed, the current selected product will be deleted from the System Products list.

Edit C40 Recipes Button


This button will display the [Edit C40 Recipes Page](#).

Import Recipes

This button will display the Import Recipes Page. **Aagard level required!**

Copy Changeover Data From

The Copy Changeover Data From button allows a particular system product to be selected and have changeover data product values copied over to it.




Back Button

This button will close and save any changes and go to the [Product Download Page](#).

Edit C40 Recipes Page


SAMPLE IMAGE



C40s Selection Tabs

The selection tabs will display the list of recipes for each C40 selectable by the selection tabs.


- **C40 Recipes List** - This list contains all the currently created recipes for the C40 selected by the C40s Selection Tab.
- **New Button** - If the New Button is pressed, the C40 Recipe Name Popup will appear. This is where the new recipe's name will be declared for the first time.



- **Recipe Name Entry Field** - This entry field is where the name of the new recipe will be defined. The **OK Button** can then be pressed if the information is to be saved, or the **Cancel Button** will close the popup and save nothing new.
- **Rename Button** - This button will allow the currently selected recipe to be renamed. When this button is pressed, a popup will appear. Replace the old name with the new name. The **OK Button** can then be pressed if the information is to be saved, or the **Cancel Button** will close the popup and save nothing new.



- **Delete Button** - This button will delete the current recipe selected.
- **Copy Data From Button** - This button, when pressed, will go through the process of copying the recipe information from another recipe to the current recipe selected. This will prompt for a previously created recipe to be selected from the Copy Recipe From Popup. If no recipes have been previously created, nothing will be available in the drop down menu. After a recipe has been selected, the **OK Button** will complete the operation and the **Cancel Button** will close the popup and save nothing new.



Back Button

This button will close and save any changes and go to the [Edit System Products Page](#).

Product Download Changeover Adjustments Page

General Page Information

This screen is active after a product download is initiated. It is a checklist for the changeover locations on the machine. Each changeover location is listed in the order that the adjustment should be executed. The target value for each changeover location is shown along with each changeover name and description. When an adjustment is completed, the button in the “Done” column may be pressed to indicate completion.

SAMPLE IMAGE

| Done | Machine | Adj. Name | Description | Value |
|------|------------------------|-----------|--------------------|-------|
| Yes | Sleever Case Packer | 1-1 | Example Adjustment | 10 |
| Yes | Sleever Case Packer | 1-2 | Example Adjustment | 2 |
| Yes | Sleever Case Packer | 1-3 | Example Adjustment | 30 |
| Yes | Sleever Case Packer | 1-4 | Example Adjustment | 40 |
| No | Sleever Case Packer | 1-5 | Example Adjustment | 50 |
| No | Sleever Case Packer | 1-6 | Example Adjustment | 60 |
| No | Sleever Case Packer | 1-7 | Example Adjustment | 70 |
| No | Sleever Case Packer | 1-8 | Example Adjustment | 80 |
| No | Sleever Case Packer | 1-9 | Example Adjustment | 90 |
| No | Sleever Case Packer | 1-10 | Example Adjustment | 100 |
| No | Sleever Case Packer | 1-11A | Example Adjustment | 110 |
| No | Sleever Case Packer | 1-11B | Example Adjustment | 120 |
| No | Sleever Case Packer | 1-11C | Example Adjustment | 130 |
| No | Sleever Case Packer | 1-11D | Example Adjustment | 140 |
| No | Sleever Case Packer | 1-11E | Example Adjustment | 150 |
| No | Sleever Case Packer | 1-11F | Example Adjustment | 160 |
| No | Sleever Case Packer | 1-12A | Example Adjustment | 170 |
| No | Sleever Case Packer | 1-12B | Example Adjustment | 180 |

Print Finish

Done

This column contains a Yes/No button for each changeover adjustment. When a changeover routine is in process, the Yes/No button may be selected to show whether or not the changeover adjustment has been completed during the current changeover routine.

Machine

This column lists which machine the changeover adjustment is located in.

Adj. Name

This column lists the name of the changeover adjustment. The name is typically a number that has been assigned to that particular changeover location.

Description

This column contains the description of the item.

Value

This is the value at which the changeover adjustment should be when completed.

Print

The print button will print the machine changeover screen to the default printer set up on the HMI. This printout can then be used during the machine changeover.

It is recommended that when the changeover is completed, the printout be discarded to ensure there are no obsolete copies.

Finish Button

Press this button to continue onto the [HMI Main Screen](#) after all of the adjustments have been completed. If any of the adjustments have not been marked completed, a popup will appear after the **Finish Button** has been pressed.

This is a warning to verify that it is OK to continue onto the [HMI Main Screen](#) even though all the adjustments haven't been marked as completed.

Log In Screen

General Page Information

This is what the Agard HMI Screen will look like if the Log In Button is pressed while no one is currently logged in. If a user is currently logged in, the button will display the text "Log Out". If the button is pressed while the "Log Out" text is displayed, the current user will be logged out and the "Log In" text will be displayed. Consult your supervisor for the correct user name and password. The machine will be logged out upon power up.

SAMPLE IMAGE



| | Machine Run | Jog, Reference & Troubleshooting | Machine Data Input | Login User Information |
|-----------------------------|-------------------------------------|-------------------------------------|-------------------------------------|-------------------------------------|
| Operator Level 1 | <input checked="" type="checkbox"/> | | | |
| Operator Level 2 | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | | |
| Advanced Technician Level 3 | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | |
| Administrator Level | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |


HMI Main Screen

General Page Information

After power up and initialization of the Packaging system, the Main screen will be displayed. This Main screen is the starting point from which everything branches. All the Message Displays combined will provide information on what is happening with the machine, displaying any faults that would prevent the system from running (guard door open, low air pressure, etc.). The Aagard HMI will go straight to the Main Screen if the HMI is closed and reopened without losing power to any part of the machine.

NOTE: The system will be in the same Mode in which it was left at power down. Correct any Fault conditions which are displayed before attempting to run the machine.

NOTE: Depending on user level, not all buttons will be visible.



System Information

This section contains the machine name, the current downloaded product name, the current system rate and any system messages. A system is also known as the S10 level of the machine.

C40 Information

This section contains the C40 name, the [state and mode](#), and any C40 messages. An example of a C40 would be a Cartoner or a Case Packer.

Rate

This entry field will allow the machine to operate at slower speeds. 100% is equal to the maximum rate at which the machine is able to operate. 50% is half that rate and so on. This only applies while in Automatic Mode

Reset

This button will reset the selected C40. This will make the machine think that there is no product in the machine. This button is a last resort to get the machine running again. After this button is pressed, all remaining product should be cleared out of the machine and then the machine can be started again.

Fault History Button

Pressing this button will open the [Fault History Page](#) for the C40 that the button was on.

Reject History Button

Pressing this button will open the [Reject History Page](#) for the C40 that the button was on.

Data Input Button

Pressing this button will open the [Data Input Page](#) for the C40 that the button was on.

Disable/Enable

Pressing this button will Disable/Enable the selected C40. When a C40 is disabled, that section of the machine will not perform its operations. When the C40 is disabled the button will be red and the State status will be Disabled. This button can only be toggled when that C40 is in Mode: Estop.

Disable/Enable Product

Pressing this button will Disable/Enable Product on the selected C40. When a C40 has Disabled Product, the button will be red. Disabled Product is a type of a dry cycle. When the machine is started back up, that section of the machine will perform its operations as if it were receiving the amount of product per minute specified in the System Rate Display. This button can only be toggled when that C40 is in Mode: Estop.

Automatic Mode Button

When the Automatic (Run) Mode Button for the C40 is pressed, that C40 will go into Automatic Mode. Press and hold the start pushbutton for 3 seconds to begin running. If no faults are detected, the Module will continue into the Producing Mode.

Manual Mode

Pressing the Manual Mode button will put the machine in manual mode and display two additional buttons: "Jog" and "Reference".

Jog Button

Pressing this button will open the [Jog Page](#) for the C40 that the button was on.

Reference Button

Pressing this button will open the [Reference Page](#) for the C40 that the button was on.

Production Data Table

This table shows the current shift's information and the current day's information. For more on this, see the [Production Data Page](#).

Production Data Button

Pressing this button will open the [Production Data Page](#) for the machine.

QC Case

This allows the machine to reject one (1) good case for Quality Control purposes.

Custom Buttons

Pressing this button will open the [Custom Buttons Page](#) for the machine.

Advanced Button

Pressing this button will open the [Advanced Page](#) for the machine.

Product Change Button

Pressing this button will open the [Product Download Page](#) for the machine.

Log In / Log Out Button


If the button displays "Log In", then no user is currently logged in and pressing this button will open the the [Log In Screen](#).

If the button displays "Log Out", then a user is currently logged in and pressing this button will cause the current user to be logged out.

NOTE: The current user name is displayed in the upper left area of the Main Page.

About Button

This button will show version and build information, and will be useful when troubleshooting with Aagard technicians.



Aagard Logo

Pressing this button will open the Aagard Machine Operator Manual from the HMI.


- o The user may be prompted to install a documentation update

Custom Buttons

General Page Information

NOTE: The items listed and their locations on this HMI page are 100% configurable and setup by an Aagard Level user during the HMI Setup process. As such, the content on this page is a representation of a possible configuration. The items and/or their locations may change as modifications to the configuration are made on a production Aagard machine in the field. Such configuration changes may not be reflected in this machine manual.

This page displays buttons that provide additional functionality for the running of the machine.



Clean Out

This will allow the machine to go into a Clean Out mode.

Load Cups Clean Out

This will cause the Case Packer to blow compressed air out of the Load Station Vacuum Cups, clearing dust and debris from the vacuum cups.

Packer Funnel Adjustment

This button will open the [Packer Funnel Adjustment Page](#).

Enable Case Refeed

This will disable the photo eyes in the case reject area, stop the Case Packer, and allow cases to be re-fed into the machine through the reject chute. Note: The Case Packer will have to be re-started once this tag is de-selected.

Arrange Buttons

This page is configurable and the buttons may be re-arranged if this checkbox is checked. **Aagard level required!**

Packer Funnel / FunTucker Adjustment Page

General Page Information


This screen provides a means for the user to make temporary adjustments to certain running parameters on the machine. These adjustments are temporary and affect only the currently downloaded product; this information is not retained from one product change to the next.

NOTE: The machine must be in E-Stop mode and re-started for the changes to take effect.


NOTE: Depending on user level, not all fields will be editable.

NOTE: The items listed and their locations on this HMI page are 100% configurable and setup by an Aagard Level user during the HMI Setup process. As such, the content on this page is a representation of a possible configuration. The items and/or their locations may change as modifications to the configuration are made on a production Aagard machine in the field. Such configuration changes may not be reflected in this machine manual.

SAMPLE IMAGE



SAMPLE IMAGE

**Funnel Offset**

This number is the amount of cam offset applied to the Funnel.

Fun-Tucker Offset

This number is the amount of cam offset applied to the Fun/Tucker.

+ Right Arrow

This will increase the total offset amount in the Offset field by the amount in the Inc By field. Each time the + right arrow is clicked, the total amount of offset will increase by the Inc By amount until the Maximum amount is reached.

- Left Arrow

This will decrease the total offset amount in the Offset field by the amount in the Inc By field. Each time the - left arrow is clicked, the total amount of offset will decrease by the Inc By amount until the Minimum amount is reached.

Minimum

This is the minimum amount of offset allowed.


Maximum

This is the maximum amount of offset allowed.

Inc By

Increment By: This number is the amount that the Offset will increase or decrease by when the + / - arrows are clicked.

State Model - Automatic Mode



The following table shows a brief description of individual machine states:

| STATE | Description |
|-----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| OFF | <p>State Type: Final</p> <p>All power to machine switched off. This state is assumed if there is no response from the machine. This is an optional Final State.</p> <p>The OFF state may be reached in two ways: first, power to the machine is switched off or second, power is removed as in a power utility failure. In the OFF state, it must be assured that the machine will go at the least to the initial stopped state when power is restored either by switch or restoration of the utility power source.</p> |
| STOPPED | <p>State Type: Final</p> <p>The machine is powered and stationary. All communications with other systems are functioning (if applicable).</p> |
| STARTING | <p>State Type: Transient</p> <p>This state allows the machine to be prepared for running. This state could include such processes as heating, self-testing, or calibration.</p> |
| READY | <p>State Type: Quiescent</p> <p>This is a state which indicates that STARTING is complete. This state maintains the machine conditions which were achieved during the STARTING state.</p> |

| STATE | Description |
|------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| STANDBY | <p>State Type: Transient</p> <p>The machine is running at the relevant set point speed, there is no product being produced.</p> <p>This state can be reached either in response to a Start Command from READY, or any internal machine logic that would dictate a temporary transition from the PRODUCING state, such as materials run-out.</p> <p>The status of "materials run-out" could be due to a lack of materials on the machine's own infeed, or a stoppage of downstream equipment.</p> |
| PRODUCING | <p>State Type: Transient</p> <p>Once the machine is processing materials, it is deemed to be producing.</p> |
| STOPPING | <p>State Type: No Command</p> <p>This state executes the logic which brings the machine to a controlled and safe stop.</p> |
| ABORTING | <p>State Type: Transient</p> <p>The ABORTED state can be entered at any time in response to the Abort Command, or on the occurrence of a machine fault. The aborting logic will bring the machine to a rapid, controlled safe stop. Operation of the Emergency Stop, or "E-Stop", will cause the machine to be tripped by its safety system. It will also provide a signal to initiate the ABORTING state.</p> |
| ABORTED | <p>State Type: Quiescent</p> <p>This state maintains machine status information relevant to the Abort condition. The Stop Command will force transition to the STOPPED state.</p> |
| HOLDING | <p>State Type: Transient</p> <p>When the machine is in STANDBY or PRODUCING, the Hold Command can be used to start Holding logic, which brings the machine to a controlled stop.</p> |
| HELD | <p>State Type: Quiescent</p> <p>The Held state would typically be used by the operator to temporarily hold the machine's operation while material blockages are cleared, or to stop throughput while a downstream problem is being resolved.</p> |

An example State transition matrix for Automatic Mode is shown below. Note the State Model does not rigidly specify the internal machine state transition logic, which will vary depending on the application.

| Initial State | Machine Status | | | | | | Commands | | | | |
|---------------|----------------|-----------|-------------------|-----------------|---------------|----------------|----------|---------|----------|---------|----------|
| | Power On | Power Off | Materials Run-Out | Materials Ready | Machine Fault | State Complete | Prepare | Start | Stop | Held | Abort |
| Off | Stopped | | | | | | | | | | |
| Stopped | | Off | | | | | Starting | | | | |
| Starting | | | | | Aborting | Ready | | | Stopping | | Aborting |
| Ready | | | | | Aborting | | | Standby | Stopping | | Aborting |
| Standby | | | Producing | | Aborting | | | | Stopping | Holding | Aborting |
| Producing | | | | Standby | Aborting | | | | Stopping | Holding | Aborting |
| Stopping | | | | | Aborting | Stopped | | | | | Aborting |
| Holding | | | | | Aborting | Held | | | | | Aborting |


| | | | | | | | | | | | |
|----------|--|--|--|--|----------|---------|--|---------|----------|--|----------|
| Held | | | | | Aborting | | | Standby | Stopping | | Aborting |
| Aborting | | | | | | Aborted | | | | | |
| Aborted | | | | | | | | | Stopped | | |

Popups and Notices

From time to time and for various reasons, certain events trigger notice popups.

These popups indicate which C40 originated the notice, device number and name, message text, message details, date and time of the notice, and number of messages currently being displayed. After the popup has been cleared, this same information is displayed in the notice history pages

SAMPLE IMAGE



NOTE: If a location is defined in the messaging database, it will be displayed between the C40 name and Device name

Edit Text Button

Users logged in Level 3 or higher may modify the message text.

Map Button

This button will appear when a location image for this device is available. [Map](#)

Info Button

Click this button to display additional PLC notice information useful when troubleshooting with Aagard personnel. [Info](#)

Clear All and Clear Buttons

There are a number of ways to clear notices from the HMI screen.

- Press the Clear button to clear an individual notice
- Press the Clear All button to clear all notices
- Energize the system by pressing the Start button once to clear all notices

NOTE: A Critical Fault will *not* be cleared by using the Clear All button or by pressing the Start button; it must be cleared individually by pressing the Clear button

Since this machine runs on a PC-based computer, other applications are running behind the HMI application. These applications also use popups, when necessary, to notify users of important information. An example of a TwinCAT error is shown below. TwinCAT is a background application required by the HMI application.



Map

This image provides a general area grid location to help the operator locate the device on the machine.

SAMPLE IMAGE

C40 Name Fault!

Device location may appear here - Device # Device Name

| | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 |
|---|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|
| A | | | | | | | | | | | | | | | | | | | |
| B | | | | | | | | | | | | | | | | | | | |
| C | | | | | | | | | | | | | | | | | | | |
| D | | | | | | | | | | | | | | | | | | | |
| E | | | | | | | | | | | | | | | | | | | |
| F | | | | | | | | | | | | | | | | | | | |
| G | | | | | | | | | | | | | | | | | | | |
| H | | | | | | | | | | | | | | | | | | | |
| I | | | | | | | | | | | | | | | | | | | |
| J | | | | | | | | | | | | | | | | | | | |
| K | | | | | | | | | | | | | | | | | | | |

Messages: 1

[Edit Text...](#) [Text](#) [Info...](#) [Clear All](#) [Clear](#)

Info

During troubleshooting, Aagard personnel may ask operators for the information displayed in the box.

SAMPLE IMAGE

| | | | | | |
|--------------|------------------------------|---------------------|------------------------------|---------------------------|-----------------------|
| App Type: 57 | App Num: 10 | Notice ID: 4 | POU Generator ID: TestingPOU | POU Sender ID: TestingPOU | |
| Messages: 1 | Edit Text... | Map | Info | Clear All | Clear |

Production Data Page

General Page Information

This page will display any production data collected by the machine. This will show how the machine is performing from day to day. The downtime tracking summary is also displayed on the page.

NOTE: The items listed and their locations on this HMI page are 100% configurable and setup by an Aagard Level user during the HMI Setup process. As such, the content on this page is a representation of a possible configuration. The items and/or their locations may change as modifications to the configuration are made on a production Aagard machine in the field. Such configuration changes may not be reflected in this machine manual.

SAMPLE IMAGE

**Time Period Drop Down Menu**

This drop down menu will allow information to be displayed for a certain selected time period.

Edit Shifts Button

This button will display the [Edit Shifts Screen](#).

Back Button

This button will display the HMI Main Screen.

Production Data Information

These items are setup by an Agard Level user during HMI Setup.

IMPORTANT! If changes are made to production data formulas, the Report Generator process *must* be restarted!

| Query Name | Short Description | Detailed Description |
|--------------------------|---------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| RunningTime | Running Time Tracking | Total amount of time the system in a producing state |
| IdleTime | Idle Time Tracking | Total amount of time the system was idle (starved or blocked) |
| UserStopsTime | User Stops Time Tracking | Total amount of downtime caused by user stops (E-Stop, Guard Door, Cycle Stop) |
| FaultTime | Fault Time Tracking | Total amount of downtime caused by faults |
| FaultAckTime | Fault Acknowledgement Time Tracking | Total amount of fault acknowledgement time |
| RunningTimeCount | Number of Running Time Occurrences | The number of instances the system went to a producing state |
| IdleTimeCount | Number of Idle Time Occurrences | Number of instances the system was not producing, caused by not receiving product or downstream not being available (starved and blocked) |
| UserStopCount | Number of User Stop Occurrences | Number of times the system was not producing, caused by a user stop (E-Stop, Guard Door, Cycle Stop) |
| FaultCount | Number of faults | Number of times the system was not producing, caused by a fault |
| DowntimeCount | # of Stops, Downtime Count | The number of instances the system was not producing, caused by a user stop or fault |
| RunningTimeSinceLastStop | Running Time Since Last User Stop Or Fault Recorded In System | Amount of time accumulated since the last time the system went into a producing or idle state |
| TargetCapacity | Target Capacity | The total number of products which could run through this machine if the machine is running at 100% for the measured time period. The machine rate is recipe-specific, as defined in the PLC program; rate changes during the measured time period are taken into account |
| UserStopLoss | Capacity Loss Due To User Stops | Capacity lost due to a user initiated downtime (E-Stop, Guard Door, Cycle Stop, and materials not available) |
| MachineStopLoss | Capacity Loss Due to Faults Or Machine Downtime | The capacity, in units, which was lost, caused by faults and idle time |
| StopLoss | Capacity Loss Due to All Stops | The capacity, in units, which was lost, caused by all stops (user stop loss and machine stop loss) |
| IdleStopLoss | Capacity Loss Due to System Being Idle | The capacity, in units, which was lost, caused by the system being idle (starved or blocked) |
| ExpectedOutput | Expected Output | The difference between Normal Production (NP) Capacity and Idle Stop Loss. NP Capacity is Target Capacity less Stop Loss |
| M(#).InfeedCount | Machine Infeed Product Count | The number of products fed into a specific machine infeed |
| M(#).UnitCount | Machine Unit Count | The number of good products discharged from a specific machine |
| M(#).RejectCount | Machine Reject Count | The number of products rejected from a specific machine |
| M(#).FaultCount | Machine Number of faults | The number of fault instances in a specific machine |
| M(#).FaultTime | Machine Fault Time | Total amount of time the system was not producing based on a specific machine's faults |
| M(#).FaultAckTime | Machine Fault Acknowledgement Time | The amount of fault acknowledgement time based on a specific machine's faults |
| M(#).MinFaultTime | Machine Minimum Fault Time | The shortest fault time length based on a specific machine's faults |

| Query Name | Short Description | Detailed Description |
|----------------------|----------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------|
| M(#)MaxFaultTime | Machine Maximum Fault Time | The longest fault time length based on a specific machine's faults |
| M(#)GDAFaultTime | Machine Greatest Deviation from Average Fault Time | The greatest deviation from average of fault time length based on a specific machine's faults |
| M(#)MinFaultAckTime | Machine Minimum Fault Ack Time | The shortest fault acknowledgement time based on a specific machine's faults |
| M(#)MaxFaultAckTime | Machine Maximum Fault Ack Time | The longest fault acknowledgement time based on a specific machine's faults |
| M(#)GDAFaultAckTime | Machine Greatest Deviation from Average Fault Ack Time | The greatest deviation from average fault acknowledgement time based on a specific machine's faults |
| R(#)StopsCount | Number of stops based on Reason Code | Total number of instances the machine was not producing based on one specific reason code |
| R(#)StopsTime | Stops Time based on Reason Code | Total amount of time the system was not producing based on one specific reason code |
| R(#)StopsMinTime | Stops Minimum Time based on Reason Code | Shortest amount of time the system was not producing based on one specific reason code |
| R(#)StopsMaxTime | Stops Maximum Time based on Reason Code | Longest amount of time the system was not producing based on one specific reason code |
| R(#)StopsGDATime | Stops Greatest Deviation from Average Stop Time based on Reason Code | Greatest deviation from average time the system was not producing based on one specific reason code |

Edit Shifts Screen

General Page Information

This screen will display the edit shifts popup section. This will allow the user to edit the shift information for that machine. This will adjust anywhere the shift feature is used, such as the time period drop down menu as described on the [Production Data Page](#). This will also affect the reports that are generated by the Report Generator. The Agard Report Generator also uses the given shifts to generate the summary reports broken down by shift. More information about the Agard Report Generator can be found in the Report Generator section.

NOTE: For proper recording and display of production data, the total of all shifts in one day *must* equal 24 hours

SAMPLE IMAGE

The screenshot shows the 'Agard HMI - Production Data' window. At the top, there is a dropdown menu for 'Shift 1' and a 'Refresh' button. Below this is a 'Shift Start Date' dropdown set to '2/26/2010'. The main area lists various production metrics for Shift 1, including System Efficiency (0.0%), Reliability (0.0%), MTBF (0S), MTRR (0S), Time Since Last Stop (0S), Total Downtime (2H 35M), Total Uptime (0S), Running Time (0S), Idle Time (0S), Fault Count (0), Fault Time (0S), Fault Ack Time (0S), # Of Stops (0), User Stops Time (2H 35M), Starved Time - OOP (0S), Carton Count (0), Case Count (0), Case Reject Count (0), Cube Count (0), and Partial Cube Count (0). On the right side, an 'Edit Shifts' popup is open, showing a list of five shifts with checkboxes and time selection fields for 'Begin' and 'End' times. Shift 1 is checked and has a begin time of 7:00:00 AM and an end time of 3:00:00 PM. Shift 2 is checked with a begin time of 3:00:00 PM and an end time of 11:00:00 PM. Shift 3 is checked with a begin time of 11:00:00 PM and an end time of 7:00:00 AM. Shift 4 is unchecked with a begin time of 9:35:08 AM and an end time of 9:35:08 AM. Shift 5 is unchecked with a begin time of 9:35:08 AM and an end time of 9:35:08 AM. At the bottom of the popup are 'Save' and 'Cancel' buttons. Below the popup, there is a printer icon and a 'Back' button.

Check Box

This will allow the correct number of shifts to be used to be selected. If a shift is to be used, this box should be checked.

Begin Entry

This will be the begin time for the shift under this entry field.

End Entry

This will be the end time for the shift under this entry field.

NOTE: For proper recording and display of production data, the total of all shifts in one day **must** equal 24 hours.

Save

This button will save the Edit Shifts information and display the [Production Data Page](#).

Cancel

This button will not save any changes made to the Edit Shifts information and display the [Production Data Page](#).

Fault History Page

General Page Information

This page keeps a record of all faults generated. This may help with diagnosing any major problems or possible problems. These notices will be stored in the database for three days, and then will be deleted. The information displayed on this page is also accessible on the [View Notices System Wide](#) page.

SAMPLE IMAGE

The screenshot shows the 'Aagard HMI - Notice History' window. The title bar indicates 'Notice History for Cartoner'. Below the title bar, there are controls for 'Move Column' (set to 'Device'), 'Left', 'Right', and a dropdown menu for 'C40 Cartoner'. The main area is a table with the following columns: Date Stamp, Device, Message, PLC Details, Notice Type, Shift, Down Time, Ack Time, Notes, Location, and HMI Details. The table contains 25 rows of fault data, including messages like 'Bar Code Scanner Failure', 'Lower Film Roll Empty', 'Fast Stop Failed', and 'Blocked Too Long'. At the bottom of the window, there is a filter bar with 'Show Latest 50' and buttons for 'Fault Shown', 'Critical Fault Shown', 'General Not Shown', 'Warning Not Shown', 'Reject Not Shown', 'Debug Not Shown', 'Utility Not Shown', 'Unhandled Not Shown', and 'Prod. Data Not Shown'. Below the filter bar are buttons for 'Individual Items', 'Totalled', 'Edit Notes...', 'Delete All', 'Refresh', and 'Back'.

| Date Stamp | Device | Message | PLC Details | Notice Type | Shift | Down Time | Ack Time | Notes | Location | HMI Details |
|------------------------|-------------------|-----------------------------|--------------------|----------------|-------|-----------|----------|-------|----------|------------------|
| 1/5/2010 8:02:25 AM | IDV1 Carton ... | Bar Code Scanner Failure | Beckhoff Error ... | Fault | 1 | | | | Cartoner | |
| 1/5/2010 8:02:17 AM | IDV1 Carton ... | Bar Code Scanner Failure | Beckhoff Error ... | Fault | 1 | | | | Cartoner | |
| 12/16/2009 11:03:24 AM | SD5 Side Fil... | Motion Control Reset Error | Servo Drive E... | Fault | 1 | 00:05:53 | 00:00:07 | | Cartoner | Cleared in 7 s |
| 12/17/2009 10:54:09 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:01:21 | 00:00:01 | | Cartoner | Cleared in 1 s |
| 12/17/2009 10:49:24 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:04:07 | 00:00:02 | | Cartoner | Cleared in 2 s |
| 12/17/2009 10:35:31 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:01:13 | 00:00:02 | | Cartoner | Cleared in 2 s |
| 12/17/2009 10:25:25 AM | EN49101 Low... | Lower Film Unwind Danc... | Encoder Pos ... | Fault | 1 | 00:05:37 | 00:00:05 | | Cartoner | Cleared in 5 s |
| 12/17/2009 9:57:13 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:01:16 | 00:00:05 | | Cartoner | Cleared in 5 s |
| 12/17/2009 9:47:40 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:08:48 | 00:08:26 | | Cartoner | Cleared in 8 ... |
| 12/17/2009 9:42:22 AM | SD6 Side Fil... | Fast Stop Failed | MC_ChangeD... | Fault | 1 | 00:03:15 | 00:00:03 | | Cartoner | Cleared in 2 s |
| 12/16/2009 11:07:22 AM | IDV7 Carton ... | Checkweigher Failure | Check Check... | Fault | 1 | 00:00:13 | 00:00:07 | | Cartoner | Cleared in 7 s |
| 12/16/2009 10:43:57 AM | IDV4 Filler B ... | Metal Detected | Metal Detecte... | Critical Fault | 1 | | 00:00:32 | | Cartoner | Cleared in 31 s |
| 12/16/2009 10:43:54 AM | IDV3 Filler A ... | Metal Detected | Metal Detecte... | Critical Fault | 1 | 00:00:49 | 00:00:32 | | Cartoner | Cleared in 32 s |
| 12/16/2009 10:25:38 AM | IDV1 Carton ... | Bad Bar Code Scanned | Remove Carto... | Critical Fault | 1 | 00:02:24 | 00:01:15 | | Cartoner | Cleared in 1 ... |
| 12/16/2009 10:21:47 AM | PE48206 Cart... | Improper Carton Transfer... | Carton Did Not... | Fault | 1 | 00:03:19 | 00:00:18 | | Cartoner | Cleared in 17 s |
| 12/16/2009 9:22:37 AM | S32_4 Analo... | Function Block Failed | Channel 2 Fail... | Fault | 1 | | 00:28:34 | | Cartoner | Cleared in 28... |
| 12/16/2009 9:02:08 AM | S32_4 Analo... | Function Block Failed | Channel 1 Fail... | Fault | 1 | | 00:13:46 | | Cartoner | Cleared in 13... |
| 12/16/2009 8:57:11 AM | S32_4 Analo... | Function Block Failed | Channel 1 Fail... | Fault | 1 | 01:04:15 | 00:00:32 | | Cartoner | Cleared in 32 s |
| 12/16/2009 7:48:17 AM | IDV7 Carton ... | Checkweigher Failure | Check Check... | Fault | 1 | 00:00:35 | 00:00:15 | | Cartoner | Cleared in 15 s |
| 12/16/2009 7:45:01 AM | IDV7 Carton ... | Checkweigher Failure | Check Check... | Fault | 1 | 00:02:57 | 00:00:23 | | Cartoner | Cleared in 23 s |
| 12/16/2009 7:39:40 AM | IDV1 Carton ... | Bad Bar Code Scanned | Remove Carto... | Critical Fault | 1 | 00:00:52 | 00:00:39 | | Cartoner | Cleared in 39 s |
| 12/16/2009 7:37:31 AM | IDV1 Carton ... | Bad Bar Code Scanned | Remove Carto... | Critical Fault | 1 | 00:01:33 | 00:01:30 | | Cartoner | Cleared in 1 ... |
| 12/15/2009 6:44:58 PM | PE42306 Sec... | Blocked Too Long | Blocked For 1... | Fault | 2 | 00:05:46 | 00:05:36 | | Cartoner | Cleared in 5 ... |

C40 Filter

Click on the drop down arrow to view history for a particular C40. If a C40 is not listed, there are no messages to display.

Filter Buttons (Fault, Critical Fault, General, Warning, Reject, Debug, Utility, and Unhandled Not Shown)

These buttons represent different notice types. Press any button to filter those notices from the list. Pressing refresh will refresh the screen, displaying only those notice types selected.

- **Fault** – a message describing an unintended event which restricts the system's ability to produce
- **Critical Fault** – same as Fault, except the operator must acknowledge each Critical Fault individually
- **General** – an informational message which relays current existing conditions within the system
- **Warning** – a message describing an event which occurred, or an existing condition, which may cause a problem if not addressed
- **Reject** – a message describing why a product was rejected from the normal flow of product
- **Debug** – a message used during the debug stage of development to monitor for specific desired or undesired events
- **Utility** – a notice used to trigger a software utility
- **Unhandled Not Shown** – a message that is sent from the PLC but not defined in the Message data base
- **Production Data Not Shown** – a message used for production data collection

Individual Items

Click this button to display the items in the grid in chronological order.

NOTE: When **Individual Items** is selected, the button color will be blue

Totaled


Click this button to display the items in the grid in a totaled fashion, displaying the number of times an item occurred. The items all totaled to allow the user to more easily view which items are occurring the most frequently.

NOTE: When **Totaled** selected, the button color will be blue

| Aagard HMI - Notice History | | | | |
|-----------------------------|----------|---------------------------------|-------|--|
| Notice History for Inserter | | | | |
| Device | Location | Message | Count | |
| CS1AE Knife ... | Inserter | Cylinder Extend Switch Not M... | 1 | |
| MS1 Custom... | Inserter | VFD Faulted | 2 | |
| MS1 Custom... | Inserter | Invalid Program Call | 16 | |
| PE6 Register... | Inserter | Sensor Failure | 8 | |
| PE6 Register... | Inserter | Not Made During Startup | 1 | |
| PE2 Web Br... | Inserter | Web Break PE Not Blocked ... | 1 | |
| PE3 Loop Low | Inserter | Eye Not Blocked When Expe... | 10 | |
| SD2 Knife | Inserter | Lag Error | 1 | |
| SD1 Pirwheel | Inserter | Cam Load Failed | 1 | |
| CTRL1 HMI | Inserter | Switching To Sercos Phase 2 ... | 1 | |
| | | | | |
| | | | | |

Edit Notes Button

Select a message in the grid and the Edit Notes Button becomes available. Click on the Edit Notes button to open a dialog window to add your notes to the messages. Double-clicking on the message itself also opens this dialog. Click OK on the dialog when finished.



Delete All Button

This button will delete the entire fault log. This will make any generated reports invalid since the Report Generator uses this fault log to generate its reports.

Refresh

This button will refresh the faults on the screen to the most current log at the time the refresh button was pressed, reflected by any filters which may have been selected.

Back Button

This button will return the user to the calling page.

Filter Drop Down List

Click on the drop down arrow to view available filters to apply to the list. Select a filter from the list to apply it. Depending on the selection, additional parameters become available to enter, such as dates and hours.

| | | |
|-----------------|-----------|------------|
| From Date/Time: | 1/ 4/2010 | 5:59:00 AM |
| To Date/Time: | 1/ 4/2010 | 5:59:00 PM |
| Show Last: | 0 Hours | 0 Minutes |

Column Options

To move a column from left to right, select a column from the dropdown list, and click Left or Right to move the column in either direction.

Device Column

This column displays the name of the device which generated the notice.

Message Column

This column displays the message which appeared on the notice. A list of possible messages, causes, and actions are given on the [Message Notices](#) section.

PLC Details Column

This column displays information received from the PLC when the notice was generated.

Shift Column

This column displays the shift in which the notice was recorded.

Down Time Column

This column displays time elapsed between notice display and when the system is started.

Ack Time Column

This column displays the length of time elapsed before the notice was acknowledged.

HMI Details Column

This column displays any additional information received from the HMI when the notice was generated.

Date Stamp Column

This column displays the date and time when the notice was generated.

Notes Column

This column displays any user entered information for the selected notice.

Notice Type

This column displays the type of notice recorded.

Location Column

This column displays the notice location or area of the machine.

Reject History Page

General Page Information

This page keeps a record of all rejects generated. This may help with diagnosing any major problems or possible problems. These notices will be stored in the database for three days, and then will be deleted. The information displayed on this page is also accessible on the [View Notices System Wide](#) page.

SAMPLE IMAGE

Aagard HMI - Notice History

Notice History for Cartoner

Move Column: C40

| Date Stamp | Device | Message | PLC Details | Notice Type | Shift | Down Time | Ack Time | Notes | Location | HMI Details |
|------------------------|-------------------|-----------------------------|--------------------|----------------|-------|-----------|----------|-------|----------|------------------|
| 1/5/2010 8:02:25 AM | IDV1 Carton ... | Bar Code Scanner Failure | Beckhoff Error ... | Fault | 1 | | | | Cartoner | |
| 1/5/2010 8:02:17 AM | IDV1 Carton ... | Bar Code Scanner Failure | Beckhoff Error ... | Fault | 1 | | | | Cartoner | |
| 12/18/2009 11:03:24 AM | SD5 Side Fil... | Motion Control Reset Error | Servo Drive E... | Fault | 1 | 00:05:53 | 00:00:07 | | Cartoner | Cleared in 7 s |
| 12/17/2009 10:54:09 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:01:21 | 00:00:01 | | Cartoner | Cleared in 1 s |
| 12/17/2009 10:49:24 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:04:07 | 00:00:02 | | Cartoner | Cleared in 2 s |
| 12/17/2009 10:35:31 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:01:13 | 00:00:02 | | Cartoner | Cleared in 2 s |
| 12/17/2009 10:25:25 AM | EN49101 Low... | Lower Film Unwind Danc... | Encoder Pos ... | Fault | 1 | 00:05:37 | 00:00:05 | | Cartoner | Cleared in 5 s |
| 12/17/2009 9:57:13 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:01:16 | 00:00:05 | | Cartoner | Cleared in 5 s |
| 12/17/2009 9:47:40 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:08:48 | 00:08:26 | | Cartoner | Cleared in 8 ... |
| 12/17/2009 9:42:22 AM | SD6 Side Fil... | Fast Stop Failed | MC_ChangeD... | Fault | 1 | 00:03:15 | 00:00:03 | | Cartoner | Cleared in 2 s |
| 12/16/2009 11:07:22 AM | IDV7 Carton ... | Checkweigher Failure | Check Check... | Fault | 1 | 00:00:13 | 00:00:07 | | Cartoner | Cleared in 7 s |
| 12/16/2009 10:43:57 AM | IDV4 Filler B ... | Metal Detected | Metal Detecte... | Critical Fault | 1 | | 00:00:32 | | Cartoner | Cleared in 31 s |
| 12/16/2009 10:43:54 AM | IDV3 Filler A ... | Metal Detected | Metal Detecte... | Critical Fault | 1 | 00:00:49 | 00:00:32 | | Cartoner | Cleared in 32 s |
| 12/16/2009 10:25:38 AM | IDV1 Carton ... | Bad Bar Code Scanned | Remove Carto... | Critical Fault | 1 | 00:02:24 | 00:01:15 | | Cartoner | Cleared in 1 ... |
| 12/16/2009 10:21:47 AM | PE48206 Cart... | Improper Carton Transfer... | Carton Did Not... | Fault | 1 | 00:03:19 | 00:00:18 | | Cartoner | Cleared in 17 s |
| 12/16/2009 9:22:37 AM | S32_4 Analo... | Function Block Failed | Channel 2 Fail... | Fault | 1 | | 00:28:34 | | Cartoner | Cleared in 28... |
| 12/16/2009 9:02:08 AM | S32_4 Analo... | Function Block Failed | Channel 1 Fail... | Fault | 1 | | 00:13:46 | | Cartoner | Cleared in 13... |
| 12/16/2009 8:57:11 AM | S32_4 Analo... | Function Block Failed | Channel 1 Fail... | Fault | 1 | 01:04:15 | 00:00:32 | | Cartoner | Cleared in 32 s |
| 12/16/2009 7:48:17 AM | IDV7 Carton ... | Checkweigher Failure | Check Check... | Fault | 1 | 00:00:35 | 00:00:15 | | Cartoner | Cleared in 15 s |
| 12/16/2009 7:45:01 AM | IDV7 Carton ... | Checkweigher Failure | Check Check... | Fault | 1 | 00:02:57 | 00:00:23 | | Cartoner | Cleared in 23 s |
| 12/16/2009 7:39:40 AM | IDV1 Carton ... | Bad Bar Code Scanned | Remove Carto... | Critical Fault | 1 | 00:00:52 | 00:00:39 | | Cartoner | Cleared in 39 s |
| 12/16/2009 7:37:31 AM | IDV1 Carton ... | Bad Bar Code Scanned | Remove Carto... | Critical Fault | 1 | 00:01:33 | 00:01:30 | | Cartoner | Cleared in 1 ... |
| 12/15/2009 6:44:58 PM | PE42306 Sec... | Blocked Too Long | Blocked For 1... | Fault | 2 | 00:05:46 | 00:05:36 | | Cartoner | Cleared in 5 ... |

C40 Filter

Click on the drop down arrow to view history for a particular C40. If a C40 is not listed, there are no messages to display.

Filter Buttons (Fault, Critical Fault, General, Warning, Reject, Debug, Utility, and Unhandled Not Shown)

These buttons represent different notice types. Press any button to filter those notices from the list. Pressing refresh will refresh the screen, displaying only those notice types selected.

- **Fault** – a message describing an unintended event which restricts the system's ability to produce
- **Critical Fault** – same as Fault, except the operator must acknowledge each Critical Fault individually
- **General** – an informational message which relays current existing conditions within the system
- **Warning** – a message describing an event which occurred, or an existing condition, which may cause a problem if not addressed
- **Reject** – a message describing why a product was rejected from the normal flow of product
- **Debug** – a message used during the debug stage of development to monitor for specific desired or undesired events
- **Utility** – a notice used to trigger a software utility
- **Unhandled Not Shown** – a message that is sent from the PLC but not defined in the Message data base
- **Production Data Not Shown** – a message used for production data collection

Individual Items

Click this button to display the items in the grid in chronological order.

NOTE: When **Individual Items** is selected, the button color will be blue

Totaled


Click this button to display the items in the grid in a totaled fashion, displaying the number of times an item occurred. The items all totaled to allow the user to more easily view which items are occurring the most frequently.

NOTE: When **Totaled** selected, the button color will be blue

| Aagard HMI - Notice History | | | | |
|-----------------------------|----------|---------------------------------|-------|--|
| Notice History for Inserter | | | | |
| Device | Location | Message | Count | |
| CS1AE Knife ... | Inserter | Cylinder Extend Switch Not M... | 1 | |
| MS1 Custom... | Inserter | VFD Faulted | 2 | |
| MS1 Custom... | Inserter | Invalid Program Call | 16 | |
| PE6 Register... | Inserter | Sensor Failure | 8 | |
| PE6 Register... | Inserter | Not Made During Startup | 1 | |
| PE2 Web Br... | Inserter | Web Break PE Not Blocked ... | 1 | |
| PE3 Loop Low | Inserter | Eye Not Blocked When Expe... | 10 | |
| SD2 Knife | Inserter | Lag Error | 1 | |
| SD1 Pirwheel | Inserter | Cam Load Failed | 1 | |
| CTRL1 HMI | Inserter | Switching To Sercos Phase 2 ... | 1 | |
| | | | | |
| | | | | |

Edit Notes Button

Select a message in the grid and the Edit Notes Button becomes available. Click on the Edit Notes button to open a dialog window to add your notes to the messages. Double-clicking on the message itself also opens this dialog. Click OK on the dialog when finished.



Delete All Button

This button will delete the entire fault log. This will make any generated reports invalid since the Report Generator uses this fault log to generate its reports.

Refresh

This button will refresh the faults on the screen to the most current log at the time the refresh button was pressed, reflected by any filters which may have been selected.

Back Button

This button will return the user to the calling page.

Filter Drop Down List

Click on the drop down arrow to view available filters to apply to the list. Select a filter from the list to apply it. Depending on the selection, additional parameters become available to enter, such as dates and hours.

| | | |
|-----------------|-----------|------------|
| From Date/Time: | 1/ 4/2010 | 5:59:00 AM |
| To Date/Time: | 1/ 4/2010 | 5:59:00 PM |
| Show Last: | 0 Hours | 0 Minutes |

Column Options

To move a column from left to right, select a column from the dropdown list, and click Left or Right to move the column in either direction.

Device Column

This column displays the name of the device which generated the notice.

Message Column

This column displays the message which appeared on the notice. A list of possible messages, causes, and actions are given on the [Message Notices](#) section.

PLC Details Column

This column displays information received from the PLC when the notice was generated.

Shift Column

This column displays the shift in which the notice was recorded.

Down Time Column

This column displays time elapsed between notice display and when the system is started.

Ack Time Column

This column displays the length of time elapsed before the notice was acknowledged.

HMI Details Column

This column displays any additional information received from the HMI when the notice was generated.

Date Stamp Column

This column displays the date and time when the notice was generated.

Notes Column

This column displays any user entered information for the selected notice.

Notice Type

This column displays the type of notice recorded.

Location Column

This column displays the notice location or area of the machine.

Jog Page

SAMPLE IMAGE

Aagard HMI - Jog Page
Jog Page for Cartoner
 Servo: Actual Position: 0.000
24 - Metering Conveyor
 Jog Fwd | Jog Rev | Jog Velocity = 10 | To Go Target Position: 0 | Go To Position
Tuning | Default | Apply Tuning Settings | Set To Default | **Alternating Jog** | Diagnose
 Velocity Prop. Gain (Kp): 0 | 0 | Position 1: 0 | Velocity: 0
 Velocity Integral Action Time (TN): 0 | 0 | Position 2: 0 | Accel: 0
 Position Prop. Gain (Kv): 0 | 0 | Alt Dwell: 0 | Torque: 0
 Rejection Frequency: 0 | 0 | Pos Err Limit: 0
 Rejection Bandwidth: 0 | 0 | **Start Alternating** | **Stop Alternating** | **Disable Servo Drive**

Solenoid Valve:
2 - Reflector Blow Off
 Left | Right
 A Coil | B Coil

Motor:
5 - Overhead Adjustment
 Left | Center | Right | Speed: 2 FPM

24 Drive Status
 Act Pos: 0.000
 Max Pos. Err. 0.000 [Reset](#)
 Max Torq. 0.000 [Reset](#)
 Disabled
 Stopped EStop


Manual SD Enabling
 SD Data Input | SV Data Input | MT Data Input | Drive Diagnostics | Member Map Diag. | I/O Diagnostics | Back

From here, the machine user is able to manually jog the prime movers that power the actions of this machine. This screen also contains the status of the selected servo drive, including Actual Position, Max Position Error, Max Torque and State – Enabled, Disabled, or Faulted. All Jogging functions are made in a manual mode, which means that no automatic functions govern their movements.

Servo Axis Jogging

To manually move a component that is driven by a servo motor, the user must define which servo axis they want to jog and select it from the servo axis drop down list. Once the machine is started and in the ready state and manual mode, the user may jog the servo axis in the desired direction. The State and Mode is displayed in the bottom left hand corner next to the Drive Status Display. Other servo jogging features include velocity, Go To Position (which sends the axis to that position), and an alternating jog function. Unlike non servo controlled motors and solenoid valves, a servo axis will only travel while the button is depressed. Once the button is released the axis will stop.

Warning: Jogging should be done very carefully and at a low velocity. This will eliminate damage to any obstructed machine parts. Use the jog velocity sliding bar to adjust velocity.

SAMPLE IMAGE**Servo Drive**

To access different servo drives, use the servo drive drop down list.

Actual Position

This display will show the actual position of the Servo.

Jog Button

This button will jog the Servo Axis in the direction the button states.

Left Arrow

This button will adjust the Velocity Adjustor Bar to the left.

Jog Velocity

This bar can be dragged or moved via the Arrow buttons on the right or left of the bar to select the velocity of the Servo Axis selected in the servo drive drop down menu.

Right Arrow

This button will adjust the Velocity Adjustor Bar to the right.

Go To Target Position

This entry field will allow a position to be specified and, when the Go To Position button is pressed, the Servo Axis will move in the shortest direction to get to the specified position.

Go To Position

This button moves the Servo Axis to the position specified in the Go To Target Position entry field via the shortest way possible.

Tuning Box

The information contained in the Servo Drive Tuning Box is explained in further detail in the Servo Drive Tuning section.

Alternating Jog Box

The information contained in the Servo Drive Alternating Jog Box is explained in further detail in the Alternating Jog section.

Diagnose

This button will display a diagnostic popup for the currently selected Servo Drive. This diagnostic popup is described in further detail on the [Drive Diagnostics Page](#).

Enable/Disable Servo Drive Button

Click this button to enable or disable this servo drive. If the drive is currently enabled, the button color will be green and the text will read Disable Servo Drive. If the drive is currently disabled, the button color will be red and the text will read Enable Servo Drive.


NOTE: This feature is only available with the correct PLC framework version in place

NOTE: This button will only be enabled when Manual Enabling is activated

Solenoid Valve Jogging

To manually move a component that is driven by a Solenoid Valve, the user must find which solenoid valve controls the component and select it from the solenoid valve drop down list. Once the machine is started and in the ready state and manual mode, the user may jog the solenoid valve in the desired direction. The State and Mode is displayed in the bottom left hand corner next to the Drive Status Display. Once a solenoid valve jog button is depressed, the valve will move in that direction until another direction button or a stop button is depressed.

SAMPLE IMAGE



Solenoid Valve

To access different solenoid valves, use the solenoid valve drop down list.

Left Jog Button

This button will jog the Solenoid Valve in the direction the button states. This button will energize the A Coil.

Center Jog Button

This button will jog the Solenoid Valve in the direction the button states. This button will d-energize the A and B Coils.


Right Jog Button

This button will jog the Solenoid Valve in the direction the button states. This button will energize the B Coil. Not all Solenoid Valves have this button.

Motor Jogging

To manually move a component that is driven by a non servo motor, the user must define which motor they want to jog and select it from the motor drop down list. Once the machine is started and in the ready state and manual mode, the user may jog the motor in the desired direction. The State and Mode is displayed in the bottom left hand corner next to the Drive Status Display. Once a motor jog button is depressed, the motor will continue to run in that direction until the "Stop" button is depressed or the machine is externally stopped (Cycle Stop or Emergency Stop).

SAMPLE IMAGE



Motor

To access different motors, use the motor drop down list.

Left Jog

This button will jog the Motor in the direction that the button states.

Center Jog

This button will shut off the Motor.

Right Jog

This button will jog the Motor in the direction the button states. Not all Motors have this button.

Speed

This entry field will set the speed at which the Motor will be jogged. Not all Motors have this entry field.

Drive Status Box

This box is located in the bottom left corner of this page. Information that is given is Actual Position, Max Position Error, Max Torque, and State of the Servo Drive. More information can be found on the [Drive Diagnostics Page](#).

Servo Drive Diagnostics Button

This button will display the [Drive Diagnostics Page](#).

Member Map Diag. Button

This button will display the [Member Map Diagnostics Page](#).

I/O Diagnostics Button

This button will display the [I/O Diagnostics Page](#).

Manual SD Enabling Button

This button will display the [Manual SD Enabling Page](#).

NOTE: This feature is only available with the correct PLC framework version in place

Back Button

This button will close this page and go to the HMI Main Screen.

Manual SD Enabling

This page is used to activate the manual servo enabling feature. When activated, individual servos may be enabled on this page or on the jog page.

| Servo Drive Name | Status | Action Button |
|-----------------------------------------|--------|---------------------|
| SD: 24 - Metering Conveyor | Green | Disable Servo Drive |
| SD: 25 - Upstream Correction Conveyor | Red | Enable Servo Drive |
| SD: 26 - Downstream Correction Conveyor | Red | Enable Servo Drive |
| SD: 27 - Launch Conveyor | Red | Enable Servo Drive |
| SD: 28 - Fixed Fan Feeder | Red | Enable Servo Drive |
| SD: 29 - Adjustable Fan Feeder | Red | Enable Servo Drive |
| SD: 30 - Overhead Sweep | Red | Enable Servo Drive |
| SD: 31 - Carton Picker | Red | Enable Servo Drive |
| SD: 33 - Barrel Cam | Red | Enable Servo Drive |
| SD: 34 - Side Flap Tucker | Red | Enable Servo Drive |
| SD: 35 - Side Compression | Red | Enable Servo Drive |
| SD: 36 - Upstream End Tuck | Red | Enable Servo Drive |
| SD: 37 - Downstream End Tuck | Red | Enable Servo Drive |
| SD: 39 - Discharge / Reject | Red | Enable Servo Drive |
| SD: 45 - Moon Nip | Red | Enable Servo Drive |
| SD: 46 - Cartoner Master | Red | Enable Servo Drive |
| SD: 32 - Nip Belt | Red | Enable Servo Drive |
| SD: 38 - Carton Flights | Red | Enable Servo Drive |

Pressing the Activate Manual Enabling button will cause all of the servo drives in this machine/C40 to be disabled!

Deactivate Manual Enabling Back

Servo Drive Name and ID

This label represents the name of the servo drive and its ID

Status Light

This light represents the actual enabled or disabled status of the servo drive. When the drive is enabled, the status light will be green. When the drive is disabled, the status light will be red.

Enable/Disable Servo Drive Button

Click this button to enable or disable this servo drive. If the drive is currently enabled, the button color will be green and the text will read Disable Servo Drive. If the drive is currently disabled, the button color will be red and the text will read Enable Servo Drive.

NOTE: This feature is only available with the correct PLC framework version in place

NOTE: This button will only be enabled when Manual Enabling is activated

Up/Down Navigation Buttons

Up and down navigation buttons will appear when not all servo drives fit onto one screen. When drives exist above the first drive shown at the top of the screen, a button with an up arrow will be displayed. When drives exist below

the last drive shown on the bottom of the screen, a button with a down arrow will be displayed.

Activate/Deactivate Manual Enabling

Press this button to activate or deactivate manual enabling of servo drives. When activated, the button color will be green and the text will read Deactivate Manual Enabling. When deactivated, the button color will be red and the text will read Activate Manual Enabling.

NOTE: When activating manual enabling, all currently enabled servo drives will become disabled

Back Button

Click here to return to the page which called this page.

Reference Page

General Page Information


Referencing is the process of setting a Servo Axis position in reference to a stationary object such as a sensor or a hard stop (travel limit). Any time the mechanical link between the servo motor and the object that the servo motor is moving has been violated (disconnected, jumped teeth), the servo motor will need to be referenced. If a servo motor is not working correctly, it may need to be replaced (please see the **Replacing an MI Drive** topic in the Troubleshooting Guide for more information).

The referencing process begins by moving the servo axis towards the stationary object used for determining the servo axis position. When the object is located, the servo motor will then move to the reference end position based on the capture position of the stationary object. When the servo axis reaches the reference end position, the motor will disable and the servo axis' position will be set. Once the position has been set, the servo axis will enable and reposition itself to the reference end position completing the reference process.

Settings for referencing each servo axis can be found on the [Servo Drive Data Page](#).

A summary of all servos and their reference positions can be viewed in the [Servo Reference Positions](#) topic in this manual.

SAMPLE IMAGE



Servo Drive

To access different servo drives, use the servo drive drop down list.

Do Reference Routine

This button will initiate the reference routine for the selected Servo Axis or Group of Servo Axis. The display in the bottom left hand corner of the page must display Ready and Manual in order to initiate the reference routine. If the start button is pressed until the top display changes to Starting, the machine will then get to Ready and the reference routine will be able to be initiated. Once the reference routine is finished, a window will popup which contains a picture of the servo correctly referenced. **NOTE:** If multiple servos are referenced in one routine, the window will popup after the complete routine is finished and it will contain tabs for each picture.

View Image Button

This button will open a window that displays the servo in the referenced position. This image is also displayed following the completion of a reference routine. To close window, click on the red X in right corner, click outside the popup, or press Esc.

NOTE: This button will not be visible if no image has been associated with the selected servo drive.



Actual Position

This display will show the actual position of the Servo.

Home Position

This display shows the position of the selected Servo's sensor or hard stop.

Home End Position

This display shows the actual position when the reference routine of the selected Servo is complete.

Reference Mark Position

The Reference Mark Position is the position the servo reads when lined up with the reference mark.

Reference Mark Location

The Reference Mark Location is a precise description of the reference mark placement in relation to a fixed member of the machine.

Direction of Positive Movement

The Direction of Positive Movement is the direction of movement which causes a positive change in the position read out.

Reference Done

This display will show "Reference Done" when the reference routine has completed successfully.

Reference Pos. Difference

This display will show the difference between the old reference position and the new reference position.

SD Data Input Button

This button will display the [Servo Drive Data Page](#).

SV Data Input Button

This button will display the [Solenoid Data Page](#).

MT Data Input Button

This button will display the [Motor Data Page](#).

Diagnose Button

This button will display a diagnostic popup for the currently selected Servo Drive. This diagnostic popup is described in further detail on the [Drive Diagnostics Page](#).

Servo Drive Diagnostics Button

This button will display the [Drive Diagnostics Page](#).

Member Map Diag. Button

This button will display the [Member Map Diagnostics Page](#).

I/O Diagnostics Button

This button will display the [I/O Diagnostics Page](#).

Back Button


This button will close this page and go to the HMI Main Screen.

Advanced Page

General Page Information

This screen provides access to advanced functions on the machine.

NOTE: Depending on user level, not all buttons will be visible





Shutdown Computer

This button will activate the process of powering down the PC on which the Aagard HMI is located. Pressing this button will stop instantly any operations the machine is doing. Shutdown Warning

Failure to properly shut down the PC may void the warranty!

| | |
|------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Switch on | The Industrial PC does not have its own main switch. The Industrial PC will start when the equipment is switched on, or when it is connected to the power supply. |
|------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|

| | |
|---------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Shutting down and switching off | When the plant is switched off, or when it is disconnected from its power supply, the Industrial PC will be switched off. Control software such as is typically used on Industrial PCs permits various users to be given different rights. A user who may not close software may also not switch the Industrial PC off, since data can be lost from the hard disk by switching off while software is running |
|  Warning! | First shut down, then switch off the PC! If the Industrial PC is switched off as the software is writing a file to the hard disk, the file will be destroyed. Control software typically writes something to the hard disk every few seconds, so the probability of causing damage by switching off the PC while the software is running is very high! |
|  Warning! | When you have shut down the Industrial PC, you have to switch off power supply for at least 10 seconds before rebooting the system. After resetting power supply, the PC will start booting automatically. |

To properly shut down the PC, contact a Level 2 or higher Operator.

Restart Computer

This button will activate the process of restarting the PC on which the Aagard HMI is located. Pressing this button will stop instantly any operations the machine is doing.

ADCOMS

When ADCOMS is enabled, this button will give access to the ADCOMS pages. Full ADCOMS Documentation is available by pressing the Help button on the ADCOMS Main page.

HMI Setup

This button gives access to the Main Page tab which allows the user to choose to view the Production Data in Classic style or as an HTML page. **Level 3 access required.**

Glue Group

****Changes made on these pages will only affect the current downloaded product****

- These buttons will open the corresponding [glue pages](#).

Data Group

****Data on these pages is for information only, and should not need to be changed on these pages****

- **View Notices System Wide Button** - This button will open the [View Notices System Wide Page](#).
- **View Change Log Button** - This button will open the [Change Log Page](#).
- **Misc Tags Button** - This button will open the [Misc Tags Page](#).
- **View Changeover Adjustments Button** - This button will open the [View Changeover Adjustments Page](#).
- **Marquee Button** - This button will open the [Marquee Page](#), if installed.
- **GMI Tags Button** - This button will open the [Tags Page](#), if installed.


Diagnostics Group

****Data on these pages is for information only****

- **Servo Drive Diagnostics Button** - This button will open the [Drive Diagnostics Page](#).
- **Member Map Diagnostics Button** - This button will open the [Member Map Diagnostics Page](#).
- **I/O Diagnostics Button** - This button will open the [I/O Diagnostics Page](#).
- **Sercos Diagnostics Button** - This button will open the [Sercos Diagnostics Page](#).

Help Group

****Buttons in this group will launch Help programs****

- **Servo Drive Help** - This button will launch the Servo Drive Help program.
- **Beckhoff Information System** - This button will launch the Beckhoff Information System program.
- **Aagard Logo** - This button will open the Aagard Machine Operator Manual from the HMI.
 - The user may be prompted to install a documentation update
-  **Button** - When installed, this button will open the Aagard Troubleshooting Guide.
 - The user may be prompted to install a documentation update

Test Carton Qty Field

The machine will pick this number of test cartons when the Start Button is pressed during machine operation, or when the start button is held longer than three seconds when starting the machine.

Test Carton

To pick and form one empty carton, and reject it from the cartoner, press the Test Carton Button while the machine is running

Remove Aagard Available For Product

This will remove the signal sent out from the Aagard telling upstream equipment that it is available for product. Selecting this will stop upstream equipment from sending product to the Aagard system.

Ignore Downstream Available

This ignores the "Downstream Available for Product" signal coming from downstream equipment. Selecting this will allow the machine to run and produce product even when downstream equipment isn't available to take product.

Set Up Users Button

This button will open the [Setup Users Page](#). This button is only visible when logged in as Administrator Level.

Back Button

This button will close this page and go to the HMI Main Screen.

Glue Group

Glue Page


General Page Information

If this feature is installed, this page allows the user to easily adjust the available glue pattern. This page shows the product as it moves through the glue heads looking at it from the operator (HMI) side of the machine (*The direction of the blue arrow indicates the direction of product flow*).

Stitch Adjust Information

To display the stitch adjustment popup in the bottom center of the screen, click on any red glue stitch that needs to be adjusted. This popup will display all the adjustment information for the selected stitch.

SAMPLE IMAGE



- **On**

This is the on point of the selected stitch. **NOTE:** The ON value must be less than the OFF value!

- **Off**

This is the off point of the selected stitch. **NOTE:** The OFF value must be greater than the ON value!

- **Left Arrow**

This arrow will move the selected stitch point to the left relative to the product shown in the picture.

- **Right Arrow**

This arrow will move the selected stitch point to the right relative to the product shown in the picture.

- **Master Offset**

This will adjust the start of the cam relative to the designated servo axis. Usually the cam will relate to a position of a servo axis that is moving the product, such as flight chains.

- **Stitch Gap %**

This is the percent of glue stitch that is taken out of the center of the selected glue stitch.

NOTE: This setting applies to Case Packers only!

- **Use Gap Check Box**

This will allow the user to decide if there is to be a gap stitch applied or a full stitch applied.

NOTE: This setting applies to Case Packers only, when this feature is enabled!

Edit

This button will open the page in edit mode. **Aagard user level required!**

Back

This button will display the [Advanced Page](#).

Data Group

View Notices System Wide

General Page Information

This page keeps a record of all notices generated. This may help with diagnosing any major problems or possible problems. These notices will be stored in the database for three days, and then will be deleted.

SAMPLE IMAGE

Agard HMI - Notice History

Notice History for Cartoner

Move Column: C40

| Date Stamp | Device | Message | PLC Details | Notice Type | Shift | Down Time | Ack Time | Notes | Location | HMI Details |
|------------------------|-------------------|-----------------------------|--------------------|----------------|-------|-----------|----------|-------|----------|------------------|
| 1/5/2010 8:02:25 AM | IDV1 Carton ... | Bar Code Scanner Failure | Beckhoff Error ... | Fault | 1 | | | | Cartoner | |
| 1/5/2010 8:02:17 AM | IDV1 Carton ... | Bar Code Scanner Failure | Beckhoff Error ... | Fault | 1 | | | | Cartoner | |
| 12/18/2009 11:03:24 AM | SD5 Side Fil... | Motion Control Reset Error | Servo Drive E... | Fault | 1 | 00:05:53 | 00:00:07 | | Cartoner | Cleared in 7 s |
| 12/17/2009 10:54:09 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:01:21 | 00:00:01 | | Cartoner | Cleared in 1 s |
| 12/17/2009 10:49:24 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:04:07 | 00:00:02 | | Cartoner | Cleared in 2 s |
| 12/17/2009 10:35:31 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:01:13 | 00:00:02 | | Cartoner | Cleared in 2 s |
| 12/17/2009 10:25:25 AM | EN49101 Low... | Lower Film Unwind Danc... | Encoder Pos ... | Fault | 1 | 00:05:37 | 00:00:05 | | Cartoner | Cleared in 5 s |
| 12/17/2009 9:57:13 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:01:16 | 00:00:05 | | Cartoner | Cleared in 5 s |
| 12/17/2009 9:47:40 AM | EN49101 Low... | Lower Film Roll Empty | Change Out Fil... | Fault | 1 | 00:08:48 | 00:08:26 | | Cartoner | Cleared in 8 ... |
| 12/17/2009 9:42:22 AM | SD6 Side Fil... | Fast Stop Failed | MC_ChangeD... | Fault | 1 | 00:03:15 | 00:00:03 | | Cartoner | Cleared in 2 s |
| 12/16/2009 11:07:22 AM | IDV7 Carton ... | Checkweigher Failure | Check Check... | Fault | 1 | 00:00:13 | 00:00:07 | | Cartoner | Cleared in 7 s |
| 12/16/2009 10:43:57 AM | IDV4 Filler B ... | Metal Detected | Metal Detecte... | Critical Fault | 1 | | 00:00:32 | | Cartoner | Cleared in 31 s |
| 12/16/2009 10:43:54 AM | IDV3 Filler A ... | Metal Detected | Metal Detecte... | Critical Fault | 1 | 00:00:49 | 00:00:32 | | Cartoner | Cleared in 32 s |
| 12/16/2009 10:25:38 AM | IDV1 Carton ... | Bad Bar Code Scanned | Remove Carto... | Critical Fault | 1 | 00:02:24 | 00:01:15 | | Cartoner | Cleared in 1 ... |
| 12/16/2009 10:21:47 AM | PE48206 Cart... | Improper Carton Transfer... | Carton Did Not... | Fault | 1 | 00:03:19 | 00:00:18 | | Cartoner | Cleared in 17 s |
| 12/16/2009 9:22:37 AM | S32_4 Analo... | Function Block Failed | Channel 2 Fail... | Fault | 1 | | 00:28:34 | | Cartoner | Cleared in 28... |
| 12/16/2009 9:02:08 AM | S32_4 Analo... | Function Block Failed | Channel 1 Fail... | Fault | 1 | | 00:13:46 | | Cartoner | Cleared in 13... |
| 12/16/2009 8:57:11 AM | S32_4 Analo... | Function Block Failed | Channel 1 Fail... | Fault | 1 | 01:04:15 | 00:00:32 | | Cartoner | Cleared in 32 s |
| 12/16/2009 7:48:17 AM | IDV7 Carton ... | Checkweigher Failure | Check Check... | Fault | 1 | 00:00:35 | 00:00:15 | | Cartoner | Cleared in 15 s |
| 12/16/2009 7:45:01 AM | IDV7 Carton ... | Checkweigher Failure | Check Check... | Fault | 1 | 00:02:57 | 00:00:23 | | Cartoner | Cleared in 23 s |
| 12/16/2009 7:39:40 AM | IDV1 Carton ... | Bad Bar Code Scanned | Remove Carto... | Critical Fault | 1 | 00:00:52 | 00:00:39 | | Cartoner | Cleared in 39 s |
| 12/16/2009 7:37:31 AM | IDV1 Carton ... | Bad Bar Code Scanned | Remove Carto... | Critical Fault | 1 | 00:01:33 | 00:01:30 | | Cartoner | Cleared in 1 ... |
| 12/15/2009 6:44:58 PM | PE42306 Sec... | Blocked Too Long | Blocked For 1... | Fault | 2 | 00:05:46 | 00:05:36 | | Cartoner | Cleared in 5 ... |

C40 Filter

Click on the drop down arrow to view history for a particular C40. If a C40 is not listed, there are no messages to display.

Filter Buttons (Fault, Critical Fault, General, Warning, Reject, Debug, Utility, and Unhandled Not Shown)

These buttons represent different notice types. Press any button to filter those notices from the list. Pressing refresh will refresh the screen, displaying only those notice types selected.

- **Fault** – a message describing an unintended event which restricts the system's ability to produce
- **Critical Fault** – same as Fault, except the operator must acknowledge each Critical Fault individually
- **General** – an informational message which relays current existing conditions within the system
- **Warning** – a message describing an event which occurred, or an existing condition, which may cause a problem if not addressed
- **Reject** – a message describing why a product was rejected from the normal flow of product
- **Debug** – a message used during the debug stage of development to monitor for specific desired or undesired events
- **Utility** – a notice used to trigger a software utility
- **Unhandled Not Shown** – a message that is sent from the PLC but not defined in the Message data base
- **Production Data Not Shown** – a message used for production data collection

Individual Items

Click this button to display the items in the grid in chronological order.

NOTE: When **Individual Items** is selected, the button color will be blue

Totaled


Click this button to display the items in the grid in a totaled fashion, displaying the number of times an item occurred. The items all totaled to allow the user to more easily view which items are occurring the most frequently.

NOTE: When **Totaled** selected, the button color will be blue

| Aagard HMI - Notice History | | | | |
|-----------------------------|----------|---------------------------------|-------|--|
| Notice History for Inserter | | | | |
| Device | Location | Message | Count | |
| CS1AE Knife ... | Inserter | Cylinder Extend Switch Not M... | 1 | |
| MS1 Custom... | Inserter | VFD Faulted | 2 | |
| MS1 Custom... | Inserter | Invalid Program Call | 16 | |
| PE6 Register... | Inserter | Sensor Failure | 8 | |
| PE6 Register... | Inserter | Not Made During Startup | 1 | |
| PE2 Web Br... | Inserter | Web Break PE Not Blocked ... | 1 | |
| PE3 Loop Low | Inserter | Eye Not Blocked When Expe... | 10 | |
| SD2 Knife | Inserter | Lag Error | 1 | |
| SD1 Pinwheel | Inserter | Cam Load Failed | 1 | |
| CTRL1 HMI | Inserter | Switching To Sercos Phase 2 ... | 1 | |
| | | | | |
| | | | | |

Edit Notes Button

Select a message in the grid and the Edit Notes Button becomes available. Click on the Edit Notes button to open a dialog window to add your notes to the messages. Double-clicking on the message itself also opens this dialog. Click OK on the dialog when finished.



Delete All Button

This button will delete the entire fault log. This will make any generated reports invalid since the Report Generator uses this fault log to generate its reports.

Refresh

This button will refresh the faults on the screen to the most current log at the time the refresh button was pressed, reflected by any filters which may have been selected.

Back Button

This button will return the user to the calling page.

Filter Drop Down List

Click on the drop down arrow to view available filters to apply to the list. Select a filter from the list to apply it. Depending on the selection, additional parameters become available to enter, such as dates and hours.

| | | |
|-----------------|-----------|------------|
| From Date/Time: | 1/ 4/2010 | 5:59:00 AM |
| To Date/Time: | 1/ 4/2010 | 5:59:00 PM |
| Show Last: | 0 Hours | 0 Minutes |

Column Options

To move a column from left to right, select a column from the dropdown list, and click Left or Right to move the column in either direction.

Device Column

This column displays the name of the device which generated the notice.

Message Column

This column displays the message which appeared on the notice. A list of possible messages, causes, and actions are given on the [Message Notices](#) section.

PLC Details Column

This column displays information received from the PLC when the notice was generated.

Shift Column

This column displays the shift in which the notice was recorded.

Down Time Column

This column displays time elapsed between notice display and when the system is started.

Ack Time Column

This column displays the length of time elapsed before the notice was acknowledged.

HMI Details Column

This column displays any additional information received from the HMI when the notice was generated.

Date Stamp Column

This column displays the date and time when the notice was generated.

Notes Column

This column displays any user entered information for the selected notice.

Notice Type

This column displays the type of notice recorded.

Location Column

This column displays the notice location or area of the machine.

Message Notices

| Device | Name | Text | Cause | Remedy | Type |
|--------|------------------------------------|----------------------------------------|-----------------------------------------------------------------|----------------------------------------------------------------------------------------|---------|
| B1 | Brick 1 SERCOS Bus Coupler | Read IDN Error | Unable to read the parameter from the brick | Use error id to find more details in the Beckhoff Information System | Warning |
| B1 | Brick 1 SERCOS Bus Coupler | SERCOS Communication Error - MDT Count | Noise was detected in transmission | Check fiber optic connections at I/O brick, check fiber optic connections before brick | Warning |
| B1 | Brick 1 SERCOS Bus Coupler | SERCOS Communication Error - MST Count | Noise was detected in transmission | Check fiber optic connections at I/O brick, check fiber optic connections before brick | Warning |
| B5 | Brick 5 SERCOS Bus Coupler | Read IDN Error | Unable to read the parameter from the brick | Use error id to find more details in the Beckhoff Information System | Warning |
| B5 | Brick 5 SERCOS Bus Coupler | SERCOS Communication Error - MDT Count | Noise was detected in transmission | Check fiber optic connections at I/O brick, check fiber optic connections before brick | Warning |
| B5 | Brick 5 SERCOS Bus Coupler | SERCOS Communication Error - MST Count | Noise was detected in transmission | Check fiber optic connections at I/O brick, check fiber optic connections before brick | Warning |
| C20 4 | Case Packer SD Reference | Invalid Axis Type | A virtual axis cannot be referenced | Do not reference a virtual axis | Fault |
| C20 4 | Case Packer SD Reference | Invalid Reference Type | The reference type selected is not correct | Choose correct reference type for specified servo drive | Fault |
| C20 4 | Case Packer SD Reference | Probe Sensor Not Found | The probe sensor was not detected during the reference routine | Check the probe sensor and the probe setup data | Fault |
| C20 4 | Case Packer SD Reference | Reference Parameter Error | The reference type selected is not allowed on that axis type | Choose correct reference type for specified servo drive | Fault |
| C20 4 | Case Packer SD Reference | Reference Routine Failed | Reference routine failed | Check message details for specific error message | Fault |
| C20 4 | Case Packer SD Reference | Switch Sensor Not Found | The switch sensor was not detected during the reference routine | Check the switch sensor and the switch setup data | Fault |
| C20 5 | Case Packer Dow nstacker Reference | Invalid Axis Type | A virtual axis cannot be referenced | Do not reference a virtual axis | Fault |
| C20 5 | Case Packer Dow nstacker Reference | Invalid Reference Type | The reference type selected is not correct | Choose correct reference type for specified servo drive | Fault |
| C20 5 | Case Packer Dow nstacker Reference | Probe Sensor Not Found | The probe sensor was not detected during the reference routine | Check the probe sensor and the probe setup data | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|--------|------------------------------------|----------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------|-------|
| C20 5 | Case Packer Dow nstacker Reference | Reference Parameter Error | The reference type selected is not allow ed on that axis type | Choose correct reference type for specified servo drive | Fault |
| C20 5 | Case Packer Dow nstacker Reference | Reference Routine Failed | Reference routine failed | Check message details for specific error message | Fault |
| C20 5 | Case Packer Dow nstacker Reference | Sw itch Sensor Not Found | The sw itch sensor w as not detected during the reference routine | Check the sw itch sensor and the sw itch setup data | Fault |
| C20 9 | Palletizer SD Reference | Invalid Axis Type | A virtual axis cannot be referenced | Do not reference a virtual axis | Fault |
| C20 9 | Palletizer SD Reference | Invalid Reference Type | The reference type selected is not correct | Choose correct reference type for specified servo drive | Fault |
| C20 9 | Palletizer SD Reference | Probe Sensor Not Found | The probe sensor w as not detected during the reference routine | Check the probe sensor and the probe setup data | Fault |
| C20 9 | Palletizer SD Reference | Reference Parameter Error | The reference type selected is not allow ed on that axis type | Choose correct reference type for specified servo drive | Fault |
| C20 9 | Palletizer SD Reference | Reference Routine Failed | Reference routine failed | Check message details for specific error message | Fault |
| C20 9 | Palletizer SD Reference | Sw itch Sensor Not Found | The sw itch sensor w as not detected during the reference routine | Check the sw itch sensor and the sw itch setup data | Fault |
| C20 11 | Case Packer Dow nstacker | Flights Too Close To Each Other | The current configuration data caused the machine to call moves on the dow nstacker flights such that they w ould have crashed together; this prevented that crash | Check the configuration data, separate the dow nstacker flights, and restart the machine | Fault |
| C20 11 | Case Packer Dow nstacker | Invalid Product At Top Of Dow nstacker | The search routine of the dow nstacker returned an invalid product in the dow nstacker; the top layer contains no first product, but it contains a second product | Arrange the cartons in the dow nstacker correctly, check dow nstacker photo eyes for proper operation, and restart the machine | Fault |
| C20 15 | Case Packer Case Former | Multiple Rejects Detected | There w ere three identical open flap case rejects in a row | Check the changeover adjustments, check the tw o open flap photo eyes and the distorted case photo eye for proper operation, and restart machine | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|--------|--------------------------------------|-------------------------------------|------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------|------------------|
| C20 15 | Case Packer Case Former | Partial Case Reject Detected | A partial case w as detected during clean out of the machine | No action required | Reject |
| C20 16 | Palletizer Tip Reject | Case Refeed Enabled | The case refeed enable button w as pressed on the HMI | When finished refeeding cases, disable the case refeed enable button on the HMI and restart case packer | Warning |
| C20 16 | Palletizer Tip Reject | Case Refeed Mode Selected | The case refeed enable button w as pressed on the HMI | When finished refeeding cases, disable the case refeed enable button on the HMI and restart case packer | General, Warning |
| C20 16 | Palletizer Tip Reject | Clear | Not applicable | Not applicable | General |
| C20 16 | Palletizer Tip Reject | QC Case Reject | The QC case button w as pressed on the HMI | No action required | Reject |
| C20 19 | Palletizer Slip Sheet Cube Discharge | Partial Cube Reject | The eject cube button on the HMI w as pressed, or a clean out w as performed | No action required | Reject |
| C40 2 | Case Packer | Cannot Send or Accept Product | Equipment dow nstream of this C40 cannot accept product | Address issue w ith dow nstream being unable to accept product | General |
| C40 2 | Case Packer | Cannot Send or Accept Product Clear | C40 is not w aiting on dow nstream or upstream sending product | No action required | General |
| C40 2 | Case Packer | Faulted State | Used for Louise data collection | No action required | Utility |
| C40 2 | Case Packer | Infeed Product Count | Used for Louise data collection | No action required | Utility |
| C40 2 | Case Packer | Products Per Unit | Used for Louise data collection | No action required | Utility |
| C40 2 | Case Packer | Reject Unit Count | Used for Louise data collection | No action required | Utility |
| C40 2 | Case Packer | Up-To-Standard Unit | Used for Louise data collection | No action required | Utility |
| C40 3 | Orienter | Cannot Send or Accept Product | Equipment dow nstream of this C40 cannot accept product | Address issue w ith dow nstream being unable to accept product | General |
| C40 3 | Orienter | Cannot Send or Accept Product Clear | C40 is not w aiting on dow nstream or upstream sending product | No action required | General |
| C40 3 | Orienter | Faulted State | Used for Louise data collection | No action required | Utility |
| C40 3 | Orienter | Infeed Product Count | Used for Louise data collection | No action required | Utility |
| C40 3 | Orienter | Products Per Unit | Used for Louise data collection | No action required | Utility |

| Device | Name | Text | Cause | Remedy | Type |
|---------|----------------------------------------------|--------------------------------|---------------------------------------------------------------------------------------------|----------------------------------------------------------------|---------|
| C40 3 | Orienter | Reject Unit Count | Used for Louise data collection | No action required | Utility |
| C40 3 | Orienter | Up-To-Standard Unit | Used for Louise data collection | No action required | Utility |
| CR30201 | Case Packer Software E Stop | Not Ready | A condition in the PLC is requiring a software emergency stop | Check reasons for PLC emergency stop condition | General |
| CR30201 | Case Packer Software E Stop | Ready | Software emergency stop contact is closed | No action required | General |
| CR50101 | Orienter Software E Stop | Not Ready | A condition in the PLC is requiring a software emergency stop | Check reasons for PLC emergency stop condition | General |
| CR50101 | Orienter Software E Stop | Ready | Software emergency stop contact is closed | No action required | General |
| ES24301 | System Emergency Stop | Depressed | The emergency stop button is depressed | Pull the emergency stop button out to resume machine operation | General |
| ES24301 | System Emergency Stop | Pulled | The emergency stop button is released | No action required | General |
| ES24303 | Case Packer Non Operator Side Emergency Stop | Depressed | The emergency stop button is depressed | Pull the emergency stop button out to resume machine operation | General |
| ES24303 | Case Packer Non Operator Side Emergency Stop | Pulled | The emergency stop button is released | No action required | General |
| ES24304 | Case Packer Operator Side Emergency Stop | Depressed | The emergency stop button is depressed | Pull the emergency stop button out to resume machine operation | General |
| ES24304 | Case Packer Operator Side Emergency Stop | Pulled | The emergency stop button is released | No action required | General |
| ES26303 | Orienter Operator Side Emergency Stop | Depressed | The emergency stop button is depressed | Pull the emergency stop button out to resume machine operation | General |
| ES26303 | Orienter Operator Side Emergency Stop | Pulled | The emergency stop button is released | No action required | General |
| ES26304 | Orienter Non Operator Side Emergency Stop | Depressed | The emergency stop button is depressed | Pull the emergency stop button out to resume machine operation | General |
| ES26304 | Orienter Non Operator Side Emergency Stop | Pulled | The emergency stop button is released | No action required | General |
| GR20601 | Case Packer Guard Relay | Guard Relay Reset Check Failed | A check was performed after all guard doors in this circuit were closed to see if the guard | If problem persists, check guard circuit | Warning |

| Device | Name | Text | Cause | Remedy | Type |
|---------|-------------------------|--------------------------------|--------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------|---------|
| | | | relay was reset; this check failed | | |
| GR20601 | Case Packer Guard Relay | Not Ready | The guard relay is not ready when all guard doors in its circuit are closed | Try opening and closing a guard door in the circuit to reset it; if that fails check guard circuit | General |
| GR20601 | Case Packer Guard Relay | Ready | Guard relay circuit is ready | No action required | General |
| GR26401 | Orienter Guard Relay | Guard Relay Reset Check Failed | A check was performed after all guard doors in this circuit were closed to see if the guard relay was reset; this check failed | If problem persists, check guard circuit | Warning |
| GR26401 | Orienter Guard Relay | Not Ready | The guard relay is not ready when all guard doors in its circuit are closed | Try opening and closing a guard door in the circuit to reset it; if that fails check guard circuit | General |
| GR26401 | Orienter Guard Relay | Ready | Guard relay circuit is ready | No action required | General |
| GS24501 | Guard Door 2_1 | Closed | Door is closed | No action required | General |
| GS24501 | Guard Door 2_1 | Open | Door is open | Close guard door | General |
| GS24501 | Guard Door 2_1 | Open When Not Expected | Door was opened while the machine safety relay was active | Properly E-Stop machine before opening a guard door | Utility |
| GS24502 | Guard Door 2_2 | Closed | Door is closed | No action required | General |
| GS24502 | Guard Door 2_2 | Open | Door is open | Close guard door | General |
| GS24502 | Guard Door 2_2 | Open When Not Expected | Door was opened while the machine safety relay was active | Properly E-Stop machine before opening a guard door | Utility |
| GS24503 | Guard Door 2_3 | Closed | Door is closed | No action required | General |
| GS24503 | Guard Door 2_3 | Open | Door is open | Close guard door | General |
| GS24503 | Guard Door 2_3 | Open When Not Expected | Door was opened while the machine safety relay was active | Properly E-Stop machine before opening a guard door | Utility |
| GS24504 | Guard Door 2_4 | Closed | Door is closed | No action required | General |
| GS24504 | Guard Door 2_4 | Open | Door is open | Close guard door | General |
| GS24504 | Guard Door 2_4 | Open When Not Expected | Door was opened while the machine safety relay was active | Properly E-Stop machine before opening a guard door | Utility |
| GS24505 | Guard Door 2_5 | Closed | Door is closed | No action required | General |
| GS24505 | Guard Door 2_5 | Open | Door is open | Close guard door | General |
| GS24505 | Guard Door 2_5 | Open When Not Expected | Door was opened while the machine safety relay was active | Properly E-Stop machine before opening a guard door | Utility |
| GS24508 | Guard Door 2_6 | Closed | Door is closed | No action required | General |

| Device | Name | Text | Cause | Remedy | Type |
|---------|-----------------------------------|---------------------------------|--------------------------------------------------------------------|------------------------------------------------------------------|---------|
| GS24508 | Guard Door 2_6 | Open | Door is open | Close guard door | General |
| GS24508 | Guard Door 2_6 | Open When Not Expected | Door was opened while the machine safety relay was active | Properly E-Stop machine before opening a guard door | Utility |
| GS24509 | Guard Door 2_7 | Closed | Door is closed | No action required | General |
| GS24509 | Guard Door 2_7 | Open | Door is open | Close guard door | General |
| GS24509 | Guard Door 2_7 | Open When Not Expected | Door was opened while the machine safety relay was active | Properly E-Stop machine before opening a guard door | Utility |
| GS26501 | Guard Door 3_1 | Closed | Door is closed | No action required | General |
| GS26501 | Guard Door 3_1 | Open | Door is open | Close guard door | General |
| GS26501 | Guard Door 3_1 | Open When Not Expected | Door was opened while the machine safety relay was active | Properly E-Stop machine before opening a guard door | Utility |
| GT9001 | Glue System | Glue Level OK | The glue level is okay | No action required | General |
| GT9001 | Glue System | Glue System Faulted | The glue system has experienced an internal fault | Check glue system display for fault information | Fault |
| GT9001 | Glue System | Low Glue Level | The glue level is low | Fill glue tank | General |
| GT9001 | Glue System | Not Ready | The glue system is not ready for normal operation | Check glue system | General |
| GT9001 | Glue System | Ready | The glue system is ready for normal operation | No action required | General |
| HCS2 | Case Packer Servo Power Converter | Failed To Clear Fault | Power supply faults were not cleared upon startup | Check the diagnostic display on the Power supply for diagnostics | Fault |
| HCS2 | Case Packer Servo Power Converter | Power Supply Faulted | The power supply has an internal fault | Check the diagnostic display on the Power supply for diagnostics | Fault |
| HCS3 | Orienter Servo Power Converter | Failed To Clear Fault | Power supply faults were not cleared upon startup | Check the diagnostic display on the Power supply for diagnostics | Fault |
| HCS3 | Orienter Servo Power Converter | Power Supply Faulted | The power supply has an internal fault | Check the diagnostic display on the Power supply for diagnostics | Fault |
| MT807 | Case Conveyor | Forward Sensor Not Made In Time | The forward sensor for the motor was not made when it was expected | Check motor for jam, check forward sensor | Fault |
| MT807 | Case Conveyor | Input Parameter Error | The configuration data for the motor is incorrect | Fix data configuration, check programming | Fault |
| MT807 | Case Conveyor | Invalid Program Call | The configuration data for the motor is incorrect | Fix data configuration, check programming | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|--------|---------------------|----------------------------------|------------------------------------------------------------------------|--------------------------------------------|-------|
| MT807 | Case Conveyor | Motor Overloaded | The motor has overloaded | Check motor for overload reason | Fault |
| MT807 | Case Conveyor | Off Sensor Not Made In Time | The motor did not stop w hen expected | Check motor for jam, check off sensor | Fault |
| MT807 | Case Conveyor | Reverse Sensor Not Made In Time | The reverse sensor for the motor w as not made w hen it w as expected | Check motor for jam, check reverse sensor | Fault |
| MT807 | Case Conveyor | Vacuum Sensor Not Made In Time | The vacuum sensor for the motor w as not made w hen it w as expected | Check vacuum, check vacuum sensor | Fault |
| MT807 | Case Conveyor | VFD Faulted | The VFD has an internal fault | Check VFD for diagnostics | Fault |
| MT1303 | Infeed Conveyor | Forw ard Sensor Not Made In Time | The forw ard sensor for the motor w as not made w hen it w as expected | Check motor for jam, check forw ard sensor | Fault |
| MT1303 | Infeed Conveyor | Input Parameter Error | The configuration data for the motor is incorrect | Fix data configuration, check programming | Fault |
| MT1303 | Infeed Conveyor | Invalid Program Call | The configuration data for the motor is incorrect | Fix data configuration, check programming | Fault |
| MT1303 | Infeed Conveyor | Motor Overloaded | The motor has overloaded | Check motor for overload reason | Fault |
| MT1303 | Infeed Conveyor | Off Sensor Not Made In Time | The motor did not stop w hen expected | Check motor for jam, check off sensor | Fault |
| MT1303 | Infeed Conveyor | Reverse Sensor Not Made In Time | The reverse sensor for the motor w as not made w hen it w as expected | Check motor for jam, check reverse sensor | Fault |
| MT1303 | Infeed Conveyor | Vacuum Sensor Not Made In Time | The vacuum sensor for the motor w as not made w hen it w as expected | Check vacuum, check vacuum sensor | Fault |
| MT1303 | Infeed Conveyor | VFD Faulted | The VFD has an internal fault | Check VFD for diagnostics | Fault |
| MT1502 | Tip/Reject Conveyor | Forw ard Sensor Not Made In Time | The forw ard sensor for the motor w as not made w hen it w as expected | Check motor for jam, check forw ard sensor | Fault |
| MT1502 | Tip/Reject Conveyor | Input Parameter Error | The configuration data for the motor is incorrect | Fix data configuration, check programming | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|---------|---------------------------------------|---------------------------------|--------------------------------------------------------------------|---------------------------------------------------------------------------------------------------|---------|
| MT1502 | Tip/Reject Conveyor | Invalid Program Call | The configuration data for the motor is incorrect | Fix data configuration, check programming | Fault |
| MT1502 | Tip/Reject Conveyor | Motor Overloaded | The motor has overloaded | Check motor for overload reason | Fault |
| MT1502 | Tip/Reject Conveyor | Off Sensor Not Made In Time | The motor did not stop when expected | Check motor for jam, check off sensor | Fault |
| MT1502 | Tip/Reject Conveyor | Reverse Sensor Not Made In Time | The reverse sensor for the motor was not made when it was expected | Check motor for jam, check reverse sensor | Fault |
| MT1502 | Tip/Reject Conveyor | Vacuum Sensor Not Made In Time | The vacuum sensor for the motor was not made when it was expected | Check vacuum, check vacuum sensor | Fault |
| MT1502 | Tip/Reject Conveyor | VFD Faulted | The VFD has an internal fault | Check VFD for diagnostics | Fault |
| OL1402 | Side Belt Non | Overloaded | The overload relay detected an over current to the motor | Check for jams, check that drive moves freely, check overload relay settings, and restart machine | Fault |
| OL1405 | Side Belt Operator Side | Overloaded | The overload relay detected an over current to the motor | Check for jams, check that drive moves freely, check overload relay settings, and restart machine | Fault |
| PB31306 | System Start | Depressed | Button is depressed | Release button | General |
| PB31306 | System Start | Released | Button is released | No action required | General |
| PB31307 | System Cycle Stop | Depressed | Button is depressed | Release button | General |
| PB31307 | System Cycle Stop | Released | Button is released | No action required | General |
| PB31401 | Case Packer System Start | Depressed | Button is depressed | Release button | General |
| PB31401 | Case Packer System Start | Released | Button is released | No action required | General |
| PB31402 | Case Packer Non Op Side Cycle Stop | Depressed | Button is depressed | Release button | General |
| PB31402 | Case Packer Non Op Side Cycle Stop | Released | Button is released | No action required | General |
| PB31404 | Case Packer Operator Side Cycle Stop | Depressed | Button is depressed | Release button | General |
| PB31404 | Case Packer Operator Side Cycle Stop | Released | Button is released | No action required | General |
| PB51105 | Orienter Operator Side Cycle Stop | Depressed | Button is depressed | Release button | General |
| PB51105 | Orienter Operator Side Cycle Stop | Released | Button is released | No action required | General |
| PB51107 | Orienter Non Operator Side Cycle Stop | Depressed | Button is depressed | Release button | General |
| PB51107 | Orienter Non Operator Side Cycle Stop | Released | Button is released | No action required | General |
| PC1 | HMI | Battery OK | The UPS battery is functioning properly | No action required | General |

| Device | Name | Text | Cause | Remedy | Type |
|--------|------|--------------------------------------------|-----------------------------------------------------------------------|----------------------------------------------------------------------------------------------|-------------------------|
| PC1 | HMI | CPU Exceeded Critical Temperature | The CPU has reached a critical temperature and must shut down | Verify PC cooling system is functioning (if applicable); check cabinet temperatures | Critical Fault |
| PC1 | HMI | CPU Exceeded Desired Usage Amount | The CPU exceeded an expected amount. | If problem persists, check programming | Warning |
| PC1 | HMI | Fan 0 RPM Out Of Expected Range | PC cooling system not functioning properly | Verify PC fans are operational and not jammed; remove any dirt or debris from the air intake | General, Warning |
| PC1 | HMI | Fan 0 RPM Speed OK | Fan is functioning properly | No action required | General |
| PC1 | HMI | Fan 1 RPM Out Of Expected Range | PC cooling system not functioning properly | Verify PC fans are operational and not jammed; remove any dirt or debris from the air intake | General, Warning |
| PC1 | HMI | Fan 1 RPM Speed OK | Fan is functioning properly | No action required | General |
| PC1 | HMI | Fan 2 RPM Out Of Expected Range | PC cooling system not functioning properly | Verify PC fans are operational and not jammed; remove any dirt or debris from the air intake | General, Warning |
| PC1 | HMI | Fan 2 RPM Speed OK | Fan is functioning properly | No action required | General |
| PC1 | HMI | HMI Requested Restart | The Restart Computer button was pressed on the Advanced page | No Action Required | Fault |
| PC1 | HMI | HMI Requested Shutdown | The Shutdown Computer button was pressed on the Advanced page | No Action Required | Fault |
| PC1 | HMI | Mother Board Exceeded Critical Temperature | The motherboard has reached a critical temperature and must shut down | Verify PC cooling system is functioning (if applicable); check cabinet temperatures | Critical Fault |
| PC1 | HMI | Mother Board Exceeded Warning Temperature | The motherboard has reached a high temperature | Verify PC cooling system is functioning (if applicable); check cabinet temperatures | General, Warning |
| PC1 | HMI | PCU Exceeded Warning Temperature | The CPU has reached a high temperature | Verify PC cooling system is functioning (if applicable); check cabinet temperatures | General, Warning |
| PC1 | HMI | PLC Shutdown PC | The PLC Shutdown the PC | Check for other message which might indicate why the PLC shutdown the PC | Critical Fault |
| PC1 | HMI | Power On Battery | Power is being supplied via battery voltage | Restore normal power | General, Critical Fault |
| PC1 | HMI | Power On Line | Power is being supplied via line voltage | No action required | General |
| PC1 | HMI | Replace UPS Battery | The UPS battery has failed | Replace the UPS battery | General, Warning |

| Device | Name | Text | Cause | Remedy | Type |
|--------|------|----------------------------------------------|------------------------------------------------------------------|-------------------------------------------------------------------------------------|----------------|
| PC1 | HMI | SERCOS Communication - In Phase 4 | SERCOS is in phase 4 | No action required | General |
| PC1 | HMI | SERCOS Communication Error - FibBr Count | Communication error - FibBr count w as incremented | Check SERCOS ring for bad connections | Warning |
| PC1 | HMI | SERCOS Communication Error - MST Early Count | Communication error -MST Early count w as incremented | Check SERCOS ring for bad connections | Warning |
| PC1 | HMI | SERCOS Communication Error - MST Late Count | Communication error - MST Late count w as incremented | Check SERCOS ring for bad connections | Warning |
| PC1 | HMI | SERCOS Communication Error - Not In Phase 4 | SERCOS is not in phase 4 | Verify ring is intact and reinitialize the system | General |
| PC1 | HMI | SERCOS Communication Error - R Count | Communication error - R count w as incremented | Check SERCOS ring for bad connections | Warning |
| PC1 | HMI | SERCOS Communication Error - RDist Count | Communication error - RDist count w as incremented | Check SERCOS ring for bad connections | Warning |
| PC1 | HMI | SERCOS Communication Error - Timing Count 1 | Communication error - timing count 1 w as incremented | Check SERCOS ring for bad connections | Warning |
| PC1 | HMI | SERCOS Communication Error - Timing Count 2 | Communication error - timing count 2 w as incremented | Check SERCOS ring for bad connections | Warning |
| PC1 | HMI | Shutdown For Power Loss | Power was lost to the PC and it shut itself down | Check power supply | Critical Fault |
| PC1 | HMI | Switching To SERCOS Phase 0 Error | Initialization failed when switching to SERCOS phase 0 | Check diagnostics messages on SERCOS devices | Fault |
| PC1 | HMI | Switching To SERCOS Phase 2 Error | Initialization failed when switching to SERCOS phase 2 | Check diagnostics messages on SERCOS devices | Fault |
| PC1 | HMI | Switching To SERCOS Phase 3 Error | Initialization failed when switching to SERCOS phase 3 | Check diagnostics messages on SERCOS devices | Fault |
| PC1 | HMI | Switching To SERCOS Phase 4 Error | Initialization failed when switching to SERCOS phase 4 | Check diagnostics messages on SERCOS devices | Fault |
| PC1 | HMI | System Exceeded Critical Temperature | The system has reached a critical temperature and must shut down | Verify PC cooling system is functioning (if applicable); check cabinet temperatures | Critical Fault |

| Device | Name | Text | Cause | Remedy | Type |
|--------|------|-------------------------------------|------------------------------------------------|-------------------------------------------------------------------------------------|------------------|
| PC1 | HMI | System Exceeded Warning Temperature | The system has reached a high temperature | Verify PC cooling system is functioning (if applicable), check cabinet temperatures | General, Warning |
| PC1 | HMI | Temp 0 Temperature OK | CPU temperature is okay | No action required | General |
| PC1 | HMI | Temp 1 Temperature OK | System temperature is okay | No action required | General |
| PC1 | HMI | Temp MB Temperature OK | Motherboard temperature is okay | No action required | General |
| PC1 | HMI | Unknown Power Status | The status of the power is unknown | Verify that power is connected properly | General, Warning |
| PC1 | HMI | Unknown UPS Battery Status | The status of the battery is unknown | Verify the battery is connected properly; replace the battery, if necessary | General, Warning |
| PC1 | HMI | Unknown UPS Comm Status | The status of the UPS communication is unknown | Verify UPS communication | General, Warning |
| PC1 | HMI | UPS Comm Failed | Communication with the UPS has failed | Verify UPS communication | General, Warning |
| PC1 | HMI | UPS Comm OK | Communication with the UPS is working | No action required | General |
| PC1 | HMI | UPS System Fault | The UPS system has faulted | Check UPS; replace the UPS system, if necessary | Warning |
| PC1 | HMI | Volt 12 Level OK | Supply voltage is within recommended range | No action required | General |
| PC1 | HMI | Volt 12 Out of Range | Supply voltage is not within recommended range | Verify power supply is functioning correctly; check for short circuit | General, Warning |
| PC1 | HMI | Volt 2a Level OK | Supply voltage is within recommended range | No action required | General |
| PC1 | HMI | Volt 2a Out of Range | Supply voltage is not within recommended range | Verify power supply is functioning correctly; check for short circuit | General, Warning |
| PC1 | HMI | Volt 2b Level OK | Supply voltage is within recommended range | No action required | General |
| PC1 | HMI | Volt 2b Out of Range | Supply voltage is not within recommended range | Verify power supply is functioning correctly; check for short circuit | General, Warning |
| PC1 | HMI | Volt 3.3 Level OK | Supply voltage is within recommended range | No action required | General |

| Device | Name | Text | Cause | Remedy | Type |
|---------|---------------------------|-----------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|------------------|
| PC1 | HMI | Volt 3.3 Out of Range | Supply voltage is not within recommended range | Verify power supply is functioning correctly; check for short circuit | General, Warning |
| PC1 | HMI | Volt 5 Level OK | Supply voltage is within recommended range | No action required | General |
| PC1 | HMI | Volt 5 Out of Range | Supply voltage is not within recommended range | Verify power supply is functioning correctly; check for short circuit | General, Warning |
| PE31702 | Product in Side Belts | Gap Between Products Was Too Small | The photo eye was unblocked shorter than expected; incoming products were too close together for proper downstacker operation | Check the adjustment value for the downstacker width, check for proper infeed rate, and restart the machine | Fault |
| PE31702 | Product in Side Belts | Not Blocked Long Enough | The photo eye was not blocked long enough to be a carton | Check for jams or debris in the side belts area, check for shredded side belt, check sensor for proper operation, and restart the machine | Fault |
| PE31702 | Product in Side Belts | Product Jam In Side Belts | The photo eye was blocked longer than the cycle time of one carton | Clear any jams or debris, check the photo eye for proper operation, and restart the machine | Fault |
| PE31703 | 2nd Carton At Downstacker | Blocked Too Long During Search Routine | The photo eye was still blocked after the search routine moved to its maximum search position | Remove any excess product or debris in the downstacker, check photo eye for proper operation, and restart the machine | Fault |
| PE31704 | 1st Carton At Downstacker | Blocked Too Long During Search Routine | The photo eye was still blocked after the search routine moved to its maximum search position | Remove any excess product or debris in the downstacker, check photo eye for proper operation, and restart the machine | Fault |
| PE31704 | 1st Carton At Downstacker | Product Detected While Product Disabled | Product was detected when no product was expected in the machine | Clean product out of the downstacker chamber and restart machine | Fault |
| PE31705 | Down Stacker Search | Blocked Too Long During Search Routine | The photo eye was still blocked after the search routine moved to its maximum search position | Remove any excess product or debris in the downstacker, check photo eye for proper operation, and restart the machine | Fault |
| PE31705 | Down Stacker Search | Downstacker Overfull | The photo eye detected too many layers of product in the downstacker | Clean out extra product from downstacker and restart machine | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|---------|-----------------------------|----------------------------------------|---------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| | | | during a search routine | | |
| PE31705 | Down Stacker Search | Unable To Accurately Count Product | Down stacker photo eyes were unable to determine the carton count in the down stacker during a search routine | Check down stacker chamber for damaged product, clean out down stacker chamber, and restart the machine; verify the correct recipe is downloaded, check changeover adjustments, and check product dimensions | Fault |
| PE31707 | Product At Downstack Pusher | Blocked Too Long | The photo eye was blocked for an entire cycle of the down stacker master | Clear any jams or debris, check the photo eye for proper operation, and restart the machine | Fault |
| PE31707 | Product At Downstack Pusher | Blocked Too Long During Search Routine | The photo eye was blocked for more than one cycle of the down stacker search routine | Clear any jams or debris, check the photo eye for proper operation, and restart the machine | Fault |
| PE31707 | Product At Downstack Pusher | Blocked When Not Expected | The photo eye was blocked when no product was expected | Clear any jams in the down stacker chamber, check the photo eye for proper operation, and restart the machine | Fault |
| PE31707 | Product At Downstack Pusher | PE Did Not Sense Stack | Stack was presented from the down stacker to the down stack pusher but the photo eye did not sense the stack | Remove any product from in front of the loader, check the photo eye for proper operation, and restart the machine | Fault |
| PE31707 | Product At Downstack Pusher | Unblocked Too Long | The photo eye was unblocked for an entire cycle of the down stack pusher master | Check the photo eye for proper operation and restart the machine | Fault |
| PE31803 | Case Blanks Present | Clear | Not applicable | Not applicable | General |
| PE31803 | Case Blanks Present | Empty Magazine | The photo eye was unblocked for too many blank picks | Refill the magazine and restart machine; if problem continues, check the photo eye for proper operation | Fault |
| PE31803 | Case Blanks Present | Low Magazine | The photo eye is unblocked while producing | Refill the magazine; if message continues, the check photo eye for proper operation | General |
| PE31903 | Case Present at Load | Blocked Too Long | The photo eye was blocked for an entire cycle of the case former master | Clear any jams or debris, check the photo eye for proper operation, and restart the machine | Fault |
| PE31903 | Case Present at Load | Case Not Detected | Case was not detected by photo eye after being setup | Remove case at load station, check photo eye for proper operation, and restart machine | Fault |
| PE31903 | Case Present at Load | Case Not Detected During Load | The photo eye became unblocked unexpectedly while case is setup, most | Check the change over adjustments for the flap holder and check photo eye for proper operation at the next machine stop | Warning |

| Device | Name | Text | Cause | Remedy | Type |
|---------|------------------------------|-------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|
| | | | likely during the loading of the case | | |
| PE31903 | Case Present at Load | Case Not Detected During Startup | During startup, the machine expected a case at the load station and the load vacuum switch detected a case, but the photo eye did not detect a case | Remove case at load, check the photo eye for proper operation, and restart the machine | Fault |
| PE31904 | Distorted Case | Blocked Too Long | The photo eye was blocked for an entire cycle of the case former master | Clear any jams or debris, check the photo eye for proper operation, and restart the machine | Fault |
| PE31904 | Distorted Case | Reject Detected | The photo eye detected an open trailing minor case flap | No action is required; if reject continues, then check the photo eye for proper operation and verify the timing of the tuckers | Reject |
| PE31904 | Distorted Case | Unblocked Too Long | The photo eye was unblocked for an entire cycle of the case former master | Check the photo eye for proper operation and restart the machine | Fault |
| PE31905 | Product At Loader | Blocked Too Long | The photo eye was blocked for an entire cycle of the loader master | Clear any jams, check the photo eye for proper operation, and restart the machine | Fault |
| PE31905 | Product At Loader | Blocked Unexpectedly During Startup | The photo eye was blocked unexpectedly during startup | Remove any product or debris from in front of the loader, check the photo eye for proper operation, and restart the machine | Fault |
| PE31905 | Product At Loader | PE Did Not Sense Stack | The downstacker pusher presented a stack to the loader but the photo eye did not detect the stack | Remove the product at the load station, check the photo eye for proper operation, and restart the machine | Fault |
| PE31905 | Product At Loader | Product Detected After Reset | The photo eye was blocked while trying to restart the machine after a reset | Remove any product or debris from in front of the loader, check the photo eye for proper operation and restart the machine | Fault |
| PE31905 | Product At Loader | Unblocked Too Long | The photo eye was unblocked for an entire cycle of the loader master | Check the photo eye for proper operation and restart the machine | Fault |
| PE51401 | Operator Side Open Case Flap | Blocked Too Long | The photo eye was blocked for an entire cycle of the case former master | Clear any jams or debris, check the photo eye for proper operation, and restart the machine | Fault |
| PE51401 | Operator Side Open Case Flap | Reject Detected | The photo eye detected an open operated side major case flap | No action required.; if reject continues, check the photo eye for proper operation, verify glue placement, and verify changeover adjustments for compression area | Reject |

| Device | Name | Text | Cause | Remedy | Type |
|---------|----------------------------------|----------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| PE51402 | Non Operator Side Open Case Flap | Blocked Too Long | The photo eye was blocked for an entire cycle of the case former master | Clear any jams or debris, check the photo eye for proper operation, and restart the machine | Fault |
| PE51402 | Non Operator Side Open Case Flap | Reject Detected | The photo eye detected an open non-operator side major case flap | No action required; if reject continues, check the photo eye for proper operation, verify glue placement, and verify changeover adjustments for compression area | Reject |
| PE51503 | Case At Tip | Blocked After Reject | The photo eye was blocked after a reject cycle was completed and machine is expecting the photo eye to become unblocked after the reject cycle is completed | Clear any jams or debris from the tip station, check the photo eye for proper operation, and restart the machine | Fault |
| PE51503 | Case At Tip | Blocked After Tip | The photo eye was blocked after a tip cycle was completed and machine is expecting the photo eye to become unblocked after the tip cycle is completed | Clear any jams or debris from the tip station, check the photo eye for proper operation, and restart the machine | Fault |
| PE51503 | Case At Tip | Unexpected Case Reject | Unexpected case entered the tip station; this usually occurs because the case packer was reset with a case in compression | No action required | Reject |
| PE51503 | Case At Tip | Unexpected Product At Startup | The photo eye was blocked unexpectedly during startup; machine does not know if product is tipped or not | Remove any product or debris in the tip station, check the photo eye for proper operation, and restart the machine | Fault |
| PE51504 | Lower Case Reject Chute | Blocked | Blocked or sensor failure | Check sensor and remove jams | General |
| PE51504 | Lower Case Reject Chute | Blocked Too Long While Rejecting | Blocked too long while rejecting | Check sensor and remove jams | Fault |
| PE51504 | Lower Case Reject Chute | Blocked When Not Expected | Sensor failure or jam | Check sensor for proper functionality | Fault |
| PE51504 | Lower Case Reject Chute | Blocked When Trying To Start | Blocked or failure when starting | Check sensor and remove jams | Fault |
| PE51504 | Lower Case Reject Chute | Unblocked | Sensor is clear | No action required | General |
| PE51505 | Case At Rotate | Blocked Too Long | The photo eye was blocked at the | Clear any jams or debris, check the photo eye for proper operation, | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|---------|---------------------------|----------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| | | | vacuum release position of the rotate cycle | and restart the machine | |
| PE51506 | Case Present After Rotate | Case Conveyor Jam | The photo eye was blocked for too long | Clear any jams or debris, place unrotated case in correct orientation after the photo eye, check the photo eye for proper operation, and restart the machine | Fault |
| PE51506 | Case Present After Rotate | Not Blocked After Rotate | The photo eye was not blocked after a rotate cycle | Clear any jams, place unrotated case in correct orientation after the photo eye, check the photo eye for proper operation, and restart the machine | Fault |
| PE51508 | Upper Case Reject Chute | Blocked | Blocked or sensor failure | Check sensor and remove jams | General |
| PE51508 | Upper Case Reject Chute | Blocked Too Long While Rejecting | Blocked too long while rejecting | Check sensor and remove jams | Fault |
| PE51508 | Upper Case Reject Chute | Blocked When Not Expected | Sensor failure or jam | Check sensor for proper functionality | Fault |
| PE51508 | Upper Case Reject Chute | Blocked When Trying To Start | Blocked or failure when starting | Check sensor and remove jams | Fault |
| PE51508 | Upper Case Reject Chute | Unblocked | Sensor is clear | No action required | General |
| PS31201 | System Air Pressure | Low Air Pressure | Air pressure is low | Check air pressure | General |
| PS31201 | System Air Pressure | Low Air Pressure | Air pressure was lost when not expected | Check valve supplying pressure switch, adjust air pressure at regulator to correct PSI | Fault |
| PS31201 | System Air Pressure | Pressure Above Set Point | Air pressure is above set point | No action required | General |
| PX31804 | Case Magazine Advance | Case Blanks Not Advancing | Magazine advance attempted to bring the case blanks forward multiple times but was not able to make the prox; advance chains jammed; changeover adjustment incorrect; case blanks out of position | Push blanks forward; check the changeover adjustments; unjam the advance chains; check that prox target can make the prox; check prox for proper operation | Warning |
| PX31908 | Load Gate Closed | Clear | Not applicable | Not applicable | General |
| PX31908 | Load Gate Closed | Gate Open When Starting Machine | The proximity switch did not detect the load gate while the machine was starting | Close the load gate, check proximity switch for proper operation, and restart the machine | Warning |
| PX31908 | Load Gate Closed | Gate Opened | The proximity switch did not detect the load gate while the machine was producing | Close the load gate, check proximity switch for proper operation, and restart the machine | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------|----------------------------------------------|-----------------------------------------------------------------------|---------|
| PX31908 | Load Gate Closed | Open | Load gate is open | Close load gate when finished | General |
| S3_5 | Analog Output Card | Function Block Failed | Internal error in function block | Refer to message details for more information | Fault |
| S5_1 | Analog Output Card | Function Block Failed | Internal error in function block | Refer to message details for more information | Fault |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Transfer Spatula Non Op Side Lower Downstacker Non Op Side Upper Downstacker Operator Side Lower Downstacker Operator Side Upper Downstacker Down Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Lower Compression Non-Operator Side Lower Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Downstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | Abort Command Failed | The drive was not able to abort successfully | Clear message and start system; if problem persists, review move data | Fault |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 | Transfer Spatula Non Op Side Lower Downstacker Non Op Side Upper Downstacker Operator Side Lower Downstacker Operator Side Upper Downstacker Down Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Lower Compression Non-Operator Side Lower Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Downstacker Pusher Master | ADS Write Error In Init Step 4 | Writing of a servo drive parameter failed | Refer to the message details for further direction | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------|--------------------------------------------------------------------|-------------------------------------------------------|---------|
| SD44 | Loader Master Tip / Reject Master Tucker Master | | | | |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Dow nstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | Axis Torque Threshold Exceeded | The axis approached its allow able torque during the move | Address issues that are causing increased torque | Warning |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Dow nstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | Brake Release IDN Write Failed | Unable to w rite an IDN | Refer to the message details for further direction | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|------------------------------------------------------------------------------|----------------------------------------------------------------------|-------|
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Dow nstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | Cam Load Failed | The cam w as not loaded correctly | Perform a reset; refer to the message details for further direction | Fault |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Dow nstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | Cam Move Failed | The drive w as unable to perform the called move under its current condition | Clear message and start system; if problem persists, review Cam data | Fault |
| SD1 SD2 SD3 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker | Cam Offset Error | Drive w as not able to perform the cam offset | Refer to the message details for further direction | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------|------------------------------------------------------------------------------|-------------------------------------------------------------------------|-------|
| SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Dow nstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | | | | |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Dow nstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | Distance Move Failed | The drive w as unable to perform the called move under its current condition | Clear message and start system; if problem persists, review move data | Fault |
| SD1 SD2 SD3 SD4 SD5 SD6 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher | Drive Error | The servo drive is disabled | Check servo drive diagnostics; use error id to look up specific message | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------|------------------------------------------------------------|-----------------------------------------------------------------------|-------|
| SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Dow nstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | | | | |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Dow nstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | Fast Stop Failed | The drive w as not able to fast stop successfully | Clear message and start system; if problem persists, review move data | Fault |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker | Get Cam Info Failed | Unable to read needed cam information from the servo drive | Refer to the message details for further direction | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------|-------------------------------------------------------------------|----------------------------------------------------------------------|-------|
| SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Dow nstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | | | | |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Dow nstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | Get Current Slave Position Failed | The PLC could not capture the current slave position of the drive | Clear message and start system; if problem persists, review Cam data | Fault |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis | Input/Output Revs Of GBX Cannot Be Set To 0 | The gearbox ratio was set to 0 | Change gearbox ratio to a valid number | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------|---------------------------------------------------------|----------------------------------------------------------------------|-------|
| SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Case Packer Robot Z Axis Case Packer Flights Lower Compression Non-Operator Side Lower Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Downstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | | | | |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 | Transfer Spatula Non Op Side Lower Downstacker Non Op Side Upper Downstacker Operator Side Lower Downstacker Operator Side Upper Downstacker Down Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Lower Compression Non-Operator Side Lower Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate | Invalid Data | Invalid drive setup data | Refer to the message details for further direction | Fault |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 | Transfer Spatula Non Op Side Lower Downstacker Non Op Side Upper Downstacker Operator Side Lower Downstacker Operator Side Upper Downstacker Down Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Lower Compression Non-Operator Side Lower Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side | Invalid Reference Verification Type | The reference verification type selected is not correct | Choose correct reference verification type for specified servo drive | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------|------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------|---------|
| SD21 | Case Tip Y Case Tipper Case Rotate | | | | |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Dow nstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | Mechanical Slip Detected | A mechanical slip may have occurred | Reference drive; check for any source of mechanical slip and check probe for proper operation | Warning |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Dow nstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | Modulo Move Failed | The drive w as unable to perform the called move under its current condition | Clear message and start system; if problem persists, review move data | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------|-----------------------------------------|---------------------------------------------------------------------|-------|
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Dow nstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | Modulo Value Is Too Large | Servo drive modulo data value too large | Check modulo value; adjust to appropriate value | Fault |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Dow nstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | Motion Control Reset Error | Drive could not reset | Check pow er supply to drives; use error id to get more information | Fault |
| SD1 SD2 SD3 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker | Phase 2 to 3 Transition Check Error | Check w hen transitioning from | Refer to the message details for further direction | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------|----------------------------------------------------------|----------------------------------------------------|-------|
| SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Dow nstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | | phase 2 to phase 3 failed | | |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Dow nstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | Phase 3 to 4 Transition Check Error | Check w hen transitioning from phase 3 to phase 4 failed | Refer to the message details for further direction | Fault |
| SD1 SD2 SD3 SD4 SD5 SD6 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher | Position Follow ing Error | The servo drive is being jammed or held by something | Look for damaged or dragging mechanical assembly | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------|--------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------|----------------|
| SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Dow nstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | | | | |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Dow nstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | Position Move Failed | The drive w as unable to perform the called move under its current condition | Clear message and start system; if problem persists, review move data | Fault |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker | Pow er Cycle Required | The functional package on the servo drive has changed and the pow er to the servo needs to be cycled in order to activate the change | Cycle pow er to the servo | Critical Fault |

| Device | Name | Text | Cause | Remedy | Type |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------|----------------------------------|----------------------------------------------------|---------|
| SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 | Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate | | | | |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Dow nstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | Read IDN Failed | Unable to read a servo drive IDN | Refer to the message details for further direction | Fault |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side | Read SERCOS IDN Failed | Unable to read a servo drive IDN | Refer to the message details for further direction | Warning |

| Device | Name | Text | Cause | Remedy | Type |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------|------------------------------------------------------------------|-----------------------------------------------------------------|---------|
| SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Downstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | | | | |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 | Transfer Spatula Non Op Side Lower Downstacker Non Op Side Upper Downstacker Operator Side Lower Downstacker Operator Side Upper Downstacker Down Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Lower Compression Non-Operator Side Lower Compression Operator Side Upper Compression Non-Operator Side Case Tip Y Case Tipper Case Rotate | Reference Position Check Failed | Servo sensor position was not inside the compare position window | Try to reference again; verify the axis is referencing properly | Fault |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 | Transfer Spatula Non Op Side Lower Downstacker Non Op Side Upper Downstacker Operator Side Lower Downstacker Operator Side Upper Downstacker Down Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Lower Compression Non-Operator Side Lower Compression Operator Side Upper Compression Non-Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Downstacker Pusher Master | Reference Position Set | Reference position was set | No action required | Utility |

| Device | Name | Text | Cause | Remedy | Type |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------|------------------------------------------------------|-----------------------------------------------------------------------------------------|-------|
| SD44 | Loader Master Tip / Reject Master Tucker Master | | | | |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate | Reference Verification Routine Failed | The reference verification routine failed | Try to reference again, check setup data | Fault |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate | Reference Verification Sensor Not Found | The verification sensor was not found during routine | Verify reference verification sensor type is correct; verify sensor is working properly | Fault |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker | SERCOS Clear Error Procedure Command Error | Weak sercos ring detected | Check for bad sercos cable/connection | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------|------------------------------|------------------------------------------|---------|
| SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Dow nstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | | | | |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Dow nstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | SERCOS Communication Error - MDT Count | Weak SERCOS communication | Check for bad sercos cable/connection | Warning |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis | SERCOS Communication Error - MST Count | Weak SERCOS communication | Check for bad sercos cable/connection | Warning |

| Device | Name | Text | Cause | Remedy | Type |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------|-----------------------------------------------------------------------|----------------------------------------------------|-------|
| SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Dow nstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | | | | |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Dow nstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | SERCOS Set Default Parameters Procedure Error | Unable to set the servo tuning parameters to factory default settings | Refer to the message details for further direction | Fault |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side | SERCOS Set Default Tuning Command Failed | Unable so set the servo tuning parameters to factory default settings | Refer to the message details for further direction | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------|-------------------------------------------|----------------------------------------------------|-------|
| SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Dow nstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | | | | |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Dow nstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | SERCOS Write Error In Init Step 3a | Writing of a servo drive parameter failed | Refer to the message details for further direction | Fault |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side | SERCOS Write Error In Init Step 3b | Writing of a servo drive parameter failed | Refer to the message details for further direction | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------|---------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------|-------|
| SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Downstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | | | | |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Transfer Spatula Non Op Side Lower Downstacker Non Op Side Upper Downstacker Operator Side Lower Downstacker Operator Side Upper Downstacker Down Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Lower Compression Non-Operator Side Lower Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Downstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | SERCOS Write Failed In Init Step 2 | Writing of a servo drive parameter failed | Refer to the message details for further direction; check servo drive parameters | Fault |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 | Transfer Spatula Non Op Side Lower Downstacker Non Op Side Upper Downstacker Operator Side Lower Downstacker Operator Side Upper Downstacker Down Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Lower Compression Non-Operator Side Lower Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper | Servo Drive Scaling Setup Invalid | Gear box input, output or inches per rev servo drive data not entered correctly | Enter valid data on servo drive page | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------|-----------------------------------------------------------|----------------------------------------------------|-------|
| SD41 SD42 SD43 SD44 | Case Rotate Case Former Master Dow nstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | | | | |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate | Servo Must Be Referenced | Servo has not been referenced since last parameter change | Reference servo motor | Fault |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Dow nstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | Set Reference Position Error | Servo drive unable to set reference position | Refer to the message details for further direction | Fault |
| SD1 SD2 | Transfer Spatula Non Op Side Low er Dow nstacker | Unknow n Drive Type Error | Unable to determine drive type | Refer to the message details for further direction | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------|------------------------------------------------------------------------------|-----------------------------------------------------------------------|-------|
| SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Dow nstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | | | | |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker Dow n Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Low er Compression Non-Operator Side Low er Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Dow nstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | Velocity Move Failed | The drive w as unable to perform the called move under its current condition | Clear message and start system; if problem persists, review move data | Fault |
| SD1 SD2 SD3 SD4 SD5 | Transfer Spatula Non Op Side Low er Dow nstacker Non Op Side Upper Dow nstacker Operator Side Low er Dow nstacker Operator Side Upper Dow nstacker | Write Torque Limit Failed | Unable to w rite the torque limit | Refer to the message details for further direction | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------|-------------------------------------------------|--------------------------------------------------------|---------|
| SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 | Down Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Lower Compression Non-Operator Side Lower Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Downstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | | | | |
| SD1 SD2 SD3 SD4 SD5 SD6 SD7 SD8 SD9 SD10 SD11 SD12 SD13 SD14 SD15 SD16 SD17 SD18 SD19 SD20 SD21 SD40 SD41 SD42 SD43 SD44 | Transfer Spatula Non Op Side Lower Downstacker Non Op Side Upper Downstacker Operator Side Lower Downstacker Operator Side Upper Downstacker Down Stack Pusher Loader Funnel Fun Tucker Tucker Product Stop Case Packer Robot X Axis Case Packer Robot Z Axis Case Packer Flights Lower Compression Non-Operator Side Lower Compression Operator Side Upper Compression Non-Operator Side Upper Compression Operator Side Case Tip Y Case Tipper Case Rotate Case Former Master Downstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | Writing SERCOS IDNs Failed in Init Step 1 | Writing of a servo drive parameter failed | Refer to the message details for further direction | Fault |
| SD40 SD41 SD42 SD43 SD44 | Case Former Master Downstacker Pusher Master Loader Master Tip / Reject Master Tucker Master | Set Master Modulo Failed | Setting the master modulo failed | Refer to the message details for further direction | Fault |
| SR20401 | Case Packer Safety Relay | Delayed Opened After Expected | The delayed contact time of the | Adjust safety relay time to be within specification | Warning |

| Device | Name | Text | Cause | Remedy | Type |
|---------|--------------------------|-------------------------------------|----------------------------------------------------------------------------------------------------------|-----------------------------------------------------|---------|
| | | | safety relay is too long | | |
| SR20401 | Case Packer Safety Relay | Delayed Opened Before Expected | The delayed contact time of the safety relay is too short | Adjust safety relay time to be within specification | Warning |
| SR20401 | Case Packer Safety Relay | Immediate Made | The safety relay is closed | No action required | General |
| SR20401 | Case Packer Safety Relay | Press Start to Continue | The safety relay is open | Press start button to continue operation | General |
| SR20401 | Case Packer Safety Relay | Safety Relay Reset Check Failed | A check was performed after the safety circuit was reset to see if the relay is reset; this check failed | If problem persists check safety circuit | Warning |
| SR26201 | Orienter Safety Relay | Delayed Opened After Expected | The delayed contact time of the safety relay is too long | Adjust safety relay time to be within specification | Warning |
| SR26201 | Orienter Safety Relay | Delayed Opened Before Expected | The delayed contact time of the safety relay is too short | Adjust safety relay time to be within specification | Warning |
| SR26201 | Orienter Safety Relay | Immediate Made | The safety relay is closed | No action required | General |
| SR26201 | Orienter Safety Relay | Press Start to Continue | The safety relay is open | Press start button to continue operation | General |
| SR26201 | Orienter Safety Relay | Safety Relay Reset Check Failed | A check was performed after the safety circuit was reset to see if the relay is reset; this check failed | If problem persists check safety circuit | Warning |
| SV30306 | Magazine Rotate Clips | Direction A Jam | Sensor was made, then unmade when not expected | Check A sensor for proper operation | Fault |
| SV30306 | Magazine Rotate Clips | Direction A Sensor Not Made In Time | The A sensor did not make in the required time from the A direction call | Check A sensor for proper operation | Fault |
| SV30306 | Magazine Rotate Clips | Direction B Jam | Sensor was made, then unmade when not expected | Check B sensor for proper operation | Fault |
| SV30306 | Magazine Rotate Clips | Direction B Sensor Not Made In Time | The B sensor did not make in the required time from the B direction call | Check B sensor for proper operation | Fault |
| SV30306 | Magazine Rotate Clips | Input Parameter Error | Incorrect SV data | Fix invalid setup parameters | Fault |
| SV30306 | Magazine Rotate Clips | Invalid Program Call | A call to the SV was invalid | Fix program call | Fault |
| SV30306 | Magazine Rotate Clips | Off Jam | Sensor was made, then unmade when | Check off sensor for proper operation | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|---------|-----------------------|-------------------------------------|------------------------------------------------------------------------------|----------------------------------------------------------------------|-------|
| | | | not expected | | |
| SV30306 | Magazine Rotate Clips | Off Sensor Not Made In Time | The off sensor did not make in the required time from the off direction call | Check off sensor for proper operation | Fault |
| SV30306 | Magazine Rotate Clips | Vacuum Lost | Vacuum sensor was made and then lost when not expected | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV30306 | Magazine Rotate Clips | Vacuum Sensor Not Made In Time | Vacuum sensor was not made in time | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV30307 | Load Cups Blow back | Direction A Jam | Sensor was made, then unmade when not expected | Check A sensor for proper operation | Fault |
| SV30307 | Load Cups Blow back | Direction A Sensor Not Made In Time | The A sensor did not make in the required time from the A direction call | Check A sensor for proper operation | Fault |
| SV30307 | Load Cups Blow back | Direction B Jam | Sensor was made, then unmade when not expected | Check B sensor for proper operation | Fault |
| SV30307 | Load Cups Blow back | Direction B Sensor Not Made In Time | The B sensor did not make in the required time from the B direction call | Check B sensor for proper operation | Fault |
| SV30307 | Load Cups Blow back | Input Parameter Error | Incorrect SV data | Fix invalid setup parameters | Fault |
| SV30307 | Load Cups Blow back | Invalid Program Call | A call to the SV was invalid | Fix program call | Fault |
| SV30307 | Load Cups Blow back | Off Jam | Sensor was made, then unmade when not expected | Check off sensor for proper operation | Fault |
| SV30307 | Load Cups Blow back | Off Sensor Not Made In Time | The off sensor did not make in the required time from the off direction call | Check off sensor for proper operation | Fault |
| SV30307 | Load Cups Blow back | Vacuum Lost | Vacuum sensor was made and then lost when not expected | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV30307 | Load Cups Blow back | Vacuum Sensor Not Made In Time | Vacuum sensor was not made in time | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV30308 | Load Vacuum | Direction A Jam | Sensor was made, then unmade when not expected | Check A sensor for proper operation | Fault |
| SV30308 | Load Vacuum | Direction A Sensor Not Made In Time | The A sensor did not make in the required time from the A direction call | Check A sensor for proper operation | Fault |
| SV30308 | Load Vacuum | Direction B Jam | Sensor was made, then unmade when not expected | Check B sensor for proper operation | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|---------|------------------|-------------------------------------|------------------------------------------------------------------------------|----------------------------------------------------------------------|-------|
| SV30308 | Load Vacuum | Direction B Sensor Not Made In Time | The B sensor did not make in the required time from the B direction call | Check B sensor for proper operation | Fault |
| SV30308 | Load Vacuum | Input Parameter Error | Incorrect SV data | Fix invalid setup parameters | Fault |
| SV30308 | Load Vacuum | Invalid Program Call | A call to the SV was invalid | Fix program call | Fault |
| SV30308 | Load Vacuum | Off Jam | Sensor was made, then unmade when not expected | Check off sensor for proper operation | Fault |
| SV30308 | Load Vacuum | Off Sensor Not Made In Time | The off sensor did not make in the required time from the off direction call | Check off sensor for proper operation | Fault |
| SV30308 | Load Vacuum | Vacuum Lost | Vacuum sensor was made and then lost when not expected | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV30308 | Load Vacuum | Vacuum Sensor Not Made In Time | Vacuum sensor was not made in time | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV30401 | Magazine Advance | Direction A Jam | Sensor was made, then unmade when not expected | Check A sensor for proper operation | Fault |
| SV30401 | Magazine Advance | Direction A Sensor Not Made In Time | The A sensor did not make in the required time from the A direction call | Check A sensor for proper operation | Fault |
| SV30401 | Magazine Advance | Direction B Jam | Sensor was made, then unmade when not expected | Check B sensor for proper operation | Fault |
| SV30401 | Magazine Advance | Direction B Sensor Not Made In Time | The B sensor did not make in the required time from the B direction call | Check B sensor for proper operation | Fault |
| SV30401 | Magazine Advance | Input Parameter Error | Incorrect SV data | Fix invalid setup parameters | Fault |
| SV30401 | Magazine Advance | Invalid Program Call | A call to the SV was invalid | Fix program call | Fault |
| SV30401 | Magazine Advance | Off Jam | Sensor was made, then unmade when not expected | Check off sensor for proper operation | Fault |
| SV30401 | Magazine Advance | Off Sensor Not Made In Time | The off sensor did not make in the required time from the off direction call | Check off sensor for proper operation | Fault |
| SV30401 | Magazine Advance | Vacuum Lost | Vacuum sensor was made and then lost when not expected | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV30401 | Magazine Advance | Vacuum Sensor Not Made In Time | Vacuum sensor was not made in time | Check vacuum cups for damage; ensure good product is being presented | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|---------|-----------------------|-------------------------------------|------------------------------------------------------------------------------|----------------------------------------------------------------------|-------|
| SV30402 | Case Packer Case Stop | Direction A Jam | Sensor was made, then unmade when not expected | Check A sensor for proper operation | Fault |
| SV30402 | Case Packer Case Stop | Direction A Sensor Not Made In Time | The A sensor did not make in the required time from the A direction call | Check A sensor for proper operation | Fault |
| SV30402 | Case Packer Case Stop | Direction B Jam | Sensor was made, then unmade when not expected | Check B sensor for proper operation | Fault |
| SV30402 | Case Packer Case Stop | Direction B Sensor Not Made In Time | The B sensor did not make in the required time from the B direction call | Check B sensor for proper operation | Fault |
| SV30402 | Case Packer Case Stop | Input Parameter Error | Incorrect SV data | Fix invalid setup parameters | Fault |
| SV30402 | Case Packer Case Stop | Invalid Program Call | A call to the SV was invalid | Fix program call | Fault |
| SV30402 | Case Packer Case Stop | Off Jam | Sensor was made, then unmade when not expected | Check off sensor for proper operation | Fault |
| SV30402 | Case Packer Case Stop | Off Sensor Not Made In Time | The off sensor did not make in the required time from the off direction call | Check off sensor for proper operation | Fault |
| SV30402 | Case Packer Case Stop | Vacuum Lost | Vacuum sensor was made and then lost when not expected | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV30402 | Case Packer Case Stop | Vacuum Sensor Not Made In Time | Vacuum sensor was not made in time | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV30403 | Case Pusher | Direction A Jam | Sensor was made, then unmade when not expected | Check A sensor for proper operation | Fault |
| SV30403 | Case Pusher | Direction A Sensor Not Made In Time | The A sensor did not make in the required time from the A direction call | Check A sensor for proper operation | Fault |
| SV30403 | Case Pusher | Direction B Jam | Sensor was made, then unmade when not expected | Check B sensor for proper operation | Fault |
| SV30403 | Case Pusher | Direction B Sensor Not Made In Time | The B sensor did not make in the required time from the B direction call | Check B sensor for proper operation | Fault |
| SV30403 | Case Pusher | Input Parameter Error | Incorrect SV data | Fix invalid setup parameters | Fault |
| SV30403 | Case Pusher | Invalid Program Call | A call to the SV was invalid | Fix program call | Fault |
| SV30403 | Case Pusher | Off Jam | Sensor was made, then unmade when not expected | Check off sensor for proper operation | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|---------|------------------|-------------------------------------|------------------------------------------------------------------------------|----------------------------------------------------------------------|-------|
| SV30403 | Case Pusher | Off Sensor Not Made In Time | The off sensor did not make in the required time from the off direction call | Check off sensor for proper operation | Fault |
| SV30403 | Case Pusher | Vacuum Lost | Vacuum sensor was made and then lost when not expected | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV30403 | Case Pusher | Vacuum Sensor Not Made In Time | Vacuum sensor was not made in time | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV30406 | FunTucker In/Out | Direction A Jam | Sensor was made, then unmade when not expected | Check A sensor for proper operation | Fault |
| SV30406 | FunTucker In/Out | Direction A Sensor Not Made In Time | The A sensor did not make in the required time from the A direction call | Check A sensor for proper operation | Fault |
| SV30406 | FunTucker In/Out | Direction B Jam | Sensor was made, then unmade when not expected | Check B sensor for proper operation | Fault |
| SV30406 | FunTucker In/Out | Direction B Sensor Not Made In Time | The B sensor did not make in the required time from the B direction call | Check B sensor for proper operation | Fault |
| SV30406 | FunTucker In/Out | Input Parameter Error | Incorrect SV data | Fix invalid setup parameters | Fault |
| SV30406 | FunTucker In/Out | Invalid Program Call | A call to the SV was invalid | Fix program call | Fault |
| SV30406 | FunTucker In/Out | Off Jam | Sensor was made, then unmade when not expected | Check off sensor for proper operation | Fault |
| SV30406 | FunTucker In/Out | Off Sensor Not Made In Time | The off sensor did not make in the required time from the off direction call | Check off sensor for proper operation | Fault |
| SV30406 | FunTucker In/Out | Vacuum Lost | Vacuum sensor was made and then lost when not expected | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV30406 | FunTucker In/Out | Vacuum Sensor Not Made In Time | Vacuum sensor was not made in time | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV30407 | Funnel In/Out | Direction A Jam | Sensor was made, then unmade when not expected | Check A sensor for proper operation | Fault |
| SV30407 | Funnel In/Out | Direction A Sensor Not Made In Time | The A sensor did not make in the required time from the A direction call | Check A sensor for proper operation | Fault |
| SV30407 | Funnel In/Out | Direction B Jam | Sensor was made, then unmade when not expected | Check B sensor for proper operation | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|---------|-------------------------|-------------------------------------|------------------------------------------------------------------------------|----------------------------------------------------------------------|-------|
| SV30407 | Funnel In/Out | Direction B Sensor Not Made In Time | The B sensor did not make in the required time from the B direction call | Check B sensor for proper operation | Fault |
| SV30407 | Funnel In/Out | Input Parameter Error | Incorrect SV data | Fix invalid setup parameters | Fault |
| SV30407 | Funnel In/Out | Invalid Program Call | A call to the SV was invalid | Fix program call | Fault |
| SV30407 | Funnel In/Out | Off Jam | Sensor was made, then unmade when not expected | Check off sensor for proper operation | Fault |
| SV30407 | Funnel In/Out | Off Sensor Not Made In Time | The off sensor did not make in the required time from the off direction call | Check off sensor for proper operation | Fault |
| SV30407 | Funnel In/Out | Vacuum Lost | Vacuum sensor was made and then lost when not expected | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV30407 | Funnel In/Out | Vacuum Sensor Not Made In Time | Vacuum sensor was not made in time | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV30408 | Casepacker Robot Vacuum | Direction A Jam | Sensor was made, then unmade when not expected | Check A sensor for proper operation | Fault |
| SV30408 | Casepacker Robot Vacuum | Direction A Sensor Not Made In Time | The A sensor did not make in the required time from the A direction call | Check A sensor for proper operation | Fault |
| SV30408 | Casepacker Robot Vacuum | Direction B Jam | Sensor was made, then unmade when not expected | Check B sensor for proper operation | Fault |
| SV30408 | Casepacker Robot Vacuum | Direction B Sensor Not Made In Time | The B sensor did not make in the required time from the B direction call | Check B sensor for proper operation | Fault |
| SV30408 | Casepacker Robot Vacuum | Input Parameter Error | Incorrect SV data | Fix invalid setup parameters | Fault |
| SV30408 | Casepacker Robot Vacuum | Invalid Program Call | A call to the SV was invalid | Fix program call | Fault |
| SV30408 | Casepacker Robot Vacuum | Off Jam | Sensor was made, then unmade when not expected | Check off sensor for proper operation | Fault |
| SV30408 | Casepacker Robot Vacuum | Off Sensor Not Made In Time | The off sensor did not make in the required time from the off direction call | Check off sensor for proper operation | Fault |
| SV30408 | Casepacker Robot Vacuum | Vacuum Lost | Vacuum sensor was made and then lost when not expected | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV30408 | Casepacker Robot Vacuum | Vacuum Sensor Not Made In Time | Vacuum sensor was not made in time | Check vacuum cups for damage; ensure good product is being presented | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|---------|---------------------|-------------------------------------|------------------------------------------------------------------------------|----------------------------------------------------------------------|-------|
| SV30703 | Product Conditioner | Direction A Jam | Sensor was made, then unmade when not expected | Check A sensor for proper operation | Fault |
| SV30703 | Product Conditioner | Direction A Sensor Not Made In Time | The A sensor did not make in the required time from the A direction call | Check A sensor for proper operation | Fault |
| SV30703 | Product Conditioner | Direction B Jam | Sensor was made, then unmade when not expected | Check B sensor for proper operation | Fault |
| SV30703 | Product Conditioner | Direction B Sensor Not Made In Time | The B sensor did not make in the required time from the B direction call | Check B sensor for proper operation | Fault |
| SV30703 | Product Conditioner | Input Parameter Error | Incorrect SV data | Fix invalid setup parameters | Fault |
| SV30703 | Product Conditioner | Invalid Program Call | A call to the SV was invalid | Fix program call | Fault |
| SV30703 | Product Conditioner | Off Jam | Sensor was made, then unmade when not expected | Check off sensor for proper operation | Fault |
| SV30703 | Product Conditioner | Off Sensor Not Made In Time | The off sensor did not make in the required time from the off direction call | Check off sensor for proper operation | Fault |
| SV30703 | Product Conditioner | Vacuum Lost | Vacuum sensor was made and then lost when not expected | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV30703 | Product Conditioner | Vacuum Sensor Not Made In Time | Vacuum sensor was not made in time | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV30705 | Magazine Top Clip | Direction A Jam | Sensor was made, then unmade when not expected | Check A sensor for proper operation | Fault |
| SV30705 | Magazine Top Clip | Direction A Sensor Not Made In Time | The A sensor did not make in the required time from the A direction call | Check A sensor for proper operation | Fault |
| SV30705 | Magazine Top Clip | Direction B Jam | Sensor was made, then unmade when not expected | Check B sensor for proper operation | Fault |
| SV30705 | Magazine Top Clip | Direction B Sensor Not Made In Time | The B sensor did not make in the required time from the B direction call | Check B sensor for proper operation | Fault |
| SV30705 | Magazine Top Clip | Input Parameter Error | Incorrect SV data | Fix invalid setup parameters | Fault |
| SV30705 | Magazine Top Clip | Invalid Program Call | A call to the SV was invalid | Fix program call | Fault |
| SV30705 | Magazine Top Clip | Off Jam | Sensor was made, then unmade when not expected | Check off sensor for proper operation | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|---------|----------------------|-------------------------------------|------------------------------------------------------------------------------|----------------------------------------------------------------------|-------|
| SV30705 | Magazine Top Clip | Off Sensor Not Made In Time | The off sensor did not make in the required time from the off direction call | Check off sensor for proper operation | Fault |
| SV30705 | Magazine Top Clip | Vacuum Lost | Vacuum sensor was made and then lost when not expected | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV30705 | Magazine Top Clip | Vacuum Sensor Not Made In Time | Vacuum sensor was not made in time | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV30707 | Magazine Bottom Clip | Direction A Jam | Sensor was made, then unmade when not expected | Check A sensor for proper operation | Fault |
| SV30707 | Magazine Bottom Clip | Direction A Sensor Not Made In Time | The A sensor did not make in the required time from the A direction call | Check A sensor for proper operation | Fault |
| SV30707 | Magazine Bottom Clip | Direction B Jam | Sensor was made, then unmade when not expected | Check B sensor for proper operation | Fault |
| SV30707 | Magazine Bottom Clip | Direction B Sensor Not Made In Time | The B sensor did not make in the required time from the B direction call | Check B sensor for proper operation | Fault |
| SV30707 | Magazine Bottom Clip | Input Parameter Error | Incorrect SV data | Fix invalid setup parameters | Fault |
| SV30707 | Magazine Bottom Clip | Invalid Program Call | A call to the SV was invalid | Fix program call | Fault |
| SV30707 | Magazine Bottom Clip | Off Jam | Sensor was made, then unmade when not expected | Check off sensor for proper operation | Fault |
| SV30707 | Magazine Bottom Clip | Off Sensor Not Made In Time | The off sensor did not make in the required time from the off direction call | Check off sensor for proper operation | Fault |
| SV30707 | Magazine Bottom Clip | Vacuum Lost | Vacuum sensor was made and then lost when not expected | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV30707 | Magazine Bottom Clip | Vacuum Sensor Not Made In Time | Vacuum sensor was not made in time | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV30801 | Load Cups Lift | Direction A Jam | Sensor was made, then unmade when not expected | Check A sensor for proper operation | Fault |
| SV30801 | Load Cups Lift | Direction A Sensor Not Made In Time | The A sensor did not make in the required time from the A direction call | Check A sensor for proper operation | Fault |
| SV30801 | Load Cups Lift | Direction B Jam | Sensor was made, then unmade when not expected | Check B sensor for proper operation | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|---------|-----------------------------|-------------------------------------|------------------------------------------------------------------------------|----------------------------------------------------------------------|-------|
| SV30801 | Load Cups Lift | Direction B Sensor Not Made In Time | The B sensor did not make in the required time from the B direction call | Check B sensor for proper operation | Fault |
| SV30801 | Load Cups Lift | Input Parameter Error | Incorrect SV data | Fix invalid setup parameters | Fault |
| SV30801 | Load Cups Lift | Invalid Program Call | A call to the SV was invalid | Fix program call | Fault |
| SV30801 | Load Cups Lift | Off Jam | Sensor was made, then unmade when not expected | Check off sensor for proper operation | Fault |
| SV30801 | Load Cups Lift | Off Sensor Not Made In Time | The off sensor did not make in the required time from the off direction call | Check off sensor for proper operation | Fault |
| SV30801 | Load Cups Lift | Vacuum Lost | Vacuum sensor was made and then lost when not expected | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV30801 | Load Cups Lift | Vacuum Sensor Not Made In Time | Vacuum sensor was not made in time | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV30805 | Lower Glue Nonoperator Side | Direction A Jam | Sensor was made, then unmade when not expected | Check A sensor for proper operation | Fault |
| SV30805 | Lower Glue Nonoperator Side | Direction A Sensor Not Made In Time | The A sensor did not make in the required time from the A direction call | Check A sensor for proper operation | Fault |
| SV30805 | Lower Glue Nonoperator Side | Direction B Jam | Sensor was made, then unmade when not expected | Check B sensor for proper operation | Fault |
| SV30805 | Lower Glue Nonoperator Side | Direction B Sensor Not Made In Time | The B sensor did not make in the required time from the B direction call | Check B sensor for proper operation | Fault |
| SV30805 | Lower Glue Nonoperator Side | Input Parameter Error | Incorrect SV data | Fix invalid setup parameters | Fault |
| SV30805 | Lower Glue Nonoperator Side | Invalid Program Call | A call to the SV was invalid | Fix program call | Fault |
| SV30805 | Lower Glue Nonoperator Side | Off Jam | Sensor was made, then unmade when not expected | Check off sensor for proper operation | Fault |
| SV30805 | Lower Glue Nonoperator Side | Off Sensor Not Made In Time | The off sensor did not make in the required time from the off direction call | Check off sensor for proper operation | Fault |
| SV30805 | Lower Glue Nonoperator Side | Vacuum Lost | Vacuum sensor was made and then lost when not expected | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV30805 | Lower Glue Nonoperator Side | Vacuum Sensor Not Made In Time | Vacuum sensor was not made in time | Check vacuum cups for damage; ensure good product is being presented | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|---------|-----------------------------|-------------------------------------|------------------------------------------------------------------------------|----------------------------------------------------------------------|-------|
| SV30806 | Low er Glue Operator Side | Direction A Jam | Sensor w as made, then unmade w hen not expected | Check A sensor for proper operation | Fault |
| SV30806 | Low er Glue Operator Side | Direction A Sensor Not Made In Time | The A sensor did not make in the required time from the A direction call | Check A sensor for proper operation | Fault |
| SV30806 | Low er Glue Operator Side | Direction B Jam | Sensor w as made, then unmade w hen not expected | Check B sensor for proper operation | Fault |
| SV30806 | Low er Glue Operator Side | Direction B Sensor Not Made In Time | The B sensor did not make in the required time from the B direction call | Check B sensor for proper operation | Fault |
| SV30806 | Low er Glue Operator Side | Input Parameter Error | Incorrect SV data | Fix invalid setup parameters | Fault |
| SV30806 | Low er Glue Operator Side | Invalid Program Call | A call to the SV w as invalid | Fix program call | Fault |
| SV30806 | Low er Glue Operator Side | Off Jam | Sensor w as made, then unmade w hen not expected | Check off sensor for proper operation | Fault |
| SV30806 | Low er Glue Operator Side | Off Sensor Not Made In Time | The off sensor did not make in the required time from the off direction call | Check off sensor for proper operation | Fault |
| SV30806 | Low er Glue Operator Side | Vacuum Lost | Vacuum sensor w as made and then lost w hen not expected | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV30806 | Low er Glue Operator Side | Vacuum Sensor Not Made In Time | Vacuum sensor w as not made in time | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV30807 | Upper Glue Nonoperator Side | Direction A Jam | Sensor w as made, then unmade w hen not expected | Check A sensor for proper operation | Fault |
| SV30807 | Upper Glue Nonoperator Side | Direction A Sensor Not Made In Time | The A sensor did not make in the required time from the A direction call | Check A sensor for proper operation | Fault |
| SV30807 | Upper Glue Nonoperator Side | Direction B Jam | Sensor w as made, then unmade w hen not expected | Check B sensor for proper operation | Fault |
| SV30807 | Upper Glue Nonoperator Side | Direction B Sensor Not Made In Time | The B sensor did not make in the required time from the B direction call | Check B sensor for proper operation | Fault |
| SV30807 | Upper Glue Nonoperator Side | Input Parameter Error | Incorrect SV data | Fix invalid setup parameters | Fault |
| SV30807 | Upper Glue Nonoperator Side | Invalid Program Call | A call to the SV w as invalid | Fix program call | Fault |
| SV30807 | Upper Glue Nonoperator Side | Off Jam | Sensor w as made, then unmade w hen not expected | Check off sensor for proper operation | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|---------|-----------------------------|-------------------------------------|------------------------------------------------------------------------------|----------------------------------------------------------------------|-------|
| SV30807 | Upper Glue Nonoperator Side | Off Sensor Not Made In Time | The off sensor did not make in the required time from the off direction call | Check off sensor for proper operation | Fault |
| SV30807 | Upper Glue Nonoperator Side | Vacuum Lost | Vacuum sensor was made and then lost when not expected | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV30807 | Upper Glue Nonoperator Side | Vacuum Sensor Not Made In Time | Vacuum sensor was not made in time | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV30808 | Upper Glue Operator Side | Direction A Jam | Sensor was made, then unmade when not expected | Check A sensor for proper operation | Fault |
| SV30808 | Upper Glue Operator Side | Direction A Sensor Not Made In Time | The A sensor did not make in the required time from the A direction call | Check A sensor for proper operation | Fault |
| SV30808 | Upper Glue Operator Side | Direction B Jam | Sensor was made, then unmade when not expected | Check B sensor for proper operation | Fault |
| SV30808 | Upper Glue Operator Side | Direction B Sensor Not Made In Time | The B sensor did not make in the required time from the B direction call | Check B sensor for proper operation | Fault |
| SV30808 | Upper Glue Operator Side | Input Parameter Error | Incorrect SV data | Fix invalid setup parameters | Fault |
| SV30808 | Upper Glue Operator Side | Invalid Program Call | A call to the SV was invalid | Fix program call | Fault |
| SV30808 | Upper Glue Operator Side | Off Jam | Sensor was made, then unmade when not expected | Check off sensor for proper operation | Fault |
| SV30808 | Upper Glue Operator Side | Off Sensor Not Made In Time | The off sensor did not make in the required time from the off direction call | Check off sensor for proper operation | Fault |
| SV30808 | Upper Glue Operator Side | Vacuum Lost | Vacuum sensor was made and then lost when not expected | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV30808 | Upper Glue Operator Side | Vacuum Sensor Not Made In Time | Vacuum sensor was not made in time | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV50201 | Case Rotate Vacuum | Direction A Jam | Sensor was made, then unmade when not expected | Check A sensor for proper operation | Fault |
| SV50201 | Case Rotate Vacuum | Direction A Sensor Not Made In Time | The A sensor did not make in the required time from the A direction call | Check A sensor for proper operation | Fault |
| SV50201 | Case Rotate Vacuum | Direction B Jam | Sensor was made, then unmade when not expected | Check B sensor for proper operation | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|---------|--------------------|-------------------------------------|------------------------------------------------------------------------------|----------------------------------------------------------------------|-------|
| SV50201 | Case Rotate Vacuum | Direction B Sensor Not Made In Time | The B sensor did not make in the required time from the B direction call | Check B sensor for proper operation | Fault |
| SV50201 | Case Rotate Vacuum | Input Parameter Error | Incorrect SV data | Fix invalid setup parameters | Fault |
| SV50201 | Case Rotate Vacuum | Invalid Program Call | A call to the SV was invalid | Fix program call | Fault |
| SV50201 | Case Rotate Vacuum | Off Jam | Sensor was made, then unmade when not expected | Check off sensor for proper operation | Fault |
| SV50201 | Case Rotate Vacuum | Off Sensor Not Made In Time | The off sensor did not make in the required time from the off direction call | Check off sensor for proper operation | Fault |
| SV50201 | Case Rotate Vacuum | Vacuum Lost | Vacuum sensor was made and then lost when not expected | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV50201 | Case Rotate Vacuum | Vacuum Sensor Not Made In Time | Vacuum sensor was not made in time | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV50703 | Tipper Case Stop | Direction A Jam | Sensor was made, then unmade when not expected | Check A sensor for proper operation | Fault |
| SV50703 | Tipper Case Stop | Direction A Sensor Not Made In Time | The A sensor did not make in the required time from the A direction call | Check A sensor for proper operation | Fault |
| SV50703 | Tipper Case Stop | Direction B Jam | Sensor was made, then unmade when not expected | Check B sensor for proper operation | Fault |
| SV50703 | Tipper Case Stop | Direction B Sensor Not Made In Time | The B sensor did not make in the required time from the B direction call | Check B sensor for proper operation | Fault |
| SV50703 | Tipper Case Stop | Input Parameter Error | Incorrect SV data | Fix invalid setup parameters | Fault |
| SV50703 | Tipper Case Stop | Invalid Program Call | A call to the SV was invalid | Fix program call | Fault |
| SV50703 | Tipper Case Stop | Off Jam | Sensor was made, then unmade when not expected | Check off sensor for proper operation | Fault |
| SV50703 | Tipper Case Stop | Off Sensor Not Made In Time | The off sensor did not make in the required time from the off direction call | Check off sensor for proper operation | Fault |
| SV50703 | Tipper Case Stop | Vacuum Lost | Vacuum sensor was made and then lost when not expected | Check vacuum cups for damage; ensure good product is being presented | Fault |
| SV50703 | Tipper Case Stop | Vacuum Sensor Not Made In Time | Vacuum sensor was not made in time | Check vacuum cups for damage; ensure good product is being presented | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|---------|------------------------------|---------------------------------|--------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------|------------------|
| TS31203 | Main Panel Temp Sensor | Above Set Point | The cabinet temperature is above the set point | Check the cabinet for excessive heat, verify cooling system is properly functioning, check temp switch for proper operation | General, Warning |
| TS31203 | Main Panel Temp Sensor | Below Set Point | The cabinet temperature is below the set point | No action required | General |
| TS31301 | HMI Cabinet Temp Sensor | Above Set Point | The cabinet temperature is above the set point | Check the cabinet for excessive heat, verify cooling system is properly functioning, check temp switch for proper operation | General, Warning |
| TS31301 | HMI Cabinet Temp Sensor | Below Set Point | The cabinet temperature is below the set point | No action required | General |
| TS51301 | Unitizer Cabinet Temp Sensor | Above Set Point | The cabinet temperature is above the set point | Check the cabinet for excessive heat, verify cooling system is properly functioning, check temp switch for proper operation | General, Warning |
| TS51301 | Unitizer Cabinet Temp Sensor | Below Set Point | The cabinet temperature is below the set point | No action required | General |
| VFD1402 | Side Belts | Forward Sensor Not Made In Time | The forward sensor for the motor was not made when it was expected | Check motor for jam, check forward sensor | Fault |
| VFD1402 | Side Belts | Input Parameter Error | The configuration data for the motor is incorrect | Fix data configuration, check programming | Fault |
| VFD1402 | Side Belts | Invalid Program Call | The configuration data for the motor is incorrect | Fix data configuration, check programming | Fault |
| VFD1402 | Side Belts | Motor Overloaded | The motor has overloaded | Check motor for overload reason | Fault |
| VFD1402 | Side Belts | Off Sensor Not Made In Time | The motor did not stop when expected | Check motor for jam, check off sensor | Fault |
| VFD1402 | Side Belts | Reverse Sensor Not Made In Time | The reverse sensor for the motor was not made when it was expected | Check motor for jam, check reverse sensor | Fault |
| VFD1402 | Side Belts | Vacuum Sensor Not Made In Time | The vacuum sensor for the motor was not made when it was expected | Check vacuum, check vacuum sensor | Fault |
| VFD1402 | Side Belts | VFD Faulted | The VFD has an internal fault | Check VFD for diagnostics | Fault |
| VS31202 | System Vacuum | Low Vacuum Supply | Vacuum is low | Check vacuum supply | General |
| VS31202 | System Vacuum | Low Vacuum Supply | Vacuum was lost when not expected | Check vacuum supply | Fault |

| Device | Name | Text | Cause | Remedy | Type |
|---------|---------------|--------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| VS31202 | System Vacuum | Vacuum Above Set Point | Vacuum is above set point | No action required | General |
| VS31708 | Load Vacuum | Vacuum Not Made Before Case Ready Position | The vacuum switch did not detect vacuum before the case former master reached the case ready position general data | Remove case at the load station, check the timing of the vacuum cam to the case ready position general data, check the vacuum switch for proper operation, and restart the machine | Fault |
| VS31708 | Load Vacuum | Vacuum Not Made During Startup | During startup, the machine expected a case at the load station and the case present at load photo eye detected a case, but the vacuum switch did not detect a case | Remove case at load, check the vacuum switch for proper operation, and restart the machine | Fault |

Change Log Page

General Page Information

This page will display any changes that have been made to the Agard HMI database. This excludes any cam changes made, which are allowable and will not be displayed here. The drop down list filter in the bottom left corner of this page will allow a specific time period to be selected. The changes logged will be deleted after three months.

SAMPLE IMAGE

The screenshot shows a window titled "Aagard HMI - Change Log" containing a table with the following columns: Location, Field, Old Value, New Value, Product, Notes, Who, Change..., and Changed Time. The table lists various system parameters and their values over time, with most changes occurring on 8/26/2009. At the bottom of the window, there is a dropdown menu set to "Show Latest 50" and three buttons: "Delete All", "Refresh", and "Back".

| Location | Field | Old Value | New Value | Product | Notes | Who | Change... | Changed Time |
|---------------|------------------------|-----------|-----------|------------|-------|---------|-----------|--------------|
| General D... | Gen#27 | 0 | 235 | 684 Carton | | Aaga... | 11/2/2009 | 11:03:40 AM |
| Solenoid ... | SV#45405 Configuration | 0 | 2 | 356 Carton | | aaga... | 8/26/2009 | 4:01:34 PM |
| Motor Dat... | MT#503 AnalogSpeed | 0 | 1 | 356 Carton | | aaga... | 8/26/2009 | 4:01:06 PM |
| Motor Dat... | MT#516 AnalogSpeed | 0 | 1 | 356 Carton | | aaga... | 8/26/2009 | 4:01:03 PM |
| Motor Dat... | MT#603 AnalogSpeed | 0 | 1 | 356 Carton | | aaga... | 8/26/2009 | 4:01:01 PM |
| Motor Dat... | MT#616 AnalogSpeed | 0 | 1 | 356 Carton | | aaga... | 8/26/2009 | 4:00:58 PM |
| Motor Dat... | MT#1703 AnalogSpeed | 0 | 1 | 356 Carton | | aaga... | 8/26/2009 | 4:00:55 PM |
| Motor Dat... | MT#10015 ATime | 1 | 0 | 356 Carton | | aaga... | 8/26/2009 | 4:00:46 PM |
| Motor Dat... | MT#10015 OffTime | 1 | 0 | 356 Carton | | aaga... | 8/26/2009 | 4:00:44 PM |
| Motor Dat... | MT#1703 OffTime | 0 | .2 | 356 Carton | | aaga... | 8/26/2009 | 4:00:35 PM |
| Motor Dat... | MT#1703 ATime | 0 | .2 | 356 Carton | | aaga... | 8/26/2009 | 4:00:32 PM |
| Motor Dat... | MT#616 OffTime | 1 | .5 | 356 Carton | | aaga... | 8/26/2009 | 4:00:28 PM |
| Motor Dat... | MT#616 ATime | 1 | .5 | 356 Carton | | aaga... | 8/26/2009 | 4:00:26 PM |
| Motor Dat... | MT#516 OffTime | 0 | .2 | 356 Carton | | aaga... | 8/26/2009 | 4:00:15 PM |
| Motor Dat... | MT#516 ATime | 0 | .2 | 356 Carton | | aaga... | 8/26/2009 | 4:00:13 PM |
| Servo Driv... | SD#45 Move#8 Decel | 0 | 20 | 356 Carton | | aaga... | 8/26/2009 | 3:59:49 PM |
| Servo Driv... | SD#45 Move#8 Accel | 0 | 20 | 356 Carton | | aaga... | 8/26/2009 | 3:59:47 PM |
| Servo Driv... | SD#45 Move#8 Velocity | 0 | 27 | 356 Carton | | aaga... | 8/26/2009 | 3:59:44 PM |
| Servo Driv... | SD#45 Move#8 Position | 0 | 15 | 356 Carton | | aaga... | 8/26/2009 | 3:59:41 PM |
| Servo Driv... | SD#45 Move#7 Decel | 0 | 65 | 356 Carton | | aaga... | 8/26/2009 | 3:59:33 PM |
| Servo Driv... | SD#45 Move#7 Accel | 0 | 65 | 356 Carton | | aaga... | 8/26/2009 | 3:59:31 PM |
| Servo Driv... | SD#45 Move#7 Velocity | 0 | 30 | 356 Carton | | aaga... | 8/26/2009 | 3:59:29 PM |
| Servo Driv... | SD#45 Move#7 Position | 0 | 15 | 356 Carton | | aaga... | 8/26/2009 | 3:59:26 PM |
| Servo Driv... | SD#45 Move#6 Decel | 0 | 30 | 356 Carton | | aaga... | 8/26/2009 | 3:59:19 PM |
| Servo Driv... | SD#45 Move#6 Accel | 0 | 30 | 356 Carton | | aaga... | 8/26/2009 | 3:59:15 PM |
| Servo Driv... | SD#45 Move#6 Velocity | 0 | 30 | 356 Carton | | aaga... | 8/26/2009 | 3:59:13 PM |
| Servo Driv... | SD#45 Move#6 Position | 0 | 30 | 356 Carton | | aaga... | 8/26/2009 | 3:59:11 PM |

Delete All

This button will delete the entire contents of the change log. This will make any change log section of the generated reports invalid because the report generator uses this change log to generate its reports.

Refresh

This button will refresh the changes on the screen to the most current log at the time the refresh button was pressed.

Back Button

This button will display the [Advanced Page](#).

Filter Drop Down List

Click on the drop down arrow to view available filters to apply to the list. Select a filter from the list to apply it. Depending on the selection, additional parameters become available to enter, such as dates and hours.

| | | |
|-----------------|-------------|--------------|
| From Date/Time: | 1/ 4/2010 ▾ | 5:59:00 AM ▾ |
| To Date/Time: | 1/ 4/2010 ▾ | 5:59:00 PM ▾ |

| | | |
|------------|--------------------------------------|----------------------------------------|
| Show Last: | <input type="text" value="0"/> Hours | <input type="text" value="0"/> Minutes |
|------------|--------------------------------------|----------------------------------------|

Location Column

This column will display on which page the change was made.

Field Column

This column will display the name of the field to which the change was made.

Old Value Column

This column will record what the value was before the change was made.

New Value Column

This column will record what the value is after the change was made.

Product Column

This column will display the product downloaded when the change was made.

Notes Column

This column will display any notes that were entered by the user into the notes popup after the change was made.

Who Column

This column will display the user that was logged on at the time of the change.

Changed Date Column

This column will display the date that the change was made.

Changed Time Column

This column will display the time that the change was made.

Misc Tags Page

General Page Information

This page is where the HMI stores information needed to operate the machine. Information used here is only temporary and is not retained for the next product change.

| Booleans: | | |
|-----------|--------------------------|-------------------------------------|
| ? 1 | <input type="checkbox"/> | Ignore Upstream Sending Product |
| ? 2 | <input type="checkbox"/> | Ignore Downstream Available |
| ? 3 | <input type="checkbox"/> | Remove Aagard Available For Product |
| ? 4 | <input type="checkbox"/> | Force Aagard Sending Product |
| ? 5 | <input type="checkbox"/> | Ignore Glue System Status |
| ? 6 | <input type="checkbox"/> | Ignore Vacuum Supply Status |
| ? 7 | <input type="checkbox"/> | Ignore Multiple Rejects |
| ? 8 | <input type="checkbox"/> | Clean Out |
| ? 10 | <input type="checkbox"/> | Enable Case Refeed |
| ? 11 | <input type="checkbox"/> | QC Case |
| ? 23 | <input type="checkbox"/> | Load Cups Clean Out |

? Button

This button will display the **Misc Data Definition Popup**. This popup contains the definition for the related Misc Tag. To close the popup, click the red X in right corner, click outside the popup, or press Esc. **NOTE:** If logged in at Aagard level, this definition is editable.

SAMPLE IMAGE



Back Button

This button will display the [Advanced Page](#).

View Changeover Adjustments

General Page Information

This page will display the changeover adjustments for the particular product selected. This page is identical to the [Product Download Changeover Adjustments Page](#) with the exception that it is for display purposes only. A popup screen will not be displayed if a changeover adjustment was not completed when exiting this page. Please go to the [Product Download Changeover Adjustments Page](#) for further details.

SAMPLE IMAGE

The screenshot shows a window titled "Aagard HMI - Adjustments" with a table of adjustment data. The table has five columns: Done, Machine, Adj. Name, Description, and Value. The "Done" column contains "Yes" (green) or "No" (red). The "Machine" column lists "Sleever Case" and "Packer". The "Adj. Name" column lists adjustment IDs from 1-1 to 1-12B. The "Description" column lists "Example Adjustment". The "Value" column lists numerical values from 10 to 180. At the bottom right of the window are "Print" and "Finish" buttons.


| Done | Machine | Adj. Name | Description | Value |
|------|------------------------|-----------|--------------------|-------|
| Yes | Sleever Case Packer | 1-1 | Example Adjustment | 10 |
| Yes | Sleever Case Packer | 1-2 | Example Adjustment | 2 |
| Yes | Sleever Case Packer | 1-3 | Example Adjustment | 30 |
| Yes | Sleever Case Packer | 1-4 | Example Adjustment | 40 |
| No | Sleever Case Packer | 1-5 | Example Adjustment | 50 |
| No | Sleever Case Packer | 1-6 | Example Adjustment | 60 |
| No | Sleever Case Packer | 1-7 | Example Adjustment | 70 |
| No | Sleever Case Packer | 1-8 | Example Adjustment | 80 |
| No | Sleever Case Packer | 1-9 | Example Adjustment | 90 |
| No | Sleever Case Packer | 1-10 | Example Adjustment | 100 |
| No | Sleever Case Packer | 1-11A | Example Adjustment | 110 |
| No | Sleever Case Packer | 1-11B | Example Adjustment | 120 |
| No | Sleever Case Packer | 1-11C | Example Adjustment | 130 |
| No | Sleever Case Packer | 1-11D | Example Adjustment | 140 |
| No | Sleever Case Packer | 1-11E | Example Adjustment | 150 |
| No | Sleever Case Packer | 1-11F | Example Adjustment | 160 |
| No | Sleever Case Packer | 1-12A | Example Adjustment | 170 |
| No | Sleever Case Packer | 1-12B | Example Adjustment | 180 |

Marquee Page

General Page Information

If this feature is installed, this page is used to define the default message displayed on the marquee. It is also used to define the communication parameters for connecting to the marquee.

SAMPLE IMAGE



Connection Display

This will display the marquee connection status.

COM Port

When this radio button is selected, the HMI will try to communicate with the marquee via the COM Port selected in the drop down list.

IP Address

When this radio button is selected, the HMI will try to communicate with the marquee via the IP address entered in the text box.

Display Address

The display address is the numerical address used by the marquee.

Default Message

The default message is the text that will display on the marquee when there are no other system messages to display.

Pause Between Messages

The amount of time the marquee will pause between displaying messages.

Emulator

Selecting this check box will enable the marquee emulator.

Test

This button tests the connection with the marquee by attempting to display the default message.

Back

This button will save the changes and return the user to the Advanced page.

GMI Tags Page

General Page Information

If this feature is installed, this page is provided at the request of the customer, and its use is dictated by the customer's requirements.

Available tags are:

Activity Code
Deal Code
Rate Code

Please see your supervisor for information regarding the use of this page.

SAMPLE IMAGE



The image shows a screenshot of a software window titled "Custom Tags". The window has a standard Windows-style title bar with minimize, maximize, and close buttons. Inside the window, there are three input fields arranged vertically. The first field is labeled "Activity Code" and contains the number "0". The second field is labeled "Deal Code" and is empty. The third field is labeled "Rate Code" and contains the number "0". At the bottom of the window, there is a "Back" button and a small icon of a keyboard with a cursor arrow pointing to it.


Diagnostics Group

Drive Diagnostics Page

General Page Information - Servo Drives

This page will display information about the Servo Drives on the machine. This is mainly a troubleshooting feature.

SAMPLE IMAGE



Servo Drive Diagnostic, Solenoid Valve, and Motor Selection Tabs

Each of these tabs will display a list of the possible Servo Drives, Solenoid Valves and Motors that can be selected to display the Diagnostic Box for the selected device.

Popup Button

This button will display a diagnostic popup window for the currently selected device. This diagnostic popup window will always be displayed regardless of which HMI page is open. This diagnostic popup window will show exactly what is shown in the diagnostic box for the selected device.

Display >> Button

This button will display device diagnostics for the selected device. For servo drives (types 2, 3, and 4 only), fault and diagnostic codes are displayed.

Drive Diagnostics Tab

| SD#2 - Linear Drive | | Close |
|---------------------------------|--------------------|-------------------------------------------|
| Drive Diagnostics | Fault Codes (P192) | Diagnostic Codes (S375) |
| <input type="radio"/> Not Used | C15: 0 | Act Pos: 0.014 |
| <input type="radio"/> Enabled | | Max Pos. Err. 0.000 Reset |
| <input type="radio"/> Ready | | Act Pos. Err. 0.000 |
| <input type="radio"/> Active | | Max Torq. 5 Reset |
| <input type="radio"/> Done | CW = Positive | Act Torq. -1 |
| <input type="radio"/> Faulted | CCW = Negative | |
| A0013 Ready for power on | | |

Not Used Status

This status will signal if the Servo Drive is not used

Enabled Status

This status will signal if the Servo Drive is enabled

Ready Status

This status will signal if the Servo Drive is ready

Active Status

This status will signal if the Servo Drive is active

Done Status

This status will signal if the Servo Drive is done

Faulted Status

This status will signal if the Servo Drive is faulted

Servo Drive Display Status

This will display what the Servo Drive Display is currently displaying. This will be displayed below the faulted status on the screen.

Location Status

This status will tell by what the Servo Drive is controlled in the program.

Positive Direction

This label communicates which direction makes the Servo Drive move in a positive direction.

Negative Direction

This label communicates which direction makes the Servo Drive move in a negative direction.

Act Pos Status

This status will display the actual position of the Servo Drive.

Max Pos Err Status

This status will display the maximum position error that has occurred on that Servo Drive. Maximum Position Error is the largest position error that has occurred since the last time the machine had been stopped.

Act Pos Err Status

This status will display the actual position error of the Servo Drive.

Max Torq Status

This status will display the maximum torque that the Servo Drive has used. Maximum Torque is the highest torque that has been used since the last time the machine had been stopped.

Act Torq Status

This status will display the actual torque that the Servo Drive is using.

Reset Features

These features will reset the Max Pos. Err. or Max Torq. values to zero and start recording the new max values of each of these statuses.

Close Button

This button will close the Servo Drive Diagnostic Box for this Servo Drive.

Fault Codes (P192) Tab

| SD#1 - Rotary Drive | | | | |
|---------------------|--------------------------------------------|------------------------|-------------------------|--|
| Close | | | | |
| Drive Diagnostics | | Fault Codes (P192) | Diagnostic Codes (S375) | |
| Code | Description | Date/Time | Operating Hours | |
| F2174 | Loss of motor encoder reference | 11/16/2010 12:10:22 PM | 6675:55:53 | |
| F2174 | Loss of motor encoder reference | 11/16/2010 10:23:18 AM | 6674:09:14 | |
| F8022 | Enc. 1: enc. signals incorr. (can be cl... | 11/16/2010 10:18:57 AM | 6674:04:53 | |
| F2174 | Loss of motor encoder reference | | 6430:19:46 | |
| F2174 | Loss of motor encoder reference | | 6430:19:39 | |
| F2174 | Loss of motor encoder reference | | 6430:19:35 | |
| F2174 | Loss of motor encoder reference | | 6430:19:30 | |
| F2008 | RL The motor type has changed. | | 6430:19:30 | |

Code

This column displays the code received from the selected servo drive.

Description

This column contains the description of the item.

Date/Time

This column displays the date and time the code was received.

Operating Hours

This value represents the current operating hours for this servo drive at the time the code was received, in hours:minutes:seconds.

Close Button

This button will close this Servo Drive Diagnostic Box.

NOTE: This button does not appear on the Sercos Diagnostics Page

NOTE: The Drive Diagnostics tab does not appear on the Sercos Diagnostics Page

NOTE: A missing description or date/time stamp may indicate either the correct PLC framework version is not in place, the error occurred prior to startup operating hours being logged, or the code is not listed in the reference

table

Diagnostic Codes (S375) Tab

| SD#1 - Rotary Drive | | | | |
|---------------------|----------------------------------------|------------------------|-------------------------|--|
| Close | | | | |
| Drive Diagnostics | | Fault Codes (P192) | Diagnostic Codes (S375) | |
| Code | Description | Date/Time | Operating Hours | |
| C0500 | Reset class 1 diagnostics | 11/16/2010 12:10:23 PM | 6675:55:54 | |
| F2174 | Loss of motor encoder reference | 11/16/2010 12:10:22 PM | 6675:55:53 | |
| C5200 | Communication phase 4 transition ch... | 11/16/2010 12:10:20 PM | 6675:55:51 | |
| A0003 | Communication phase 3 | 11/16/2010 12:10:17 PM | 6675:55:48 | |
| A0002 | Communication phase 2 | 11/16/2010 12:10:16 PM | 6675:55:48 | |
| C0100 | Communication phase 3 transition ch... | 11/16/2010 12:10:16 PM | 6675:55:48 | |
| A0002 | Communication phase 2 | 11/16/2010 12:10:16 PM | 6675:55:48 | |
| C0500 | Reset class 1 diagnostics | 11/16/2010 12:10:16 PM | 6675:55:47 | |

Code

This column displays the code received from the selected servo drive.

Description

This column contains the description of the item.

Date/Time

This column displays the date and time the code was received.

Operating Hours

This value represents the current operating hours for this servo drive at the time the code was received, in hours:minutes:seconds.

Close Button

This button will close this Servo Drive Diagnostic Box.

NOTE: This button does not appear on the Sercos Diagnostics Page

NOTE: The Drive Diagnostics tab does not appear on the Sercos Diagnostics Page

NOTE: A missing description or date/time stamp may indicate either the correct PLC framework version is not in place, the error occurred prior to startup operating hours being logged, or the code is not listed in the reference table

Clear All Button

This button will clear all the displayed diagnostic boxes off the screen.

Fault Code History Button

This button will display the [Fault Code History Page](#).

NOTE: This feature is only available with the correct PLC framework version in place


Back Button

This button will display the [Advanced Page](#).

General Page Information - Solenoid Valves

This page will display information about the Solenoid Valves on the machine. This is mainly a troubleshooting feature.

SAMPLE IMAGE



Solenoid Valve Diagnostic Box

Close Button - This button will close the Solenoid Valve Member Map Diagnostic Box for that Solenoid Valve

Internal Group

Not Used Status - This status will signal if the Solenoid Valve is not used.

Ready Status - This status will signal if the Solenoid Valve is ready.

Active Status - This status will signal if the Solenoid Valve is active.

Done Status - This status will signal if the Solenoid Valve is done.

Faulted Status - This status will signal if the Solenoid Valve is faulted.

Location Status - This status will tell by what the Solenoid Valve is controlled in the program.

Output Group

A Coil - This status will signal if the Solenoid Valve should have the A Coil energized.

B Coil - This status will signal if the Solenoid Valve should have the B Coil energized.


Input Group

A Switch - This status will signal if the Solenoid Valve's A Switch is energized.

B Switch - This status will signal if the Solenoid Valve's B Switch is energized.

General Page Information - Motors

This page will display information about the Motors on the machine. This is mainly a troubleshooting feature.

SAMPLE IMAGE**Motor Diagnostic Box**

Close Button - This button will close the Motor Member Map Diagnostic Box for that Motor.

Speed - This status will display the speed at which the motor should be traveling.

Internal Group

Not Used Status - This status will signal if the Motor is not used.

Ready Status - This status will signal if the Motor is ready.

Active Status - This status will signal if the Motor is active.

Done Status - This status will signal if the Motor is done.

Faulted Status - This status will signal if the Motor is faulted.

Location Status - This status will tell by what the Motor is controlled in the program.

Output Group

Enable - This status will signal if the Motor is enabled.

Forward - This status will signal if the Motor should have the forward signal energized.

Reverse - This status will signal if the Motor should have the reverse signal energized.

Input Group

Forward - This status will signal if the Motor's forward switch is energized.

Reverse - This status will signal if the Motor's reverse switch is energized.

Fault Code History Page

SAMPLE IMAGE

Aagard HMI – Drive Diagnostics - Fault Code History

Servo Drive: All Servo Drives

| SD# | Servo Drive Name | Type | Code | Description | Date/Time | Operating Hours |
|-----|------------------|------|-------|------------------------------------------------|--------------------|-----------------|
| 1 | Rotary Drive | A | A0013 | Ready for power on | 11/23/2010 7:07 AM | 6823:52:14 |
| 1 | Rotary Drive | A | A0012 | Control and power sections ready for operation | 11/23/2010 7:07 AM | 6823:52:14 |
| 2 | Linear Drive | A | A0012 | Control and power sections ready for operation | 11/23/2010 7:07 AM | 6823:56:42 |
| 2 | Linear Drive | A | A0012 | Control and power sections ready for operation | 11/23/2010 7:07 AM | 6823:56:42 |
| 2 | Linear Drive | A | A0012 | Control and power sections ready for operation | 11/23/2010 7:07 AM | 6823:56:42 |
| 2 | Linear Drive | A | A0013 | Ready for power on | 11/23/2010 7:07 AM | 6823:56:42 |
| 2 | Linear Drive | A | A0012 | Control and power sections ready for operation | 11/23/2010 7:07 AM | 6823:56:41 |
| 2 | Linear Drive | A | A0013 | Ready for power on | 11/23/2010 7:07 AM | 6823:56:41 |
| 2 | Linear Drive | A | A0012 | Control and power sections ready for operation | 11/23/2010 7:06 AM | 6823:56:05 |
| 1 | Rotary Drive | A | A0012 | Control and power sections ready for operation | 11/23/2010 7:06 AM | 6823:51:35 |
| 1 | Rotary Drive | A | A0104 | Position mode lagless | 11/23/2010 7:06 AM | 6823:51:35 |
| 2 | Linear Drive | E | E8260 | Torque/force command value limit active | 11/23/2010 7:06 AM | 6823:56:03 |
| 1 | Rotary Drive | E | E8260 | Torque/force command value limit active | 11/23/2010 7:06 AM | 6823:51:33 |
| 1 | Rotary Drive | A | A0104 | Position mode lagless | 11/23/2010 7:05 AM | 6823:50:32 |
| 2 | Linear Drive | A | A0104 | Position mode lagless | 11/23/2010 7:05 AM | 6823:55:01 |
| 2 | Linear Drive | A | A0012 | Control and power sections ready for operation | 11/23/2010 7:05 AM | 6823:54:57 |
| 1 | Rotary Drive | A | A0012 | Control and power sections ready for operation | 11/23/2010 7:05 AM | 6823:50:29 |
| 1 | Rotary Drive | A | A0013 | Ready for power on | 11/23/2010 7:04 AM | 6823:48:07 |
| 2 | Linear Drive | C | C0500 | Reset class 1 diagnostics | 11/23/2010 7:02 AM | 6823:52:36 |
| 1 | Rotary Drive | C | C0500 | Reset class 1 diagnostics | 11/23/2010 7:02 AM | 6823:48:07 |
| 2 | Linear Drive | A | A0013 | Ready for power on | 11/23/2010 7:02 AM | 6823:52:36 |
| 2 | Linear Drive | A | A0013 | Ready for power on | 11/23/2010 7:02 AM | 6823:52:35 |
| 1 | Rotary Drive | F | F2174 | Loss of motor encoder reference | 11/23/2010 7:02 AM | 6823:48:05 |
| 2 | Linear Drive | A | A0051 | Operating mode | 11/23/2010 7:02 AM | 6823:52:34 |

Time Period: Last hour

Individual Items | Totaled | Refresh | Back

Filters Applied: Reset Filters | Refresh | Back

NOTE: Fault and Diagnostic codes displayed on the Sercos Diagnostics Page are read directly from the servo drive, whereas errors displayed on the Fault Code History page are read from a database

Servo Drive

To access different servo drives, use the servo drive drop down list.

Column Headings and Filters

Optionally click on a column to sort the column in ascending order; click it again to sort in descending order.

Optionally click ▾ in the column header to apply filters to a column. When filters are defined, the ▾ will change to ▾.

NOTE: Any filters applied will be used until Reset Defaults is clicked

SD#

This column displays the servo drive number.

Servo Drive Name

This column displays the servo drive name.

Type

This column displays the type of code received.

Code

This column displays the code received from the selected servo drive.

Description

This column displays the description of the code.

Date/Time

This column displays the date and time the code was received.


Operating Hours

This value represents the current operating hours for this servo drive at the time the code was received, in hours:minutes:seconds.

Time Period Selection

Click on the drop down arrow to view available time period filters to apply to the list. Select a filter from the list to apply it.

When selecting the custom date/range filter, additional date and time parameters become available to enter. After entering date and time parameters, click Apply.



NOTE: Any filters applied will be used until Reset Defaults is clicked

Individual Items

Click this button to display the items in the grid in chronological order.

NOTE: When **Individual Items** is selected, the button color will be blue

Totaled

Click this button to display the items in the grid in a totaled fashion, displaying the number of times an item occurred. The items all totaled to allow the user to more easily view which items are occurring the most frequently.

NOTE: When **Totaled** selected, the button color will be blue

Refresh Button

Click this button to update the database with the latest information from the servo drives, and then display that information on this page.

Reset Filters Button

Click this button to reset the screen to default sort and filter settings.

NOTE: This button will only appear when filters have been applied to this page

NOTE: When filters are applied, text indicating so will be displayed above the Reset Filters button

Back

This button will display the [Drive Diagnostics Page](#).

Member Map Diagnostics Page

General Page Information

This screen displays the status information for different drives and sections of the machine. This is mainly a troubleshooting function.

SAMPLE IMAGE

SD#1 - Rotary Drive Close

Drive Diagnostics | Fault Codes (P192) | Diagnostic Codes (S375)

Not Used C15: 0 Act Pos: 142.638
 Enabled
 Ready Max Pos. Err. 0.000 [Reset](#)
 Active Act Pos. Err. 0.000
 Done CW = Positive Max Torq. 1.462 [Reset](#)
 Faulted CCW = Negative Act Torq. 2

A0013 Ready for power on

SV#30702 - Cylinder Close

Internal: Not Used C15: 0 A Coil A Switch
 Ready B Coil B Switch
 Active
 Done
 Faulted

MT#207 - Carton Discharge Conveyor Close

Internal: Not Used C15: 0 Speed: 0
 Ready Enable Forward
 Active Forward Reverse
 Done Reverse
 Faulted

Buttons: **Popup** **Display >>** **Clear All** **Back**

Member Map Diagnostic Selection Tree

This will display a list of the possible devices that can be displayed in a diagnostic box. Double click an item to open the diagnostic box.

Popup Button

This button will display a diagnostic popup window for the currently selected device. This diagnostic popup window will always be displayed regardless of which HMI page is open. This diagnostic popup window will show exactly what is shown in the diagnostic box for the selected device.

Display >> Button

This button will display device diagnostics for the selected device. For servo drives (types 2, 3, and 4 only), fault and diagnostic codes are displayed.

Drive Diagnostics Tab

| SD#2 - Linear Drive | | Close |
|---------------------------------|--------------------|-------------------------------------------|
| Drive Diagnostics | Fault Codes (P192) | Diagnostic Codes (S375) |
| <input type="radio"/> Not Used | C15: 0 | Act Pos: 0.014 |
| <input type="radio"/> Enabled | | Max Pos. Err. 0.000 Reset |
| <input type="radio"/> Ready | | Act Pos. Err. 0.000 |
| <input type="radio"/> Active | | Max Torq. 5 Reset |
| <input type="radio"/> Done | CW = Positive | Act Torq. -1 |
| <input type="radio"/> Faulted | CCW = Negative | |
| A0013 Ready for power on | | |

Not Used Status

This status will signal if the Servo Drive is not used

Enabled Status

This status will signal if the Servo Drive is enabled

Ready Status

This status will signal if the Servo Drive is ready

Active Status

This status will signal if the Servo Drive is active

Done Status

This status will signal if the Servo Drive is done

Faulted Status

This status will signal if the Servo Drive is faulted

Servo Drive Display Status

This will display what the Servo Drive Display is currently displaying. This will be displayed below the faulted status on the screen.

Location Status

This status will tell by what the Servo Drive is controlled in the program.

Positive Direction

This label communicates which direction makes the Servo Drive move in a positive direction.

Negative Direction

This label communicates which direction makes the Servo Drive move in a negative direction.

Act Pos Status

This status will display the actual position of the Servo Drive.

Max Pos Err Status

This status will display the maximum position error that has occurred on that Servo Drive. Maximum Position Error is the largest position error that has occurred since the last time the machine had been stopped.

Act Pos Err Status

This status will display the actual position error of the Servo Drive.

Max Torq Status

This status will display the maximum torque that the Servo Drive has used. Maximum Torque is the highest torque that has been used since the last time the machine had been stopped.

Act Torq Status

This status will display the actual torque that the Servo Drive is using.

Reset Features

These features will reset the Max Pos. Err. or Max Torq. values to zero and start recording the new max values of each of these statuses.

Close Button

This button will close the Servo Drive Diagnostic Box for this Servo Drive.

Fault Codes (P192) Tab

| Code | Description | Date/Time | Operating Hours |
|-------|--------------------------------------------|------------------------|-----------------|
| F2174 | Loss of motor encoder reference | 11/16/2010 12:10:22 PM | 6675:55:53 |
| F2174 | Loss of motor encoder reference | 11/16/2010 10:23:18 AM | 6674:09:14 |
| F8022 | Enc. 1: enc. signals incorr. (can be cl... | 11/16/2010 10:18:57 AM | 6674:04:53 |
| F2174 | Loss of motor encoder reference | | 6430:19:46 |
| F2174 | Loss of motor encoder reference | | 6430:19:39 |
| F2174 | Loss of motor encoder reference | | 6430:19:35 |
| F2174 | Loss of motor encoder reference | | 6430:19:30 |
| F2008 | RL The motor type has changed. | | 6430:19:30 |

Code

This column displays the code received from the selected servo drive.

Description

This column contains the description of the item.

Date/Time

This column displays the date and time the code was received.

Operating Hours

This value represents the current operating hours for this servo drive at the time the code was received, in hours:minutes:seconds.

Close Button

This button will close this Servo Drive Diagnostic Box.

NOTE: This button does not appear on the Sercos Diagnostics Page

NOTE: The Drive Diagnostics tab does not appear on the Sercos Diagnostics Page

NOTE: A missing description or date/time stamp may indicate either the correct PLC framework version is not in place, the error occurred prior to startup operating hours being logged, or the code is not listed in the reference

table

Diagnostic Codes (S375) Tab

| SD#1 - Rotary Drive | | | | |
|---------------------|----------------------------------------|------------------------|-------------------------|--|
| Close | | | | |
| Drive Diagnostics | | Fault Codes (P192) | Diagnostic Codes (S375) | |
| Code | Description | Date/Time | Operating Hours | |
| C0500 | Reset class 1 diagnostics | 11/16/2010 12:10:23 PM | 6675:55:54 | |
| F2174 | Loss of motor encoder reference | 11/16/2010 12:10:22 PM | 6675:55:53 | |
| C5200 | Communication phase 4 transition ch... | 11/16/2010 12:10:20 PM | 6675:55:51 | |
| A0003 | Communication phase 3 | 11/16/2010 12:10:17 PM | 6675:55:48 | |
| A0002 | Communication phase 2 | 11/16/2010 12:10:16 PM | 6675:55:48 | |
| C0100 | Communication phase 3 transition ch... | 11/16/2010 12:10:16 PM | 6675:55:48 | |
| A0002 | Communication phase 2 | 11/16/2010 12:10:16 PM | 6675:55:48 | |
| C0500 | Reset class 1 diagnostics | 11/16/2010 12:10:16 PM | 6675:55:47 | |

Code

This column displays the code received from the selected servo drive.

Description

This column contains the description of the item.

Date/Time

This column displays the date and time the code was received.

Operating Hours

This value represents the current operating hours for this servo drive at the time the code was received, in hours:minutes:seconds.

Close Button

This button will close this Servo Drive Diagnostic Box.

NOTE: This button does not appear on the Sercos Diagnostics Page

NOTE: The Drive Diagnostics tab does not appear on the Sercos Diagnostics Page

NOTE: A missing description or date/time stamp may indicate either the correct PLC framework version is not in place, the error occurred prior to startup operating hours being logged, or the code is not listed in the reference table

Clear All Button

This button will clear all the displayed diagnostic boxes off the screen.

Back Button

This button will display the [Advanced Page](#).

Motor Diagnostic Box

Close Button - This button will close the Motor Member Map Diagnostic Box for that Motor.

Speed - This status will display the speed at which the motor should be traveling.

Internal Group

Not Used Status - This status will signal if the Motor is not used.

Ready Status - This status will signal if the Motor is ready.

Active Status - This status will signal if the Motor is active.

Done Status - This status will signal if the Motor is done.

Faulted Status - This status will signal if the Motor is faulted.

Location Status - This status will tell by what the Motor is controlled in the program.

Output Group

Enable - This status will signal if the Motor is enabled.

Forward - This status will signal if the Motor should have the forward signal energized.

Reverse - This status will signal if the Motor should have the reverse signal energized.

Input Group

Forward - This status will signal if the Motor's forward switch is energized.

Reverse - This status will signal if the Motor's reverse switch is energized.

Solenoid Valve Diagnostic Box

Close Button - This button will close the Solenoid Valve Member Map Diagnostic Box for that Solenoid Valve

Internal Group

Not Used Status - This status will signal if the Solenoid Valve is not used.

Ready Status - This status will signal if the Solenoid Valve is ready.

Active Status - This status will signal if the Solenoid Valve is active.

Done Status - This status will signal if the Solenoid Valve is done.

Faulted Status - This status will signal if the Solenoid Valve is faulted.

Location Status - This status will tell by what the Solenoid Valve is controlled in the program.

Output Group

A Coil - This status will signal if the Solenoid Valve should have the A Coil energized.


B Coil - This status will signal if the Solenoid Valve should have the B Coil energized.

Input Group

A Switch - This status will signal if the Solenoid Valve's A Switch is energized.

B Switch - This status will signal if the Solenoid Valve's B Switch is energized.

SAMPLE IMAGE

**C40 Member Map Diagnostic Box**

This diagnostic box is displayed when a motor is added to the display side of the screen.

E-Stopped Status - This status will signal if the C40 is E-stopped.

Power Status - This status will signal if the C40 has power.

State Status - This status will display the state of the C40.

Mode Status - This status will display the mode of the C40.

Rate Status - This status will tell the rate of the C40.

Close Button - This button will close the C40 Member Map Diagnostic Box for that C40.

C20 Member Map Diagnostic Box

In Use Status - This status will signal if the C20 is not used.

State Complete Status - This status will signal if the C20 is state complete.

Ready Status - This status will signal if the C20 is ready.

Active Status - This status will signal if the C20 is active.

Done Status - This status will signal if the C20 is done.

Faulted Status - This status will signal if the C20 is faulted.

Sequence Step Status - This status will indicate in which sequence step the C20 is in the program.

Close Button - This button will close the C20 Member Map Diagnostic Box for that C20.

C15 Member Map Diagnostic Box

In Use Status - This status will signal if the C15 is not used.

Fault Response Complete Status - This status will signal if the C15 fault response is complete.

Recovery Complete Status - This status will signal if the C15 recovery is complete.

Ready Status - This status will signal if the C15 is ready.

Active Status - This status will signal if the C15 is active.

Done Status - This status will signal if the C15 is done.

F-Stopped Status - This status will signal if the C15 is fault stopped.

Use Sync Recovery Status - This status will signal if the C15 is using sync recovery.

Wait For Sync Status - This status will signal if the C15 is waiting to be in sync.

Faulted Status - This status will signal if the C15 is faulted.

E-Stop Recovery Step Status - This status will tell what E-stop recovery step the C15 is in the program.

Close Button - This button will close the C15 Member Map Diagnostic Box for that C15.

I/O Diagnostics Page


General Page Information

This page is only for status information. It shows the user whether or not an I/O point is energized on an I/O Brick and Slice. If an I/O point is energized the status dot will be red. This page will display all the I/O points on the machine. Through I/O points, the controller communicates to the devices on the machine or anything in the physical world. This is mainly a troubleshooting feature.

Hover over a point with the mouse and a tool tip will display brick, slice, and point.

Click on the + (plus symbol) to expand a node, or click on the - (minus symbol) to minimize a node.

SAMPLE IMAGE



Search

Type text into the box and click search. If what you are searching for is found, the first instance of the searched-for text is highlighted in the tree. If it is not found, the search box will turn red. Clicking search repeatedly acts as "Next".

Collapse Tree

Clicking this button collapses all nodes in the tree.

Add

Click to add an IO node.

Delete

Click to delete the selected IO node.

Back Button

This button will display the [Advanced Page](#).

Sercos Diagnostics Page

General Page Information

This page is only for information and used primarily during troubleshooting.

NOTE: Fault and Diagnostic codes displayed on the Sercos Diagnostics Page are read directly from the servo drive, whereas errors displayed on the Fault Code History page are read from a database

SAMPLE IMAGE

Aagard HMI - Sercos Diagnostics

Sercos Ring: 1

Master Status

- Actual Phase: 4
- System State: Phase 4
- System Error: No error
- TimingErrorCnt1: 0
- TimingErrorCnt2: 0
- RDistErrorCnt: 0
- FibBrErrorCnt: 0
- RErrErrorCount: 0
- MstLateErrorCnt: 0
- MstEarlyErrorCnt: 0

Sercos Control

Init

E-Stop Mode

Reinitialize System

Servo Drive Data

Request Phase 1

Request Phase 2

Request Phase 3

Request Phase 4

Node Selection

- 1 - Rotary Drive
- 2 - Linear Drive
- 1 - Slice 1

Node Status

MST error counter (S28): 0 IDN S28 & S29 will only refresh while in phase 4.

MDT error counter (S29): 0

Diagnostic message (S95): A0013 Ready for power on

List of invalid operation data for CP2 (S21):

List of invalid operation data for CP3 (S22):

Fault Codes (P192) | Diagnostic Codes (S375)

| Error Code | Description | Date/Time | Operating Hours |
|------------|-------------------------------------------------------|-------------------------|-----------------|
| F2174 | Loss of motor encoder reference | 11/16/2010 12:10:22 ... | 6675:55:53 |
| F2174 | Loss of motor encoder reference | 11/16/2010 10:23:18 ... | 6674:09:14 |
| F8022 | Enc. 1: enc. signals incorr. (can be cleared in ph... | 11/16/2010 10:18:57 ... | 6674:04:53 |
| F2174 | Loss of motor encoder reference | | 6430:19:46 |
| F2174 | Loss of motor encoder reference | | 6430:19:39 |
| F2174 | Loss of motor encoder reference | | 6430:19:35 |
| F2174 | Loss of motor encoder reference | | 6430:19:30 |

Manufacturer Version: FWA-INDRV®-MPB-04V24-D5-1-NNN-NN

Startup Operating Hours: 6675:56:05

Refresh Status

Fault Code History Back

Sercos Ring

This is a drop down list containing a list of the Sercos rings. Select a ring from the list to view the diagnostics for that ring.

Master Status

This is a list of the ring status and error counts from the currently selected ring.

Sercos Control Buttons and Mode

Init / E-Stop Mode

This displays the current mode of the machine.

**Button**

Click this button to view all C40 modes.

NOTE: This button will be visible when more than one C40 exists

E-Stop Mode / Initialize Mode

Click the Initialize Mode button to request Init Mode. How To Reinitialize

These steps are done via the Sercos Diagnostics Page in the HMI

- 1) E-Stop the machine
- 2) Go to the Sercos Diagnostic Page
- 3) Click on Initialize
- 4) The text on the Initialize Button changes to E-Stop
- 5) Click on "Reinitialize System", and wait for the machine to reinitialize the sercos ring
NOTE: Although no physical adjustments need to be made, you will need to download the correct product size and Inserter recipe, if installed, and initialize the Barcode Scanner, if installed
 - a) If you downloaded a product other than what was previously downloaded, the Product Download Changeover Adjustments Page will be displayed
- 6) When complete, the Sercos Diagnostics Page will be displayed
- 7) Click on E-Stop on the HMI screen
 - a) The text on the button returns to "Initialize"
CAUTION: If you downloaded the wrong product during the Sercos Ring re-initialization routine, you must go to the Main Page and download the correct product
- 8) Pull the E-Stop button, and restart the machine

A simple but more time consuming alternative to these steps is to restart the HMI from the Advanced Page.

NOTE: If the system is already in Init mode, this button will read **E-Stop Mode**. Click this button to take the system out of Init mode

NOTE: When in Init Mode, these additional buttons become available

Reinitialize System

This button will perform an initialization function when all major sections of the system are in Init mode. This button is only available when the system is in Init mode.

Servo Drive Data

This button will open the Servo Drive Data page

Request Phase 1

This button, when pressed, will force the current selected ring to phase 1.

Request Phase 2

This button, when pressed, will force the current selected ring to phase 2.

Request Phase 3

This button, when pressed, will force the current selected ring to phase 3.

Request Phase 4

This button, when pressed, will force the current selected ring to phase 4.

Node Selection

This is a list of available nodes from the currently selected Ring.

Node Status

Node Status and error counts from the currently selected Node of the currently selected Ring.

IDN 28 – MST Error Count

IDN 29 – MDT Error Count

IDN 95 – Node Display Status

IDN 21 – List of IDN with invalid values for change of phase form 2 to 3

IDN 22 – List of IDN with invalid values for change of phase form 3 to 4

IDN P-192 – List of up to 50 error codes

IDN S-375 – List of up to 50 diagnostic codes

Fault Codes (P192) Tab

| Code | Description | Date/Time | Operating Hours |
|-------|--------------------------------------------|------------------------|-----------------|
| F2174 | Loss of motor encoder reference | 11/16/2010 12:10:22 PM | 6675:55:53 |
| F2174 | Loss of motor encoder reference | 11/16/2010 10:23:18 AM | 6674:09:14 |
| F8022 | Enc. 1: enc. signals incorr. (can be cl... | 11/16/2010 10:18:57 AM | 6674:04:53 |
| F2174 | Loss of motor encoder reference | | 6430:19:46 |
| F2174 | Loss of motor encoder reference | | 6430:19:39 |
| F2174 | Loss of motor encoder reference | | 6430:19:35 |
| F2174 | Loss of motor encoder reference | | 6430:19:30 |
| F2008 | RL The motor type has changed. | | 6430:19:30 |

Code

This column displays the code received from the selected servo drive.

Description

This column contains the description of the item.

Date/Time

This column displays the date and time the code was received.

Operating Hours

This value represents the current operating hours for this servo drive at the time the code was received, in hours:minutes:seconds.

Close Button

This button will close this Servo Drive Diagnostic Box.

NOTE: This button does not appear on the Sercos Diagnostics Page

NOTE: The Drive Diagnostics tab does not appear on the Sercos Diagnostics Page

NOTE: A missing description or date/time stamp may indicate either the correct PLC framework version is not in place, the error occurred prior to startup operating hours being logged, or the code is not listed in the reference table

Diagnostic Codes (S375) Tab

| SD#1 - Rotary Drive | | | | |
|---------------------|----------------------------------------|------------------------|-------------------------|--|
| Close | | | | |
| Drive Diagnostics | | Fault Codes (P192) | Diagnostic Codes (S375) | |
| Code | Description | Date/Time | Operating Hours | |
| C0500 | Reset class 1 diagnostics | 11/16/2010 12:10:23 PM | 6675:55:54 | |
| F2174 | Loss of motor encoder reference | 11/16/2010 12:10:22 PM | 6675:55:53 | |
| C5200 | Communication phase 4 transition ch... | 11/16/2010 12:10:20 PM | 6675:55:51 | |
| A0003 | Communication phase 3 | 11/16/2010 12:10:17 PM | 6675:55:48 | |
| A0002 | Communication phase 2 | 11/16/2010 12:10:16 PM | 6675:55:48 | |
| C0100 | Communication phase 3 transition ch... | 11/16/2010 12:10:16 PM | 6675:55:48 | |
| A0002 | Communication phase 2 | 11/16/2010 12:10:16 PM | 6675:55:48 | |
| C0500 | Reset class 1 diagnostics | 11/16/2010 12:10:16 PM | 6675:55:47 | |

Code

This column displays the code received from the selected servo drive.

Description

This column contains the description of the item.

Date/Time

This column displays the date and time the code was received.

Operating Hours

This value represents the current operating hours for this servo drive at the time the code was received, in hours:minutes:seconds.

Close Button

This button will close this Servo Drive Diagnostic Box.

NOTE: This button does not appear on the Sercos Diagnostics Page

NOTE: The Drive Diagnostics tab does not appear on the Sercos Diagnostics Page

NOTE: A missing description or date/time stamp may indicate either the correct PLC framework version is not in place, the error occurred prior to startup operating hours being logged, or the code is not listed in the reference table

Manufacturer Version

This label displays the current firmware version of the selected servo drive node.

Startup Operating Hours

This label displays the total operating hours of the selected servo drive node.

Refresh Status

When this button is pressed, the Node Status values are updated for the currently selected Node of the currently selected Ring.

Fault Code History Button

This button will display the [Fault Code History Page](#).

NOTE: This feature is only available with the correct PLC framework version in place

Back

This button will open the previous page.

Remove

Clicking this button will disassociate the selected FOB Card from the selected user, and remove the card from the system.

Logged In TimeOut

This entry field specifies the length of time the HMI will stay logged on as the current user without being used. After this time limit expires, the HMI will automatically log out of this user.

Save Button

This button will save the information edited on this page and then display the [Advanced Page](#).

Cancel Button


This button will not save any information edited on this page and then display the [Advanced Page](#).

Data Input Page

General Page Information

Each C40 (Main Section of the machine) has a Data Input Page. From this page branch categorized data entry pages for manipulating the data needed for the machine to operate properly. The data entry pages are categorized into two groups, the "Setup Data" and the "Product Data". There are two groups for a very important reason. Data changes made to the Setup Data category will affect all products that the machine runs, not just the product currently downloaded. Data changes made to the Product Data category will only affect the product that is currently downloaded. This information is very important to remember when editing data in these pages.

SAMPLE IMAGE



Setup Data Group

****Changes made on these pages will affect all products****

- **Servo Drive Data Button** - This button will open the [Servo Drive Data Page](#).
- **Solenoid Data Button** - This button will open the [Solenoid Data Page](#).
- **Motor Data Button** - This button will open the [Motor Data Page](#).

Product Data Group

****Changes made on these pages will only affect the current downloaded product****

- **Cam Data Button** - This button will open the [Cam Data Page](#).
- **Servo Moves Data Button** - This button will open the [Servo Moves Data Page](#).
- **General Data Button** - This button will open the [General Data Page](#).
- **Cam Offsets Button** - This button will open the [Cam Offsets Page](#).
- **Change Over Adjustments Button** - This button will open the [Adjustments Page](#).

Back Button

This button will close this page and go to the HMI Main Screen.

Servo Drive Data Page

General Page Information

This page shows Servo Drive Data for each Servo Drive on the machine. This page is identical to the [Servo Drive Data Page](#), with the addition of one check mark box in the bottom left hand corner of the screen labeled "Include This Servo In Initialization". Checking this box will do a full initialization to the Servo Drive that is currently selected the next time an initialization is done. A full initialization will load all the parameters specified under the Initialization Column on the [Servo Drive Data Page](#). Information about the parameters on this page can be found under the [Servo Drive Data Page](#).

User Level 3 required!

Initialize Data Section

Initialize Data Category

The machine controller uses this data in the machine start up to configure each servo axis. This data will require a full initialize on that servo axis before the changes will take effect. More information on how to do a full initialize on a servo axis can be found on the [Start Up Page](#).

Referencing Data Section

Referencing Data Category

This data is for machine referencing of the currently selected servo axis. Data changed in this category will take effect immediately after entering the data.

Jog Data Section

Jog Data Category

This data is used while in manual mode and jogging the currently selected servo axis. Data changed in this category will take effect immediately after entering the data.

Motion Data Section

Motion Data Category

This data is used as default variables and starting speeds for the currently selected servo axis. Data changed in this category will take effect immediately after entering the data.

Cam Data Section

Cam Data Category

This data is used when the axis is cam coupled to a master. If zero is specified, the default value in the Motion Data Category will be used. Data changed in this category will take effect immediately after entering the data.

Torque Monitoring Section

Torque Monitoring Category

This data is used as default variables and starting speeds for the currently selected servo axis. Data changed in this category will take effect immediately after entering the data.

SAMPLE IMAGE

Servo Drive: (5) 5 - Carton Picker

Standard | Advanced

Initialize Data

Motion Type: Rotary
Unit: Inches
Feed Forward:
Negate Feedback:
Inches Per Revolution: 0
Input Revolutions: 10
Output Revolutions: 1
Feedback Reference: Load
Modulo: 0
Velocity Limit: 1500
Max Velocity Limit: 3,476.772
Accel Limit: 100000000
Max Accel Limit: 116,889,663.063
In Position Bandwidth: 1
In Position Monitor Time: 0
Disable Drive Loop Monitoring: (WARNING! This also disables runaway detection!)
Enable Probe:
Probe Direction: Bi-Directional

Referencing Data

Standard Referencing:
Referencing Type: Switch Rev
Referencing Direction: Positive
Ref Verification Type: None
Torque: 50
Reference Velocity: 30
Low Velocity: 20
Accel: 720
Decel: 720
End Position: 0
Reference Position: -12
Sensor Clear Dist: 30
Sensor Compare Pos.: 0
Sensor Bandwidth: 0
Lag Limit: 0
Move #: 1

Motion Data

Default Velocity: 30
Default Accel: 250
Default Decel: 250
Default Torque: 180
Default Lag Limit: 5
E-Stop Recovery Accel: 250
E-Stop Fast Decel: 500

Cam Data

Master Offset Step: 0.01
Slave Offset Step: 0.1
Torque Limit: 0
Lag Limit: 0

Torque Monitoring

Torq. Averaging Count: 2
Torq. Warning Threshold %: 100

Jog Data

Move #: 2
Accel: 250
Decel: 250
Torque Limit: 50
Lag Limit: 0

Notes

Edit

11 Drive Status

Act Pos: 0.000
Max Pos. Err: 0.000 [Reset](#)
Max Torq: 0.000 [Reset](#)
Disabled

Diagnose Copy From... Back

Servo Drive

To access different servo drives, use the servo drive drop down list.

Notes

These notes can be edited by pressing the **Edit Button** located to the bottom right of the SD Notes Box. Once the Edit Button has been pressed, the text on the Edit Button will change to "Save" and the notes are now able to be edited. After the notes are edited, the **Save Button** will have to be pressed in order for the notes to be saved.

Drive Status Box


This box is located in the bottom left corner of this page. Information that is given is Actual Position, Max Position Error, Max Torque, and State of the Servo Drive. More information can be found on the [Drive Diagnostics Page](#).

Diagnose

This button will display a diagnostic popup for the currently selected Servo Drive. This diagnostic popup is described in further detail on the [Drive Diagnostics Page](#).

Copy From Button


This button will allow all the data from another servo axis to be copied, replacing all of the data for the currently selected servo axis. This feature may be useful when setting up a new servo axis. Pressing this button will display the **Copy From Popup**.

**Back Button**

This button will close and save any changes and go to the [Data Input Page](#).

Advanced Tab

SAMPLE IMAGE



Reference Mark Location

The Reference Mark Location is a precise description of the reference mark placement in relation to a fixed member of the machine.

Direction of Positive Movement

The Direction of Positive Movement is the direction of movement which causes a positive change in the position read out.


Reference Mark Position

The Reference Mark Position is the position the servo reads when lined up with the reference mark.

Precision

Change the precision setting for the selected drive. **WARNING: Data loss will occur when going from higher precision to lower!**

Reference Image

The Reference Image is the image that will display at the end of the reference routine. Push the  button to browse to the image file location.

Note: The image can only be 640 x 480 max.

Drive Status Box


This box is located in the bottom left corner of this page. Information that is given is Actual Position, Max Position Error, Max Torque, and State of the Servo Drive. More information can be found on the [Drive Diagnostics Page](#).

Diagnose

This button will display a diagnostic popup for the currently selected Servo Drive. This diagnostic popup is described in further detail on the [Drive Diagnostics Page](#).

Copy From Button

This button will allow all the data from another servo axis to be copied, replacing all of the data for the currently selected servo axis. This feature may be useful when setting up a new servo axis. Pressing this button will display the **Copy From Popup**.



Back Button

This button will close and save any changes and go to the [Data Input Page](#).

Solenoid Data Page

General Page Information

The configuration of each solenoid valve controlled actuator is contained on this screen. Changing the configuration of a valve can greatly affect how the machine functions. For instance, a solenoid valve controlling vacuum must have the configuration data of a vacuum valve. A vacuum controlling solenoid valve must also have the A Sensor activated because a vacuum sensor is connected to this input. Thus, the "A" Time is the time allowed for a vacuum to be made. If a cylinder is slowed via the flow controls and the cylinder does not make the cylinder switch in the time displayed in 'sensor time', then the cylinder will give a "Jam" fault. If it is desired to slow a cylinder, make sure that the time for that direction is raised to accommodate the slower action time.

Solenoid Valve Parameters Fields

Solenoid Valve Parameter Entry Fields

The solenoid valve parameters that can be specified for a specific solenoid valve are Configuration, "A" Time, "B" Time, "DeBounce" Time, "Jam" Time, "A" Sensor, and "B" Sensor. View the Solenoid Data Page Items page for more information on each field.

SAMPLE IMAGE

Solenoid Valve


To access different solenoid valves, use the solenoid valve drop down list.

Notes

These notes can be edited by pressing the **Edit Button** located to the bottom right of the SD Notes Box. Once the Edit Button has been pressed, the text on the Edit Button will change to "Save" and the notes are now able to be edited. After the notes are edited, the **Save Button** will have to be pressed in order for the notes to be saved.

Copy From Button

This button will allow all the data from another solenoid valve to be copied and replace all of the currently selected solenoid valve data. This feature may be useful when setting up a new solenoid valve. Pressing this button will display the **Copy From Popup**.

**Back Button**

This button will close and save any changes and go to the [Data Input Page](#).

Motor Data Page

General Page Information

The configuration of each non servo motor is contained in this screen. Changing the configuration of any motor can greatly affect how the machine functions.

Motor Parameter Fields

Motor Parameter Entry Fields

These parameters are described in further detail in the Motor Data Page Items topic.

SAMPLE IMAGE

Aagard HMI - Data Input - Motor

Motor:
 (3) 1115 - Layer Pad Magazine

Configuration: 3) VFD

"Forward" Time: 0 Seconds

"Reverse" Time: 0 Seconds

Change Director Delay: 0 Seconds

"Forward" Sensor:

"Reverse" Sensor:

Notes: **Edit**

This motor advances the Layer Pad blanks in the Layer Pad Magazine.
 (0.599 FPM @ 60 Htz)

Copy From... **Back**

Motor


To access different motors, use the motor drop down list.

Notes

These notes can be edited by pressing the **Edit Button** located to the bottom right of the SD Notes Box. Once the Edit Button has been pressed, the text on the Edit Button will change to "Save" and the notes are now able to be edited. After the notes are edited, the **Save Button** will have to be pressed in order for the notes to be saved.

Copy From Button

This button will allow all the data from another motor to be copied and replace all of the data for the currently selected motor. This feature may be useful when setting up a new motor. Pressing this button will display the **Copy From Popup**.

**Back Button**

This button will close and save any changes and go to the [Data Input Page](#).

Cam Data Page

General Page Information

A device cam is an electronic coupling of one or more devices to a master. The Cam Data Input Page contains the master/slave positions for each device. The slave is electronically coupled to the master by position, and the table contains those position to position couplings. The points in the table are also shown on a graph. The cams are very tightly coupled with the master and even a slight position change can greatly affect machine function.

SAMPLE IMAGE

Agard HMI - Data Input - Cam Data

Current Recipe: #1 (884 Carton)

Cam Table:
 16 - Magazine Vacuum (SV)

Cam Table Length: 3 Currently Looking at #: 0

Remove From Cam Generator New Rename Delete

| | 1 | 2 | 3 |
|-------------|---|-----|------|
| Master Pos: | 0 | 400 | 1050 |
| Slave Pos: | 0 | 1 | 0 |

Notes:

Slave Pos of -1 = OFF (B Coil)
 Slave Pos of 0 = OFF (B Coil)
 Slave Pos of 1 = ON (A Coil)
 Magazine Master is the master for this cam.

Refresh Graph Graph All (Slow) Graph Current Slope Graph Square Wave Graph

Position (Max: 1.00000, Min: 0.00000)

Depending on the type of cam you have selected, some of these fields could have different definitions. Click a button below to view more information on that specific cam type.

Cam Table

This is a drop down menu to allow any solenoid valve or motor cam to be selected. The data being displayed on the page pertains to the selected cam.


Remove From Cam Generator

Press this button to remove the selected cam from Cam Generator. **Use with caution!**

Aagard level required!

New


This button will display the **New Cam Popup** which will create a new cam.



- **Number Entry Field** - This entry field is for the new cam ID number.
- **Name Entry Field** - This entry field is for the new cam name.
- **OK Button** - This button will close and save the information entered.
- **Cancel Button** - This button will close but not save the information entered.

Rename

This button will display the **Rename Cam Popup** which will allow the currently selected cam to be renamed.



- **Name Entry Field** - This entry field is where the cam name can be edited.
- **OK Button** - This button will close and save the information entered.
- **Cancel Button** - This button will close but not save the information entered.

Delete

This button allow the currently selected cam to be deleted.

Cam Table Length

This field will allow the cam to be setup to have as many points needed to make the proper cam. The previous example screen has 4 cam points.

Currently Looking at

This field will allow the cam point entered to be viewed on the cam table right below this entry field.

Notes

These notes can be edited by pressing the **Edit Button** located to the bottom right of the SD Notes Box. Once the Edit Button has been pressed, the text on the Edit Button will change to "Save" and the notes are now able to be edited. After the notes are edited, the **Save Button** will have to be pressed in order for the notes to be saved.

Refresh Graph

This button will refresh the graph shown.

Graph Selection

This feature displays cams in different graph formats.

- Graph All (Slow) uses all of the points in the cam to generate the graph
- Graph Current uses the points currently displayed on the screen to generate the graph
- Slope Graph displays the points in a slope (best suited for servo drives)
- Square Wave Graph displays the points in a square wave (best suited for solenoid valves)

Cam Generator Button

This button will open the Cam Generator Program. This program is used to create Servo Drive Cams. The Cam Generator is an Aagard developed application that generates cam tables. Opening the cam generator application allows the user to manipulate cam tables generated with the Aagard Cam Generator.

Back Button

This button will close and save any changes and go to the [Data Input Page](#).

Servo Drive Cams

The servo drive cams should be altered through the [Cam Generator](#). These cams are described in further detail in the [Cam Generator](#) help section.

Solenoid Valve Cams

The solenoid valve cams should be altered on the [Cam Data Page](#). These cams are described in further detail in the [Solenoid Valve Cams](#) topic.

Motor Cams


The motor cams should be altered on the [Cam Data Page](#). These cams are described in further detail in the [Motor Cams](#) topic.

Cam Generator

Choose Cam Group

General Page Information

The first screen to popup after the cam generator button is pressed is the Cam Generator Choose Cam Group Screen. The cam group is a group of servo axes that may have related functions.



Existing Cam Group Option

The user is prompted to select a cam group from the existing cam groups available that contains all the information needed to build the cam table wanted.

New Cam Group Option

If a new cam group is wanted, the New Option Button will have to be pressed.

- **Name Entry Field** - A name will have to be entered in the Name Entry Field.
- **C40 Drop Down Menu** - A C40 will have to be selected from the C40 Drop Down Menu. The C40 that should be selected from this menu is the C40 in which the Servo Drive(s) are located.

OK Button

This button will save any new Cam Groups and go to the Choose Product Screen (see below).


Cancel Button

This button will exit the Cam Generator and not save any changes.

Choose Product

General Page Information

The next screen to pop up after the OK button on the Cam Generator Choose Cam Group Screen is pressed is the Choose Product screen. The product to choose is the one to which you would like the changes applied.



Existing Drop Down Menu

The user is prompted to select a product from the existing list of products available that contains all the information needed to build the cam table wanted.

OK Button

This button will go to the [Cam Generator Main Screen](#).

Cancel Button

This button will exit the Cam Generator.

Main Screen

General Page Information

This is the Cam Generator Main Screen. This is where all Servo Drive Cams are made and edited. Once changes are complete, the generated positions are placed into the HMI database. A product download will be needed for the modifications to take effect. The Product Download will then load the generated positions to create the new cam.

Cam Generator has different ways the created cam can be viewed, if desired. The Cam Generator will default to the Setup Viewing Feature shown on the Cam Generator Main Screen. Other possible viewing features are [Graph](#) and [Points](#). There is also a [Misc](#) Viewing Feature, which allows notes to be assigned to each cam.

SAMPLE IMAGE

The screenshot displays the Cam Generator software interface. The main window is titled "Cam Generator" and shows two cam configurations for a "Product: 684 Carton".

#19 Bucket X Drive (Number of points to use: 293)

- MDist Multiplier: 1000 (Add, Remove)
- Setup | Graph | Points | Misc
- Master Start: 0, Slave Start: 0.87, Velocity Start: 0, Master End: , Slave End: (Calculate)
- Dwell Bot Compress** (Green): Dwell #1, Time: 0.275
- Wait For BottomBucket** (Orange): Dwell #1, Time: 0.4
- Form Top Bucket** (Cyan): Move #1, Time: 0.84, SDist: 26.225, Max Vel: 40, Max Acc: 0
- Wait For Compres** (Red): Dwell #1, Time:

#20 Bottom Bucket (Number of points to use: 293)

- Master Start: 0, Slave Start: 22.813, Velocity Start: 0, Master End: , Slave End: (Calculate)
- Dwell Bot Compress** (Green): Dwell #1, Time: 0.275
- Pull Out Of Carton** (Orange): Move #1, Time: 0.7, SDist: -22.813, Max Vel: 0, Max Acc: 0
- Dwell Out Of Carton** (Red): Dwell #1, Time: 0.675
- Dwell Top Compre** (Red): Dwell #1, Time:


Buttons at the bottom: Quit, Save, Load, View Timing Graph, View Overlay Graph, View 2 Axis Graph.

Cam Group Information

MDist Multiplier

This entry field makes the MDist displayed in the different information blocks relate to something such as time or distance of another axis. Keep in mind that the MDist is only equal to time when operating at 100% rate.

Add Cam Button - This button will display the Choose Cam Popup. This popup will allow a new cam to be added to or created in the cam generator. If the cam exists already, select the Existing Option and select the cam from the drop down menu. If the cam doesn't exist, select the New Option and specify the cam number in the left entry field and put the name of the cam in the right entry field. The OK Button will save the information, and the Cancel Button will close the popup and go to the Cam Generator Main Screen.



Remove Button - This button will remove the currently selected cam.

Rename Cam - A cam can be renamed by clicking on the cam name at the top of the cam.

Number of Points to Use

This field defines the maximum number of points that the cam generator program uses to generate the table for the drive data for this cam.

NOTE: Using more points will produce smoother motion

Add Data Type Button - This button will display the [Select Type of Data Popup](#).

Remove

This button will remove the currently selected cam data type

Move>>

This button will move the currently selected Cam Data Type to the right.

<<Move

This button will move the currently selected Cam Data Type to the left.

Master Start

This is the Master Position at which the cam should start.

Slave Start

This is the Slave (Servo Drive) Position at which the cam should start.

Velocity Start

This is the velocity at which the Servo Drive should start its cam.

Calculate

This button will calculate the Master End, Slave End, and all the status information generated in each Cam Data Type for the cam.

Master End Status

This position will be generated after the Calculate Button has been pressed. This status is the position at which the master currently ends. This should always equal the length of the master's travel after all changes have been made.

Slave End Status

This position will be generated after the Calculate Button has been pressed. The status is the position at which the slave (Servo Drive) currently ends. This position should usually equal the slave start unless the axis rolls its position over to zero at some point.

Quit Button - This button will ask if any changes want to be saved and start the process to exit cam generator and display the [Cam Generator Warning Screen](#).

Save Button - This button will save any changes made to the cams.

Load Button - This button will ask if any changes want to be saved and go to the [Cam Generator Choose Cam Group Screen](#) to load another group of cams.

View Timing Graph

This feature displays the relationship (in time) between each segment of the cam to the overall length of the cam.

View Overlay Graph


This feature displays the position of the axis (Show Slave selection) as well as the velocity of the axis (Show Velocity selection) over the length of the cam.

View 2 Axis Graph

This feature displays the profile of a two-axis cam, graphing the position of one axis over the position of another.

General Page Information


This popup will allow a new cam to be added to or created in the cam generator.



General Page Information

Cam Generator has different ways the created cam can be viewed, if desired. The Cam Generator will default to the Setup Viewing Feature shown on the [Cam Generator Main Screen](#). Other possible viewing features are [Graph](#) and [Points](#). There is also a [Misc](#) Viewing Feature, which allows notes to be assigned to each cam.

SAMPLE IMAGE



This viewing feature displays the cam shown as a graph, which allows the user to be able to clearly see the profile of the cam that is currently created.


See Graph For Drop Down List

This drop down list will allow the user to view the graph for the whole cam or just the graph for individual Cam Data Boxes.

General Page Information

This viewing feature displays the cam points shown in a spreadsheet format, displaying each cam point created by the current cam.

SAMPLE IMAGE



See Points For Drop Down Menu

This drop down menu will allow the user to view all the points in this cam or points for individual Cam Data Boxes.

Points View Label

- Static Seg: This displays how many static segments are in the cam, and the number of points they consume
- Const Vel Segs: This displays how many constant velocity segments are in the cam, and the number of points they consume
- Changing Vel Segs: This displays how many changing velocity segments are in the cam, and the number of points they consume
- Starting Point: This displays the starting point of the cam

Index Column

This column lists the point number for the row of information.

Master Column

This column lists the master position at that point in the cam.

Slave Column

This column lists the slave (servo axis) position at that point in the cam.

Velocity Column

This column lists the velocity at that point in the cam.


Misc Column

This column defines the beginning and end of a segment. 1 defines the beginning of a segment; 2 defines the end of a segment.

This viewing feature allows notes to be assigned to each cam.

General Page Information

This viewing feature allows notes to be assigned to each cam.

SAMPLE IMAGE**Send this cam to another master**

This button will allow the user to move the cam to another cam group that is perhaps more integrated with this cam.

Copy Data From Another Cam/Product


This button will allow the user to copy data from another cam to replace the current cam profile.

Notes

This box is for notes that may need to be listed with this cam.

General Page Information

Each cam is made of a group Cam Data Types which, put together, create the servo axis motion needed to complete the function of that servo axis. Select one of the data types and it will be added to the cam. Every Cam Data Type has certain input parameters that need to be specified. The rest of the parameters can be calculated from the input parameters and are displayed below the input parameters in the Cam Data Type after the calculate button has been pressed.



Segment #1 (Incr Pos & Vel) - This is a segment data type with input parameters of Incremental Position and Velocity. This data type will only accelerate or decelerate the Servo Axis.

SDist - This is the Slave (Servo Axis) Distance to be traveled during this Data Type.

End Vel - This is the velocity wanted at the end of the Data Type.

Segment #2 (Abs Pos & Vel) - This is a segment data type with input parameters of Absolute Position and Velocity. This data type will only accelerate or decelerate the Servo Axis.

End SPos - This is the Slave (Servo Axis) Position wanted at the end of the Data Type.

End Vel - This is the velocity wanted at the end of the Data Type.

Segment #3 (Incr Pos & Time) - This is a segment data type with input parameters of Incremental Position and Time. This data type will only accelerate or decelerate the Servo Axis.

SDist - This is the Slave (Servo Axis) Distance that is to be traveled during this move.

MDist - This is the Master Distance in which the segment is to be completed.

Segment #4 (Abs Pos & Time) - This is a segment data type with input parameters of Absolute Position and Time. This data type will only accelerate or decelerate the Servo Axis.

End SPos - This is the Slave (Servo Axis) Position wanted at the end of the Data Type.

MDist - This is the Master Distance in which the segment is to be completed.

Segment #5 (Time & Vel) - This is a segment data type with input parameters of Time and Velocity. This data type will only accelerate or decelerate the Servo Axis.

MDist - This is the Master Distance in which the segment is to be completed.

End Vel - This is the velocity wanted at the end of the Data Type.

Custom #1 (Open Case w/Tail) -

Cam # - This specifies the cam number in which this custom cam is built.

SDist \ Radius - This is the Slave (Servo Axis) Distance that is to be traveled during this move.

Move MDist - This is the Master Distance in which the segment is to be completed.

Custom #2 (MDist Arc) -

SDist \ Radius - This is the Slave (Servo Axis) Distance that is to be traveled during this move.

MDist - This is the Master Distance in which the segment is to be completed.

Move #1 - This is a move data type with input parameters of Time, SDist, MaxVel, and MaxAcc. This data type will accelerate and then decelerate the Servo Axis to a stop.

Time - This is the Master Distance in which the move is to be completed.

SDist - This is the Slave(Servo Axis) Distance to be traveled during this move.

MaxVel - This is the Max Velocity allowed for this move. If 0 is specified, the default max velocity specified on the [Servo Drive Data Page](#) will be used. If the max velocity is reached during this move, the move profile will be a trapezoid move. If the max velocity isn't reached during this move, the move profile will be a triangle move.

MaxAcc - This is the Max Acceleration and Deceleration wanted for this move. If 0 is specified, the default max velocity specified on the [Servo Drive Data Page](#) will be used.

Dwell - This is a dwell data type with an input parameter of MDist. This data type will not move the servo axis for the amount of Master Distance specified.

MDist - This is the Master Distance in which the segment is to be completed.

Const Vel #1 (Time) - This is a constant velocity data type with an input parameter of MDist. This data type will continue the velocity at which the Servo Axis is at the beginning of this data type for the amount of Master Distance specified.

MDist - This is the Master Distance in which the segment is to be completed.

Const Vel #2 (Dist) - This is a constant velocity data type with an input parameter of SDist. This data type will continue the velocity at which the Servo Axis is at the beginning of this data type for the amount of Slave Distance specified.

SDist - This is the Slave (Servo Axis) Distance that is to be traveled during this move.

Curve #1 Master - This is a move data type with input parameters of ID #, Start Angle, End Angle, X Radius, and Time. This data type along with the Curve #1 Slave data type will allow a two axis robot to move in a arc profile.

ID # - This specifies the ID Number for the Curve Master.

Start Angle - This specifies the Start Angle of the curve in relationship to the axes and center point of the curve.

End Angle - This specifies the End Angle of the curve in relationship to the axes and center point of the curve.

X Radius - This specifies X Radius of the curve.

Time - This is the Master Distance in which the move is to be completed.

Curve #1 Slave - This is a move data type with input parameters of Master ID # and Y Radius. This data type along with the Curve #1 Master data type will allow a two axis robot to move in a arc profile.

Master ID # - This specifies the ID Number of the Curve Master in which this Curve Slave is built.

Y Radius - This specifies Y Radius of the curve.

? Buttons

The "?" buttons will describe what that data type is.

Cancel Button

The Cancel Button will close the popup and not add any data types.

Warning Screen

General Page Information

After exiting the Aagard Cam Generator, the operator will receive a message stating that a product download must be made after modifying the cam data in the cam generator. Because the Cam Generator is a separate application, it does not directly communicate with the machine's controller and the cams need to be downloaded independently.



After the OK Button is pressed the [Cam Data Page](#) will be displayed.

Solenoid Valve Cams

Solenoid Valve Cams

The solenoid valve cams should be altered on the Cam Data Page. The Slave Pos. row contains the data that will energize or not energize the solenoid valve. The Master Pos. row contains the master's position at each function of the solenoid valve.

- **Solenoid Master Pos.** - Master's Position of each slave position.
- **Solenoid Slave Pos.**
 - Spring Return or Vacuum Solenoid Valve - 1 will energize and 0 will not energize
 - Double Detent Solenoid Valve - 1 will energize and -1 will not energize

| | 1 | 2 | 3 |
|--------------------|---|---|----|
| Master Pos: | 0 | 5 | 10 |
| Slave Pos: | 0 | 1 | 0 |

Example Cam in above screen - At point 1 the master position is 0 and the slave position is 0 which is not energized. Point 1 should always be master position 0 in order to know the solenoid valve's position at the start of the cycle. At point 2 the master position is 5 and the slave position is 1 which is energized. At point 3 the master position is 10 and the slave position is 0 which is not energized.

Cam Data Page

Motor Cams

Motor Cams

The motor cams should be altered on the Cam Data Page. The Slave Pos. row contains the data that will energize or not energize the motor. The Master Pos. row contains the master's position at each function of the motor.

- **Motor Master Pos.** - Master's Position of each slave position.
- **Motor Slave Pos.**
 - VFD controlled - The number will be the device speed wanted in FPM
 - Motor Starter controlled - 1 will energize and 0 will not energize

| | 1 | 2 | 3 |
|--------------------|---|----|----|
| Master Pos: | 0 | 5 | 10 |
| Slave Pos: | 0 | 90 | 0 |

Example Cam in above screen - At point 1 the master position is 0 and the slave position is 0 which is not energized or if VFD controlled running at a speed of 0 FPM. Point 1 should always be master position 0 in order to know the motor's speed or status at the start of the cycle. At point 2 the master position is 5 and the slave position is 90 which is, if VFD controlled, running at a speed of 90 FPM. If the motor wasn't VFD controlled, then the slave position would be 1 which is energized. At point 3 the master position is 10 and the slave position is 0 which is not energized, or if VFD controlled, running at a speed of 0 FPM.

Cam Data Page

Servo Moves Data Page

General Page Information

This screen provides a means to adjust servo axis move parameters. Most servo-controlled motions use this move data.

SAMPLE IMAGE

Aagard HMI - Data Input - Servo Drive Moves

Current Recipe: #1 (684 Carton)

Servo Drive: 5 - Carton Picker

Move: 3 - Alt Jog 1 (Auto Calc)

Position: 0 (Default)

Velocity: 0 (360)

Accel: 0 (720)

Decel: 0 (720)

Torque: 0 (150)

Position Error Limit: 0 (4.000)

Servo Modulo: 0.000

Notes: This is Designated As The Alternate Jog 1 Move (Go To the Jog Page To Change).

5 Drive Status
Act Pos: 0.000
Max Pos. Err. 0.000 [Reset](#)
Max Torq. 0.000 [Reset](#)
Disabled

Smoothest Triangle Move (Dist, Time)

| | Time | Dist | Time into 1st Seg: |
|--------------------|------|------|--------------------|
| Dist: 0 | | | 0 |
| Time: 0 | | | |
| Acc: | | | |
| Vel Max: | | | |
| Seg1: | | | |
| Seg2: | | | |
| Totals: | | | |
| Dist into 1st Seg: | | | |
| Time: | | | |
| Vel: | | | |

Diagnose

Back

Servo Drive

To access different servo drives, use the servo drive drop down list.

Move

Each servo axis has a collection of moves accessible via the drop down menu. Some of these are auto calculated by the controller and values don't need to be entered for these moves. Move numbers 1 through 5 are always auto calculated. Any move numbers higher than 5 will be labeled if they are auto calculated.

New

This button will display a **New Move Popup** window. This feature will allow a new move to be created.



SD # Entry Field - This number should be the same as the Servo Drive number for which the move needs to be created.

Number - This number is equal to the move number that is specified in the controller program for this move.

Name - This is where the name of the move should be specified.

OK Button - This button will save any new information and close the popup window.

Cancel Button - This button will not save any new information and close the popup window.

Rename Button

This button will display a **Rename Move Popup** window. This feature will allow an existing move to be renamed.



Name - This is where the name of the move should be specified.

OK Button - This button will save any new information and close the popup window.

Cancel Button - This button will not save any new information and close the popup window.

Delete Button

This button will delete the currently selected move for the currently selected servo drive.

Servo Axis Move Parameters Entry Field Column

The move parameters that can be specified for a specific move are Position, Velocity, Accel, Decel, Torque, and Position Error Limit. These parameters are described in further detail on the [Servo Modes Data Page Items](#) topic.

Default Fields

This column will display the default parameters set in the [Servo Drive Data Page](#) for the selected servo drive.

Notes

These notes can be edited by pressing the **Edit Button** located to the bottom right of the SD Notes Box. Once the Edit Button has been pressed, the text on the Edit Button will change to "Save" and the notes are now able to be edited. After the notes are edited, the **Save Button** will have to be pressed in order for the notes to be saved.

Drive Status Box

This box is located in the bottom left corner of this page. Information that is given is Actual Position, Max Position Error, Max Torque, and State of the Servo Drive. More information can be found on the [Drive Diagnostics Page](#).

Servo Move Calculator Box

This box will display different types of possible move calculators depending on what is selected in the Servo Move Calculator Drop Down Menu. This tool will allow information about a move to be calculated once the required information is entered.

Diagnose

This button will display a diagnostic popup for the currently selected Servo Drive. This diagnostic popup is described in further detail on the [Drive Diagnostics Page](#).

Back Button

This button will close and save any changes and go to the [Data Input Page](#).

General Data Page

General Page Information

The data contained on this page is provided as a means to adjust certain running parameters. These values pertain to the current downloaded product only. If changes are desired on any other products, a product download will have to be performed and then changes made to that specific downloaded product.

[Case Packer General Data Page Items](#)

[Palletizer General Data Page Items](#)

Button

This button will display the **General Data Definition Popup**. This popup contains the definition for the related General Data item. To close the popup, click the red X in top right corner, click outside the popup, or press Esc.

NOTE: If logged in at Aagard level, this definition is editable.



Back Button

This button will display the [Data Input Page](#).

Case Packer General Data Page Items

INFEED

Product Rate

This entry field sets the velocity of the cartoner master move.

Metering Conveyor Speed (FPF)

This entry field specifies the speed of the Metering Conveyor. The unit of measure for this entry field is feet per minute (FPM).

Side Belt Speed (FPM)

This entry field specifies the speed of the Side Belts. The Side Belts should usually travel at 400 FPM. The unit of measure for this entry field is feet per minute (FPM).

Trigger Downstack From Side Belt Sensor Delay (Time in Seconds)

This entry field delays the Downstacker Flights from downstacking a layer after the rising edge of the Side Belt PE. The unit of measure for this entry field is seconds.

Retract Spatula After First Product Delay (Time in Seconds)

This entry field delays the Spatula from returning after the first product is put into the Downstacker. The unit of measure for this entry field is seconds.

Trigger spatula Transfer From Side Belts PE Delay (Time in Seconds)

This entry field delays the Spatula from extending after the rising edge of Product seen by the Product in Side Belts PE. The unit of measure for this entry field is seconds.

DOWNSTACKER

Product Height

This entry field specifies the height of the product as it enters the machine. The unit of measure for this entry field is inches.

Layers Per Stack (Integer Value)

This entry field specifies the number of layers in each complete stack of cartons.

Downstack Push Plate Height From Deck (in)

This entry field specifies the position of the downstacker flights when the downstack pusher is clear to begin its cycle. The unit of measure for this entry field is Inches.

Stack Complete Position From Deck (in)

This entry field specifies the position of the downstacker flights when the Downstacker Pusher is trigger to start moving. The unit of measure for this entry field is inches.

Downstacker First Layer Delay

This entry field specifies the time delay of the downstacker. The unit of measure is seconds.

Downstacker First Layer Position

This entry field specifies the position of the downstacker flights when they are ready to accept product. The unit of measure for this field is inches.

Downstacker Prime Position

This entry field specifies the position of the downstacker flights when they are primed for the next downstacker cycle. The unit of measure for this field is inches.

DOWNSTACKER PUSHER

Downstack Pusher Stack Presented Position (Master Position)

This entry field specifies the Master Position during a cycle of the Downstack Pusher when a completed stack has been delivered to the Loader. The unit of measure for this entry field is in the Master Position of the Downstack Pusher.

Downstack Pusher Available Position (Master Position)

This entry field specifies the Master Position during a cycle of the Downstack Pusher when it is available to receive product. The unit of measure for this entry field is in the Master Position of the Downstack Pusher.

Downstack Pusher Condition Product Before Extended

This entry field specifies the downstacker pusher master position when the product conditioner comes down. The unit of measure for this field is the master position of the downstack pusher.

LOADER

Product In Case Position

This is the position of the loader master at which the product stop and tucker will move to hold the minors closed. This keeps product from continuing past the non load side score line.

Case Filled Position (Master Position)

This entry field specifies the position of the Loader Master when the Case Filled status is set. The unit of measure for this entry field is in the Master Position of the Loader Master.

Loader Available Before Cycle End Position (Master Position)

This entry field specifies the Master Position Distance of the Loader Master when the Loader becomes available to receive product before the end of the cycle. The unit of measure for this entry field is in the Master Position of the Loader Master.

Loader Release Product Conditioner Position

This entry field specifies the loader master position when the product conditioner is retracted. The unit of measure for this field is the master position of the loader.

CASE FORMER

Enable Glue Gap

This check box enables the Glue Pattern Gapping feature. If this box is checked the gapping feature is enabled. This feature should only be edited from the Case Glue Page.

Enable Glue Gap Percentage (%)

This entry field specifies the amount of gap to be used in the glue beads. This value will only be used if the Glue Pattern Gapping feature is enabled. This feature should only be edited from the Case Glue Page.

Case Ready Position (Master Position)

This entry field specifies the position of the Packer Main Master when the case is ready for the Loader to fill the case of cartons. The unit of measure for this entry field is in the Master Position of the Packer Main Master.

Palletizer General Data Page Items

TIP REJECT

Tip/Reject Conveyor Speed (FPM)

This field specifies the speed of the Tip/Reject Conveyor. The unit of measure for this entry field is Feet Per Minute (FPM).

Drop Product Stop Position (Master Position)

This entry field specifies the Master Position of the Tip/Reject Master where the Product Stop is dropped. The unit of measure for this entry field is in the Master Position of the Tip/Reject Master.

Re-Enable Tip/Reject Conveyor (Master Position)

This entry field specifies the Master Position of the Tip/Reject Master where the Tip/Reject Conveyor is turned on. The unit of measure for this entry field is in the Master Position of the Tip/Reject Master.

ROTATE AND ACCUMULATION

Rotate Cases

This check box allows for the Case Rotate to be enabled on the sizes where the case needs to be rotated in order to obtain the correct orientation.

Begin Rotate Delay Time (Time in Seconds)

This field specifies the time between when a product is sensed and the rotate cycle begins. The unit of measure for this entry field is Seconds (Sec).

Release Vacuum Early Distance (Degrees)


This field specifies the amount of rotation in degrees that will remain on the Rotate SD when vacuum is released. The unit of measure for this entry field is Degrees.

Cam Offsets Page

General Page Information

This screen allows the user to slightly adjust a complete cam while the machine is operating. It may be convenient to make slight adjustments to a cam while the machine is still in operation. Individual parts of the cam can't be adjusted from this page, but the whole cam can be adjusted slightly earlier or later. The servo drive start position of the cam can also be adjusted slightly from this page. CAUTION! Changes made here may greatly affect the performance of this machine.

SAMPLE IMAGE



Servo Drive

To access different servo drives, use the servo drive drop down list.

Solenoid Valve

To access different solenoid valves, use the solenoid valve drop down list.

Master Offset

This entry field will adjust the master offset of the cam for the selected device. This will offset the cam for the selected device by the Master Distance. For example: At 0 the cam and master will both start at the same time. If 5 is entered in the Master Offset Entry Field the cam will now be advanced by a Master Position of 5. If -5 is entered in the Master Offset Entry Field the cam will now be delayed by a Master Position of 5.

Slave Offset Entry Field

This entry field will adjust the slave offset of the cam for the selected drive. For example: At 0 the slave will start at the position specified by the cam in cam generator. If 5 is entered in the Slave Offset Entry Field the slave will now start the cam at the position specified in the cam plus 5 units. If -5 is entered in the Slave Offset Entry Field the slave will now start the cam at the position specified in the cam minus 5 units. The units will vary depending on how the drive is configured. The units of the drive are specified on the Servo Drive Data Page.

Diagnose

This button will display a diagnostic popup for the currently selected Servo Drive. This diagnostic popup is described in further detail on the [Drive Diagnostics Page](#).

Back Button

This button will close and save any changes and go to the [Data Input Page](#).

Changeover Adjustments Page

General Page Information

This page provides a list of adjustments and values for the currently downloaded product. Values are adjustable from this page.

Columns indicate the Adjustment Name, Value, and Description.

SAMPLE IMAGE

The screenshot shows a software window titled "Aagard HMI - Data Input - Adjustments". Inside the window, there is a section labeled "Current Product:" followed by a list of adjustments. Each adjustment is represented by a row with an ID, a value in a text box, and a description. At the bottom of the window, there are three buttons: "Export List Of All Values For All Products" (with a keyboard icon), "ReArrange", and "Back".

| Adjustment ID | Value | Description |
|---------------|---------------|----------------------------------------|
| 2-1 | 88 | Operator Side Magazine Width |
| 2-2 | 21 | Non-Operator Side Magazine Width |
| 2-3 | 180 | Non-Operator Side Magazine Rotate Clip |
| 2-4 | 205 | Operator Side Magazine Rotate Clip |
| 2-5 | 380 | Top Clip |
| 2-6 | 42 | Bedplate Width |
| 2-7 | 100 EXTEND | Product Stop - Upper |
| 2-8 | EXTEND | Product Stop - Lower |
| 2-9A | 1/4" DOWN FRO | Flap Tucker - Upper |
| 2-9B | 145 | Flap Tucker - Lower |
| 2-10 | LOWER | Robot Pick Cups |
| 2-11 | 185 | Robot Case Pusher Horizontal |
| 2-12 | 330 | Robot Case Pusher Vertical |
| 2-13 | ON | 5th Cup Vacuum Control Valve |
| 2-14 | OFF | 4th Cups Vacuum Control Valve |

Export List Of All Values For All Products Button

This button will export a list of all values for all products in default order to a Microsoft Excel file, which may also be opened by other application programs.

ReArrange Button

This button will display the [ReArrange Page](#).

Rearrange Page

General Page Information

This will allow the changeover order be adjusted when changing from one product to another. Having the changeover adjustments in the correct order for all the different size changes may eliminate any possible interferences that may occur.


SAMPLE IMAGE

Aagard HMI - Data Input - Adjustment Order

Product Combination: From: 684 Carton To: 699 Carton

| Number | Default Order | Modified Ord | Name |
|--------|---------------|--------------|----------------------------------|
| 1-1 | 1 | -1 | Infeed Conveyor Width |
| 1-2 | 2 | -1 | Blank Backstop Width |
| 1-3 | 3 | -1 | Bucket Changeout |
| 1-4 | 4 | -1 | Backstop Offset |
| 1-5 | 5 | -1 | Side Seam Compression |
| 1-6 | 6 | -1 | Nip Belt Height |
| 1-7 | 7 | -1 | Picker Arm-Change Part |
| 1-8 | 8 | -1 | Magazine Height |
| 1-9 | 9 | -1 | Top Carton Drive Height |
| 1-10 | 10 | -1 | Carton Blank Width |
| 1-11 | 11 | -1 | Magazine Horizontal Adjustment |
| 1-12 | 12 | -1 | Carton Slot Guide |
| 1-13 | 13 | -1 | Upper Carton Clamp |
| 1-14 | 14 | -1 | Lower Carton Clamp |
| 1-15 | 15 | -1 | Upper Flite Chain Width |
| 1-16 | 16 | -1 | Lower Flite Chain Width |
| 1-17 | 17 | -1 | Tucker Height |
| 1-18 | 18 | -1 | Operator Upstream Glue Height |
| 1-19 | 19 | -1 | Operator Lower Compression Plate |
| 1-20 | 20 | -1 | Operator Downstream Glue Height |
| 1-21 | 21 | -1 | Operator Upper Compression Plate |
| 1-22 | 22 | -1 | Discharge Conveyor Width |
| 1-23 | 23 | -1 | Domino Laser Position |
| 1-24 | 24 | -1 | After Tuck Rail |

If the Modified Order Value = "-1" then the Default Order Value will be used in its place.
Changing The Default Order will change it for all Product Combinations.

 **Back**

Product Combination Drop Down List

This list will allow the correct product combination to be selected when going from a particular product to another product.

Number Column

This column will show the different adjustment changeover numbers.

Default Order Column

This column will show the changeover adjustment's default order that is displayed on the [Adjustments Page](#). This order can be changed from this page. This will change the default order on all sizes.

Modified Order Column

This will show the changeover adjustment's modified order. This column can be different depending on what Product Combination is selected. If the order needs to be modified, change the -1(Default Order) in the Modified Order Column to the appropriate number that will place it correctly in the Default Order.

Name Column


This column will display the changeover adjustment names.

About

General Page Information

This screen contains software version information and is displayed by pressing the About button on the Main page.

SAMPLE IMAGE



Report Generator

General Page Information


The Report Generator is a stand-alone program and is automatically loaded into memory when the HMI application runs. The Report Generator is accessible from the system tray.

This program will create reports that will assist in improving the performance of the machine. The information given is created by analyzing information stored in the Aagard HMI database. Everything documented in this generated report can be seen in the Aagard HMI. The Report Generator will create a Detailed Report and a Summary Report daily, at the beginning of the first shift for the prior day's shifts. The following information is documented in the Summary Report: HMI Recorded From, Time Report was Generated, Products downloaded for each Shift, Barcode downloaded if applicable for each Shift, Time the Product was downloaded for each Shift, Downtime Tracking Information by Section and by the whole System for each Shift, Production Data Information for each Shift. The following information is documented in the Detailed Report: System Wide Fault History Log, Change Log, Downtime Log, and System Wide Reject History Log.

This popup screen will allow the user to configure the Report Generator. The configuration setup on the popup screen will only be applied to the current logged on user. Five possible locations for reports can be specified, if desired.

If the Report Generator Program is running, the status icon should be shown in the bottom right hand corner of the PC Screen as shown below. The Aagard HMI must be logged in as Level 3 or higher in order for the PC Screen to be viewable. If the Report Generator Icon is right-clicked, the options shown below will be shown. If the Exit option is selected the Report Generator Program will be Shutdown. The Configure option will display the popup screen.

Report Generator Status Icon Options



Report Generator Configure Option
SAMPLE IMAGE

Output Path Check Box

This check box will generate a Summary and Detailed Report to the Output Path specified in the Output Path entry field located to the right of the check box. If this box is not checked, no reports will be generated to the specified location.

Output Path Entry Field

This entry field will specify the location to which the Summary and Detailed Report will be generated if the Output Path check box to the left of the Output Path Entry Field is checked. If this box is not checked no reports will be generated to this specified location.

... Button

This button will allow the user to search for a location for the reports to be generated to. After a location is found, the location will be specified in the Output Path Entry Field.

Delete Files Older Than...

This entry field will specify when the files are to be deleted. The Report Generator will delete any files older than the specified amount of days prior to the current date when the new reports are generated for that day.

Archive Messages Check Box

This check box will generate an archive messages database when an Archive Path has been defined. If this box is not checked, no database will be generated to the specified location.

Archive Path

The archive messages database will be written to the folder defined in this field.

Delete Records Older Than...

To manageable file sizes, records older than the number of days filled in this field will be deleted from the MessageLogArchive database.

Report Process DLL

On some Agard machines, extended data reporting is available. The name of the dynamic link library must be entered in this field when using extended reporting.

Report Process Config

This field is reserved for future functionality.

Entry Point

On some Agard machines, extended data reporting is available. The name of the entry point must be entered in this field when using extended reporting.

Custom Configuration

Clicking this button opens the [Custom Configuration](#) page. This button is only available when the Report Process DLL field is filled in.

Test Reports/Output Button

This button will allow the user generate Summary and Detailed Reports for the current shift and prior shifts after the current shift for the prior day.

Shut Down Rpt Generator Button

This button will allow the user to shut down the Report Generator Program.

OK

This button will allow the user to close the Report Generator Configure screen and will save any changes that have been made.


Close

This button will allow the user to close the Report Generator Configure screen and will not save any changes that have been made.

Custom Configuration

Click Custom Configuration button to configure information for extended data collection. In this screen, you must indicate which C40 is associated with the given selection.

IMPORTANT: This configuration is key in order for the data to be processed properly into the ExtendedData.mdb file.



The screenshot shows a dialog box with the following fields:

- Infeed C40: 0 - None
- Cartoner C40: 0 - None
- Case Packer C40: 0 - None
- Palletizer C40: 0 - None

An OK button is located at the bottom right of the dialog box.

C40 Infeed

The C40 which corresponds to infeed product count

C40 Cartoner

The C40 which corresponds with a hard-coded position in the spreadsheet

NOTE: If the system does not have a cartoner, leave this field blank

C40 Case Packer

The C40 which corresponds with a hard-coded position in the spreadsheet

NOTE: If the system does not have a case packer, leave this field blank

C40 Palletizer/Unitizer


The C40 which corresponds with a hard-coded position in the spreadsheet

NOTE: If the system does not have a palletizer/unitizer, leave this field blank

Changeover Adjustments




Changeover Adjustments



[Training Index](#)

[Next Level 2 Training](#)


2-1 to 2-5



[Training Index](#)

[Next Level 2 Training](#)

2-1




Using crank handle, adjust scale to the value shown on the View Changeover Adjustments page for this changeover location.

2-1A



Using quick handle, adjust position to the value shown on the View Changeover Adjustments page for this changeover location.

2-2



Using crank handle, adjust scale to the value shown on the View Changeover Adjustments page for this location.

2-3




Loosen quick handle and adjust the scale to the value shown on the View Changeover Adjustments page for this changeover location. Retighten quick handle!

2-4




Loosen quick handle and adjust the scale to the value shown on the View Changeover Adjustments page for this location. Retighten quick handle!

2-5




Using crank handle, adjust scale to the value shown on the View Changeover Adjustments page for this location.

2-6 to 2-24




2-6




Using crank handle, adjust scale to the value shown on the View Changeover Adjustments page for this location.

2-7A




Loosen quick handles and replace part according to the value shown on the View Changeover Adjustments page for this location. Retighten quick handles!

2-7, 2-8



Loosen quick handles and adjust scale to the values shown on the View Changeover Adjustments page for these locations. Retighten quick handles!


2-9A, 2-9B



For 2-9A, loosen bolts or quick handles and adjust to the value shown on the View Changeover Adjustments page for this changeover location. Retighten bolts!


For 2-9B, loosen quick handles and adjust scale to the value shown on the View Changeover Adjustments page for this changeover location. Retighten quick handles!

2-10




Unscrew hand knob and move part to value shown on the View Changeover Adjustments page for this location. Replace hand knob!

2-11, 2-12



Loosen quick handles and adjust scales to the values shown on the View Changeover Adjustments page for these locations. Retighten quick handles!


2-13, 2-14, 2-14A



Adjust valves according to the values shown on the View Changeover Adjustments page for these locations.

NOTE: If valve is inline with hose, the valve is ON.


2-14B



Adjust valve according to the value shown on the View Changeover Adjustments page for this location.

NOTE: If valve is inline with hose, the valve is ON.


2-14C



Adjust valve according to the value shown on the View Changeover Adjustments page for this location.


NOTE: If valve is inline with hose, the valve is ON.

2-15

Transfer Plates


Remove or install parts according to the value shown on the View Changeover Adjustments page for this location. Tighten hand knobs underneath transfer area.

2-16



Loosen quick handle and adjust scale to the value shown on the View Changeover Adjustments page for this location. Retighten quick handle!

2-17




Remove or install part according to the value shown on the View Changeover Adjustments page for this location. Tighten hand knobs if installing!

2-18




Remove and install part according to the value shown on the View Changeover Adjustments page for this location.

2-19




Using crank handle, adjust scale to the value shown on the View Changeover Adjustments page for this location.

2-20




Loosen quick handle and adjust scale to the value shown on the View Changeover Adjustments page for this location.
Retighten quick handle!

2-21




Loosen quick handle and adjust scale to the value shown on the View Changeover Adjustments page for this location.
Retighten quick handle!

2-22




Loosen quick handle and adjust scale to the value shown on the View Changeover Adjustments page for this location. Retighten quick handle!

2-23



Lift pins and replace the parts according to the value shown on the View Changeover Adjustments page for this location. Reset pins!

2-24




Using crank handle, adjust scale to the value shown on the View Changeover Adjustments page for this location.

2-25 to 2-31




2-25




Lift pins and replace parts according to the value shown on the View Changeover Adjustments page for this location. Reset pins!

2-26




Loosen quick handle and adjust scale to the value shown on the View Changeover Adjustments page for this location. Retighten quick handle!

2-27




Loosen quick handle and adjust scale to the value shown on the View Changeover Adjustments page for this location. Retighten quick handle!

2-28




Loosen quick handle and adjust scale to the value shown on the View Changeover Adjustments page for this location. Retighten quick handle!

2-29




Using crank handle, adjust scale to the value shown on the View Changeover Adjustments page for this location.

2-30




Loosen quick handles and replace part according to the value shown on the View Changeover Adjustments page for this location. Retighten quick handles!

2-31




Replace part according to the value shown on the View Changeover Adjustments page for this location.

2-32 to 2-35




2-32, 2-33




Unscrew hand knobs and move parts to correct holes according the value shown on the View Changeover Adjustments page for this location. Retighten hand knob!

2-34




Using crank handle, adjust scale to the value shown on the View Changeover Adjustments page for this location.

2-35




Loosen quick handles and replace part according to the value shown on the View Changeover Adjustments page for this location. Retighten quick handles!

2-36 to 2-37




2-36



Loosen quick handle and adjust scale to the value shown on the View Changeover Adjustments page for this location. Retighten quick handle!

2-37




Using crank handle, adjust scale to the value shown on the View Changeover Adjustments page for this location.

3-1 to 3-2, 3-4




3-1




Using crank handle, adjust scale to the value shown on the View Changeover Adjustments page for this location.

3-2



Loosen quick handle and remove or install part according to the value shown on the View Changeover Adjustments page for this location. Retighten quick handle!

3-4



Using crank handle, adjust scale to the value shown on the View Changeover Adjustments page for this location.

Changeover Quick Reference Chart

NOTE: Please refer to the HMI for the current changeover values.

NOTE: Please refer to the HMI for the correct changeover sequence.

| Number | Name | (future products) | | |
|--------------------------------|------------------------------------------------------------|-------------------|--|--|
| CASE PACKER ADJUSTMENTS | | | | |
| 2-1 | Operator Side Magazine Width | | | |
| 2-1A | Operator Side Magazine Side Guide | | | |
| 2-2 | Non-Operator Side Magazine Width | | | |
| 2-3 | Non-Operator Side Magazine Rotate Clip | | | |
| 2-4 | Operator Side Magazine Rotate Clip | | | |
| 2-5 | Top Clip | | | |
| 2-6 | Bedplate Width | | | |
| 2-7 | Product Stop - Upper | | | |
| 2-7A | Product Stop Top Plate | | | |
| 2-8 | Product Stop - Lower | | | |
| 2-9A | Flap Tucker - Upper | | | |
| 2-9B | Flap Tucker - Lower | | | |
| 2-10 | Robot Pick Cups | | | |
| 2-11 | Robot Case Pusher Horizontal | | | |
| 2-12 | Robot Case Pusher Vertical | | | |
| 2-13 | Wide Load Vacuum Control Switch A | | | |
| 2-14 | Wide Load Vacuum Control Switch B | | | |
| 2-14A | Operator Side Load Cups On/Off | | | |
| 2-14B | RR Center Load Cups On/Off | | | |
| 2-14C | Operator Side Wide Load Cups On/Off | | | |
| 2-15 | Load Deck Transfer Plate Change Parts | | | |
| 2-16 | Top Flap Lift | | | |
| 2-17 | Product Conditioner Extension | | | |
| 2-18 | Funnel | | | |
| 2-19 | Upper Compression Height | | | |
| 2-20 | Operator Side Upper Glue Height | | | |
| 2-21 | Operator Side Tucker Rail Height | | | |
| 2-22 | Operator Side Lower Glue Height | | | |
| 2-23 | Operator Side Comp. Extension Plates | | | |
| 2-24 | Upper Compression Width | | | |
| 2-25 | Non-Operator Side Comp. Extension Plates | | | |
| 2-26 | Non-Operator Side Upper Glue Height | | | |
| 2-27 | Non-Operator Side After Tucker Rail Height | | | |
| 2-28 | Non-Operator Side Lower Glue Height | | | |
| 2-29 | Product Conditioner Height | | | |

| Number | Name | (future products) | | |
|-----------------------------|-------------------------------------------------------|-------------------|--|--|
| 2-30 | Loader Plate | | | |
| 2-31 | Fun-Tucker | | | |
| 2-32 | Dow nstacker Backstop Fixed Side | | | |
| 2-33 | Dow nstacker Backstop Adjustable Side | | | |
| 2-34 | Dow nstacker Width | | | |
| 2-35 | Dow nstack Pusher Change Part | | | |
| 2-36 | Infeed Conveyor Rail | | | |
| 2-37 | Funnel Width | | | |
| ORIENTER ADJUSTMENTS | | | | |
| 3-1 | Robot Tipper Horizontal | | | |
| 3-2 | Case Rotate Arm | | | |
| 3-4 | Conveyor Side Rail | | | |

(Print this topic as a reference when setting up new pack patterns!)

Training Index

Next Level 2 Training

Troubleshooting and Maintenance



Troubleshooting and Maintenance



NOTE: Not all items listed in this document pertain to your Aagard machinery system

Troubleshooting

NOTE: Not all items listed in this document pertain to your Aagard machinery system

Carton Quality

If you are experiencing skewed or crooked cartons, it is important to examine the carton closely, and to isolate the area of the cartoner and the exact cause.

Side Seam



Side Seam Glue Strip Not Parallel

A very slight angle may be normal for your machine, but a glue strip which is not straight indicates the carton is getting skewed before it enters the nip roller and belts. This would include Carton Picking, Moon Nip Rollers, Side Seam Rollers, and Nip Belts/Bogie Wheels.

Is the side seam glue strip not parallel to the edge of the carton?

Possible causes might be one of the following:

[Warped Cartons](#)

[Incorrect Magazine Changeover Location Values](#)

[Incorrect Carton Picker Position](#)

[Vacuum Cups Wear or Damage](#)

[Incorrect Moon Nip Roller Pressure](#)

[Incorrect Nip/Metal Roller Gap](#)

[Nip Belts and Bogie Wheels Bind or Jam](#)


[Bogie Wheel Tension Against Nip Belt](#)

Warped Cartons

Are the carton blanks badly warped?

There are **NO** special adjustments which will fix carton pick/feed problems when warped cartons are involved. However, listed here are some things that you might try:

- Raise or lower the Top Carton Guide adjustment
 - a .030 -.060 gap is desired
 - **NOTE:** A carton with warp will not stand vertically as tall as a carton without warp
- Widen the Carton Magazine Width adjustment
 - a .030" gap is desired
- Turn magazine blower off and/or turn air knives on
 - These functions will help separate carton blanks if the warp causes excessive pressure on the clips and spring pressure bar
- Back-break a small group of cartons before loading into magazine as a last resort
 - Replacing with good cartons is desired



Did this solve the problem?




Incorrect Magazine Changeover Location Values

Are the magazine changeover location values correct for the currently-downloaded product?

Check values of all magazine changeover locations for accuracy.

Especially check the correct Magazine Pressure Bar Extension part for the larger carton products, and the correct Carton Pick Stop part, if used, for the smaller carton products.



The Top Carton Guide and Carton Magazine Width adjustments are important, especially if the cartons are warped. There must be clearance so the cartons can be pulled out of the pressure bar easily. Warped cartons may bind on the top or side as they are flattened out.

Did this solve the problem?



Incorrect Carton Picker Position

Is the carton picker correctly positioned?

Reference the carton picker servo drive, if necessary

- Use the visual reference marks to verify servo has referenced to its proper location
-

Did this solve the problem?



Vacuum Cups Wear or Damage

Are the vacuum cups worn or damaged?

Check the vacuum cups for wear and/or damage, and replace if necessary.

NOTE: The on/off vacuum timing is critical and should not be changed, unless authorized by Aagard.


Did this solve the problem?



Incorrect Moon Nip Roller Pressure


Do the four vertical urethane moon nip rollers have even pressure?
Do they just touch the outer surface of the Moon Nip?

The four vertical urethane moon nip rollers should have even pressure and just touch the outer surface of the Moon Nip.



Adjusting Moon Nip Roller Pressure

The four moon nip rollers are adjustable as a group. Each roller should be adjusted within its mounting slot so they are all on the same plane. Then, the assembly plate should be adjusted at the top and bottom so the rollers just touch the outer surface of the moon nip.




Did this solve the problem?



Incorrect Nip/Metal Roller Gap


Is there proper gap between the urethane nip roller and the bottom metal roller?

There should be a .008" - .010" gap between the bottom metal and urethane nip rollers




The gap between the metal and neoprene rollers is adjusted using a jacking bolt on the neoprene roller assembly. Care should be taken to loosen all the mounting bolts before adjusting.

NOTE: Some bolts may be mounted from beneath the assembly



Adjustment bolt



Mounting bolts
(beneath assembly)

Did this solve the problem?



Nip Belts & Bogie Wheels Bind or Jam

Do the bogie wheels bind or jam when pushed against the spring?

When the bogie wheels are pushed against the spring, they must not bind or jam.

- Inspect belts and replace, if necessary
 - Inspect wheels and replace, if necessary
-

Did this solve the problem?




Bogie Wheel Tension Against Nip Belt

Does the bogie wheel assembly have equal tension along the belt?

The Bogie wheel assembly must have equal tension along the belt.

- Adjust the wheels so they just touch the belt, and then go in against the belt an additional 1/8"
- When a carton is in the nip belts, it should not slip
- When turning the nip belts by hand, the carton cannot be held or slip in the belts



Did this solve the problem?



Uneven Side Seams

Are any of the buckets bent or damaged?

A bent bucket can cause uneven side seams.

- Inspect each bucket
-

Did this solve the problem?




Side Seam Fold Not on Score Line

Is the glue strip straight but the flap is not folded on the score line?

The score line of the side seam will line up with the bottom side of the rail, as indicated with the "Side seam score line" callout below.

- Adjust the Side Seam Height adjustment
- Examine rollers for binds and dirt buildup; clean, if necessary



The last roller is adjustable and should not be changed from its factory setting. If it is too tight, it will drag too hard on the side seam, causing the carton to skew in the nip belts.

Did this solve the problem?



Side Seam Not Straight


Is the side seam not straight?

If the side seam is not straight, check the adjustment of the Carton Forming Overhead Rail Height adjustment.

This is a critical adjustment.

- The rail should be 1/32" – 1/16" (approximately 1 mark on the scale) above the top edge of the bucket
 - If this is too high, the side seam will be above the score line

CAUTION: If the adjustment is too low, it can cause damage to the buckets and/or skew the carton



Additionally, check items in [Side Seam Fold Not on Score Line](#)


Did this solve the problem?




Deck Extension Fingers Damage

Are the side seam extension fingers bent?

If fingers are bent down, the bottom of the carton drops down causing the side seam to be too high.



The fingers are located in the deck opening where the compression comes up from underneath. See the top view mechanical drawing below.



Did this solve the problem?



Side Seam Damage

Is the side seam damaged?

The compression flight and/or the tucker timing might be off causing the flap to come down on top of the flight

- Reference barrel cam if timing is off
-

Did this solve the problem?





Incorrect Carton Magazine Horizontal Adjustment Value

Is the distance between the carton stop and carton slot guide correct?

The Carton Magazine Horizontal adjustment sets the distance between the carton stop and the carton slot guide.

- It should be approximately 1/16" greater than the carton width
 - If it is too loose, the carton can tip
 - If it is too tight, the carton can skew when forming around the bucket



Did this solve the problem?



End Flaps



Out-of-Square End Flaps

Are any of the buckets bent or damaged?

A bent bucket can cause out-of-square end flaps.

- Inspect each bucket
-

Did this solve the problem?



Incorrect Magazine Height Adjustment Value

Are the operator side and/or non-operator side end flaps bent or damaged?

The Magazine Height adjustment should be adjusted so the carton slot lines up with the welded tab on the bucket.

Did this solve the problem?





Incorrect Vertical Slot Guide Adjustment Value

Are the operator side and/or non-operator side end flaps bent or damaged?

With a carton aligned with the tab on the bucket and its non-operator side edge flat against the Carton Stop, the Vertical Slot Guide adjustment must line up with the operator side carton slot.

One way to check the vertical slot guide is to hang a carton by its slots between the bucket tab and the vertical slot guide. The top edge of a straight bucket can be compared to the carton score line.



Did this solve the problem?



End Flaps Damage

Are the operator side end flaps and/or non-operator side end flaps bent or damaged?

- Reference the barrel cam
-

Did this solve the problem?



Cartons Not Cut Correctly

Are the cartons cut correctly?

Examine the cartons closely to ensure they are made to specifications.

Determine if the cartons really are not square, or if they are square but the end flaps are cut so they just appear crooked? If the end flaps are cut crooked, determine if the carton blanks are acceptable for use. Replace if necessary.

Did this solve the problem?




Incorrect Overhead Rail Height Adjustment Value

Is the Overhead Rail adjustment correct?

Check adjustment of the Overhead Floating Top Rail. The Overhead Floating Rail is adjusted with the Overhead Rail adjustment.

- Verify the Floating Rail does not bind and is free to move up or down
- The Overhead Rail can be adjusted slightly lower to help with warped cartons, but it must not be so low that it causes cartons to drag.




Did this solve the problem?



Incorrect Bed Plate Adjustment Values

Are the operator side and non-operator side bed plates too tight or too loose?

- When the Operator Side Bed Plates or Non-Operator Side Bed Plates adjustments are too tight, the carton can drag /skew backwards
- Bed plates too loose will allow the carton to move and skew before the glue is dry




Did this solve the problem?



Incorrect Tucker Disk Installed

Is the correct tucker disk installed on the downstream tucker?

- Verify correct disk(s) are installed on downstream tucker
- After correct tucker disk is installed, verify correct timing; reference barrel cam if necessary



Damaged end flaps can also be an indication of feed problems. Check: [Side Seam Fold Not on Score Line](#)



Did this solve the problem?



Skewed End Flaps

Are the end flaps skewed because the side seam is crooked?

Skewed end flaps may be caused when the side seam is skewed. Check to ensure the side seam is straight.




Did this solve the problem?



Bent Dust Flap Plows

Are the dust flap plows bent?

Check the condition of the top and bottom Dust Flap Plows.




Did this solve the problem?



Glue Buildup - Dust Flap Plows

Is glue build up causing the carton to drag?

Check for glue buildup on the top and bottom Dust Flap Plows. Glue buildup can cause the carton to drag.




Did this solve the problem?



Glue Buildup - Major Flap Plows

Is there glue buildup on the Top and Bottom major flap closing plows?

- Check for glue buildup on the Top and Bottom major flap closing plows
- Check to ensure Top and Bottom major flap plows are in their factory-marked positions




Did this solve the problem?



Glue Buildup - Side Rails

Is there glue buildup on the Side Rails?

Carton must stay back against aluminum flight block to ensure proper dust flap tucking and squareness.




Did this solve the problem?



Glue Buildup - Carton Forming

Is there glue buildup in the Carton Forming area?

Check for glue build-up in the Carton Forming area, especially the side seam compression.



Side seam compression
(quantity: 3)

Glue build-up


Did this solve the problem?



Incorrect Overhead Brush Position

Is the Overhead Brush in the correct position?

The Brush is adjusted with the Carton Forming Overhead Rail adjustment. It should never be adjusted separately using the slotted mounting holes; the factory setting is marked and should not be changed.



Did this solve the problem?




Locked Dust Flap Corners

Are the dust flaps locked?

Warped cartons can sometimes cause the dust flaps to lock with the top and/or bottom end major flaps. This will cause open flaps and/or skewed cartons.

- Check the corners of the dust flaps
- Lower Overhead Rail Height adjustment



Did this solve the problem?



Film



Film Not Aligned

[Is the tracking running constantly, running to one side or the other?](#)

[Are the two films not aligned at the side seal?](#)

Tracking Running Constantly or Side to Side

Is the tracking running constantly, running to one side or the other?

Tracking running constantly, or running to one side or the other may be caused by one of the following:

- Dirty rollers
- Film not being sensed
- Faulty photo eyes
- Film out of specification

Take these steps to resolve this issue:

- Clean nip rollers and tracking rollers
 - Clean photo eye
 - Check film to see if it is within specification
-

Did this solve the problem?



Films Not Aligned At Side Seal

Are the two films not aligned at the side seal?

The two films not aligned at the side seal may be caused by the following:

- Alignment film alignment sensor is incorrect
- Film is incorrectly placed on spool

Take these steps to resolve this issue:

- Clean nip rollers
 - Clean tracking rollers
 - Clean photo eyes
 - Adjust lower nip roller tracking photo eye (PE42101)
 - Adjust upper nip roller tracking photo eye (PE57904)
-

Did this solve the problem?



Check Photo Eyes

- 1) Check function of photo eyes
 - a) If the photo eye is functioning correctly but is not seeing the reflector, replace reflector
 - b) If the photo eye is not functioning correctly, replace the photo eye

Did this solve the problem?



Film Not Sealing Properly

Is the film not sealing properly?

Film not sealing properly may be caused by the following:

- The temperature is set incorrectly

Take these steps to resolve this issue:

- Clean sealing bars
 - Check alignment of sealing bars
 - Adjust heater bar temperatures
-

Did this solve the problem?



Splice Tape In Side Seal

Is film broken or non-sealed?

Broken or non-sealed film may be caused by the following:

- Missed changeover adjustment

Take these steps to resolve this issue:

- Check changeover adjustment position
 - Review film path to ensure it is correct
-

Did this solve the problem?



Safety Circuit



Messages on HMI Screen

Which of the following messages are appearing on the HMI?

Case Packer Software E-stop message

Follow this [link](#)

Unitizer Software E-stop message

Follow this [link](#)

Case Packer Safety Relay message

Follow this [link](#)

Unitizer Safety Relay message

Follow this [link](#)

Case Packer Guard Relay message

Follow this [link](#)

Unitizer Guard Relay message

Follow this [link](#)

Emergency Stop message

Pull all depressed E-Stop buttons

Guard Door message

Close all open guard doors

Light Curtain message

Remove light curtain obstructions

Did this solve the problem?



Prior Safety Circuit Rewiring

Was any rewiring done on safety circuit prior to this issue?

If so, was power removed from machine when this was done?

If not, then you may need to cycle power to reset safety relays.

If either channel 1 or 2 is open before the other, it can cause the safety relay to go into a lockup. This situation requires power cycling to reset. This typically happens if someone was working on guard circuit wiring and hooked up one channel before the other; both channels need to open and close at the same time.

Sample Image

Did this solve the problem?



Channel 1 and 2 Safety Relay Input Lights

Are channel 1 & 2 safety relay inputs lit when all guard doors are closed and E-stops pulled out?

If one or both channels are not lit, use a volt ohm meter to check each loop. Once an "open" in the circuit is found, check device preceding that "open" in the circuit.

E-Stop Buttons, Guard Relays, and Software E-Stop Relays are in the channel 1 & 2 safety loops.

Sample Image

Did this solve the problem?



Safety Reset Relay Malfunction

Is safety reset relay functioning when output is turned on?

If not, there are two possibilities:

Check wiring from output slice to relay and 24VDC common wire. If wiring is good and power is getting to the relay when output is turn on but relay doesn't function, replace relay.

Check to make sure contacts are closed from pins 11 to 14 on the relay when it is energized. If contacts are not closing when relay is energized, replace relay.

Sample Image

Did this solve the problem?



Open Monitoring Loop

Is monitoring loop closed?

Verify that monitoring loop is closed by checking terminal points Y1 to Y2 on main safety relays for each machine section.

Sample Image

If there is an open in this circuit, determine which component is causing the open; every component in this circuit should have N/C contact.

Check for loose wiring or if component has failed. Replace if necessary.

Did this solve the problem?



Channel 1 and 2 Output Lights

Are both channel 1 and 2 output lights lit when system is reset?

If one or both lights are not lit, it is possible there is a faulty relay with a sticking output contact. Replace relay.

Sometimes tapping rather aggressively on relay with screw driver handle will jar contacts loose to make it work again, but the relay still needs to be replaced.

Sample Image

Did this solve the problem?



Channel 1 and 2 Guard Relay Lights

Are channel 1 and 2 guard relay lights lit when all guard doors are closed and E-stops pulled out?

If one or both channels are not lit, use a volt ohm meter to check each loop.

Older Aagard systems with Sentrol guard switches will need to have continuity checked from the start of the channel loop to each termination point, until complete loop is checked for an open point. Check continuity with an ohm meter from the start of the loop, checking each component as you move through the loop.

NOTE: Always keep one end at start of loop

Newer Aagard systems with RFID guard switches can be checked for voltage at each termination point from the start of the channel loop until end of the loop, looking for lack of voltage.

Once an "open" in the circuit is found, check device preceding that "open" in the circuit; it is most likely the cause of the issue.

Check for loose or frayed wiring, or if component has failed. Replace if necessary.

Sample Image

More help:

[SensaGuard RFID Switches](#)

[Guard Master TSL-GD2 Switches](#)

Did this solve the problem?



SensaGuard RFID Switches

Is guard door indicator light, at guard door, flashing green/orange?

Typically, this means magnet is too far way from switch in threshold area; switch will still work, allowing guard circuit to function properly.

Take loose magnet and move next to switch to be sure switch indicator light changes to green only

- If it does not change to green only or flashing green, then faulty switch which needs to be replaced
- If it does change to green, then remount magnet or switch closer to each other so they are not in threshold range

Is guard door indicator light, at guard door, flashing green?

This means an upstream guard door is open.
Follow guard door loop back to open guard door and close it.

Is guard door indicator light, at guard door, red?

This means a guard door is open.
Close guard door.

Is guard door indicator light, at guard door, flashing red?

This means there is a hard fault.
Try cycling power to safety circuit and inputs.

Additional resource for SensaGuard RFID switches troubleshooting:

[SensaGuard Rectangular Flat Pack Install](#)

Guard Master TLS-GD2 Switches

Additional resources for TLS-GD2 Guard Master switches troubleshooting:

[TLS-GD2](#)

[TLS GD2 Locking Guard Door Switch](#)

Servo Drives



Blown Fuses

Are you experiences a high rate of blown fuses?

- 1) View fault history for all drives
- 2) View and record the Fault Status on the HCS (servo power supply) display by viewing the HCS display in the electrical cabinets
- 3) If fuses have blown, locate the KCU (servo control unit) which has the blown fuses and determine which one controls which motor drive combinations in the electrical cabinet
- 4) Power down the machine for at least 3 minutes to allow the DC Bus Voltage to dissipate
IMPORTANT: Verify that the Bus voltage has dissipated with a volt/ohm meter
- 5) Visually and physically inspect the cables (kinked, cut, cracked, too tight bend radius, loose connectors) and remove, if necessary
SAFETY: Only remove if power has been removed from the servo system and capacitors have drained. There can be a potential for up to 700 volts DC in the system; running hands across cables before power has been removed is not recommended
- 6) Visually and physically inspect all plug connections, ensuring they are tight and secure, both out at the motors and on the KCU
- 7) If there is a second KCU tied to the HCS, remove it from the HCS by removing the bus bars and the ribbon cable
- 8) Locate the terminating plug at the end of the line for the KCU unit which has the blown fuses
- 9) Relocate this plug to the first motor drive combo on that line, eliminating the rest of the motors and cables on the machine for that KCU unit. The first motor on the line is the first one on the orange what from the electrical cabinet
- 10) Replace **BOTH** fuses in the KCU unit and the supply fuses for the HCS (power supply), even if only one fuse is blown
NOTE: The **KCU** unit fuses are 30 amp fuses
NOTE: The **HCS** fuses are 15 amp fuses in the 480 supply
- 11) Restore power to the machine and monitor the incoming power to the HCS with an amp meter on power up and during testing
- 12) Test the motor drive combo for proper operation. If operation is correct, power down the machine for a minimum of 3 minutes and verify bus voltage has dissipated before moving on to the next motor drive combo. If the operation of the motor drive combo does not operate and blows the fuses, refer back to steps 1, 2, 4, 10, and then step 13
- 13) Determine if the motor drive combo or the cable is bad. Inspect the cable for damage. If there are no signs of damage to the cable, replace the motor drive combo. If there is no physical damage to the cable, this does not mean that the cable is NOT bad. If the cable appears to be damaged, replace the cable. If there are no error messages on the drive, then suspect the cable
- 14) Keep moving the terminating plug to the next motor drive combo until the fuses blow in the KCU unit. Once found that the fuses have blown or proper operation does not occur, refer back to steps 1, 2, 4, 10 and then step 13

NOTE: This test cannot be performed without disabling the motor drive combos that are not in the loop of communication, or the ones that are past the terminator plug for that KCU unit. Only Aagard can disable each of the drives at this time

NOTE: If at any time during this process a faulty or damaged component is found, it is still recommended to continue adding one servo at a time to the loop to ensure that no other problems exist; if they do exist, we would be able to isolate them in an effective manner

Did this solve the problem?



F8060 Errors

Are you seeing F8060 drive errors?

The F8060 drive error indicates over-current in the power section.

1. Restart machine
-

Did this solve the problem?



Cycle Power

After restarting the machine, do the F8060 errors persist?

- 1) Cycle power on the machine
 - 2) Restart machine
-

Did this solve the problem?



Check Cabling

After cycling power, do the F8060 errors persist?

- 1) Check all cabling to drive (kinked, cut, cracked, too tight bend radius, loose connectors) and address any problems
-

Did this solve the problem?



Replace Drive

After completing all previous troubleshooting methods, do the F8060 errors persist?

1) Replace drive

Additional Verification Steps:

If the issue has been resolved by replacing the drive, reinstall the faulty drive to verify failure. If the error returns, reinstall the replacement drive; if the error does not return, monitor the drive for other error codes or how quickly the F8060 error code may return, and under which circumstances

Did this solve the problem?



SERCOS Communication




Ring

Introduction

SERCOS is an abbreviation for SErial Real-time COmmunication System

IMPORTANT NOTE: Due to the complex nature of SERCOS, it is highly recommended to contact Aagard for SERCOS related support issues

If you are experiencing issues with SERCOS, this guide will help you troubleshoot the SERCOS ring. First, before doing any troubleshooting on the ring, locate the electrical prints and go to the SERCOS Loop page. Below is a simple example which demonstrates the SERCOS loop starting at the PC and continuing through the rest of the devices in the system, and then finally returning to the PC.



NOTE: The system may have two SERCOS rings, with one setup as the master; if the master ring goes down, the slave ring will go down as well. If the slave ring goes down, the master ring might not go down.

NOTE: If your system is using MI motors, the SERCOS will go from the KCU through all of the drives on that KCU before communication leaves the KCU. If your system uses IndraDrive motors, the SERCOS loop will go through each servo drive through fiber optic cable

NOTE: Machines built prior to 2009 may not have the SERCOS Loop page defined in the electrical drawings; it is a good idea to draw one out.

IMPORTANT NOTE: References to the SERCOS loop page in the prints will be made throughout the rest of the document, so please keep it handy. Also, it is important to remember that, in troubleshooting SERCOS, you will always start from the PC and work your way through the devices in the order in which they appear in the loop


Before troubleshooting may begin, the System Manager must be open. To open the System Manager, follow this [link](#).

If you already know how to open the TwinCAT system manager, click [here](#).

Opening System Manager


To open the TwinCAT system manager to help troubleshoot phases and count issues, follow these steps.

- 1) Go to C:\Aagard\Source Code\Controller and open the TwinCAT System Manager (.tsm) file labeled with the machine # (### Proj.tsm)
- 2) Once open, go to the SERCOS device in the tree on the left, shown in this example.



NOTE: Each SERCOS device will have three slanted red lines as a symbol. From this point, we can manually change phases, set up parameters on the SERCOS card, and view error counts.

We will be using the online tab to help us manually cycle through phases.



Now that we have the SERCOS loop print page and TwinCAT system manager open, we are ready to begin troubleshooting.

[Begin Troubleshooting](#)

Which Sercos Issue?

Which issue are you having with SERCOS?

[Cannot Get Phase 0](#)

[Cannot Get Phase 1](#)

[Cannot Get Phase 2](#)

[Cannot Get Phase 3](#)

[Cannot Get Phase 4](#)

[Losing Phase 4](#)

[Multiple Error Counts and Unstable Ring](#)

Cannot Get Phase 0

Are you unable to achieve phase 0?

To achieve phase 0, there must be a complete and closed loop. If you cannot achieve phase 0, the ring is not closed, meaning there is a break somewhere in the loop.

First, start by checking the most obvious items in the loop. Using the SERCOS loop page from the prints, start at the PC and work your way out.

Inspecting Cables

- 1) Check each cable for proper connection. Connections should be hand tightened only; no wrenches should be used. If over-tightened, the fitting can become damaged
 - 2) Check cables for damage. Look for any obvious damage to cables, splices, wear and tear, and repair if any damage is found
 - 3) Check cable radius. Cables should not have a bend in them with a radius of less than six inches; a small radius in the cable can cause SERCOS errors
 - 4) See [SERCOS Fiber Optic Cable Assembly](#) for more information
-

Did this solve the problem?



Inspecting Bricks

Inspecting Bricks

- 1) Ensure bricks inside the electrical cabinets have power. Check 24-volt power to each brick; voltage should be greater than 24-volts and stable
- 2) Check LED status. The LEDs on the brick can give immediate information about the brick. Check LED status for error. For more information, see page 17 and 18 in [SERCOS Coupler BK7500](#). Look for *The diagnostic LEDs*, *Code of flashes* paragraphs and the *Terminal bus error* table
- 3) Ensure baud rate is set correctly. Check the first I/O page in the electrical drawings for baud rate setting and set brick accordingly

NOTE: Changing the baud rate will require cycling the power on the brick for it to take effect. For more information, see *Setting the Transmission Rate* topic on page 19 in [SERCOS Coupler BK7500](#)

- 4) Check intensity setting. Make sure transmission setting is set to those in the electrical drawings (first I/O page) and it matches the proper length of the corresponding SERCOS cable. For more information, see the *Setting the Cable Length* topic on page 19 in [SERCOS Coupler BK7500](#)
-

Did this solve the problem?



Drive type?

Which type of drive do you have?

IndraDrive

MI Drive

Inspecting Servo Drives *(applies to IndraDrive)*

- 1) Ensure drives have power
 - 2) Ensure baud rate is set correctly
 - 3) Check transmission setting. For information on how to check the transmission setting, see the *Switch S20* section on page 137 and 138 in [Rexroth ECODRIVE03 Drive Controllers](#)
-

Did this solve the problem?



Inspecting KCU *(applies to MI drives)*

- 1) Ensure HCS and KCU have power
 - 2) Check transmission setting. Make sure transmission setting is set to those in the electrical drawings (See servo wiring pages) and it matches the proper length of the corresponding SERCOS cable. For more information, see *S6, SERCOS Transmission Power* table on page 65 in [Rexroth IndraDrive MI Drive Systems](#)
 - 3) Check wiring sequence of motors from KCU. SERCOS communication travels through each motor after being converted in the KCU from optic to electrical. The sequence of cables to each MI motor and the terminating plug must be properly set up. For more information, view [Proper Wiring Order for MI Motors](#)
-


Did this solve the problem?



Inspecting TwinCAT System Manager Settings

To inspect the TwinCAT System Manager Settings, follow these steps.

- 1) On the FC75xx tab, check transmission setting (Send Power)
- 2) Ensure baud rate is set correctly. The baud rate must match those in the electrical drawings for the devices



Did this solve the problem?



Eliminate Items in the Loop

If you have checked all of these items above and did not find a problem, then there is a simple technique to locate the break in the loop. To start this process of elimination, you must first get a SERCOS test cable and then systematically work your way out from the PC.

- 1) Start by connecting a test cable to the receive (Rx) and transmit (Tx) ports of the SERCOS card in the PC
 - 2) Check if you have phase 0
 - a) If you do not have phase 0, the card has failed
 - b) If you do have phase 0, run the test cable from the Rx port of the card to the Tx port of the first device in the loop
 - i) If you do not have phase 0, the issue is either with the device or with the cable between Tx port of the card and the Rx port of the cable. To determine if it is the device or the cable, use another test cable from the Rx port of the first device in the loop back to the Tx port of the card
 - (1) If you have phase 0, the cable has failed
 - (2) If you do not have phase 0, the device has failed
 - 3) Sequentially, move to subsequent devices, repeat the above steps to isolate the problem
- NOTE:** Always connect the test cable connected to the card Tx port with the device Rx port
NOTE: When a second test cable is required to determine if a specific cable or device has failed, always connect the Tx port of the previous device with the Rx port of the current device


If you make it through all the devices with phase 0 at every point, then the problem may reside in the last cable back to the PC. While this method will quickly find where a break may occur, additional troubleshooting will be needed to determine issues with devices in the loop.

Did this solve the problem?




SERCOS Fiber Optic Cable Assembly


- 1) Cut the sheath of the 6mm fiber optic cable 2" from the end of the cable
- 2) Cut the fiber optic cable 1" from the end of the sheath
- 3) Strip the fiber optic jacket ½" from the end of the sheath with the 1mm fiber optic stripper




- 4) Slide the Rubber Strain relief onto cable
- 5) Slide metal crimp sleeve onto cable
- 6) Assemble the connecting nut and the connecting nose and slide onto cable, make sure the connecting nose is pushed under the sheath up to the raised knurled stop
- 7) Crimp with the "A" opening on the fiber optic crimper as shown in the diagram below




- 8) Pull Kevlar strands to remove any slack bunched up under the sheath



- 9) Cut the Kevlar strands ½" from the end of the sheath
- 10) Trim the fiber cable from the front of the nose, leaving enough to sand flush



- 11) Apply plastic half shell as shown in the diagram below
- 12) Slide the Metal crimp sleeve over the plastic half shell
- 13) Crimp the Metal sleeve with the "B" opening on the fiber optic crimper



- 14) Screw the new cable end completely into the fiber optic sanding puck
- 15) Place a fine sheet of sanding paper on a flat surface
- 16) Sand the fiber in a figure eight motion using the sanding puck

Technical Notes

Max Bend Radius:

- 2.2mm = 2" (Internal cabinet use)
- 6.0mm = 3.5" (External Cabinet use)

The not shielded cable must never be used outside an electrical cabinet.

Avoid coiling the Fiber Optic cables, this distorts the attenuation of the light waves.

Cannot Get Phase 1

When transitioning to Phase 1, the device addresses are checked. If an address is not found, it cannot transition to Phase 1. Typically, a message like this will be displayed:



TwinCAT I/O will report the address it cannot find. Check that device for proper address.

Setting drive addresses


- 1) For information on how to set the brick address, see the *Setting the Station Address* topic on page 20 in [SERCOS Coupler BK7500](#).
- 2) For information on how to set the IndraDrive address, see the *H1, S1, S2, S3: Diagnostic display, Reset key, Address switch* topic on page 202 and the *Setting the Drive Address* topic on 203 in [Rexroth ECODRIVE03 Drive Controllers](#)
- 3) To set the MI motor address, see the S5 and S4 settings in the *Setting/Description* table on page 108 in [Rexroth IndraDrive Mi Drive Systems](#)

Did this solve the problem?



Cannot Get Phase 2

In transitioning to phase 2, load communication parameters are checked.



Issues with IDNs on the servo drives may need to be resolved.

- 1) Try doing a full initialization for the drive that has the error, through the SERCOS diagnostics page in the HMI; if problem persists go to the next step
- 2) Try replacing drive which has the error
- 3) **Do not attempt this step without first calling Aagard for support:** Read IDN S-0-0021 for invalid list of IDNs. Change the operation data for those IDNs within value range and insert those IDNs in the Edit Slave Startup List. Read S18 to determine if there are specific IDNs which must be sent. Check to see if phase 3 communication check passed

Did this solve the problem?



Cannot Get Phase 3

In transitioning to phase 3, the process loads other drive parameters. If it fails here, there may be an issue with drive data.

- 1) Try doing a full initialization for the drive that has the error, through the SERCOS diagnostics page in the HMI; if problem persists go to the next step
- 2) Check HMI drive data to ensure it is valid by checking the HMI Change Log to determine if changes were made. Otherwise contact Aagard support to determine valid drive data
- 3) **Do not attempt this step without first calling Aagard for support:** Read IDN S-0-0022 for invalid list of IDNs. Change the operation data for those IDNs within value range and insert those IDNs in the Edit Slave Startup List. Also read IDN S-0-0019 to be sure all IDNs required in phase 3 have been sent. Check to see if phase 4 communication check passed

Did this solve the problem?



Cannot Get Phase 4

In transitioning to phase 4, the ring begins exchanging cyclic data. If it fails here, there may be an issue with drive data, or the firmware of the drive.

- 1) Try doing a full initialization for the drive that has the error, through the SERCOS diagnostics page in the HMI; if problem persists go to the next step
- 2) Check HMI drive data to ensure it is valid by checking the HMI Change Log to determine if changes were made. Otherwise contact Aagard support to determine valid drive data
- 3) **Do not attempt this step without first calling Aagard for support:** Read IDN S-0-0022 for invalid list of IDNs. Change the operation data for those IDNs within value range and insert those IDNs in the Edit Slave Startup List
- 4) **Do not attempt this step without first calling Aagard for support:** Read IDN S-0-0030 for manufacturer version; make sure the version is V30 (MPB-04V30)

Did this solve the problem?



Losing Phase 4

Losing Phase 4 can be caused by error counts in the ring (for example, lost packets of data) or loss of power.

- 1) Check 24-volt power source to devices in the ring, and make sure power is not being lost
 - 2) If error counts precede the loss of SERCOS, consider [stabilizing the ring](#)
-

Did this solve the problem?




Multiple Error Counts and Unstable Ring

It is highly recommended to call Aagard for support for this topic.

Error counts are caused by lost information in the ring. These error counts come as warnings, but may point out a future failure waiting to happen. When error counts are seen, it is a good idea to stabilize the ring.

NOTE: The higher you can set the baud rate, the more stable you can get the ring. If you can set the baud rate to 8 MBaud, then stabilize it, and then set it down to 4 MBaud; the ring will be more stable

NOTE: It is a good idea, before beginning this process, to follow the same instructions on checking devices and cables in the system as described in the [Cannot Get to Phase 0](#) topic



Working your way out from the start of the ring, follow these instructions:

- 1) Make sure that each intensity setting is set to the appropriate length of cable through which it is sending
- 2) Get the ring to phase 4 by clicking the Set Phase 4 button on the Online tab
- 3) One by one, check how far the cable end can be removed from the device before the ring goes down; only one end per cable needs to be tested
NOTE: The ring will need to be reset to phase 4 before testing the next cable
- 4) If the ring goes down before the connector is about half way unscrewed, boost the intensity on the FC 75xx tab through that cable by one notch and re-test
NOTE: If the intensity setting is modified, the configuration file must be activated
- 5) If still unstable, check and/or replace the cable and test again

- 6) After all the cables have been checked in this fashion, run the machine. After multiple e-stops and starts, check the error counters on the input section of the SERCOS card in TwinCat system manager; these should be all zero
- 7) If the error counters are not all zero, then check IDN S-0-0028 and IDN S-0-0029 on each of the SERCOS devices. These are error counters in the devices themselves
 - a) If there is a device with more errors than others, suspect the cable or intensity immediately before this device
 - b) If all of the devices have errors, but they all have the same amount, suspect the first cable out of the SERCOS Card, or the intensity setting of the SERCOS Card
 - c) If none of the devices have errors, but there are still error counts on the SERCOS card, suspect the last cable, or the intensity setting of the last device

NOTE: Too weak of a signal will have the same symptoms as too strong of a signal. This is because a weak signal will not be strong enough to decipher, but too strong of a signal will distort the electronics of the optic receiver, also making the signal undecipherable

Did this solve the problem?



Functional Stability

NOTE: This topic applies to the Rexroth MI drive system

To test the functional stability of SERCOS communication, check the following areas of concern:

[Error Counters](#)

[Drive Firmware Version](#)

[Control Voltage](#)

[Motor Temperature](#)

[Noise Measurement](#)

[Checklist to Record Test Results](#)

Error Counters

Stable Condition:


Circled error counts in the sample image below should not be incrementing.

How to Check:

From the HMI Main Screen, navigate to Advanced > Motion Bus Diagnostics

- The counts circled in red should be a small number, incrementing less than 5 per hour
- For each drive, the counts circled in blue should be a small number, incrementing less than 10 per hour

NOTE: These counts continue to increment until the SERCOS ring is reset or power cycled; this means the numbers may be higher if the system has been powered up for an extended period of time



Resolutions:

If SERCOS Error counters are high:

- Look for loose servo cables
- Look for loose or kinked fiber optic cables
- Verify the SERCOS intensity setting switch matches the print


Drive Firmware Version

Stable Condition:

For each drive, the drive firmware should be 04V30 as shown in the following image.

How to Check:

From the HMI Main Screen, navigate to Advanced > Motion Bus Diagnostics



Resolution:

Update the firmware to 04V30 if it is incorrect.

Control Voltage

IMPORTANT NOTE: The machine must be running to test control voltage!

Stable Condition:

No drive Error Codes of F8069 or F8070 are recorded and the HCS and KCU control units is between 24 and 27 volts DC.

How to Check:

From the HMI Main Screen, navigate to Advanced > Motion Bus Diagnostics

- For each drive, look for Error Codes of F8069 or F8070
- Measure the control voltage to the HCS and KCU units to be between 23 and 26 volts DC
 - Measure voltage at the device

| Fault Codes (P192) | | Diagnostic Codes (S375) | |
|--------------------|-------------------------------------------------------|-------------------------|--|
| Error Code | Description | Date/Time | |
| F2174 | Loss of motor encoder reference | 11/16/2010 | |
| F2174 | Loss of motor encoder reference | 11/16/2010 | |
| F8022 | Enc. 1: enc. signals incorr. (can be cleared in ph... | 11/16/2010 | |
| F2174 | Loss of motor encoder reference | | |
| F2174 | Loss of motor encoder reference | | |
| F2174 | Loss of motor encoder reference | | |
| F2174 | Loss of motor encoder reference | | |
| F2174 | Loss of motor encoder reference | | |

Manufacturer Version: FWA-INDRV*-MPB-04V24-D5-1-NNN-NN

Resolutions:

- Check power supplies
 - Output voltage
 - Error status
 - Intermittent issues
- Wiring Issues
 - Loose wires
 - Bad connections
 - etc.

Motor Temperature

Stable Condition:

The temperature of each drive should not exceed 90° C after continuous running (approximately eight hours)

How to Check:

Open System Manager and navigate to I/O Configuration > I/O Devices > Device 1

- On the online tab, view the S-0-0384 parameter value for each axis listed

The screenshot shows the 'I/O Configuration' window for 'Device 1 (FC75xx)'. The 'Online' tab is active, showing a table of diagnostic parameters. A red arrow points to the 'S-0-0384 Amplifier temperature' parameter, which has a value of 26.9 °C. The 'Online' tab label is circled in red.

| IDN | Name | Unit | Value |
|----------|-----------------------------------------|------|-----------|
| S-0-0375 | List of diagnostic numbers | -- | (list) |
| S-0-0378 | Absolute encoder range of motor enc... | Deg | 73728.000 |
| S-0-0379 | Absolute encoder range of optional e... | Deg | 0.000 |
| S-0-0380 | DC bus voltage | V | -2.2 |
| S-0-0382 | DC bus power | Watt | 0 |
| S-0-0384 | Amplifier temperature | °C | 26.9 |
| S-0-0386 | Active position feedback value | Deg | 110.513 |

Resolutions:

- If too hot, clean the motor so it can dissipate heat properly
- Look for mechanical binding issues
- Compare motion profile of drive to baseline values
- Compare torque limits to baseline values

Noise Measurement

IMPORTANT NOTE: The machine must be running to test noise measurement!

Stable Condition:

Excessive noise should not be detected at the 24V connections of the PC, KCU units, or other components in the SERCOS ring, such as 24V power supply or I/O modules.

How to Check:

Using a 200 MHz or greater oscilloscope, verify voltage noise amplitude is less than 6 volts at the following points:

NOTE: 200 μ s (microseconds) per division recommended

- Probe on PC +24V wire, common on PC 0V wire
 - Probe on PC +24V wire, common on ground connection
 - Probe on KCU +24V wire, common on KCU 0V wire
 - Probe on KCU +24V wire, common on ground connection
 - On the power supply which provides power to sercos devices
 - Probe on +24VDC power supply wire, common on 0V wire
 - Probe on +24VDC power supply wire, common on ground connection
-

Resolutions:

- Check for loose ground wires especially on the servo and VFD cable shields
- Check for noise issues on incoming power to the machine

Scope View 2

NOTE: Scope View 2 is an upgrade option

The purpose of these topics is to provide a basic overview for using Scope View 2 with Agard machinery systems.

These topics are not intended to duplicate or replace the help document from Beckhoff, accessible by pressing F1 from inside Scope View 2.

What Is Scope View 2

Scope View 2 is an analysis tool with graphical output to evaluate system states and system variables, with the ability of showing signal processes of multiple devices. The graphical output may be recorded for later analysis.

Usage and Benefits

- Troubleshoot unexpected machine behavior
- Troubleshoot sensor failures
- Analyze and monitor servo positions
- Monitor for false triggers, or blips, in sensors
- Scopes may be triggered to start or stop recording based on a specific tag value
- Recorded scopes may be viewed by Aagard personnel to assist in troubleshooting
- Existing scopes may be easily modified to expand use

Audience

- PSEs
- Level 3 Technicians
- Plant Engineers

How To Find

- Access to Scope View 2 is from the Windows start menu
 - Start > All Programs > TwinCAT System > TwinCAT Scope 2 > TwinCAT Scope View 2
-

- A Level 3 HMI login is required to minimize the HMI and access start menu
- Depending on HMI setup, links to predefined scopes may be available from a button in the HMI

Using Scope View 2

Servo drive axes and I/O devices are of primary interest in setting up scopes for Aagard machinery system applications. Axes and I/O devices are identified and added to scopes.

First, a few notes about how Aagard names tags for I/O devices in the PLC code:

B = Boolean

A Boolean has only two values: 0 or 1

*Typically, the zero and one translate into **False and True, Not Made and Made, or Low and High***

I = Input

An Input is a signal from a device, such as a photo eye

A Boolean Input tag will always have this prefix: BI_

Q = Output

An Output is a signal to a device, such as a solenoid valve or VFD

A Boolean Output tag will always have this prefix: BQ_

Aagard I/O tag names are made up of its tag type, its device-type abbreviation or acronym, its I/O assignment, its description, and its I/O name. The description and I/O name are intended to be somewhat indicative of the purpose of the device.

Tag examples:

BI_GS23111GUARDDOOR1_18LOCKED

Boolean Input - Guard Switch 23111 (Column 231, Row 11) Guard Door 1-18 Locked

When its value is 1 (high), the guard door switch is expected to be locked

(Recall that, typically, a value of 1 translates into High, True, or Made)

BI_PE34003BAGAATLAUNCHPRESENT

Boolean Input - Photo Eye 34003 (Column 340, Row 3) Bag At Launch Present

When its value is 1 (true), a bag is expected to be present at launch

BQ_BL39102BEACONLIGHTRED

Boolean Output - Beacon Light 39102 (Column 391, Row 2) Beacon Light Red

When its value is 1 (made), the red beacon light is expected to be illuminated


BQ_SV36401MANUFACTURERGLUEON

Boolean Output - Solenoid Valve 36410 (Column 364, Row 10) Manufacturer Glue On

When its value is 1, the manufacturer glue solenoid valve is expected to be on

Basic View

The following image shows the default view for Scope View 2.




Reopen Closed Tabs

If any of the tabs or the object browser have been closed, they may be reopened by clicking View, followed by the desired item. To restore the default view, select Reset Layout.


| View | Options | Info |
|--------------|---------------------|-------|
| | Object Browser | Alt+1 |
| | Target Browser | Alt+2 |
| | Scope Settings | Alt+3 |
| | Chart Settings | Alt+4 |
| | Axis Settings | Alt+5 |
| | Channel Settings | Alt+6 |
| | Channel Acquisition | Alt+7 |
| | Cursor | Alt+8 |
| | Trigger | Alt+9 |
| Reset Layout | | |

Location of Axes


1. Click on desired node under ROUTES, and then on the + to expand the node




1. Click on TCNC.Nc... and then on the + to expand TCNC.Nc...



2. Click on the + to expand the Axes node




3. Click on an axis, and view the available tags in the tag name panel immediately to the right




4. The servo drive tags of interest are those beginning with ACT and SET
 - a. ACTACC = Actual Acceleration
 - b. ACTPOS = Actual Position
 - c. ACTPOSMODULO = Actual Position Modulo
 - d. ACTVEL = Actual Velocity
 - e. SETACC = Set (or Commanded) Acceleration
 - f. SETPOS = Set (or Commanded) Position
 - g. SETPOSMODULO = Set (or Commanded) Position Modulo
 - h. SETVEL = Set (or Commanded) Velocity

Location of I/O


1. Click on desired node under ROUTES, and then on the + to expand the node



2. Click on TCPLC.Plc... and then on the + to expand TCPLC.Plc...




3. Click on the first node which shows the period (.), and view the available tags in the tag name panel immediately to the right




4. Scroll down in the tag names panel to identify BI_ and BQ_ tags of interest

Creating a Scope


1. Find a tag you want included in the scope:



2. In the target browser, double-click directly on the tag
 - a. The scope, chart, axis, and channel (tag) are added to the object browser



3. Double-click another tag in the target browser
 - a. The channel is added to the existing scope



NOTES:


- Note color coding of channels
- By default, the channel name is the name of the double-clicked tag
 - You may optionally rename any node in the object browser to help understand the scope
 - To do so, click on the item in the node, press F2, type a new name, and then press enter

Running a Scope

Click here to start recording a scope



Click here to stop recording a scope



Click here to resume playing a scope which has been paused while recording

Use these additional tools to zoom the view, slide the scope, or jump to a specific time of a recorded scope.

Many of these tools are much like a digital video player on a computer.


Deciphering a Scope

This topic will decipher scope results by comparing them with the physical action on a machine.

NOTE: For the purposes of this illustration, the colors in the model have been matched to those used in the scope

- [3D Model](#)
- [Sequence of Operation](#)
- [Scope Results](#)
- [Offsets](#)
- [What the Lines Represent](#)
- [Putting It All Together](#)


3D Model



Sequence of Operation

1. A completed case is pushed downstream into the **INVERTER** by the **CASE PUSHER**. After its push stroke, the **CASE PUSHER** returns to its resting position.
2. When the **CASE PUSHER** has reached a defined position during its return move, the **CASE AT CASE INVERTER** photo eye is evaluated to see if it is blocked. If the **CASE AT CASE INVERTER** photo eye is blocked, the **INVERTER** will begin its motion. The **INVERTER** has a circular motion, rotating 180° at a time to invert the completed case; what was the top of the case is now the bottom.
3. The inverted case is released onto a discharge conveyor. When no longer blocked, the **CASE DISCHARGE** photo eye signals the **INVERTER** that it is clear to begin its next cycle.
4. When a case is rejected from the machine, the **INVERTER** starts its cycle but holds at a defined position as the rejected case is pushed onto the reject chute. When the **CASE REJECT** photo eye is no longer blocked, the **INVERTER** is signaled that it may continue with its cycle.

Scope Results



Offsets

Recall that I/O devices are of type Boolean, which means they only have values of 0 and 1. As such, the three I/O devices in this example have been offset from each other to make it easier to see their values. The two drives have quite different profiles and are easy to see. Therefore, they have not been offset from each other.

What the Lines Represent

- The red line is the modulo set position of the Inverter
 - The straight vertical drop indicates the start and end point of the modulo (its circular cycle) - see **1**
 - Click here for a more detailed **MODULO DEFINITION**

When working with servo drives, the length of a modulo refers to a circular move, where the end position of one cycle (360° for example) is the same as beginning of the next (0° for example). In simpler terms, think of an analog clock: 12:00am and 12:00pm occupy the same space. With each rotation, the cycle starts over at zero.

Other Aagard uses of modulo:

- Flight chain - with each index of the flights, the modulo position starts at zero again
- Virtual master - virtual masters, tying two or more physical drives together, are often setup with units representing milliseconds, and the modulo value of the virtual is set to the cycle time of the assembly (2.5 seconds, for example); then, for each cycle of the machine, the master moves from 0ms to 2500ms and rolls over to 0 for the start of the next cycle

- The light blue line is the set position of the Case Pusher
 - The up/down slope of the line indicates the positions during its back and forth (upstream and downstream) motion
- The green line is the 0 (low)/1 (high) value of the Case At Case Inverter photo eye
 - When high (blocked), its value is 1, meaning something is blocking the photo eye
 - Note that this photo eye is setup to be high when blocked, while the other photo eyes in this example are setup to be high when *not* blocked
- The dark blue line is the false/true value of the Case At Discharge photo eye
 - When high (not blocked), its value is 1, meaning nothing is blocking the photo eye
- The orange line is the false/true value of the Case Reject photo eye
 - When high (not blocked), its value is 1, meaning nothing is blocking the photo eye

Putting It All Together

1. As the case is pushed into the Inverter, the Case At Case Inverter photo eye becomes blocked - see **2**
2. When the Pusher has retracted to a defined position, the Inverter begins its motion - see **3**
3. Since the case is not pushed all the way to the backstop of the Inverter, there is a brief moment when the Case At Case Inverter photo eye is not blocked during the motion of the Inverter
 - i. That is why the green line blips low/high - see **4**
 - ii. Since this brief moment is not long enough, the Pusher is not signaled to push the next case
4. As the Inverter rotates, each of the three fingers blocks and unblocks the Case At Discharge photo eye
 - a. That is why the dark blue line blips low/high - see **5**
 - b. Since these moments are not long enough, the Inverter does not stop and start its cycle
5. As the Inverter is rotating, the Case At Case Inverter photo eye becomes unblocked (low) - see **6**
6. Also as the Inverter is rotating, the Case At Discharge photo eye becomes blocked (low) with a case - see **7**
7. At **8**, the Case At Discharge becomes no longer blocked (high) and the next full cycle may begin, providing a case is ready
8. The cycle in this example did not have a rejected case, so the Case Reject photo eye was not blocked (high) throughout the entire cycle - see **9**

Tips

This topic provides other miscellaneous items or ideas for working with Scope View 2.

- The Axis node does not mean axis as in a drive, but rather axis of the scope or chart
- Consider putting I/O channels on a separate axis from drive channels to make the changes in value easier to see due to scaling
- Consider stacking or offsets to separate axes from each other
- Changes cannot be made to a scope which is recording; first stop recording before making changes
- Nodes in the object browser may be dragged and dropped from axis to axis
 - Nodes cannot be easily reordered within the axis

Please view Beckhoff's Scope View 2 documentation for more information by pressing F1 while inside the Scope View 2 application.

Scope View Tutorial

Documentation from Beckhoff provides much more information on configuring, visualizing, running, analyzing, modifying, and saving defined scopes. Reading through it will provide more ideas on how to best customize scopes for your particular situation.

You are encouraged to read through the Scope 2 Handbook and Scope 2 Tutorial sections inside the Beckhoff help documentation (press F1)

IMPORTANT NOTE: Do not run the TwinCAT test project available inside the Beckhoff help documentation unless you are using a computer with TwinCAT which is NOT running the PLC of an Aagard machinery system!

Imaged 4 GB CF Card Will Not Boot

On some occasions, the C6325 Beckhoff PC may not boot imaged 4 GB compact flash cards properly. A BIOS setting must be changed in order to resolve this issue.

Please follow these steps:

- 1) Shut down PC
- 2) Reboot into BIOS
 - a) Press **DELETE** key during reboot and before Windows starts
- 3) Select Integrated Peripherals
- 4) Select OnChip IDE Device
- 5) Select IDE Primary Master UDMA
 - a) Disable it
- 6) Select ID Primary Slave UDMA
 - a) Disable it
- 7) Select IDE Secondary Master UDMA
 - a) Disable it
- 8) Select IDE Secondary Slave UDMA
 - a) Disable it
- 9) Press F10
- 10) Press Enter to save changes
- 11) Allow the PC to reboot

Now the PC is not limited to any specific compact flash card version, nor is it limited to using only a 2 GB compact flash card.

Did this solve the problem?

 Yes No

General Troubleshooting Suggestions

NOTE: Not all items listed in this document pertain to your Aagard machinery system

AIR CYLINDER

Cylinder not extending or retracting

- Check air supply
- Check cylinder switches for proper function; switches should "make" at ends of cylinder stroke
- Check flow controls
- Check to ensure cylinder is not bent or broken
- Check valve to ensure it is functioning properly
- Manually cycle valve to ensure cylinder is receiving proper signal

BEARINGS

Bearing noise

- Check for proper lubrication
- Check for proper shaft alignment
- Check for broken housings
- Ensure all setscrews are in place and tight

Bearing Seized

- Replace

CHAIN WEAR

Excessive Chain Wear

- Check chain and sprocket alignment
- Check drive requirements
- Check for abnormal tension
- Check for components interfering with chain

CONVEYOR

Conveyor not running

- Check bearings, motors and drives
- Check for proper chain lubrication
- Check drive fuses
- Check E-Stop buttons
- Check for adequate power to drive or contactor
- Check for VFD faults (reference manufacturer's documentation)
- Check guard doors
- Check motor starters and contactors for functionality
- Check photo eyes
- Check upstream surge controls, photo eyes etc.
- Clear any jams
- Ensure motor is running
- Ensure product availability

FLAPS

Flaps not glued

- Check air supply to tank and glue heads
- Check for clogged nozzles (most common condition) - **NOTE:** If this machine has in-line filters in the hose at glue head fitting, these filters should be replaced regularly
- Check for debris in glue path
- Check for proper nozzle aim and glue placement
- Check glue tank for product and correct temperature
- Ensure glue bead settings have not been changed or altered
- Ensure glue heads are functioning
- Ensure sensor is functioning (if a sensor is used)
- Call for Technical Support

MACHINE FAULT

Fault will not reset

- Clear all fault pop-up messages on message center
- Clear all fault causes
- Ensure all guard doors are closed
- Ensure all guard door switches are functioning properly
- Call for Technical Support

MACHINE START OR RUN

Machine will not start or run

- Check air supply level
- Check magazine levels
- Check message center
- Ensure machine faults have been reset
- Ensure all guard doors are closed
- Ensure E-Stop buttons are not pressed
- Check upstream surge controls
- Ensure adequate vacuum levels exist
- Ensure all guard door switches are functioning properly
- Ensure glue systems are ready
- Ensure servos are in proper start position

MOTOR (AC OR DC)

Motor not running as expected

- Check drive and/or motor starter fuses
- Check Variable Frequency Drive to ensure proper function
- Ensure proper voltage is being supplied to motor

PHOTO EYES

Photo eyes not responding as expected

- Ensure LED cycles when blocked and unblocked
- Ensure photo eye has not been moved or bumped out of position
- Ensure photo eye is clean and its sight path is uninhibited
- Ensure reflector is in place
- Ensure photo eye and cable are correctly connected
- Check sensitivity level setting
- Check input and output in electrical cabinet(s)

SERVO MOTOR

Servo motor not performing correct motion profile

- Ensure motion path is free from obstructions
- Ensure settings on HMI are correct
- Check motor and feedback cable for damaged or broken wires
- Replace drive
- Replace motor
- Call for Technical Support

Servo motor not in reference or correct position

- Check for jam not allowing motor to finish motion profile
- Check for bent or broken parts
- Check if values for reference positions have changed on HMI
- Ensure mechanical attachment is tight and has not moved, for instance: belt clamp and belt
- Re-reference motor to reference location
- Check if motor is referenced against correct permanent stop
- Check if motor is properly referenced and triggering homing prox

Noisy servo motor

- Check for outside interferences
- Ensure internal brake is off/on at proper times (for most brake motors, brake engages when power is removed, such as in an E-Stop condition)
- Ensure mechanical coupling is tight and not slipping
- Call for Technical Support

VACUUM

Vacuum cups or heads not picking case, carton, or product

- Check vacuum cups for damage, debris, tears or leaks (place a non-porous material over vacuum cups; vacuum switch or gauge should show adequate vacuum levels)
- Check vacuum lines
- Ensure vacuum cups contact case or product (see servo positions)
- Check for plugged lines or orifices
- Check product for areas that may cause leaks or lack of vacuum
- Check system vacuum by activating vacuum valve manually and checking vacuum level

Call for Support

The Agard Group, LLC

3711 Iowa Street
Alexandria, MN 56308
www.aagard.com

Normal Business Hours:

Monday through Friday
8:00 AM to 4:30 PM

320-763-6043 (Voice)

320-763-7859 (Fax)

Parts: Option 4

Technical Service: Option 5

After-Hours Technical Service: Option 6

E-Mail:

service@aagard.com
spareparts@aagard.com

How To

The How To section offers instructions for many common tasks, as well as for some diagnostic tools and maintenance items.

NOTE: Not all items listed in this document pertain to your Aagard machinery system

Diagnostics



Barcode Scanner Diagnostics

NOTE: This feature may not be installed on all machinery systems

To test the barcode scanner, follow these steps:

- 1) Place a case under the barcode scanner head as if the case was being run through compression, with the barcode on the case under the barcode scanner head
 - 2) Press the Start Testing Bar Code Scanner Button
 - a) A percentage bar will be displayed while the barcode is being scanned
 - 3) If the barcode scanner is having trouble reading and the scanner head position is determined to be the problem, the scanner head may be adjusted to improve the reading reliability of the barcode scanner
 - 4) When testing is completed, press the Stop Testing Barcode Scanner Button to deactivate testing
-

This same principle applies to the other barcode scanners which may be installed on this machine.

Check I/O Device

When checking I/O devices, it is important to also check the wiring associated with the device. Input devices, such as photo eyes, may change states when being blocked or unblocked, but this might not be sensed by the machine controls due to faulty wiring or a bad connection.

To check I/O devices, follow these steps:

- 1) On the HMI Main Screen, login as level 2 or higher
- 2) Press the Advanced button
- 3) Press the I/O Diagnostics button
- 4) Click on the box next to the group which includes the device you want to check.
 - a) For example: Photo Eye PE31803 would be in group 318
- 5) Watch the circle next to the device name (in this case PE31803) while someone else flags the device
- 6) Verify the state changes as this is done
 - a) The circle next to the device name will be red when its input is energized

Clear Notices

There are a number of ways to clear notices from the HMI screen.

- Press the Clear button to clear an individual notice
- Press the Clear All button to clear all notices
- Energize the system by pressing the Start button once to clear all notices

NOTE: A Critical Fault will *not* be cleared by using the Clear All button or by pressing the Start button; it must be cleared individually by pressing the Clear button

Dry Cycle

SAMPLE IMAGE




- 1) On the HMI Main Screen, place the machine in automatic mode
- 2) Press the Disable Product button
 - a) The button color will turn to red, and the text will read Enable Product
- 3) Start the machine by pressing and holding the start button for three seconds
- 4) The machine will operate as if it is receiving product
- 5) Use the rate field to slow the operation down for further diagnostic assistance

Motor Jogging

To manually move a component that is driven by a non servo motor, the user must define which motor they want to jog and select it from the motor drop down list. Once the machine is started and in the ready state and manual mode, the user may jog the motor in the desired direction. The State and Mode is displayed in the bottom left hand corner next to the Drive Status Display. Once a motor jog button is depressed, the motor will continue to run in that direction until the “Stop” button is depressed or the machine is externally stopped (Cycle Stop or Emergency Stop).

SAMPLE IMAGE



Reinitialize

These steps are done via the Sercos Diagnostics Page in the HMI

- 1) E-Stop the machine
 - 2) Go to the Sercos Diagnostic Page
 - 3) Click on Initialize
 - 4) The text on the Initialize Button changes to E-Stop
 - 5) Click on "Reinitialize System", and wait for the machine to reinitialize the sercos ring
NOTE: Although no physical adjustments need to be made, you will need to download the correct product size and Inserter recipe, if installed, and initialize the Barcode Scanner, if installed
 - a) If you downloaded a product other than what was previously downloaded, the Product Download Changeover Adjustments Page will be displayed
 - 6) When complete, the Sercos Diagnostics Page will be displayed
 - 7) Click on E-Stop on the HMI screen
 - a) The text on the button returns to "Initialize"
CAUTION: If you downloaded the wrong product during the Sercos Ring re-initialization routine, you must go to the Main Page and download the correct product
 - 8) Pull the E-Stop button, and restart the machine
-


A simple but more time consuming alternative to these steps is to restart the HMI from the Advanced Page.

Servo Axis Jogging

To manually move a component that is driven by a servo motor, the user must define which servo axis they want to jog and select it from the servo axis drop down list. Once the machine is started and in the ready state and manual mode, the user may jog the servo axis in the desired direction. The State and Mode is displayed in the bottom left hand corner next to the Drive Status Display. Other servo jogging features include velocity, Go To Position (which sends the axis to that position), and an alternating jog function. Unlike non servo controlled motors and solenoid valves, a servo axis will only travel while the button is depressed. Once the button is released the axis will stop.

Warning: Jogging should be done very carefully and at a low velocity. This will eliminate damage to any obstructed machine parts. Use the jog velocity sliding bar to adjust velocity.


SAMPLE IMAGE



Servo Referencing

NOTE: Before referencing a servo, remove all product from the machine; remove any other material that might interfere with the movement of the servo. Any obstruction could cause the servo to reference to the wrong position. It is very important to visually check the position after you have referenced a servo.

SAMPLE IMAGE




- 1) Login to the HMI as level 2 or higher
- 2) Put machine in manual mode by pressing manual mode button
- 3) Press the Reference button on the right side of the HMI main screen
 - a) Make sure the machine is in the ready state and in manual mode (the mode and state are displayed in the bottom left corner of the reference page)
- 4) Select the servo you want to reference from the drop-down menu
- 5) Press the "Do Reference Routine" button and, if possible, watch the machine while pressing the button to verify movement
- 6) After the Reference Done message appears, depress an Emergency Stop and, with visual inspection, verify the reference routine completed correctly by ensuring that the position of the drive matches the reference description and the displayed image

Solenoid Valve Jogging

To manually move a component that is driven by a Solenoid Valve, the user must find which solenoid valve controls the component and select it from the solenoid valve drop down list. Once the machine is started and in the ready state and manual mode, the user may jog the solenoid valve in the desired direction. The State and Mode is displayed in the bottom left hand corner next to the Drive Status Display. Once a solenoid valve jog button is depressed, the valve will move in that direction until another direction button or a stop button is depressed.

SAMPLE IMAGE



HMI Operations



Clean Out

- 1) While the machine is running, press the Cleanout button to activate this feature
- 2) Wait for the machine to complete the cleanout function
- 3) When Cleanout is complete, a “Cleanout Done” warning message will be displayed


Enable Case Refeed Mode

- 1) While machine is running, click the Enable Case Refeed Mode Button on the Auxiliary Operations screen or select the Case Refeed selector switch at the case refeed station
- 2) Wait for upstream Aagard equipment to enter State: Held
 - a) Any downstream Aagard equipment will continue to run
- 3) While upstream Aagard equipment is in State: Held, the Case Reject Clear photo eye is disabled
 - a) If equipped, Z-Axis Tipper robot is retracted
- 4) Reach through Case Reject Chute and place case against backstop in same orientation in which it was AFTER case was tipped
- 5) When finished, click on Enable Case Refeed Mode Button; machine will resume normal operation

Load Cups Cleanout

If your machine does not have a Load Cups Cleanout button on the HMI Main Screen, use the following procedure:

SAMPLE IMAGE



- 1) Login as level 2 or higher
- 2) On the HMI Main Screen press the manual button to put machine in manual mode
- 3) Press the Jog button
- 4) Select Load Cups Blowback from the solenoid valve drop down list
- 5) Machine must be in ready state and manual mode
- 6) Press the On button to blow air, press the Off button to stop

Retract Mechanism

NOTE: This feature may not be installed on all machinery systems

- 1) After a jam has caused the machine to fault and come to a stop, with the machine energized, press the applicable Retract Button (Retract Vertical Tip Access, Retract Packer Robot, etc.) to move the mechanism out of the way
 - a) If necessary, press the Start Button once to energize the system

Vacuum Pump Shutdown

From time to time, it may be necessary or desirable to turn off the vacuum pump.

On machines with standard System Start and System Cycle Stop buttons, follow these instructions:

- 1) Cycle-stop machine
 - 2) Depress system E-Stop button
 - 3) After machine is E-Stopped, simultaneously press System Start and System Cycle Stop buttons on the HMI panel
-

On machines which have an additional physical Reset button, follow these instructions instead:

- 1) Cycle-stop machine
 - 2) Depress system E-Stop button
 - 3) After machine is E-Stopped, simultaneously press Reset and System Cycle Stop buttons on the HMI panel
-

If machine has been E-stopped for one hour, the vacuum pump will automatically turn off. When machine is started, vacuum pump will turn on automatically and no further action is required.

Maintenance



General Information



Maintenance Schedule

These maintenance items should be checked and performed periodically to ensure optimum performance of your system.

NOTE: Not all items listed in this document pertain to your Aagard machinery system

| Every Shift, or Daily |
|------------------------------------------------------------------------------------------------------------------------------------|
| Check conveyor belts for wear, alignment and cleanliness |
| Check gearboxes for leaks |
| Check photo eyes and reflectors for proper operation and positioning |
| Check vacuum lines, hoses and cups |
| Clean dust and debris from photo eyes |
| Clean glue from machine |
| Drain air filters and regulators |
| Inspect machine for unusual component wear or fatigue |
| Remove debris, dirt, grime, dust and other foreign materials from moving parts to lengthen life |
| Vacuum cooling fan intake filter |
| Every 50 Hours of Operation |
| Check chain drive for tension and adjust to 1/2" to 3/4" total play between sprockets, if needed |
| Grease rod ends, using #1 or #2 food grade grease |
| Grease Thomson bearings on magazine, using #1 or #2 food grade grease compatible with Mystic FG 2 |
| Lightly oil roller chain if it runs continuously |
| Every 100 Hours of Operation |
| Check vacuum pump oil level and fill as needed. Refer to Manufacturer's data sheet for recommended oil and maintenance information |
| Inspect cooling fan exhaust filter |
| Weekly |
| Check air cylinders, replace as needed |
| Check and clean or replace vacuum filters |
| Check chain and belt tension |
| Check chains for wear and proper alignment |
| Check for loose fasteners |
| Lightly oil v-wheel rollers and rails |
| Monthly |
| Check all safety circuits (Guard Doors, E-Stop Buttons) |
| Check cartridge bearings, replace as needed |
| Check for bent shafts, screws or other components |
| Check V-rollers periodically; tighten if required. For more information, see: How To |
| Check chain adjustment; lightly oil roller chains |
| Replace cooling fan intake filter |
| Every Six Months |

Check gear box fluid levels and refill as necessary. Refer to Manufacturer's data sheet for recommended oil, grease and maintenance information

Grease Elmo Rietschle Vacuum Pump, applying 1 full pump of grease. (or alternatively, 2 grease pumps once per year)

IMPORTANT! Do not over-grease or grease can get into motor windings and cause motor damage!

Bolt Torque Settings

Aagard always uses the manufacturer's recommendation for torque settings. On Aagard machines with servo motors, set screws on the coupling between the motor and Alpha gearbox are set to manufacturer's recommended torque setting; this setting is size-dependent. Set screws on bevel gears coupling the infeed side belt motors to their gearbox are set per manufacturer's recommendation. Torque settings may be found in Manufacturers' Information Binder which was provided at delivery with the Aagard machine.

Replacing Parts

NOTE: The position of adjustable parts should be marked and/or measured before removal so the new parts can be installed in the exact same position.

While replacing parts, always square them with their mating part. This especially applies to critical or adjustable parts.

Tucker Arm

This topic applies to Case Packers only

There are three tucker arms on the tucker in the case setup area. At this time, all three tucker arms are not required for all sizes. Depending on the size of product being run on a machine, the top arm is generally kept in the very top position and is not used. However, the top arm is provided for possible future sizes, or if certain conditions occur where it would be beneficial to have a third tucker arm.


Access to Machine



Second End Seal Lift

NOTE: This topic applies to vertical cartoner machines


From time to time, it may be necessary to gain access to the second end seal area for maintenance.



To gain access to the second end seal area, follow these steps:

- 1) Stop the machine
- 2) On the HMI, navigate to Custom Buttons Page > Manual Operations Page
- 3) Energize the system by pressing the green start button
NOTE: Do not start the machine by holding the button down!
- 4) Press the **LIFT SECOND END SEAL** button

View from
operator side




Second End Seal
in up position

- 5) Depress any E-Stop button
- 6) Attach safety cable!

⚠ DANGER Do not enter area without safety
cables attached! **⚠**



- 7) For additional security, secure the raised assembly with blocks of wood
- 8) Perform maintenance as required
- 9)  **CAUTION** Remove safety cable and store



- 10) Close any open guard doors
- 11) Pull out any depressed E-Stops
- 12) Energize the system by pressing the green start button
NOTE: Do not start the machine by holding the button down!
- 13) Press the **LOWER SECOND END SEAL** button

Adhesives



Adjust Glue Head Position

When replacing a glue head (nozzle), it is important to position the new head at exactly the same angle as the old one. Some case packers have a guide for proper positioning (part # Z0098687). If your nozzles are at 90 degrees and you do not have a guide, as a general rule, set them flat horizontally. If either of these do not apply to your machine, set glue head angle so glue strip is positioned the same vertically on both sides of the case or carton.

Adjust Glue Head Pressure

Set glue to appropriate pressure to ensure proper pattern control and clean cutoff at glue nozzle.

Standard Settings (for HB Fuller Advantra adhesive)

| EQUIPMENT | TEMPERATURE | PRESSURE |
|---------------------------------|-------------|-------------|
| Tank | 335°F-350°F | 30-40 PSI |
| Hose | 335°F-350°F | N/A |
| Guns with adjustable regulators | 335°F-350°F | 65-70 PSI * |
| Guns with fixed regulators | 335°F-350°F | 65 PSI |

* Glue nozzle pressure for adjustable regulators is dependent on glue nozzle model installed on machine. If unsure of correct setting for your machine, refer to Nordson documentation or pneumatic page in electrical drawings.


All Aagard machines use regulators to set glue head air pressure. These regulators either control each head individually, or in a set grouped by location of glue strip. For example, the operator side upper glue strips on a case may have two heads but are controlled by one regulator, while the bottom head or heads are controlled by another regulator.

Some regulators (on older machines) are adjustable so the air pressure can be changed, while some do not adjust and have a fixed setting of 65 psi. It is recommended that all heads have the same pressure. If the regulator is adjustable, to adjust air pressure, pull up on regulator knob to unlock it, turn knob until gauge shows correct pressure, and push regulator knob back down to lock.

The Aagard recommended glue head pressure on adjustable regulators should typically be set at 65 – 70 PSI. Glue head pressure is dependent on model of glue head installed on machine. If you are unsure of correct setting for your machine, refer to pneumatic page in the electrical drawings.

Most heads use an internal spring to shut off glue. Increasing air pressure will cause glue to shut off more slowly as the spring must overcome more pressure. Air pressure set too high may also cause the valve to slam into the spring, causing the spring to become stuck.

SAMPLE IMAGE




Adjust Glue Tank Pressure & Temperature

Set glue to appropriate temperature to ensure proper pattern control and clean cutoff at glue nozzle.

Standard Settings (for HB Fuller Advantra adhesive)

| EQUIPMENT | TEMPERATURE | PRESSURE |
|---------------------------------|-------------|-------------|
| Tank | 335°F-350°F | 30-40 PSI |
| Hose | 335°F-350°F | N/A |
| Guns with adjustable regulators | 335°F-350°F | 65-70 PSI * |
| Guns with fixed regulators | 335°F-350°F | 65 PSI |

* Glue nozzle pressure for adjustable regulators is dependent on glue nozzle model installed on machine. If unsure of correct setting for your machine, refer to Nordson documentation or pneumatic page in electrical drawings.

SAMPLE IMAGE**Adjust Glue Tank Temperature:**

To globally set all glue components to same temperature, do the following:

- 1) Press and hold tank key for three seconds; left display will flash
- 2) Use arrow key to scroll left display to 0
- 3) Press enter key
- 4) Right display flashes
- 5) Use keypad to enter temperature recommended by glue manufacturer; Aagard recommended glue temperature is 335°F - 350°F
- 6) Press tank key again (see first step); all components will begin to heat/cool to new temperature

Set Auto-Standby:

Configure auto-standby by setting parameters on the Nordson control panel. You can automatically go into standby mode a number of different ways. Typically, however, it is done after a certain amount of inactivity (0 to 1440 minutes, or 0-24 hours). You may also set the amount that the temperature will drop (default is 100°F). Additionally, you may take the tank out of standby manually using a function key, or automatically after a set amount of time. Information on how to configure these settings may be found in the Nordson Manual (Section 3, Setting Up the Melter).

Adjust Glue Tank Pressure:

Follow these instructions to set glue tank air pressure:

- 1) Gauge indicates the air pressure supplied to tank pump
- 2) Use Allen head adjusting screw located to right of gauge to adjust air pressure

Glue Filter Replacement

Tools Required:

- Metric Wrench Set

Routine:

- 1) Turn off glue system
- 2) Wait one hour for system to cool down
- 3) Remove filter with metric wrench; filter is next to glue head
- 4) Put new filter in and tighten (snug down with wrench, but do not over tighten)
- 5) Turn on glue system

Glue Gun Replacement

Tools Required:

- Standard Wrench Set
- Metric Allen Pack

Routine:

- 1) Turn off glue system
- 2) Wait one hour for system to cool down
- 3) Unhook all air and glue lines from head
- 4) Remove head from mount
- 5) Replace with new head
- 6) Hook all lines back up
- 7) Turn on glue system

Glue Hose Replacement

Tools Required:

- Standard Wrench Set


Routine:

- 1) Turn off glue system
- 2) Wait one hour for system to cool down
- 3) Remove hose from glue head and glue tank
- 4) Put in new hose
- 5) Tighten both ends of hose
- 6) Turn on glue system

Glue Nozzle Jig

These drawings and instructions pertain only to Aagard systems with hot adhesive systems.

**When setting glue nozzles, nut on nozzle must be loose.
Insert jig over both nozzles.
Hold nozzles with jig while tightening nuts.**



Glue Nozzle Replacement

Tools Required:

- Metric Wrench Set

Routine:

- 1) Turn off glue system
- 2) Let system cool down for one hour
- 3) Remove old nozzle with 14 mm wrench and replace with new one
- 4) Tighten down snug with 14mm wrench
- 5) Turn on glue system

Glue Solenoid Valve Replacement

Tools Required:

- Flathead Screwdriver Set
- Electrical Prints

Routine:

- 1) Turn off main air
- 2) Disconnect all air lines and electrical wires on valve
- 3) Remove bolts that mount valve
- 4) Replace old valve with new valve (you may use same fitting or get new ones)
- 5) Mount new valve with same bolts
- 6) Reconnect all air lines and electrical wires (see electrical prints)
- 7) Turn on main air

Glue Tank Replacement

Tools Required:

- Standard Wrench Set
- Standard Allen Pack
- Flathead Screwdriver Set
- Phillips Screwdriver Set
- Nordson Manual
- Leak-Proof Container (for draining glue tank)

Routine:

NOTE: This procedure may require use of Nordson Manual

- 1) Record the following four glue tank settings of unit to be replaced, if possible:
 - a) Tank Temperature
 - b) Line Temperature
 - c) Gun Temperature
 - d) Air Pressure
- 2) Drain glue into a leak proof container using drain behind lower front panel of unit
- 3) When glue is drained, remove power from unit using Glue Disconnect
- 4) Allow glue tank to cool (minimum of 1 hour)
- 5) Once glue tank has cooled, disconnect all hoses and power cords at tank
- 6) Loosen or remove mounting hardware
- 7) Remove old unit from its mounting brackets
- 8) Set new unit in place
- 9) Attach new glue tank unit to mounting brackets
- 10) Reconnect power and hoses
- 11) Apply power
- 12) Fill tank with new glue pellets
- 13) Adjust settings for new unit to original settings recorded earlier; use the Nordson Manual as needed
- 14) Typical setting ranges for Aagard glue are as follows:

NOTE: These settings may vary depending on application and machine set up

Standard Settings (for HB Fuller Advantra adhesive)

| EQUIPMENT | TEMPERATURE | PRESSURE |
|---------------------------------|-------------|-------------|
| Tank | 335°F-350°F | 30-40 PSI |
| Hose | 335°F-350°F | N/A |
| Guns with adjustable regulators | 335°F-350°F | 65-70 PSI * |
| Guns with fixed regulators | 335°F-350°F | 65 PSI |

* Glue nozzle pressure for adjustable regulators is dependent on glue nozzle model installed on machine. If unsure of correct setting for your machine, refer to Nordson documentation or pneumatic page in electrical drawings.

Hot Melt Adhesive System

When a hot melt adhesive system is installed, set glue to appropriate temperatures and pressure to ensure proper pattern control and clean cutoff at glue nozzle.

Standard Settings *(for HB Fuller Advantra adhesive)*

| EQUIPMENT | TEMPERATURE | PRESSURE |
|---------------------------------|-------------|-------------|
| Tank | 335°F-350°F | 30-40 PSI |
| Hose | 335°F-350°F | N/A |
| Guns with adjustable regulators | 335°F-350°F | 65-70 PSI * |
| Guns with fixed regulators | 335°F-350°F | 65 PSI |

* Glue nozzle pressure for adjustable regulators is dependent on glue nozzle model installed on machine. If unsure of correct setting for your machine, refer to Nordson documentation or pneumatic page in electrical drawings.

Bearings, Pulleys and Shafts



Bearing and Shaft Replacement

Tools Required:

- Standard Wrench Set
- Standard Allen Pack

Routine:

- 1) Remove drive belt or chain
- 2) Loosen set screws on bearing
- 3) Remove sprocket or pulley off shaft
- 4) Take bearings off of mounts and slide off shaft
- 5) Remove bearing plate
- 6) If bearings are pressed in, press out bearings which need to be replaced
- 7) Place new bearings in plate
- 8) Place plate back in machine
- 9) Place new bearings on ends of shaft and put hardware in mount but do not tighten
- 10) Make sure shaft is square
- 11) Tighten bearings down
- 12) Tap on shaft to set bearings (make sure inner race spins freely on shaft)
- 13) Tighten set screws on bearing
- 14) Place drive belt or chains back in

Pulley and Idler Shaft Replacement

Tools Required:

- Standard Wrench Set

Routine:

- 1) Loosen tension so belt can be removed
- 2) Keep spacers
 - a) If spacers need to be replaced, do so at this time
- 3) If bolts are bad, replace with new ones
- 4) Replace pulleys and bearings with new ones
- 5) Tighten all bolts for pulleys
- 6) Put belt back on
- 7) Re-tension belt

Rod Ends Replacement

Tools Required:

- Standard Wrench Set

Routine:

- 1) Measure amount of thread left on cylinder shaft before moving anything
- 2) Loosen jam nut on shaft with one half inch wrench
- 3) Take bolt out of rod end
- 4) Take rod end off
- 5) Put new rod end on with same amount of thread left on cylinder shaft
- 6) Lock down jam nut

Slip Sheet Pick Bearing Replacement

This topic only applies to Unitizers

Tools Required:

- Standard Wrench Set
- Standard Allen Pack


Routine:

- 1) Remove pivot arms that are connected to shaft
- 2) Loosen set screws on bearings
- 3) Take bearings off of mounts and slide off shaft
- 4) Place new bearings on ends of new shaft and put hardware in mount but do not tighten
- 5) Make sure shaft is square
- 6) Tighten bearings down
- 7) Tap on shaft to set bearings
 - a) Make sure inner race spins freely on shaft
- 8) Tighten set screws on bearing
- 9) Reattach the pivot arms


Split Linear Bearing Replacement

NOTE: This topic only applies to Machine 180

The Overhead Carton Loader assembly shafts use a non-lubricated split linear bearing manufactured by Igus, Inc.





First, a few precautions and notes:


- For ease access, Overhead Carton Loader assembly should be lifted into changeover position
 - Follow Lockout/Tagout procedures
 - There are four split bearings inside each bearing enclosure
 -  Do not break or tear o-rings when removing bearings
 - It is recommended that all four bearings be replaced at same time
 - Work will need to be done on both sides of machine
-

Follow these steps to remove and replace the failed bearing:


- 1) Raise Overhead Carton Loader assembly into changeover position
- 2) Following first part of changeover routine, remove all loader plates
- 3) Follow Lockout/Tagout procedures of your facility
- 4) On non-operator side of machine, slide load gate air cylinder toward operator side of machine







- 5) Manually rotate Overhead Carton Loader to make non-operator side end cap accessible





- 6) To make operator side end cap accessible, remove upstream containment rail by removing four 7/16" bolts



- 7) Remove screws and end caps
8) Carefully pull out split bearings

 Do not scratch coated surface of shaft 
 Do not break or tear o-rings when removing bearings 

- a) Replacing o-rings requires opening both drive chains and removing containment assembly from the Overhead Carton Loader
b) If necessary, gently pull on exposed bearing end with channel locks
- 9) Slip off o-rings
10) Remove and replace split bearing and clearance gasket
11) Slip on o-ring
12) Move bearing with o-rings into position
a) It may be helpful to apply a very small amount of grease on o-rings to slide replacement bearing into position

 These split linear bearings are lubricant free; do not apply any grease to the bearing itself 

- 13) Reinstall end caps
14) Reinstall upstream containment rail
15) Move next loader carriage into position


- 16) Repeat previous steps for each four bearings in each of 11 loader carriages
- 17) Install correct loader plates
- 18) Restore Lockout/Tagout
- 19) Lower Overhead Carton Loader into run position

Belts, Chains and Rollers



Adjust Belt Tension

When belt is idle, there should be 1/64" deflection for every 1" of span length with 30 pounds of force for a single belt (60 pounds of force for a double belt). Force should be applied perpendicular to belt and in center of span. When Aagard tensioners are used with a spring, spring should be compressed down to 2" in length.




Span is defined as distance between drive pulley/sprocket (usually at motor) and driven pulley/sprocket (usually at shaft which is being driven).

First, a few simple rules:


- 1) Check tension on a new drive belt frequently during first 24 to 48 hours
 - 2) Do not tension belt by feel as this may cause performance problems
 - 3) Too much tension will shorten life of belt and bearings
 - 4) The average static tension will shorten life of belt and bearings
 - 5) Be sure one pulley is free to rotate; make sure an even force is applied to entire length of belt
 - 6) Be careful not to over tighten belt clamp plates to prevent plates from bending or wrapping over belt
-

Belts with Spring Tensioner:

Loosen locking bolts and turn spring adjustment bolt until spring is 2" in length. Re-tighten locking bolts!

**Belts with Jack Bolt Tensioner:**


Loosen locking bolts and turn jack bolt until you have proper tension. Re-tighten locking bolts!



Adjust Chain Tension

Chain slack should be 4% of the span. Slack should be measured halfway between the span.

For Example: 25" of span = 1" of slack ($25" \times 0.04 = 1$).




For heavy loads and frequent starting, it should be 2% of the span.

For example: 25" of span = 0.5" of slack ($25" \times 0.02 = 0.5"$).

Span is defined as distance between drive pulley/sprocket (usually at motor) and driven pulley/sprocket (usually at shaft which is being driven).


Chains with Jack Bolt Tensioner:

Loosen locking bolts and turn jack bolt until you have proper tension. Retighten locking bolts!





Chains with Sprocket Tensioner

Loosen locking bolts and adjust sprocket (move up or down) until you have proper tension. Retighten locking bolts!



Special note for vertical cartoner:

Chain tensioners on the discharge section have multiple holes in the bracket to allow for increased take up range.




- 1) Remove four slide washer shoulder bolts
- 2) Reposition take-up bracket with take-up holes over slide washer holes
- 3) Re-tighten shoulder bolts

Adjust Chain Tension - Downstackers

NOTE: This topic relates specifically to downstackers; for general chain tension instructions, see: [Adjust Chain Tension](#)

Since the downstacker has four chains on the operator side and another four chains on the non-operator side, it is important to always adjust tension for each set of chains using tightest chain. Chains are not always exactly the same length and chains stretch differently. Using tightest chain will ensure no chain is too tight. Chains tensioned too tightly cause stress on the shaft, bearings, and gearbox.

Proper slack on tightest chain should be 2% of span; slack should be measured halfway between the span. Span is defined as distance between drive sprocket and driven sprocket.



Downstacker chain span, from sprocket to sprocket, is approximately 35 inches. Using the 2% guide, 35" of span translates to .7" of slack ($35 \times .02 = 0.7$), or roughly 3/4". The measurement for slack should be made 17.5" between sprockets.

Care must also be taken to ensure jack bolts are adjusted equally on upstream and downstream side of machine, ensuring shaft is not on an angle.



Adjust V-Rail Rollers

- 1) Tighten adjustable rollers by turning clockwise until wheel just makes contact with track
- 2) Tighten lock nut fully, and then check roller tension against track
NOTE: Always check after tightening nut because rollers normally will get tighter after nut is tightened
- 3) When tension is correct, one should be able to spin adjustable wheel by hand, or very easily with a channel lock
NOTE: Both wheels need to contact both sides of track. If both sides of all rollers are not contacting V track and rollers are considered tight, the assembly is probably not square

NOTE: You should always check roller tension in several locations along track to make sure there are no tight spots

Belt Replacement

Tools Required:

- Standard Wrench Set

Routine:

- 1) Loosen pulley jack bolt and move pulley so belt is loose
- 2) Loosen bolts that clamp belt down on pusher
- 3) Remove belt from both sides of clamp
- 4) Take a new belt of same length and replace old one
- 5) Place new belt in both sides of clamp evenly
- 6) Tighten bolts on the clamp just enough so belt stays in clamp but still moves slightly
- 7) Tighten jack bolt to tension belt; tension so belt moves about 1/2" when pushed on in center
- 8) Move pusher back and forth a couple of times so belt straightens itself out
- 9) Tighten bolts on clamp and on pulley mount

Chain Replacement

Tools Required:

- Pliers
- Chain Pliers

Routine:

- 1) Remove materials from chain area
- 2) Find connector link on chain
- 3) Remove connector link with pliers
- 4) Replace chain with a new chain of same length
- 5) Put new connector link in

Downstacker Chain Replacement

This topic only applies to Case Packers

Tools Required:

- Standard Wrench Set
- Pliers

Routine:

- 1) Take flights off of chain
- 2) Loosen jack bolts on bottom of downstacker (both sides)
- 3) Loosen assembly so servo and shaft move up far enough so chain is loose
- 4) Find connector link on each chain and take them off with pliers
- 5) Remove old chain and replace it with new one
- 6) Place connector link back on chains
- 7) Re-tension assembly on bottom so chains are tight
- 8) Tighten all bolts
- 9) Put flights back on

Drive Belt Replacement

Tools Required:

- Standard Wrench Set

Routine:


- 1) Loosen the gearbox from the mount and loosen the tensioner (jack bolt) so the belt can be removed
- 2) Replace old belt with new one
- 3) Re-tension belt according to specifications: [Adjust Belt Tension](#)
- 4) Tighten bolts under gearbox

End Seal Belt Path

NOTE: This topic applies only to the 1st and 2nd end seals stations of the vertical cartoner machines

In the diagram below, the pulleys and belts are color-coded to indicate which belt goes on which pulley; this is for illustration purposes only! Actual belts and pulleys may not be colored.


The top belt goes with the red pulleys, while the lower belt goes with the black pulleys.



Infeed Flight Position

This topic applies to Cartoners with Case Packers only

Main Cartoner Flight to Case Packer Infeed Flight
 Mechanical position requirement



SETUP NOTE:
 FACE OF CARTON FLIGHT TO FACE OF FLIGHT
 ON MATTOP IN CASEPACKER INFEED IS 20.50"

Infeed Product Belt Replacement

This topic only applies to Case Packers

Tools Required:

- Standard Wrench Set
- Pliers

Routine:

- 1) Locate clipper lace on belt and move to accessible area
- 2) Loosen belt tensioners on both sides of belt so belt hangs loosely
- 3) Remove pin in clipper lace
- 4) Remove belt
- 5) Place new belt in and put pin in clipper lace making sure belt is centered
- 6) Re-tension belt so it does not sag, making sure both tensioners are equal
- 7) Tighten down tensioners, making sure not to over-tighten

Mattop Conveyor Belt Replacement

Tools Required:

- Long punch
- Hammer

Routine:

- 1) Remove guard at end of transfer conveyor
- 2) Take conveyor belt slack up to a workable position so you can get to red pins on side
- 3) Take long punch and remove one pin with hammer
- 4) Now remove old conveyor belt and replace it with a new one of same length
- 5) Put link back in using a hammer if necessary
- 6) Allow slack under conveyor to fall back in its usual position


Replace Barrel Cam Chain

There are several steps involved in replacing barrel cam chains. Two key steps, however, are aligning (phasing) chains and adjusting tensioner cylinder switches.


NOTE: Images displayed in this topic are for reference only; your machine may be slightly different

NOTE: Replacing barrel cam chain is a two-person job

- 1) Remove buckets
- 2) Lockout/Tagout
- 3) If air on tensioner has not been dropped, do so now
 - a) Make sure ratchet locks are lifted while dropping air




- 4) Remove drive belt to make it easier to manually move entire barrel cam




- 5) Remove bucket carriages by removing bolts from underside of tabs which are attached to chains
 - a) There are eight bolts, four on each end of barrel cam

NOTE: The best access point is on upstream end of barrel cam assembly

NOTE: Take care when moving bucket carriage assemblies as shafts freely slide out




- 6) Look for master links, which are generally painted a different color




- 7) Remove chains
8) Move tensioner assembly at downstream end of barrel cam back and forth to make sure it moves freely without side-to-side movement, and that it is square
a) Remember to lift ratchet locks
b) If it is not free, locate bind point and correct
c) If it is not square or has side-to-side movement, check bolts on tensioner assembly for tightness; square and re-tighten bolts if necessary
9) Install new chains
10) Make sure chains are aligned
a) The same link type (inner or outer) should be in same position and on same sprocket tooth when looking across sprockets
b) Position master links so they are generally across from each other
11) Align chains with each other
a) Clamp a metal squaring block to a cross member
b) Position squaring block so carriage assembly tabs attached to chain meet it
c) Do this for both chains

NOTE: Make sure squaring block is positioned on same side of tab and on same side of frame member as on opposite side of barrel cam



- d) Move barrel cam chains so tabs meet attached squaring blocks
- e) If tabs from both chains do not meet attached squaring blocks at exactly the same time, chains need to be phased
 - i) To phase chains, loosen bolts on slotted sprocket on driven end




- ii) Turn sprocket in slots to adjust chain to match chain position on other side of barrel cam exactly
- iii) Re-tighten bolts
- iv) Re-test phasing
- v) Remove squaring blocks and clamps

- 12) Reattach one bucket carriage assembly
 - a) Use Loctite blue (medium)
- 13) Manually rotate barrel cam one full revolution to verify chains are in rails
- 14) Reattach rest of bucket carriage assemblies
 - a) Use Loctite blue (medium)
- 15) Again, manually rotate barrel cam one full revolution to check if chains are in rails
- 16) If rails have been replaced, install one bucket
 - a) Rotate barrel cam to check bucket to forming/compression deck clearance
 - b) Adjust deck if necessary
 - i) Clearance should be thickness of one carton

NOTE: Carton must move freely, without binding

- 17) Install remaining buckets
- 18) Restore air to tensioning cylinder(s)
 - a) Set to 50psi
- 19) Remove LOTO
- 20) Reinstall drive belt
 - a) Tension drive belt according to specifications; see: [Adjust Belt Tension](#)
- 21) Reference barrel cam
- 22) If carton flight chain has been replaced on an older machine which has carton flight reference prox located near compression and rotary tuckers, cam offset may need to adjusted; call Aagard for support
- 23) Run barrel cam for at least 30 minutes
 - a) This step is required to ensure chain is run in and tensioning cylinders are at a position where they will stay for some time

- 24) With pressure still on air cylinders, loosen tightening screw attaching switch to cylinder
- Slide switch until it is made (light turns on)
 - Mark its position
 - From its made position, move switch toward rod end 1/2"
 - Re-tighten screw



NOTE: If each cylinder has a switch, be sure to adjust both

Side Belt Replacement

This topic only applies to Case Packers

Tools Required:

- Standard Wrench Set
- Standard Allen Pack

Routine:

- 1) Remove product rail below belt
- 2) Loosen jack bolt tensioner and loosen pulley mount
- 3) Move pulley so belt can be removed
- 4) Remove plate mount to gain access to belt
- 5) Remove belt
- 6) Replace old belt with the new one
 - a) Make sure arrows are in right direction
- 7) Replace plate mount
- 8) Tension belt with jack bolt
- 9) Average static tension (tension when belt is idle) is 1/64" deflection per every 1" of span length with 30 pounds of force for single belt, 60 pounds for double belt
- 10) Tighten down pulley mount
- 11) Re-install product rail

Unitizer Slip Sheet Roller Replacement

This topic only applies to Unitizers

Tools Required:

- Standard Wrench Set
- Standard Allen Pack

Routine:

- 1) Remove caps on both ends of rollers
- 2) Remove chains connecting each roller
- 3) Remove old roller and replace it with new roller
- 4) Put chains back on
- 5) Put caps back on

V Roller Replacement

Tools Required:

- Standard Allen Pack

Routine:

- 1) Loosen eccentric rollers so you have more room to work
- 2) Remove V rollers carefully so prevent V rail edge from being damaged
- 3) Adjustable / eccentric wheels should be lower wheels if track is horizontal
 - a) If track is vertical, be sure eccentric wheels are both on same side, and on side where they can be adjusted easiest
- 4) Check to make sure that the V rail edge is clean and not damaged or bent
- 5) Wheel installation:
 - a) Install and fully tighten fixed wheels
 - b) Install and snug adjustable wheels tight enough so they are flush with mount but loose enough so eccentric wheels can still be turned
 - c) Tighten by turning clock wise until wheel just makes contact with track
 - d) Tighten the nut fully and then check wheel tension against track
 - i) Always check after tightening nut since wheels normally will tighten slightly more after nut is tightened


With correct tension, you should be able to spin wheel by hand or very easily with a channel lock. Wheels need to contact both sides of rail. If both sides of all wheels are not contacting rail and wheels are at correct tension then there is a problem with the assembly, such as it is not square or it may be bent.

Computer and Software




Flash Drive Replacement


- 1) Power down the PC from the Advanced Page
- 2) Open the HMI panel
- 3) Remove Drive: C
- 4) Install "C: Spare from Aagard"
- 5) Reboot PC
 - a) The HMI will start automatically
- 6) Login to the HMI, and then close the HMI application using the X in the top right corner of the screen
- 7) Open Windows Explorer and navigate to the D: Drive
- 8) Open the desired "D:\Aagard Critical Back Up"
- 9) In a separate window, open "C:\Aagard"
- 10) Replace the Source Code and Runtime Folders in the C: drive with the ones from the D: drive.
 - a) You may first need to unzip the files and place them into the designated folders
- 11) Once the folders have been replaced, open "C:\Aagard\SourceCode\Controller\###Proj.pro"
 - a) ### is the number of the machine




- 12) Click Project > Clean All




- 13) A dialog box may appear displaying, "Attention! After this action you can no longer login without download! Do you wish to continue?" Select Yes
- 14) A dialog box will appear displaying, "Attention! Would you like to keep the TwinCAT_configuration unchanged?" Select No
- 15) Save by either clicking the Save icon or by going to the "File" menu and selecting "Save"
- 16) Click Project > Rebuild All




- 17) Save by either clicking the Save icon or by going to the "File" menu and selecting "Save"
- 18) Go back to the "Controller" folder and open the ".tsm" file, ("C:\Aagard\SourceCode\Controller\###Proj.tsm"), (Where ### is the number of the machine)



- 19) On the tree to the left, expand "PLC – Configuration". Then Right-click on the child tree item labeled by for this machine number and project under, "PLC – Configuration" and select "Rescan Project..."




- 20) Save by either clicking the Save icon or by going to the "File" menu and selecting "Save"
- 21) Click Actions > Activate Configuration



- 22) A dialog box will appear displaying, "Document is modified! Generate mapping before activate configuration?"
Select Yes
- 23) A dialog box will appear displaying "Activate configuration, (Old Configurations will be overwritten!)" Select OK
- 24) A dialog box will appear displaying, "Restart TwinCAT System in Run Mode?" Select OK
- 25) An error message box may display: "TwinCAT PLC Server: PLC Error(1804)loading boot project of run time system1. Run time started without boot project"
- 26) This is expected and not a problem, so just select OK
- 27) Click File > Save
- 28) Close the TwinCAT System Manager file (which is the .tsm file)
- 29) Go back to the PLC program (the .pro file)
- 30) Click Online > Login



- 31) A dialog box will appear. "The program has changed! Download the new program?" Select Yes.
- 32) Click Online > Create Bootproject



- 33) Click File > Save
- 34) Close the TwinCAT Project file (which is the ###proj.pro file)

- 35) Click Start > Restart and wait for the HMI to reinitialize
 - a) You may have to Click Start > Shut Down > Restart

CRITICAL NOTE: A new cloned spare flash drive should be obtained as soon as possible!



To Update the Manuals and Help Files:

NOTE: This procedure updates the manuals and help files so that they are at the most recent level. This Procedure should be done but is not required for the machine to run, and can be done at any time once machine is up and producing after Flash Drive Replacement.

- 1) Go to "D:\Aagard General Files Backup"
- 2) Open "General Files Back up month of ####-##-## (year-month-day)" (Where # stands for the current date in year, month, day order)
- 3) Copy "Aagard Icons" and "Help" Folders
- 4) Go to "C:\Aagard Documents"
- 5) Replace existing "Aagard Icons" and "Help" Folders with the ones you copied from the D:Drive

Shutting Down PC

Failure to properly shut down the PC may void the warranty!

| | |
|---------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Switch on | The Industrial PC does not have its own main switch. The Industrial PC will start when the equipment is switched on, or when it is connected to the power supply. |
| Shutting down and switching off | When the plant is switched off, or when it is disconnected from its power supply, the Industrial PC will be switched off. Control software such as is typically used on Industrial PCs permits various users to be given different rights. A user who may not close software may also not switch the Industrial PC off, since data can be lost from the hard disk by switching off while software is running |
|  Warning! | First shut down, then switch off the PC! If the Industrial PC is switched off as the software is writing a file to the hard disk, the file will be destroyed. Control software typically writes something to the hard disk every few seconds, so the probability of causing damage by switching off the PC while the software is running is very high! |
|  Warning! | When you have shut down the Industrial PC, you have to switch off power supply for at least 10 seconds before rebooting the system. After resetting power supply, the PC will start booting automatically. |

To properly shut down the PC, contact a Level 2 or higher Operator.

Drives



Servo Drives

[Downstacker Servo Gearbox Coupling Replacement](#)

[Indradrive C Purge Assembly](#)

[MI Drive Replacement](#)

[Purchasing MI Servos Directly From Rexroth](#)

[Sealing Rexroth Servo Assemblies](#)

[Servo Cable Replacement](#)

[Servo Gearbox Replacement](#)

[Slide-Rite Gearbox Lubrication](#)

Downstacker Servo Gearbox Coupling Replacement

This topic only applies to Case Packers

Tools Required:

- Standard Wrench Set
- Standard Allen Pack
- Metric Allen Pack

Routine:

- 1) Disconnect main power
- 2) Unhook servo cables
- 3) Mark position of hub on both shafts with a marker before removing them
- 4) Remove servo gearbox assembly with mount attached
- 5) Take coupling assembly out and replace it with new one (put it in same position as old one as marked on shafts)
- 6) Put servo gearbox assembly back in; it should go back together with very little force
- 7) Tighten all bolts
- 8) Reconnect servo cables
- 9) Reconnect main power

Indradrive C Purge Assembly

This system is put in place to verify that a vacuum will not be generated inside the servo motor housing while the servo heats up and cools down. There is a 5/32" tube connected to each servo motor at the encoder connection which is fed from an air preparation assembly near the main air drop to the machine. This air preparation assembly removes particulates and humidity from the air which could possibly damage the motor.

The parts of this assembly are as follows:

- manual dump valve
- standard air filter
- water separator
- mist & micro-mist (oil) separator
- air dryer
- precision regulator (set & locked at 2 psi)
- relief valve (set & locked at 3 psi)
- pressure sensor
- flow sensor

The manual dump valve is provided to release pressure from the system when maintenance to the system is required. Pressure should remain in the system at all other times to ensure that substance ingress is kept to a minimum.

The four filters preceding the air dryer are to ensure the long life of the drying unit. These filters and drying unit reduce the relative humidity of the air supplied to the motors to a point which is acceptable to the manufacturer.

The precision regulator is set and locked at manufacturer suggested 2 psi, and a relief valve is provided, set, and locked at 3 psi to ensure that pressure stays below the manufacturer stated servo motor limits (3 psi).

A pressure switch is installed to give the HMI indication if pressure goes outside of acceptable limits, and a flow switch is installed to give indication if there is excessive leakage in the system (i.e. tubing disconnecting from the motor fitting).

MI Drive Replacement

To replace an MI Drive, follow these steps:


- 1) Shutdown the HMI computer
- 2) Remove 480V power
- 3) Follow lockout/tagout procedures

⚠ WARNING Allow 30 minutes for the internal capacitors to discharge before removing any cables


- 4) Remove the cables from the failed motor by opening the metal clamps and pulling the cables off of the motor



- 5) Remove mounting hardware which holds the servo motor and related mechanical assemblies in place
- 6) Remove failed motor
- 7) Install new motor in the same orientation as the failed motor
- 8) Replace mounting hardware
- 9) Set the address the new motor inside of the termination plugs. One side will have an H stamped inside; set this potentiometer to the left most digit in the servo address. The other side will have an L stamped inside; set this potentiometer to the right most digit in the servo address. Example, for servo axis 08: H = 0, L = 8



- 10) Reattach the cables (cables are keyed so they will only go onto the correct terminal) and secure by pushing in on the metal clamps
- 11) Restore 480V power
- 12) Launch the HMI
- 13) Select Servo Initialization Options from the following screen - within nine seconds!




- 14) Enter your username and password
- 15) Select Initialization Data from the following screen



16) Select the correct drive from the dropdown list and check the Include This Servo in Initialization checkbox

SAMPLE IMAGE



- 17) Click Back
- 18) Click Continue
- 19) Once the initialization process is complete, reference the drive (see [Servo Referencing](#))

Purchasing MI Servos Directly From Rexroth

Due to known issues with MI servo motors using firmware later than 4V30, be sure to specify Firmware 4V30 when ordering MI servo motors directly from Rexroth or through your own supplier.

The manufacturer part number for Firmware 4V30 is R911330522.

NOTE: The correct firmware version will be used when ordering MI servo motors through Aagard

Sealing Rexroth Servo Assemblies

This topic applies to Nema 4 and 4x machinery systems.

[Sealing Servo Motor to Gearbox](#)

[Sealing Gearbox to Mount Plate](#)

[End Seal-Cap Edge Sealing \(Rexroth MI Motors Only\)](#)

[Installing Clamp \(Rexroth MI Motors Only\)](#)

Sealing Servo Motor to Gearbox

- 1) Use Loctite 518 sealant between the servo and the Alpha gearbox
 - a) Loctite 518 usually comes with the washdown GCR Alpha gearboxes
- 2) When the servo motor does not cover the mounting plate on the Alpha gearbox, the exposed part of the counterbore, after the motor is mounted, will need to be filled and sealed with Loctite 5512 or Henkel MS939
 - a) If a gasket plate is used, apply Loctite 518 to both sides of the gasket, sealing the gasket to both the servo motor and gearbox
- 3) Use Loctite 574 sealant on the washdown GCR Alpha gearbox screw in plug
- 4) If the gearbox input bushing has a keyway in it, put food-grade high-temp anti-seize on the servo output shaft when mounting to the Alpha gearbox

CAUTION: Do not put anti-seize on the outside of the bushing



CAUTION: If there is no keyway in the bushing, no anti-seize should be used

Sealing Gearbox to Mount Plate



- 1) Put a bead of Loctite 518 around the output housing between output housing and outer bearing race to keep moisture from entering the gearbox and to seal the gearbox to the mounting plate

- 1) Clean the end seal-cap where it attaches to the motor
- 2) Seal the joint between the end cap and the motor with a 1/4" to 3/8" bead of Loctite 5512 or Henkel MS939
- 3) Use the following images as a reference





- 4) Use your finger to push down on the Loctite to create a sound seal
NOTE: Moisten your fingers with soapy water to keep the Loctite from sticking to your fingers
 - 5) Let the motor sit for at least 24 hours before using
-

Installing Clamp (*Rexroth MI Motors Only*)

When the motor is mounted, the cable clamp needs to be installed.

Torque settings for clamps are as follows:

- 61/76 clamps (tapped, using blue Loctite) with 15 inch-pounds (+/- 25%)
- 41 clamps (with SS Nyloc nut) with 24 inch-pounds (+/- 25%)

A general rule of thumb is when the clamp being installed is tight enough, the existing clamps on the motor will be loose.

If the clamps are over-tightened, the motor will not initialize. If this occurs, remove the clamp, initialize the machine, and reinstall the clamp.

Servo Cable Replacement

Tools Required:

- Flathead Screwdriver Set

Routine:

- 1) Disconnect main power
 - a) Wait 30 minutes
- 2) Flip open cable clamp on servo with screw driver, one end of cable at a time
- 3) Pull cable plug straight down
 - a) Do not twist or bend it
- 4) Do same to other end of cable
- 5) Put in new cable, in reverse order
- 6) Clamp both ends of cable down with servo clamp
- 7) Reconnect main power

Servo Gearbox Replacement

Tools Required:

- Flathead Screwdriver Set
- Metric Allen Wrench Set
- Torque Wrench with Metric Allen Sockets
- LP+/LPB+ Operating Manual
- Rexroth IndraDrive Instruction Manual

Routine:

- 1) Disconnect main power
- 2) Remove cables from failed motor by opening metal clamps and gently pulling cables off of motor to prevent damage to plug
- 3) Remove small cap that covers set screw in gear box and loosen set screw but Do NOT REMOVE IT
- 4) Remove mounting hardware that holds servo motor and related mechanical assemblies in place
- 5) Remove failed motor
- 6) Compare part numbers of old and new motors to make sure new motor is correct motor
- 7) Clean all mating surfaces and install new motor in same orientation as failed motor. Motor should slide into gearbox with very little resistance
- 8) Apply a small amount of Loctite (#243) to bolts and then bolt motor to gearbox
 - a) Use only Grade 8 Bolts
- 9) Torque set screw in gear box to one of the following:
 - a) Gear box LPB090, Torque to 23 (Nm)
 - b) Gear box LPB120, Torque to 45(Nm)
- 10) Replace small plastic cap that covers set screw hole on gear box
- 11) Set address for new motor inside of termination plugs
 - a) One side will have an H stamped inside; set this potentiometer to left most digit in servo address
 - b) The other side will have an L stamped inside; set this potentiometer to right most digit in servo address for example: for servo axis 08: H = 0, L = 8
NOTE: New version drives use SW 4 and SW5 for setting node address (SW5 = Value of tens, SW4 = Value of ones), for example: for servo axis 08: SW5=0 and SW4=8
- 12) Reattach cables, being careful not to damage connectors
 - a) Cables are keyed so they will only go onto correct terminal
 - i) Secure cables by pushing in on metal clamps
- 13) Replace KCU module fuses
- 14) Reconnect main power
- 15) Reference drive

Slide-Rite Gearbox Lubrication

The Slide-Rite gearbox is lubricated at the factory and ready for installation. For most applications, the gearbox is lubricated for life. In the instance where additional lubrication is needed, an extreme-pressure synthetic lubrication which exhibits excellent anti-wear and rust protection qualities, such as Anderol® 786 [14 oz. cartridge #0100-1604] or equivalent, is recommended.

NOTE: For hand-crank applications, additional lubrication is not required

Solenoid Valves

[Glue Solenoid Valve Replacement](#)

Glue Solenoid Valve Replacement

Tools Required:

- Flathead Screwdriver Set
- Electrical Prints

Routine:

- 1) Turn off main air
- 2) Disconnect all air lines and electrical wires on valve
- 3) Remove bolts that mount valve
- 4) Replace old valve with new valve (you may use same fitting or get new ones)
- 5) Mount new valve with same bolts
- 6) Reconnect all air lines and electrical wires (see electrical prints)
- 7) Turn on main air

Motors

[Motor and Gearbox Replacement](#)

[Motor and Gearbox Replacement for Side Belts](#)

[Slide-Rite Gearbox Lubrication](#)

Motor and Gearbox Replacement

Tools Required:

- Standard Wrench Set
- Standard Allen Pack

Routine:

- 1) Disconnect main power
- 2) Disconnect wires to motor
- 3) Loosen bolts on bottom of gearbox and loosen tensioner to take belt off of gearbox pulley
- 4) Take pulley off of gearbox
 - a) Save key!
- 5) Remove motor and gearbox assembly by taking bolts completely out of bottom of gearbox by mount
- 6) Remove motor from gearbox
 - a) Mount should slide out without force
 - b) Save key
- 7) Put anti-seize on edge of new gearbox where motor surface mounts
- 8) Place new motor and new gearbox together with same key in motor shaft
 - a) It should slide together without force
 - b) You may need to modify key or get a new one
- 9) Use existing bolts to secure motor and gearbox together
- 10) Place assembly back into machine
- 11) Use same bolts to mount gearbox to machine
- 12) Reconnect wires to motor
- 13) Reconnect main power

Motor and Gearbox Replacement for Side Belts

This topic only applies to Case Packers

Tools Required:

- Standard Wrench Set
- Standard Allen Pack

Routine:

- 1) Disconnect main power
- 2) Disconnect wires to motor
- 3) Loosen belt tensioner, and take off belt
- 4) Take pulley off of gearbox
 - a) Save key
- 5) Loosen bolts on bottom of gearbox and loosen tensioner to take belt off gearbox pulley
- 6) Remove motor and gearbox assembly by taking bolts completely out of bottom of gearbox by mount
- 7) Remove motor from gearbox
 - a) Mount should slide out without force
 - b) Save key
- 8) Put anti-seize on edge of new gearbox where motor surface mounts
- 9) Place new motor and new gearbox together with same key in motor shaft
 - a) It should slide together without force
 - b) You may need to modify key or get a new one
- 10) Use existing bolts to secure motor and gearbox together
- 11) Place assembly back into machine
- 12) Use same bolts to mount gearbox to machine
- 13) Put pulley back on
- 14) Put belt back on and tension
- 15) Reconnect wires to motor
- 16) Reconnect main power

Slide-Rite Gearbox Lubrication

The Slide-Rite gearbox is lubricated at the factory and ready for installation. For most applications, the gearbox is lubricated for life. In the instance where additional lubrication is needed, an extreme-pressure synthetic lubrication which exhibits excellent anti-wear and rust protection qualities, such as Anderol® 786 [14 oz. cartridge #0100-1604] or equivalent, is recommended.

NOTE: For hand-crank applications, additional lubrication is not required

Knives



Knife Replacement and Setup

NOTE: This topic only applies to Machines 62 and 94

If this feature is installed, use this document for knife replacement and operating specifications.



Anvil



Knife



Anvil and Knife Combined

General Operation of the knife mechanism:

The anvil is in a fixed position, while the knife travels up and down and rides against the front face of the anvil. The cutting edge must be the only point of contact between the knives. Pressure to cutting edges is applied by two springs pushing out on the upper edge of the knife.

NOTE: If springs are replaced, springs must be identical with respect to wire gauge, diameter and length.

The following steps detail the necessary procedure to properly and safely remove and replace the fly knife and anvil, and to set the proper gap.

NOTE: Knife and Anvil must be replaced as a set!

To remove the Fly Knife and Anvil:

1. Dump the air supply to the machine
2. Turn the bellcrank to raise the fly knife mount, and lock it into position with the stored pin






Image may be reversed with opposite flow Inserter.

3. Remove the anvil bolts, and pull off the anvil
4. Remove the knife bolts and nyloc nuts, and pull off the fly knife. **Don't lose the springs!**



To replace the Anvil and Fly Knife, and set proper gap:


1. If the bellcrank is no longer locked in the up position, do so now
2. Fasten anvil into place
3. Unlock bellcrank and lower knife to lowest position, and store pin in unlocked position
4. Restore air supply
5. Insert springs between knife and mount while seating nyloc nut into the slot




6. Insert grade-8 socket heads and tighten enough to keep springs and nyloc nuts in place. **Do not tighten all the way!**
7. Draw the guided side in until it just makes contact with anvil from top to bottom
8. Draw the non-guided side in until it just makes contact
9. Back out guided side until the gap is between .013" and .016" at the bottom edge of the knife
10. Draw non-guided side in until top edge of guided side closes to .001" - .002" (paper thickness)
11. You may need to readjust the guided or non-guided sides until the target gaps are achieved

Note: Knife must be in closed or "cut" position when setting clearances.

(Exaggerated Clearances Shown)





(Exagerated Clearances Shown)

Knife Replacement and Setup

NOTE: This topic only applies to Machines 146 and 147



Anvil



Knife




Anvil and Knife Combined

The anvil (upper knife) is a fixed knife, while the fly knife (lower knife) travels in an upstream / downstream direction, and rides against the front face of the anvil. The cutting edge must be the only point of contact between the knives. Pressure to cutting edges is applied by two springs pushing out on upper edge of the fly knife.


NOTE: If springs are replaced, springs must be identical with respect to wire gauge, diameter and length.

The following steps detail the necessary procedure to properly and safely remove and replace the fly knife and anvil, and to set the proper gap.



To remove the Fly Knife and Anvil:

- 1) Turn the knife crank arm so the knife is extended to its downstream position and lock into position with lock pin





- 2) Loosen the two (2) fly knife assembly bolts; while holding the bolts, remove nyloc nuts, and pull off the fly knife carefully. Don't lose the springs!
- 3) Remove the three (3) anvil knife assembly bolts and remove the anvil from the machine

To replace the Anvil and Fly Knife, and set proper gap:

- 1) If the knife crank arm is no longer extended to its downstream position and locked in place, do so now
- 2) Fasten anvil into place with three (3) bolts
- 3) Insert springs into fly knife mount blocks
- 4) Re-install fly knife with the two (2) bolts with cutting edge toward the anvil and facing down; then screw on nyloc nuts
- 5) Unlock the lock pin on the knife crank arm and move the knife assembly to its farthest upstream position ("cut" position)
- 6) Turn fly knife bolts in to draw fly knife close to anvil
- 7) Adjust the guided side in until it just makes contact with anvil from top to bottom
- 8) Adjust the non-guided side in until it just makes contact
- 9) Back out guided side until there is approximately .020" gap at the top edge of the knife
- 10) Adjust non-guided side in until top edge of guided side closes to .001 - .002 (paper thickness)
NOTE: Now you should have a .013 to .016" gap at the lower guided side.
- 11) **Important!** When knife replacement process is complete, ensure that the crank arm lock pin is **not** in the lock position!

NOTE: Knife must be in closed or "cut" position when setting clearances



Knife Replacement and Setup

NOTE: This topic only applies to Machine 148



Anvil



Knife




Anvil and Knife Combined

The anvil (upper knife) is a fixed knife, while the fly knife (lower knife) travels in an upstream / downstream direction, and rides against the front face of the anvil. The cutting edge must be the only point of contact between the knives. Pressure to cutting edges is applied by two springs pushing out on upper edge of the fly knife.


NOTE: If springs are replaced, springs must be identical with respect to wire gauge, diameter and length.

The following steps detail the necessary procedure to properly and safely remove and replace the fly knife and anvil, and to set the proper gap.



To remove the Fly Knife and Anvil:

- 1) Turn the knife crank arm so the knife is extended to its downstream position and lock into position with lock pin





- 2) Loosen the two (2) fly knife assembly bolts; while holding the bolts, remove nyloc nuts, and pull off the fly knife carefully. Don't lose the springs!
- 3) Remove the three (3) anvil knife assembly bolts and remove the anvil from the machine

To replace the Anvil and Fly Knife, and set proper gap:

- 1) If the knife crank arm is no longer extended to its downstream position and locked in place, do so now
- 2) Fasten anvil into place with three (3) bolts
- 3) Insert springs into fly knife mount blocks
- 4) Re-install fly knife with the two (2) bolts with cutting edge toward the anvil and facing down; then screw on nyloc nuts
- 5) Unlock the lock pin on the knife crank arm and move the knife assembly to its farthest upstream position ("cut" position)
- 6) Turn fly knife bolts in to draw fly knife close to anvil
- 7) Adjust the guided side in until it just makes contact with anvil from top to bottom
- 8) Adjust the non-guided side in until it just makes contact
- 9) Back out guided side until there is approximately .020" gap at the top edge of the knife
- 10) Adjust non-guided side in until top edge of guided side closes to .001 - .002 (paper thickness)
NOTE: Now you should have a .013 to .016" gap at the lower guided side.
- 11) **Important!** When knife replacement process is complete, ensure that the crank arm lock pin is **not** in the lock position!


NOTE: Knife must be in closed or "cut" position when setting clearances




Taper Knife Replacement

NOTE: This topic only applies to Machines 88 and 114

From time to time, the taper knives may need to be changed.



To do so, cover the knives with the protective cover. Loosen the three bolts with a 5/32" Allen wrench, and carefully remove the knives. Remove the protective cover.




Upstream Knife




Downstream Knife

Install new knives, making sure they are out far enough and at an angle (drawings are not to scale).



Upstream Knife Measurements (top view)




Downstream Knife Measurements (top view)

Knife Replacement - Vertical Cartoner


NOTE: This topic applies to vertical cartoner machines

Based on the number of machine cycles, the knife may need to be changed periodically. Because the knife blade is inside the lower seal jaw assembly, the upper seal jaw assembly must be positioned out of the way so that the knife can be removed from the top of the lower seal jaw assembly.


- 1) Remove the connecting rod bolt from the upper seal jaw assembly
CAUTION: Hold the assembly securely so it doesn't drop once the bolt is removed!




- 2) Raise seal jaw assembly fully up and secure in the raised position
NOTE: A small C-clamp clamped on the rail works well



3) Remove the two (2) bolts securing the knife



4) Carefully lift knife up and out of lower seal jaw. Note the orientation of the knife cutting angle. The angle should face toward the front of the seal jaw (upstream).



Lubrication




Bundler Unitizer Lube Points


NOTE: This topic applies to bundler unitizer machines

There are three points on the Bundler Unitizer which require lubrication approximately one time per week: [Turner Assembly](#), [Nip Roller Assembly](#) and [Knife Assembly](#). Apply the recommended amount of grease to each grease zerk.

NOTE: Each bearing manufacturer has different requirements for amount, frequency and type of lubrication; always follow manufacturer guidelines when lubricating the machine




Turner Assembly



Nip Roller Assembly



Knife Assembly




Vertical Cartoner Lube Points

NOTE: This topic applies to vertical cartoner machines

There are several points on the Vertical Cartoner which require regular lubrication. Apply the recommended amount of grease to each grease zerk.

NOTE: Each bearing manufacturer has different requirements for amount, frequency and type of lubrication; always follow manufacturer guidelines when lubricating the machine

NOTE: Flip image for opposite-hand machines!



| | |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>Side Seal</p> <ul style="list-style-type: none"> Shuttle (6) Bottom Seal (2) Top Seal (2) Knife (2) Rod Ends (if any exist) | <p>Magazine</p> <ul style="list-style-type: none"> Wheels (2) Push Clip (2) Bottom Magazine Clip (2) Carton Slide Rod End (1) Nip Belt Drive Shaft (2) Floating Blank Guide (2) |
| <p>First End Seal</p> <ul style="list-style-type: none"> Shuttle (4) Bottom Seal (2) Top Seal (2) Rod Ends (if any exist) Fingers (4) (n/a on Aagard 149) In/Out Axis (2) (n/a on Aagard 149) | <p>Second End Seal</p> <ul style="list-style-type: none"> Shuttle (4) Operator Side Seal (2) Non-Operator Side Seal (2) Rod Ends (if any exist) Fingers (4) (n/a on Aagard 149) In/Out Axis (2) (n/a on Aagard 149) |
| <p>First End Tuck (1)</p> | <p>Second End Tuck (1)</p> |

Installation procedure

- 1) Before installation process, clean and inspect all mounting surfaces
 - a) Look for and remove burrs, nicks, dirt, etc.
- 2) Remove anti-rust/preservative oil
- 3) Install lube fitting/piping joint into the block
- 4) Lubricate block according to recommendations
- 5) Carefully slide block onto rail using arbor – be sure to keep the carriage in line with the rail

IMPORTANT: Do not angle or force carriage onto rail; you will potentially loose ball bearings
- 6) Install plugs in bolt holes of rail, keeping plugs flush with the top of the rails

Additional Documentation

[THK Grease Amounts for Blocks](#)

Manufacturer's Information

[THK, LM Guide Installation](#)

[THK AFG MSDS](#)

Machine 200

NOTE: This topic only applies to Machine 200

| Tray Loading | |
|-----------------------------------------------|----------------|
| tray lift | 1 cylinder |
| tray transfer | 1 cylinder |
| bullet transfer from dagger boards to slides | 2 cylinders |
| bullet pick | 5 cylinders |
| bullet stops | 5 cylinders |
| trolley dump | 1 cylinder |
| bullet hopper | 1 cylinder |
| linkage arms on the bullet pick transfer area | 12 lube points |
| Cartoner | |
| carton transfer into star wheel | 1 cylinder |
| carton reject | 1 cylinder |
| carton squaring | 1 cylinder |
| one each side, flap tuck | 2 cylinders |
| carton load (tray load into carton) | 1 cylinder |
| tray reject and refeed | 2 cylinders |
| tray refeed up stack | 1 cylinder |
| tray up stack before loader | 1 cylinder |
| Mega Cartoner | |
| Carton pick | 2 cylinders |
| mega compression (one each side) | 2 cylinders |
| mega funnels (one each side) | 2 cylinders |
| carton load into mega carton | 1 cylinder |
| mega reject | 1 cylinder |
| mega carton transfer | 1 cylinder |
| Case Packer / Palletizer | |
| compression | 4 cylinders |
| flap tuck before compression | 2 cylinders |
| case magazine | 1 cylinder |
| case magazine access clamp | 1 cylinder |
| case rotate robot | 1 cylinder |

| | |
|-------------------------|---------------|
| case pusher robot | 1 cylinder |
| carton load into case | 2 cylinders |
| lowerator | 1 cylinder |
| linkage for case rotate | 2 lube points |

Pneumatics



Cylinder Replacement

Tools Required:

- External Snap Ring Pliers
- Standard Wrench Set
- Metric Wrench Set
- Standard Allen Pack

Routine:

- 1) Turn off main air
- 2) For top and bottom cylinders, remove bolt at end of rod
- 3) Use snap ring pliers to remove pin at base of cylinder
- 4) Remove cylinders and replace with new ones, remove with wrench; you may use same fittings or new ones
- 5) Use same rod ends
- 6) Put cylinders back in reverse order
- 7) For cylinders on the side, remove finger on top of shaft
- 8) Remove all bolts which mount cylinder to plate
- 9) Replace old cylinder with the new one; you may use same fittings or new ones
- 10) Put new cylinders back in reverse order
- 11) Turn on main air

Suction Cup Replacement

Tools Required:

- Standard Allen Pack
- Standard Wrench Set

Routine:

- 1) Use Allen wrench to remove mounting bolt on inside of cup
- 2) Replace old cup with new cup
 - a) Use new thread tape on new cups
- 3) Make sure all new cups are turned in same length so vacuum is even on all cups

Valve Bank Replacement

Tools Required:

- Standard Allen Pack


Routine:

- 1) Turn off main air
- 2) Remove all air lines from valve bank
 - a) Make sure all lines are labeled
- 3) Replace single valve or whole bank with new one
- 4) Refer to pneumatics print and hook up all air lines
- 5) Turn on main air
- 6) Manually fire each valve to make sure valve is working properly

Printers and Scanners



Create/Adjust Printer Message



Create Message On Marsh Printer

- 1) On the Marsh Printer Controller's home screen, press the Messages function key
- 2) Use the arrow keys to highlight the New menu item
- 3) Press Enter to display the new message screen
- 4) After keying in your message, press the Messages function key
- 5) Use the arrow keys to highlight the Save menu item, then press Enter
- 6) Key in a name for your message in the Save Message As field
- 7) Press the OK function key to add the name to the list of existing messages
- 8) Press Esc to return to the home screen

Adjust Message Position on Marsh Printer

- 1) On the Marsh Printer Controller's home screen, press the Print Settings function key to display the character width screen
- 2) Use the arrow keys to highlight the Print Position menu item and press Enter to display the print position screen
- 3) Press the Move Left or Move Right function key to move one space at a time
- 4) To move left or right ten spaces, press the Shift key in combination with the Move Left or Move Right function key
- 5) Press the OK function key to save your changes and return to the home screen

Adjust Message Width on Marsh Printer

- 1) On the Marsh Printer Controller's home screen, press Print Settings to display the character width screen
- 2) To change width, press the Narrower or Wider function key
- 3) Press the OK function key to save your changes and return to the home screen

For more information on the Marsh Printer, please view the Marsh Printer manual.

Marsh Ink Head Replacement

Tools Required:

- Metric Wrench Set

Routine:

- 1) Turn off air and power to the printer
- 2) Disconnect all ink lines and wires to the print head
- 3) Remove the bolts under head and mount
- 4) Replace the old head with the new head
- 5) Make sure the dip switches inside the head are set the same as the old head
- 6) Reconnect all ink lines and wires
- 7) Turn on air and power

Marsh Ink Supply Tank Replacement

Tools Required:

- None

Routine:

- 1) Remove all air lines and ink lines from the tank
- 2) Remove the cap with ink lines that is on the tank
- 3) Replace the old tank with the new tank
- 4) Put the original cap with the ink lines on the new tank
- 5) Reconnect all air and ink lines

Marsh Printer Controller Replacement

Tools Required:

- Metric Wrench Set

Routine:

- 1) Turn off power to the printer
- 2) Disconnect all wires behind the controller
- 3) Remove mount on the bottom of the controller
- 4) Remove the old controller and replace with the new controller
- 5) Mount the new controller
- 6) Reconnect all wires
- 7) Turn on power to the printer

Microscan Barcode Scanner Replacement


This procedure applies to the Microscan MS- 820 Serial Communication Barcode Scanner.



NOTE: ESP software from Microscan must be installed on computer connecting to barcode scanner

IMPORTANT NOTE: Aagard custom-made barcode scanner configuration cable, part number Z0239915, is required for this procedure

- 1) Connect Aagard custom-made barcode scanner configuration cable




- a) Insert 15-pin end of cable into barcode scanner, in same port as standard cable, the cable used while machine is running
- b) Insert 9-pin end of cable into serial port on computer
- 2) **NOTE:** ESP software must be installed
 - a) Connect power wires from cable using previously installed quick connect dongle
 - i) On machines with Beckhoff controls, the dongle is most likely inside the HMI panel
 - ii) On machines with Allen-Bradley controls, the dongle is most likely inside a junction box near the barcode scanner


- 3) Open ESP software
- 4) Select MS-820
- 5) Check Skip EZ Mode




- 6) Click OK
- 7) When prompted, click Yes to "Would you like to connect to the MS-860?"
 - a) If not prompted, click Connect > Connect > Connect




- 8) Open saved configuration file
 - a) File name and path may be similar to the following: C:\Aagard\Source Code\Misc\MicroScan\### MicroScan backup file.esp
- 9) Click Send/Receive



- 10) Click Save to Reader



- 11) Click Send and Save



- 12) When completed, reconnect normal operation cable to barcode scanner

Printer Hose Replacement


Tools Required:

- Wire cutter
- Pliers

Routine:

- 1) Turn off air to the printer
- 2) Unhook both sides of the hose on the tank and head
- 3) Cut all zip ties
- 4) Replace the old hose with the new one
- 5) Zip tie back in place
- 6) Reconnect both sides of the hose on the tank and head
- 7) Turn on air to the printer

Purge Printer



⚠ Without something to catch the ink, the printhead will spray the inside of the machine with ink!

On the Marsh Controller:

- 1) Press the Utility function key
- 2) Use the arrow keys to highlight the Purge menu item and press the Enter key
- 3) Press the Select Printhead function key to toggle between printheads. The LED on the back of the selected printhead will flash amber
- 4) Select the printhead you want to purge, and then press the Add Head function key
- 5) If you want to purge an individual nozzle, use the up down arrow keys to select the nozzle, otherwise all nozzles will purge
- 6) Press the Enable Purge function key. It doesn't matter if the green LED is lit on the controller for the purge to enable

Block the "case at printer" (also often called "case present after rotate") photo eye to start purging. This is the upstream photo eye closest to the print heads. If the photo eye is unblocked, the purging will stop.

For more information on the Marsh Printer, please view the Marsh Printer manual.

SICK 400 Series Barcode Scanner

This procedure applies to configuring replacement SICK 400 Series Serial Communication Barcode Scanners.




NOTE: To configure barcode scanner, CLV Setup from SICK must be installed on computer connecting to barcode

To configure a SICK 400 Series barcode scanner, follow these steps:


- 1) Evaluate how current barcode scanner is connected to computer
- 2) Evaluate how current barcode scanner is powered

NOTE: You may need a custom cable to provide power to scanner while also connecting it to a computer


- 3) Determine if CLV Setup is installed on HMI
- 4) Connect barcode scanner to computer
- 5) Open CLV Setup
- 6) Click OK on Welcome to CLV Setup screen




7) Click File > Open




- 8) Locate and open backup configuration file
- 9) Naming conventions used in the past follow these patterns: "MachineNumber_CLV ScannerModel SickBarCodeScanner.scl" or "MachineNumberSickBarCodeScanner.scl"
- 10) Click OK to acknowledge file was loaded




11) Note "No Connection!" status in bottom right corner of application window




12) Click Tools > CLV Assistant




13) Select Parametrize a scanner and click Next




14) Click Next




15) Once connected, click Next




16) Click Next



- 17) Default settings are loaded
- 18) Click CLV### and select Download to device



- 19) Select Permanent to store the parameters on the scanner



- 20) Close CLV Setup
- 21) Disconnect barcode scanner from computer and reconnect it to machine
- 22) Test scanner

SICK 600 Series Barcode Scanner

This procedure applies to configuring replacement SICK 600 Series Serial Communication Barcode Scanners.



- 1) **IMPORTANT NOTE:** Different methods for configuring SICK 600 series barcode scanners have been used

[Configured by PLC code](#)
[With backup micro SD card](#)
[With backup .spr file](#)

Configured by PLC code

- 1) Install and connect replacement barcode scanner
- 2) Test scanner

PLC will automatically configure barcode scanner

With backup micro SD card

Some cards have a backup Micro SD card with a parameter file clone.

- 1) Install and connect replacement barcode scanner
- 2) Locate micro SD card
 - a) Card may be in HMI cabinet or in old scanner
- 3) Insert micro SD card into scanner
- 4) Cycle power to the scanner
- 5) Test scanner
- 6) Remove micro SD card and store in HMI cabinet

With backup .spr file

NOTE: SOPAS from SICK must be installed on computer connecting to barcode; software may already be installed on HMI

- 1) Connect barcode scanner to computer which has SOPAS
- 2) Open SOPAS software

- 3) Locate and open backup project file (*.spr)
- 4) Connect software to device
- 5) Click Communication > Download all Parameters to Device
- 6) Save
- 7) When using a computer other than the HMI, disconnect scanner from computer and reconnect it to machine
- 8) Test scanner

Sanitation



Hoppers

NOTE: This topic applies to vertical cartoner machines

For sanitation purposes, it will be necessary to gain access to the hopper area.





To gain access to the hopper area, follow these steps:

- 1) Using the changeover procedure for Buckets, remove buckets
 - a) When removal of all buckets is not required, remove at least 8 buckets for this procedure
 - b) If not all buckets have been removed from the machine, manually rotate the bucket carousel in reverse until the opening created by removing the buckets is in front of the hopper area; do so from the bucket changeover location

Rail to be removed



- 2)  Remove high voltage and lockout the machine
- 3) Fully open Guard Doors 9 and 11
- 4) Open and remove Guard Door 10 by lifting it off of its hinges
 - a) Store guard door out of the way
- 5) Using 1/2" wrench, remove the two center guard door posts




a) Store upstream post as shown below



- b) Store downstream post out of the way
- 6) Place a board or other solid object inside the machine to create a platform on which to stand



- 7) Remove all dust collection hoses and tubing from both upstream and downstream hoppers
- NOTE:** Use either side of the machine for best access
 - IMPORTANT NOTE:** When standing inside the machine on the non-operator side of the machine, do not stand on chains!




- 8) Lift and prop up the drop chute by placing a block between the frame member and tube collar



- Repeat this process on the second drop chute


- 9) Using 1/2" wrench, remove bolts securing rail
 - a) **NOTE:** If working alone, use a c-clamp to hold up one end of the rail




- 10) Carefully lower rail and store inside bucket carousel



- 11) Carefully tip bucket "T" bars in and down



- a) If necessary for clearance, manually rotate the bucket carousel; do so from the bucket changeover location
- 12) Release the assembly by turning the manual valve into the **RETRACT** position, with the valve handle pointing down




- 13) Carefully and slowly pull the entire assembly toward the operator side of the machine


- a) **NOTE:** Watch for clearance!




- 14) With the assembly fully extended, secure it with a c-clamp



- 15) Remove the pin from rod end mount on downstream side of hopper
 a) Allow pin to dangle
- 16) Pull rod off of rod end mount
 a) Allow rod end to dangle




17) Using 9/16" wrench, remove hopper nuts on downstream side of hopper



18) Standing on upstream side of hopper, pull hopper upstream, and lift up and out



To remove hopper,
pull upstream and lift up



19) After sanitation or repairs have been completed, reassemble in reverse order

Machine Heat Up Process

When heat is used for sanitary purposes, special steps must be taken to protect the machine.

IMPORTANT! Machine and its components must not exceed 150°F!

Prior to heat up cycle, Urethane belts must be removed from pulleys and in a relaxed state to prevent additional stretching due to heating process. Some integrated equipment may also need to be removed during heat up process.

Listed below are manufacturer storage temperature specifications for their products which may be installed on this machinery system:

- Allen Bradley – 120°F
- Domino – 140°F
- Marsh – 120°F

Sealing Rexroth Servo Assemblies

This topic applies to Nema 4 and 4x machinery systems.

[Sealing Servo Motor to Gearbox](#)

[Sealing Gearbox to Mount Plate](#)

[End Seal-Cap Edge Sealing \(Rexroth MI Motors Only\)](#)

[Installing Clamp \(Rexroth MI Motors Only\)](#)

Sealing Servo Motor to Gearbox

- 1) Use Loctite 518 sealant between the servo and the Alpha gearbox
 - a) Loctite 518 usually comes with the washdown GCR Alpha gearboxes
- 2) When the servo motor does not cover the mounting plate on the Alpha gearbox, the exposed part of the counterbore, after the motor is mounted, will need to be filled and sealed with Loctite 5512 or Henkel MS939
 - a) If a gasket plate is used, apply Loctite 518 to both sides of the gasket, sealing the gasket to both the servo motor and gearbox
- 3) Use Loctite 574 sealant on the washdown GCR Alpha gearbox screw in plug
- 4) If the gearbox input bushing has a keyway in it, put food-grade high-temp anti-seize on the servo output shaft when mounting to the Alpha gearbox

CAUTION: Do not put anti-seize on the outside of the bushing


CAUTION: If there is no keyway in the bushing, no anti-seize should be used

Sealing Gearbox to Mount Plate



- 1) Put a bead of Loctite 518 around the output housing between output housing and outer bearing race to keep moisture from entering the gearbox and to seal the gearbox to the mounting plate

- 2) If an O-ring seal is used on the Alpha gearbox output shaft, apply food grade high-temp anti-seize to the O-ring fitted over the output shaft
NOTE: Do not allow Loctite to come in contact with O-Ring
- 3) Seal the O-ring cover plate to the gearbox mount plate with Loctite 518





End Seal-Cap Edge Sealing (*Rexroth MI Motors Only*)


Each **Rexroth MI** servo motor must have the end seal-cap edge sealed with Loctite 5512 or Henkel MS939.

NOTE: Rexroth IndraDrive C motors will not need end caps sealed (new washdown servo motors)

IMPORTANT NOTE: Do not void your warranty by removing the end seal-cap!

- 1) Clean the end seal-cap where it attaches to the motor
- 2) Seal the joint between the end cap and the motor with a 1/4" to 3/8" bead of Loctite 5512 or Henkel MS939
- 3) Use the following images as a reference





- 4) Use your finger to push down on the Loctite to create a sound seal
NOTE: Moisten your fingers with soapy water to keep the Loctite from sticking to your fingers
 - 5) Let the motor sit for at least 24 hours before using
-

Installing Clamp (*Rexroth MI Motors Only*)

When the motor is mounted, the cable clamp needs to be installed.

Torque settings for clamps are as follows:

- 61/76 clamps (tapped, using blue Loctite) with 15 inch-pounds (+/- 25%)
- 41 clamps (with SS Nyloc nut) with 24 inch-pounds (+/- 25%)

A general rule of thumb is when the clamp being installed is tight enough, the existing clamps on the motor will be loose.

If the clamps are over-tightened, the motor will not initialize. If this occurs, remove the clamp, initialize the machine, and reinstall the clamp.

Washdown Considerations

If this machine is washdown, there are specific points to consider in order to properly maintain your system.

NOTE: Not all sections of this system may be washdown!

For more information regarding washdown on this machine, please view the Aagard Equipment Standard.

Before Washdown

- Avoid direct spray to electrical components where possible (AC motors, sensors, solenoid valves, and especially on servo drives)
- Cover glue tanks
- Cover printers or other components not rated for washdown
- Cover entire HMI cabinet where possible

NOTE: Use of high pressure or reduced nozzles to create more pressure, including using a finger on the end of a hose, may cause moisture to reach inside washdown components

After Washdown

- Blow off machine after washdown to remove standing water
- Dry off areas which come in contact with liquid-absorbent materials
- Grease after each washdown since some washdown chemicals are a degreaser
 - The higher the pressure used to washdown, the more likely grease will be washed out of bearings
 - Using a washdown degreaser chemical increases the possibility of grease being washed from bearings
- Apply a light coat of oil to all linear rails (Thomson, THK, V-Rails, etc.)
 - Do not contaminate the surrounding areas by applying too much oil

IMPORTANT NOTE: Dry cycle machine after entire washdown is complete; doing so gets new lubrication worked into bearings; this is especially important if machine will be idle for a long period of time after washdown

Sensors, Switches and Gauges



Your Aagard Machine contains proximity switches, Hall effect guard door switches, cylinder switches, and photo electric eyes.

- The Hall Effect guard door switches use a magnet, which makes or breaks an electrical contact.
- Proximity switches generate a high frequency electromagnetic field. When an object enters this field, the prox's circuit recognizes a change and turns its solid state output ON or OFF.
- Cylinder switches detect the extended or retracted position of an actuating cylinder.
- There are three types of Photoelectric switches - **Reflective Units**, **Thru- Beam Units**, and **Fiber Optic Units**.
 - **Reflective Units** project a beam from a transmitter/receiver unit to a reflector. Object detection occurs when the beam is interrupted.
 - **Thru-Beam Units** project a beam from a transmitter unit to a receiver unit. Object detection occurs when the beam is interrupted.
 - **Fiber Optic Units** function as either Reflective Units or Thru-Beam Units. (The transmitter and receiver are in the same housing.)

Please see the Manufacturers' Information Binder and Manuals, provided during machine installation, for specific product information on the sensors located on your Aagard Machine.

Cognex Checker Replacement

NOTE: This topic only applies to Aagard Machines with a Cognex Checker installed



Overview Steps

- Power down machine
- Disconnect quick-disconnect connectors on top of checker
- Unbolt Cognex checker from mount
- Bolt replacement Cognex checker to mount
- Connect both quick-disconnects on top of checker
- Power up machine
- Set personality type
- Set Cognex focus
- Set Cognex name
- Load jobs to new checker
- Apply job control settings


NOTE: Due to differences in 3G and 4G software, some screens may appear differently

Specific Steps

- 1) After the PC has started, login to the HMI with Level 3 or higher access, and minimize the HMI application
- 2) From the Windows Start bar, click Start > All Programs > Cognex >
 - a) For 3G software, the path continues to: Checker Vision Sensors 2.6 > Checker 2.6
 - b) For 4G software, the path continues to: Checker Vision Sensors 3.1 > Checker 3.1

- 3) Once the Cognex interface software is running, select the new checker from the Checkers Column in the Connection panel, and click Connect.

NOTE: The new checker will show up in the list as a number; it has not yet been named




Please continue with one of the following series of steps.

[4G Connection and Configuration](#)

[3G Configuration](#)

4G Connection and Configuration


- 1) Click **ADD CHECKER BY IP** to connect to a 4G Cognex Checker




- 2) Enter IP Address



- 3) Click **OK**
- 4) Select **USE CUSTOM SETTINGS**




- 5) Enter Subnet Mask
- 6) Click **APPLY**
- 7) **NOTE:** The added checker will be shown in the list
- 8) Once the checker is added, click **CONNECT**




- 9) The configuration menu will appear



- a) Click **SET PERSONALITY**
 - i) Select **PRESENCE**
- b) Click **SET I/O MODE**
 - i) Select **JOB CHANGE**
- c) Click **NETWORK SETTINGS**
 - i) Verify pre-filled information is correct
- d) Click **PASSWORDS**
 - i) Accept default settings
- e) Click **PROTOCOL SETTINGS**
 - i) Accept default settings
- f) Job Control - skip this step for now
- g) Click **MANAGE JOBS**



- i) Add pre-existing jobs, if any are available on the PC
 - (1) Browse to the job location
 - (2) Make the appropriate **PC OPERATIONS** selection(s)
 - (3) Click **DONE**
- h) Click **JOB CONTROL**, if pre-existing jobs were added in manage jobs
- i) Set jobs to the desired job slots



- j) Set up Boot Job to run
 - i) If there are multiple jobs, select **THE CURRENT RUNNING JOB** as the boot job
 - ii) If there is only one job, as in the above example, select it as the boot job
 - iii) Click **OK**

10) Click **OK** again to close the configuration window

NOTE: 4G Cognex Checker connection and configuration is complete!


NOTE: If new jobs are created, they will have to be configured

3G Configuration


- 1) Set personality type
 - a) From the menu bar, click Checker > Select Personality...



- b) Click Presence to select it as the personality type




- 2) Set Cognex focus
 - a) To see the camera view, click on Create a New Job




- b) Go the setup image screen, where the brightness can be adjusted to see the image properly
- 3) **NOTE:** This job is only used temporarily for adjusting the focus, and will not be saved


- a) Reference electrical prints to find focal distance required for the Checker; place an object at that distance in front of the lens, and focus the camera onto that object by rotating the lens cover of the Cognex
- 4) **NOTE:** There is a set screw which will need to be loosened to rotate the lens cover; retighten when finished!
- 5) **NOTE:** In some cases, it may be easier to focus the camera before mounting it to the machine
- 6) Set Cognex name
 - a) From the menu bar, click Checker > Rename Checker...




- 7) Type the new name of the checker which was replaced; for this machine, use either IcingInBucketChecker or IcingInPouchChecker



- 8) Click OK
- 9) Load jobs to new Checker
 - a) From the menu bar, click Checker > Manage Jobs...




- b) In the *Folders on the PC* panel of the *Manage Jobs* dialog, browse to: My Computer\Aagard### (C:) \Aagard\Source Code\Misc\Cognex Checker



- c) Select the job files appropriate for the checker
 d) Click Copy the Selected Jobs to Checker
 e) Click Done
 10) Set up the Job Control:
 a) From the menu bar, click Checker > Set up Job Control...



- b) If prompted to save current job, click No
- c) Set up Job Slot 0 and Job Slot 1 as shown below
- d) **NOTE:** Specific job name is dependent on the checker



- 11) Select the Boot Job. Click OK when done
- 12) Close interface software
 - a) If prompted to save current job, click No

NOTE: 3G Cognex Checker configuration is complete!

Guard Door Switch Replacement

Tools Required:

- Phillips Screwdriver Set

Routine:

- 1) Disconnect wires to guard switch
- 2) Remove guard switch with screwdriver
- 3) Put new switch in
- 4) Reconnect wires to new switch
- 5) If magnet is bad, remove magnet with screwdriver
- 6) Replace magnet with a new one
 - a) Make sure magnet is in same direction as old one

Light Curtain Replacement

Tools Required:

- Standard Wrench Set
- Metric Wrench Set

Routine:

- 1) Disconnect main power
- 2) Disconnect all electric cables from light curtains
- 3) Remove 1/4 x 20 bolts with standard wrench on bottom and top of light curtains
- 4) Put new light curtains together with metric wrench, using old light curtains as a reference
- 5) Place new light curtains on machine using standard wrench
- 6) Tighten down all mounting bolts
- 7) Reconnect all electric wires to light curtains
- 8) Reconnect main power

Photo Eye Cleaning

Use air to blow dust and dirt off of photo eyes and reflectors. If further cleaning is required, use a damp cloth. Make sure cloth is just slightly damp. Unless your machine is designed as a washdown machine, too much moisture can cause harm to photo eye. Avoid using paper towels which can scratch photo eye lens or reflector.

Photo Eye Excess Wire Loops

Photo eyes generally have excess wire loops. Excess wire is intentional, done at Aagard when the machine is built, so we can easily make minor changes to photo eye location. For the same reason, if the photo eye or cable is replaced, it is recommended that excess be maintained for possible future modifications and/or new product sizes.

Photo Eye Replacement

Tools Required:

- Metric Allen Pack

Routine:

- 1) Disconnect wire to photo eye
- 2) Remove photo eye with metric allen wrench
- 3) Replace old photo eye with new one
- 4) Reconnect wires
- 5) Make sure photo eye "sees" reflector; if not, adjust accordingly
- 6) Tighten screws after adjustment

Photo Eye Setup: KT8L

Agard Part Number: Z0123715

Possible Usage(s):
Case Present At Load

The Sick KT8L Photo Eye measures contrast difference between a case present and no case present, reflecting off the top flap lift. To ensure eye will detect various shades of cases, we recommend using light material when doing this procedure. Factory default static 2-point teach-in method is used to set photo eye. For more information, refer to document sent with photo eye.

To set photo eye, do the following:

- 1) Place a sheet of white paper on top of top flap lift to simulate a case present while pressing and releasing SET button
 - a) Wait at least one second
- 2) Remove piece of material so eye hits top flap, press and release the SET button again



The green LEDs indicate the contrast difference. More lights on indicates a higher contrast difference. To ensure good detection reliability, you should have four or more LEDs on when there is no case present.

Photo Eye Setup: WL12G

Aagard Part Number: Z0154591

Possible Usage(s):
Smart Belt Infeed

To correctly setup the Sick WL12G photo eye, follow these steps to ensure proper operation:


- 1) Disconnect cable and remove old photo eye
- 2) Install new photo eye and plug in cable

NOTE: Make sure photo eye and reflector are clean, and no product is between eye and reflector

- 3) On the top of photo eye turn dial to Teach



- 4) LED will blink after 2 seconds
5) Once LED starts blinking, turn the dial to Mode II



- 6) Setup is complete and photo eye is ready to use

Pressure Regulator Gauge Replacement

Tools Required:

- None

Routine:

- 1) Turn off main air
- 2) Remove all air lines from regulator
- 3) Remove plastic nut from on top of regulator
- 4) Once removed, regulator should come out without force
- 5) Replace old regulator with new regulator
 - a) Same fittings may be used
- 6) Put plastic nut back on and tighten by hand
- 7) Reconnect all air lines to regulator
- 8) Turn on main air

Pressure Sensor Replacement and Setup

Replacement

Tools Required:

- Adjustable Wrench

Routine:

- 1) Turn off main air
 - 2) Disconnect electrical wire on sensor
 - 3) Loosen sensor using crescent wrench
 - 4) Remove sensor and replace with new one
 - a) Be sure to use thread tape
 - 5) Tighten sensor down so it is easily readable
 - 6) Reconnect electrical wire on sensor
 - 7) Turn on main air
-

ISE40A Pressure Switch Setup (A model only):

- 1) Enter Function Selection mode – Press and hold S key (> 2 sec.) until display reads F 0
- 2) From F 0 press UP button to navigate to F 1 and press S key 3 times until display reads P_1
- 3) Using UP and DOWN buttons, set display to setting on Aagard wiring diagram
 - a) Aagard standard setting is 65 psi
- 4) Press S key once to display H_1
 - a) Using UP and DOWN buttons set display to 1.0
 - b) Press S key 2 times to return to F 1.
- 5) Return to main display by pressing and holding S key for > 2 seconds; main display should be showing a low number reading

NOTE: Out 1 indicator should not be illuminated at this point if system air has not yet been applied

System pressure switch settings – P_1 = 65.0

By setting ISE40A switch up in this manner, pressure switch will provide an output when system pressure gets to 65.0 PSI; it will loose its signal when it drops below 64.0 PSI.

Proximity Sensor Replacement

Tools Required:

- Proximity Wrenches

Routine:

- 1) Measure distance of thread on either side of prox mount so that new prox can be put in same exact same spot
- 2) Remove wire on proximity sensor
- 3) Use proximity wrenches to remove proximity sensor
- 4) Replace old sensor with new sensor
- 5) Put proximity sensor in same exact spot as old one and tighten down nuts
- 6) Reconnect proximity wire

Slip Sheet in Place Switch Replacement

This topic only applies to Unitizers

Tools Required:

- Flathead Screwdriver Set
- Metric Allen Set
- Standard Allen Set

Routine:

- 1) Disconnect wires to switch
- 2) Remove vertical mount with 5/32" Allen wrench
- 3) Remove switch from mount with Allen wrench
- 4) Replace old switch with new switch and secure on mount
- 5) Place mount back on machine
- 6) Reconnect wires to the switch
- 7) Adjust new switch with small flat screw driver so it sees slip sheet

Vacuum Switch Setup

ZSE40 Vacuum Switch Setup:

- 1) In Aagard wiring diagram, find correct ON and OFF trigger values
- 2) Press and hold SET button until a unit of measure is displayed (example KPa)
- 3) Use UP and DOWN buttons to navigate until inH is displayed (inches of mercury)
- 4) Press and release SET button; this will set inH as unit of measure and display should show a low number as current reading
- 5) Press and release SET button; display should toggle between P_1 and a number
- 6) Use arrow buttons to adjust number of ON trigger value (example -15.0)
- 7) Press and release SET button; display should toggle between P_2 and a number
- 8) Use arrow buttons again to adjust number of OFF trigger value (example -12)
- 9) Press and release SET button; display will toggle between P_3 and a number
- 10) Default value is used for P_3; press/release SET button to go to P_4
- 11) Again, default value is used for P_4; press/release SET button until display is back to main page, which should be showing a low number reading

OUT 1 indicator should not be illuminated, and you are ready for production. Vacuum switch will provide an output when vacuum gets to ON trigger value (example -15.0) and will not turn off output unless vacuum drops below OFF trigger value (example -12.0).

ZSE40A Vacuum Switch Setup:

- 1) In Aagard wiring diagram, find correct P1 and H1 values
- 2) Press and hold SET button until a function is displayed (example F 0)
- 3) Use UP and DOWN buttons to navigate until Uni is displayed
 - a) Use UP key to set display to inH (inches of mercury)
- 4) Press and release SET button; this will set inH as unit of measure and display should show a low number as current reading
- 5) From F 0, press UP key once to navigate to F 1
 - a) Press SET button 3 times so display reads P_1
- 6) Use UP and DOWN buttons to adjust set point to what is stated on wiring diagram
- 7) Press SET button 1 more time so display reads H_1
- 8) Use UP and DOWN buttons to set display to 3.0
- 9) Press SET button 2 times to return to F 1
- 10) Press and hold SET button until display is back to main page; main display should be showing a low number reading

OUT 1 indicator should not be illuminated, and you are ready for production. Vacuum switch will provide an output when vacuum gets to ON trigger value (example -15.0) and will not turn off output unless vacuum drops below OFF trigger value (example -12.0).

Vacuum



Oil Level and Changing Oil in Vacuum Pump

Tools Required:

- Metric Allen Pack

Routine:

- 1) Check oil level in sight glass once daily
- 2) If necessary, put oil in pump to top of sight glass
- 3) First oil change should be after 500 hours of operation
 - a) Subsequent oil changes should be at 500-2000 hours intervals
- 4) Turn pump off
- 5) Using metric Allen wrench, drain oil from plug under sight glass
- 6) Put plug back in
- 7) Refill pump with oil
 - a) About three quarts
- 8) Put cap back on

Suction Cup Replacement

Tools Required:

- Standard Allen Pack
- Standard Wrench Set

Routine:

- 1) Use Allen wrench to remove mounting bolt on inside of cup
- 2) Replace old cup with new cup
 - a) Use new thread tape on new cups
- 3) Make sure all new cups are turned in same length so vacuum is even on all cups

Vacuum Filter Replacement

Tools Required:

- None

Routine:

- 1) Make sure vacuum pump is off
- 2) Open latches on filter housing
- 3) Bleed off vacuum pressure by pressing manual override on valve, or wait for vacuum to dissipate inside canister
- 4) Take old filter out and replace it with new filter
- 5) Put cover back on
- 6) Close latches on filter housing

Vacuum Hose Replacement

Tools Required:

- Flathead Screwdriver Set

Routine:


- 1) Make sure vacuum pump is off
- 2) Verify hose size
- 3) Loosen hose clamps
- 4) Pull hose off fittings on both sides
- 5) Replace old hose with new hose
 - a) The same hose clamps may be used
- 6) Tighten hose clamps

Vacuum Hub Replacement

Although this topic applies specifically to machine 197, principles may apply to other Aagard rotary placer assemblies.


[Replacement Procedure](#)
[Phase Pick Arm Assembly](#)
[Inspection and Lubrication](#)

The vacuum hub is a wear part which will, from time to time, need to be replaced.




Replacement Procedure

- 1) Remove pick head assemblies by removing two 9/16" bolts on each pick head assembly end (12 bolts total)




- 2) Loosen four Allen head bolts (red arrows) on Aagard hub


NOTE: Three Allen head bolts on face of Aagard hub (blue arrows) may also need to be loosened



- 3) Push rotary pick arm assembly toward motor and gearbox, and remove key



- 4) Remove rotary pick arm assembly
- 5) Remove four Allen head bolts holding vacuum hub to vacuum hub mounting plate




- 6) Remove vacuum hub

- 7) Clean vacuum hub mounting plate, removing grease which may be inside vacuum ports
- 8) Apply DOW Corning® High Vacuum Grease to replacement vacuum hub

NOTE: Do not apply grease into any of the vacuum ports

- 9) Reassemble in reverse order
 - a. When re-installing pick head assemblies, rotate each assembly so it is in top center position, at 0°
 - b. Button head of pick head sprocket must be aligned with button head of the dowel pin plate


NOTE: Pick head pick cups must be pointed 180° in opposite direction of button head



Phase Pick Arm Assembly

Phase each pick arm assembly to adjust when sleeves are picked and placed, if necessary.

- 1) Loosen bolts in slots on both sides of the vacuum hub assembly



- 2) Using an angle finder, rotate pick arm assembly to position between 84° and 85°, left of center




- 3) Re-tighten bolts

Inspection and Lubrication

It is recommended that vacuum hub assembly surfaces and lubrication inspections be made frequently until wear history has been established.

Inspect for:

- nicks and gouges
- excess or missing lubrication
- lubrication inside vacuum ports



Vacuum Sensor Replacement

Tools Required:

- Standard Wrench Set

Routine:

- 1) Turn off vacuum
- 2) Disconnect electrical wire on sensor
- 3) Loosen sensor with standard wrench
- 4) Remove sensor and replace it with new one
 - a) Be sure to use thread tape
- 5) Tighten the new sensor down so it is easily readable
- 6) Reconnect the electrical wire on the sensor
- 7) Turn vacuum on

Vacuum Switch Setup

ZSE40 Vacuum Switch Setup:

- 1) In Aagard wiring diagram, find correct ON and OFF trigger values
- 2) Press and hold SET button until a unit of measure is displayed (example KPa)
- 3) Use UP and DOWN buttons to navigate until inH is displayed (inches of mercury)
- 4) Press and release SET button; this will set inH as unit of measure and display should show a low number as current reading
- 5) Press and release SET button; display should toggle between P_1 and a number
- 6) Use arrow buttons to adjust number of ON trigger value (example -15.0)
- 7) Press and release SET button; display should toggle between P_2 and a number
- 8) Use arrow buttons again to adjust number of OFF trigger value (example -12)
- 9) Press and release SET button; display will toggle between P_3 and a number
- 10) Default value is used for P_3; press/release SET button to go to P_4
- 11) Again, default value is used for P_4; press/release SET button until display is back to main page, which should be showing a low number reading

OUT 1 indicator should not be illuminated, and you are ready for production. Vacuum switch will provide an output when vacuum gets to ON trigger value (example -15.0) and will not turn off output unless vacuum drops below OFF trigger value (example -12.0).

ZSE40A Vacuum Switch Setup:

- 1) In Aagard wiring diagram, find correct P1 and H1 values
- 2) Press and hold SET button until a function is displayed (example F 0)
- 3) Use UP and DOWN buttons to navigate until Uni is displayed
 - a) Use UP key to set display to inH (inches of mercury)
- 4) Press and release SET button; this will set inH as unit of measure and display should show a low number as current reading
- 5) From F 0, press UP key once to navigate to F 1
 - a) Press SET button 3 times so display reads P_1
- 6) Use UP and DOWN buttons to adjust set point to what is stated on wiring diagram
- 7) Press SET button 1 more time so display reads H_1
- 8) Use UP and DOWN buttons to set display to 3.0
- 9) Press SET button 2 times to return to F 1
- 10) Press and hold SET button until display is back to main page; main display should be showing a low number reading


OUT 1 indicator should not be illuminated, and you are ready for production. Vacuum switch will provide an output when vacuum gets to ON trigger value (example -15.0) and will not turn off output unless vacuum drops below OFF trigger value (example -12.0).

Ventillation



Cooling Fan Filter - Hoffman SR1616424

An electrical enclosure may have a Hoffmann SR1616424 cooling fan installed.



At a minimum, the intake filter should be vacuumed daily and replaced monthly. If the intake filter is properly maintained, the exhaust filter should be inspected every 100 hours.

NOTE: Aagard recommends vacuuming the filter instead of blowing it out so that filtered material is not reintroduced into the environment

Adjust frequency of inspection and cleaning based on environmental conditions.

Intake Filter

Remove cover to remove mat for cleaning or replacement.

Exhaust Filter

Carefully lift mat from behind the four screws and over the fan hood.

NOTE: There is one screw centered on each side of the exhaust filter housing



When vacuuming alone is not sufficient to clean filters, follow these manufacturer guidelines:

Wash filter mat in water of up to 104°F, with a mild detergent added if necessary. To clean filter, it is also possible to beat, vacuum, or blow with compressed air. In case of greasy substances, wash filter mat in benzine, trichlorethylene, or warm water with grease solvent added. Do not wring mat or use sharp jet.

Spare Parts, Drawings and Manuals



Spare Parts, Drawings and Manuals

The files made available on this page are the PDF file type and are primarily associated with Adobe Acrobat. When viewing these files, it is possible to click the SAVE button on the Adobe Acrobat toolbar and save a copy of the file being viewed to a new location.

Follow these links to view the following files:

[Spare Parts Lists](#)

[Electrical Drawings](#)

[3D Documentation Model](#)

[3D Documentation Model Tutorial](#)

NOTE: 3D Documentation Models are not available on the HMI PC!

Please reference the following items provided during machine installation:

Manufacturers' Information Binder

NOTE: The following manufacturers' manuals are provided as a courtesy to our customers. These manuals were provided to Aagard when the components were purchased for inclusion on this machine. Updated eManuals may be available from the manufacturers' websites.

Nordson ProBlue Manual ([for PDF version, click here](#)), when so equipped

Marsh Printer Manual ([for PDF version, click here](#)), when so equipped

SmartScan Light Curtain Manual ([for PDF version, click here](#)), when so equipped

To open a .PDF version of this **Machine Operator Manual**, [click here](#).

To contact Aagard regarding Machine Serial #120 :

The Aagard Group, LLC
3711 Iowa Street
Alexandria, MN 56308
www.aagard.com

Normal Business Hours:

Monday through Friday
8:00 AM to 4:30 PM

320-763-6043 (Voice)

320-763-7859 (Fax)

Parts: Option 4

Technical Service: Option 5

After-Hours Technical Service: Option 6

E-Mail:

service@aagard.com

spareparts@aagard.com

Index

- . -

.tsm 5-67

- 1 -

114 5-226
 146 5-220
 147 5-220
 148 5-223
 149 5-136, 5-262
 180 5-158
 197 5-307

- 2 -

2 GB 5-106
 24v 5-80

- 4 -

4V30 5-200

- 6 -

62 5-215

- 8 -

88 5-226

- 9 -

94 5-215

- A -

Aagard 1-2, 5-110
 About 1-3, 3-188
 AC 5-108
 Adcoms 1-81, 3-56
 Address 1-2
 Adhesive 5-148, 5-152
 Adjust Barrel Cam 5-178
 Air 5-196
 Air Cylinders 5-107

Alternating Jog

Accel 1-100, 3-46
 Alt Dwell 1-100, 3-46
 Pos Err Limit 1-100, 3-46
 Position 1 1-100, 3-46
 Position 2 1-100, 3-46
 Start 1-100, 3-46
 Stop 1-100, 3-46
 Torque 1-100, 3-46
 Velocity 1-100, 3-46

Aluminum flight block 5-37

Anvil 5-215, 5-220, 5-223

As-Built 2-3

Assembly 5-196

Associated Devices 1-126, 2-27

Auto-Standby

Configure 5-143

Standby 5-143

- B -

Back-break carton 5-7

Balloon

Drawings 6-2

Barcode

Scanner 5-113

Baud rate 5-71

Bearing 5-154, 5-157

Bearings 5-107

Beckhoff

Help 1-81, 3-56

Bed plates

Non-operator side 5-31

Operator side 5-31

Belt 5-170

Drive 5-173

Product 5-176

Side 5-184

Tension 5-163

Belts 5-15

Bend radius 5-74

Bent 5-34

Bill of Materials 2-3

BIOS 5-106

Blank stop 5-8

Blanks 1-30, 1-31, 1-33, 1-59, 1-60, 1-62, 2-10, 2-11

Blower 5-7

Bogie 5-15, 5-16

Bolt torque 5-132

- BOM 2-3
- Boolean 5-92
- Booleans
- Clean Out 1-19, 1-66, 1-171, 3-16, 3-118
 - Force Aagard Send 1-81, 1-171, 3-56, 3-118
 - Ignore Downstream Avail 1-81, 1-171, 3-56, 3-118
 - Ignore Glue Sys Status 1-171, 3-118
 - Ignore Laser Printer Status 1-171, 3-118
 - Ignore Multiple Rejects 1-171, 3-118
 - Ignore Upstream Send Prod 1-81, 1-171, 3-56, 3-118
 - No Display 1-171, 3-118
 - Park Overhead Adjust 1-171, 3-118
 - QC Carton 1-19, 1-66, 1-171, 3-16, 3-118
 - Remove Aagard Avail 1-81, 1-171, 3-56, 3-118
 - Remove Carton for Wrong Bar Code 1-81, 1-171, 3-56, 3-118
 - Yes Display 1-171, 3-118
- Boot 5-106
- Bowing 1-232
- Buckets
- Bent 5-17, 5-24
 - Damaged 5-17, 5-24
- Bundle Unitizer Lube Points 5-232
- Button 1-13, 1-16, 1-227, 1-230
- C -**
- C15 Diagnostics
- Active SStatus 1-144, 3-131
 - Done Status 1-144, 3-131
 - EStop Recovery Step 1-144, 3-131
 - Fault Response Complete 1-144, 3-131
 - Faulted Status 1-144, 3-131
 - FStopped Status 1-144, 3-131
 - In Use Status 1-144, 3-131
 - Ready Status 1-144, 3-131
 - Recovery Complete 1-144, 3-131
 - Use Sync Recovery 1-144, 3-131
 - Wait For Sync 1-144, 3-131
- C20 Diagnostics
- Active Status 1-144, 3-131
 - Done Status 1-144, 3-131
 - Faulted Status 1-144, 3-131
 - In Use Status 1-144, 3-131
 - Ready Status 1-144, 3-131
 - Sequence Step Status 1-144, 3-131
 - State Complete Status 1-144, 3-131
- C40
- Copy 1-191, 3-11
 - Delete 1-191, 3-11
 - Diagnostics 1-144, 3-131
 - Disable 1-19, 1-66, 3-16
 - Edit 1-191, 3-11
 - EStopped Status 1-144, 3-131
 - Message 1-19, 1-66, 3-16
 - Mode 1-19, 1-66, 1-144, 3-16, 3-131
 - New 1-191, 3-11
 - Power Status 1-144, 3-131
 - Rate 1-19, 1-66, 1-144, 3-16, 3-131
 - Recipes 1-189, 1-191, 3-9, 3-11
 - Rename 1-191, 3-11
 - Reset 1-19, 1-66, 3-16
 - State 1-19, 1-66, 1-144, 3-16, 3-131
- Cable 5-69
- Cam 3-174
- Add 1-207, 3-164
 - Adjust 1-200, 3-183
 - Calculate 1-207, 3-164
 - Data 1-202, 3-159
 - Delete 1-202, 3-159
 - Diagnose 1-200, 3-183
 - Editing Features 3-170
 - Graph 1-202, 3-159
 - Load 1-207, 3-164
 - Master End 1-207, 3-164
 - Master Offset 1-200, 3-183
 - Master Pos 1-202, 3-159
 - Master Start 1-207, 3-164
 - New 1-202, 3-159
 - Offsets Page 1-200, 3-183
 - Position 1-202, 3-159
 - Remove 1-207, 3-164
 - Remove From Cam Gen 1-202, 3-159
 - Rename 1-202, 3-159
 - Segment 1-207, 3-164, 3-170
 - Servo Drive 1-200, 3-183
 - Setup 1-207, 3-164
 - Slave End 1-207, 3-164
 - Slave Offset 1-200, 3-183
 - Slave Pos 1-202, 3-159
 - Slave Start 1-207, 3-164
 - Solenoid Valve 1-200, 3-183
 - Table Length 1-202, 3-159
 - Velocity Start 1-207, 3-164
 - Warning 3-173
- Cam Data 1-202, 3-159

- Cam Data 1-202, 3-159
 Lag Limit 1-156, 1-180, 3-150
 Master Offset Step 1-156, 1-180, 3-150
 Slave Offset Step 1-156, 1-180, 3-150
 Torque Limit 1-156, 1-180, 3-150
- Cam Generator
 2 Axis Graph 1-207, 3-164
 Cam Group 1-205, 3-162
 Choose Product 1-206, 3-163
 Main Screen 1-207, 3-164
 Overlay Graph 1-207, 3-164
 Timing Graph 1-207, 3-164
- Cam Group
 Choose 1-205, 3-162
 Existing 1-205, 3-162
 New 1-205, 3-162
- Cam Segment
 Add 1-207, 3-164, 3-170
 Cam Number 3-170
 Color 1-207, 3-164
 Const Vel 1 (Time) 3-170
 Const Vel 2 (Dist) 3-170
 Curve 1 Master 3-170
 Curve 1 Slave 3-170
 Custom 1 (Open Case w/Tail) 3-170
 Custom 2 (MDist Arc) 3-170
 Dwell 1 3-170
 Edit 3-170
 End Angle 3-170
 End SPos 3-170
 End Vel 3-170
 ID # 3-170
 Master ID # 3-170
 MaxAcc 3-170
 MaxVel 3-170
 MDist 3-170
 Move 1-207, 3-164
 Move 1 3-170
 Move MDist 3-170
 Remove 1-207, 3-164
 SDist 3-170
 SDist Radius 3-170
 Segment 1 (Incr Pos & Vel) 3-170
 Segment 2 (Abs Pos & Vel) 3-170
 Segment 3 (Incr Pos & Time) 3-170
 Segment 4 (Abs Pos & Time) 3-170
 Segment 5 (Time & Vel) 3-170
 Start Angle 3-170
 Time 3-170
- X Radius 3-170
 Y Radius 3-170
- Camera 5-277
- Carton
 Description 2-2
 Carton Blanks 1-30, 1-31, 1-59, 1-60, 2-10
 Carton forming overhead rail 5-39
 Carton forming overhead rail height 5-19
 Carton magazine horizontal adjustment 5-22
 Carton magazine width 5-8
 Carton slot 5-25
 Carton stop 5-26
- Case
 Description 2-2
 Case Blanks 1-30, 1-33, 1-59, 1-62, 2-10, 2-11
 Case Dimension Data
 Palletizer Case Height 3-182
 Palletizer Case Width 3-182
 Case Packer Data 3-180
 Case Refeed
 Enable 5-124
 Case Rotate Data
 Rotate Enable 3-182
- CF 5-106
- Chain 5-171
 Downstacker 5-172
 Tension 5-165
 Wear 5-107
- Change Log 1-89, 1-172, 3-116
 Changeover 1-48, 1-55, 4-2, 4-34
 Adjustments 1-91, 1-193, 3-119, 3-185
 Default Order 1-194, 3-186
 Description 1-91, 3-119
 Download 1-57, 3-13
 Export 1-193, 3-185
 Modified Order 1-194, 3-186
 Name 1-91, 1-194, 3-119, 3-186
 Number 1-194, 3-186
 Product 1-57, 3-13
 Product Combination 1-194, 3-186
 ReArrange 1-193, 3-185
 Value 1-57, 1-91, 3-13, 3-119
- Changeover Location 1-48, 4-2
- Changes 2-4
- Chart 1-55, 4-34
- Checker 5-277
- Clean Out 1-19, 1-66, 3-16, 5-123
 Load Cups 5-125
- Cleanout 5-123, 5-125, 5-262

Cognex 5-277
Compact Flash 5-106
Computer
 Restart 1-81, 3-56
 Shutdown 1-14, 1-81, 1-228, 3-56, 5-192
Connection 5-69
Contact 1-2, 5-110
Continuous Running 1-31, 1-33, 1-34, 1-60, 1-62, 1-63, 2-11, 2-12
 Blanks 1-30, 1-59, 2-10
 Cardboard 1-30, 1-59, 2-10
 Glue Tank 1-30, 1-59, 2-10
 Ink 1-30, 1-59, 2-10
 Sheets 1-30, 1-59, 2-10
Conveyor 5-107, 5-177
Copy data from another cam 3-169
Crooked 5-29
Cross Push Data
 Close Front Containment Pos 3-180
 Cross Push Blend To Loader Time 3-180
C-Stop 1-16, 1-230
Cube Data
 Palletizer Cases Per Row 3-182
 Palletizer Layers Per Cube 3-182
 Palletizer Rows Per Layer 3-182
Cups
 Pick 5-240, 5-304
 Suction 5-240, 5-304
Custom Configuration 3-189
 Cartoner C40 3-192
 Case Packer C40 3-192
 Infeed C40 3-192
 Palletizer C40 3-192
Cycle power 5-50
Cycle Stop 1-13, 1-16, 1-227, 1-230
Cylinder 5-239
Cylinder Switch 1-92, 2-20

- D -

Damage 1-232, 2-4, 5-10, 5-69
Danger 1-12, 1-226
Data Exports 1-81, 3-56
Data Input 3-149
Data rate 5-72
date 1-3
DC 5-108
Deck extension 5-20
Delevery 2-4

Device 1-36, 2-13
 Function 1-126, 2-27
Diagnostics 1-81, 3-56, 5-113, 5-114, 5-116
 Box 1-130, 3-123
 C15 1-144, 3-131
 C20 1-144, 3-131
 C40 1-144, 3-131
 I/O 1-98, 3-139
 Member Map 1-144, 3-131
 Motors 1-135, 3-128
 Popup 1-130, 3-123
 Sercos 1-138, 3-141
 Servo Drive 1-130, 3-123
 Solenoid Valves 1-134, 3-127
Dimension 2-9
Dirt buildup 5-18
Disconnect 1-13, 1-92, 1-227, 2-20
Disk 5-32
Download
 Product 1-47, 3-8
Drawing 1-48, 4-2
Drawings
 Electrical 6-2
 E-Stop 1-13, 1-227
 Floor Plan 1-13, 1-227, 2-9
Drive 1-186, 5-120
 Function 1-126, 2-27
 Status 1-100, 1-156, 1-180, 3-46, 3-150
Dry Cycle 5-116
DryLine 5-158

- E -

Effect 1-36, 2-13
Efficiency 2-7
Eject Cube 1-19, 1-66, 3-16
Electrical
 Drawing 6-2
 Panel 2-26
 Spare Parts 6-2
Email 5-110
E-mail 1-2
Emergency 1-13, 1-227
 Stop 1-16, 1-230
Emergency Stop 1-16, 1-92, 1-230, 2-20
Enable Case Refeed 1-81, 3-56
Equipment 2-3
Error count 5-81
Estop 1-13, 1-227

E-Stop 1-13, 1-16, 1-227, 1-230

- F -

Fault 1-15, 1-43, 1-229, 3-28, 5-126

Clear 1-43, 3-28, 5-115

Fault History

Ack Time 1-69, 1-73, 1-86, 1-158, 1-162, 1-168, 3-38, 3-42, 3-61

Critical 1-69, 1-73, 1-86, 1-158, 1-162, 1-168, 3-38, 3-42, 3-61

Date Stamp 1-69, 1-73, 1-86, 1-158, 1-162, 1-168, 3-38, 3-42, 3-61

Debug 1-69, 1-73, 1-86, 1-158, 1-162, 1-168, 3-38, 3-42, 3-61

Device 1-69, 1-73, 1-86, 1-158, 1-162, 1-168, 3-38, 3-42, 3-61

Down Time 1-69, 1-73, 1-86, 1-158, 1-162, 1-168, 3-38, 3-42, 3-61

Filter 1-69, 1-73, 1-86, 1-158, 1-162, 1-168, 3-38, 3-42, 3-61

General 1-69, 1-73, 1-86, 1-158, 1-162, 1-168, 3-38, 3-42, 3-61

HMI Details 1-69, 1-73, 1-86, 1-158, 1-162, 1-168, 3-38, 3-42, 3-61

Individual 1-69, 1-73, 1-86, 1-158, 1-162, 1-168, 3-38, 3-42, 3-61

Message 1-69, 1-73, 1-86, 1-158, 1-162, 1-168, 3-38, 3-42, 3-61

PLC Details 1-69, 1-73, 1-86, 1-158, 1-162, 1-168, 3-38, 3-42, 3-61

Prod Data 1-69, 1-73, 1-86, 1-158, 1-162, 1-168, 3-38, 3-42, 3-61

Reject 1-69, 1-73, 1-86, 1-158, 1-162, 1-168, 3-38, 3-42, 3-61

Shift 1-69, 1-73, 1-86, 1-158, 1-162, 1-168, 3-38, 3-42, 3-61

Totaled 1-69, 1-73, 1-86, 1-158, 1-162, 1-168, 3-38, 3-42, 3-61

Type 1-69, 1-73, 1-86, 1-158, 1-162, 1-168, 3-38, 3-42, 3-61

Unhandled 1-69, 1-73, 1-86, 1-158, 1-162, 1-168, 3-38, 3-42, 3-61

Utility 1-69, 1-73, 1-86, 1-158, 1-162, 1-168, 3-38, 3-42, 3-61

Warning 1-69, 1-73, 1-86, 1-158, 1-162, 1-168, 3-38, 3-42, 3-61

FC75xx 5-72

Filter Regulator 1-92, 2-20

Find Layer Row 1-19, 1-66, 3-16

Fine Print 2-4

Fingers 5-20

Firmware 5-200

Flaps 5-108

Flash Drive

Replacement 5-188

Flight 5-175

Floor Plan 2-9

Floorplan 2-9

FOB Reader

FOB ID 3-147

Remove 3-147

Site 3-147

Full initialization 5-77, 5-78, 5-79

Function 1-36, 1-126, 2-13, 2-27

Fuse

Location 2-26

- G -

Gap 5-7, 5-13

Gearbox 5-211, 5-212

General Data 1-196, 3-179, 3-180, 3-182

Glue 1-30, 1-59, 1-81, 2-10, 2-12, 3-56

Buildup 5-35, 5-36, 5-37, 5-38

Carton forming 5-38

Dust flap plows 5-35

Edit 1-84, 1-174, 3-59

Filter 5-145

Gun 5-146

Head 5-140, 5-141

Hose 5-147

Hot Melt 5-152

Jig 5-148

Load 1-34, 1-63, 2-12

Major flap plows 5-36

Master Offset 1-84, 1-174, 3-59

Nozzle 5-148, 5-149

Offset Pos 1-84, 1-174, 3-59

Side rails 5-37

Solenoid Valve 5-150, 5-209

Tank 1-34, 1-63, 2-12, 5-143, 5-151

Valve 5-150, 5-209

Glue Head

Adjustments 5-140

Position 5-140

Pressure 5-141

Glue Stitch 1-84, 1-174, 3-59

Glue strip 5-6

Glue Tank 1-34, 1-63, 2-12

Glue Tank 1-34, 1-63, 2-12
 Adjust 5-143

GMI 3-122

Grease 5-130

Guage 5-297

Guard Switch 1-92, 2-20

- H -

HCS 5-59, 5-71

Heat Up 5-270

Help

Aagard Logo 1-19, 1-66, 3-16

About 1-19, 1-66, 3-16

Beckhoff 1-81, 3-56

Servo Drive 1-81, 3-56

User Manual 1-19, 1-66, 1-81, 3-16, 3-56

HMI

Advanced 1-81, 3-56

Main Screen 1-19, 1-66, 3-16

Navigation 1-65, 3-2

Startup 3-4

Version 3-188

Hoppers 5-262

Hot 5-152

How To 5-111

- I -

I/O

Device 5-114

Diagnostics 1-98, 3-139

Search 1-98, 3-139

IDE Device 5-106

Idler Shaft 5-155

IDN S-0-0019 5-78

IDN S-0-0021 5-77

IDN S-0-0022 5-78, 5-79

IDN S-0-0030 5-79

Ignore Downstream Avail 1-81, 3-56

Ignore Upstream Send Prod 1-81, 3-56

Igus 5-158

Index Column 3-168

Inradrive 5-71

Inradrive address 5-76

Inradrive C 5-196

Inradyn 5-196

Infeed 5-176

Bag Length 1-196, 3-179

Bags Per Carton 1-196, 3-179

Carton Filled Position 1-196, 3-179

Flight Position 5-175

Infeed Data

Down Stack Delay 3-180

Full Stack Count 3-180

Infeed Conveyor Speed 3-180

Side Belts Speed 3-180

Init

All 1-156

None 1-156

This Servo 1-156

Initialize 1-138, 3-141, 5-118

Data 1-155, 1-156

Options 1-153, 1-155, 3-5

Standard 1-156

Initialize Data

Accel Limit 1-156, 1-180, 3-150

Drive Loop Monitoring 1-156, 1-180, 3-150

Feed Forward 1-156, 1-180, 3-150

Feedback Reference 1-156, 1-180, 3-150

In Position Bandwidth 1-156, 1-180, 3-150

In Position Monitor Time 1-156, 1-180, 3-150

Inches Per Revolution 1-156, 1-180, 3-150

Input Revolutions 1-156, 1-180, 3-150

Max Accel Limit 1-156, 1-180, 3-150

Max Velocity Limit 1-156, 1-180, 3-150

Modulo 1-156, 1-180, 3-150

Motion Type 1-156, 1-180, 3-150

Negate Feedback 1-156, 1-180, 3-150

Output Revolutions 1-156, 1-180, 3-150

Probe Bandwidth 1-156, 1-180, 3-150

Probe Compare Pos 1-156, 1-180, 3-150

Probe Direction 1-156, 1-180, 3-150

Probe Enable 1-156, 1-180, 3-150

Unit 1-156, 1-180, 3-150

Velocity Limit 1-156, 1-180, 3-150

Initializing 3-7

Input 5-92

Inspect 5-130

Inspection 5-307

Installation 1-232

- J -

Jog

Alternating 1-185

Diagnose 1-100, 3-46

Down 1-100, 3-46

Jog

Motor 1-100, 3-46, 5-117
 Non Operator Side 1-100, 3-46
 Off 1-100, 3-46
 On 1-100, 3-46
 Operator Side 1-100, 3-46
 Servo 1-100, 3-46
 Servo Axis 1-100, 3-46, 5-119
 Solenoid Valve 1-100, 3-46, 5-121
 Stop 1-100, 3-46
 Target Position 1-100, 3-46
 Up 1-100, 3-46
 Velocity 1-100, 3-46

Jog Data

Accel 1-156, 1-180, 3-150
 Decel 1-156, 1-180, 3-150
 Lag Limit 1-156, 1-180, 3-150
 Move # 1-156, 1-180, 3-150
 Torque Limit 1-156, 1-180, 3-150

Jogging 1-100, 3-46, 5-117, 5-119, 5-121

- K -

KCU 5-59, 5-71

Keyboard

Keybd 1-18, 3-3

Knife

Fly knife 5-215, 5-220, 5-223
 Maintenance 5-215, 5-220, 5-223
 Replacement 5-215, 5-220, 5-223, 5-226

- L -

Layout 2-9

LED 5-70

Level Topics 1-211

Liability 2-4

Lift 5-136

Light

Flashing 1-16, 1-230, 5-56
 Flashing Green 5-56
 Flashing Orange 5-56
 Flashing Red 5-56
 Solid 1-16, 1-230
 Solid Red 5-56

Light Curtain 5-290

Lights 1-15, 1-229

Lit 5-51, 5-54, 5-55

Load Cups

Clean Out 5-125

Cleanout Button 5-125

Maintenance 5-125

Load Cups Clean Out 1-19, 1-66, 3-16

Location 1-48, 4-2

Lock 5-40

Lockout 1-12, 1-226

Log 1-89, 1-172, 3-116

Log In

Password 1-17, 1-64, 3-15

User 1-17, 1-64, 3-15

Log Out 1-19, 1-66, 3-16

Logged In Timeout 3-147

Login 1-17, 1-64, 3-15

Long Reals

Bags In Hopper 1-171, 3-118

Lower overhead rail height 5-40

Lubrication 5-130, 5-231, 5-232, 5-307

- M -

Machine 1-108, 2-31

Description 2-2

Dimensions 2-2

Fault 5-108

Operation 1-14, 1-228

Run 5-108

Start 5-108

Machine Operation 1-14, 1-228

Made to specifications 5-29

Magazine

Magazine Advance Speed 1-196, 3-179

Magazine Air Knife Enable 1-196, 3-179

Magazine Blower Enable 1-196, 3-179

Magazine Offset 1-196, 3-179

Magazine height 5-25

Magazine pressure bar extension 5-8

Magazine width 5-7

Main

Carton Ready Pos 1-196, 3-179

Carton Width Between Flights 1-196, 3-179

Cartons Per Minute 1-196, 3-179

Laser Printer Trigger Pos 1-196, 3-179

Overhead Adjust Centerline Pos 1-196, 3-179

Send Carton Blank Pos 1-196, 3-179

Maintenance 1-225

Belt 5-130, 5-163

Chain 5-130, 5-165

Glue 5-140, 5-141, 5-143

- Maintenance 1-225
 - Knife 5-215, 5-220, 5-223, 5-226, 5-228
 - Load Cups 5-125, 5-130
 - Photo Eye 5-130, 5-291, 5-294, 5-295
 - Printer 5-243, 5-252
 - Replacement 5-228
 - Schedule 5-130
 - Servo Motor 1-231
- manual 1-3
- Manufacturer version 5-79
- Manufacturers' Information 6-2
- Marquee 3-120
 - COM Port 3-120
 - Connection Type 3-120
 - Default Message 3-120
 - Display Address 3-120
 - Emulator 3-120
 - IP Port 3-120
 - Settings 3-120
 - Test 3-120
- Marsh 5-243, 5-245, 5-246, 5-247, 5-251
 - Printer 5-252
 - Purge 5-252
- Master Column 3-168
- Materials 1-30, 1-59, 2-10
- Mattop 5-177
- Mechanical
 - Drawing 6-2
 - Spare Parts 6-2
- Member Map 1-144, 3-131
 - Diagnostics 1-144, 3-131
 - Popup 1-144, 3-131
- Message
 - Banner 1-19, 1-66, 3-16
 - C40 1-19, 1-66, 3-16
 - System 1-19, 1-66, 3-16
- Messages 1-43, 3-28, 3-65
 - Cause 3-65
 - Details 3-65
 - Emergency stop 5-49
 - E-Stop 5-49
 - Guard door 5-49
 - Guard relay 5-49
 - Light curtain 5-49
 - Remedy 3-65
 - Safety relay 5-49
 - Type 3-65
- Metal roller 5-13
- MI Drive 5-71, 5-197
- MI motor address 5-76
- Misc Column 3-168
- Misc Tags 1-171, 3-118
- Mode
 - Automatic 1-19, 1-66, 3-16
 - Manual 1-19, 1-66, 3-16
- Modes 1-22, 3-24
- Moon nip roller 5-11
- Motion Data
 - Default Accel 1-156, 1-180, 3-150
 - Default Decel 1-156, 1-180, 3-150
 - Default Lag Limit 1-156, 1-180, 3-150
 - Default Torque 1-156, 1-180, 3-150
 - Default Velocity 1-156, 1-180, 3-150
 - EStop Fast Decel 1-156, 1-180, 3-150
 - EStop Recovery Accel 1-156, 1-180, 3-150
- Motor 1-93, 2-21, 5-108, 5-211, 5-212
 - Analog Speed 1-176, 3-157
 - Cam 3-175
 - Change Direction Delay 1-176, 3-157
 - Configuration 1-176, 3-157
 - Data 1-176, 3-157
 - Forward Sensor 1-176, 3-157
 - Forward Time 1-176, 3-157
 - Jogging 1-100, 3-46, 5-117
 - Master Pos 3-175
 - Reverse Sensor 1-176, 3-157
 - Reverse Time 1-176, 3-157
 - Slave Pos 3-175
 - Speed 1-100, 3-46
 - VFD Controlled 3-175
- Motor Diagnostics
 - Active Status 1-130, 3-123
 - done Status 1-130, 3-123
 - Enable 1-130, 3-123
 - Faulted Status 1-130, 3-123
 - Forward 1-130, 3-123
 - Input 1-130, 3-123
 - Internal 1-130, 3-123
 - Location Status 1-130, 3-123
 - Not Used Status 1-130, 3-123
 - Output 1-130, 3-123
 - Ready Status 1-130, 3-123
 - Reverse 1-130, 3-123
 - Speed 1-130, 3-123

- N -

Nordson 1-34, 1-63, 2-12, 5-143, 5-152

Not sealing 5-46
 Notice History 1-69, 1-73, 1-86, 1-158, 1-162,
 1-168, 3-38, 3-42, 3-61
 Notices 1-43, 3-28
 Type 3-65
 NumberPad
 NumPad 1-18, 3-3

- O -

 Oil
 Changing 5-303
 Level 5-303
 Vacuum Pump 5-303
 Open circuit 5-53
 Open contacts 5-52
 Operation 1-14, 1-36, 1-228, 2-13
 Output 5-92
 Overhead floating top rail 5-30
 Overhead rail 5-30

- P -

 Packer Main Data
 Check Open Trailing Minor Position 3-180
 Glue Gap % 3-180
 Glue Gap Enable 3-180
 Load Cups Blowout Time 3-180
 Palletizer
 Data 3-182
 General Data 3-182
 Panel
 Electrical 2-26
 Parts 5-133, 6-2
 Pause 5-100
 PC
 Shutting Down 1-14, 1-81, 1-228, 3-56, 5-192
 PDF 6-2
 Performance 2-4
 Phone 1-2, 5-110
 Photo Eye 1-93, 2-21
 Cleaning 5-291
 Excess wire 5-292
 PE 5-114, 5-291, 5-294, 5-295
 Replace 5-293
 Setup 5-294, 5-295
 Wire loops 5-292
 Wiring 5-292
 Photo Eyes 5-108

Pick Bearing 5-157
 Popup 1-43, 3-28
 Position 1-108, 2-31, 5-175
 Power 1-232, 5-70
 Loss 1-14, 1-81, 1-228, 3-56, 5-192
 Shutting Down 1-14, 1-81, 1-228, 3-56, 5-192
 Pressure 5-11, 5-141, 5-143
 Pressure Regulator 5-297
 Pressure Sensor
 Replacement 5-298
 Setup 5-298
 Pressure Switch 1-94, 2-22
 Printer
 Controller 5-247
 Hose 5-251
 Ink Head 5-245
 Ink Supply 5-246
 Marsh 5-243, 5-245, 5-246, 5-247, 5-251, 5-252
 Message 5-243
 Purge 5-252
 Process of elimination 5-73
 Product 2-2
 Change 1-19, 1-57, 1-66, 3-13, 3-16
 Changeover 1-57, 3-13
 Download 1-19, 1-57, 1-66, 3-13, 3-16
 Product Data
 Cam Data 3-149
 Cam Offsets 3-149
 Changeover Adjustments 3-149
 General Data 3-149
 Servo Moves Data 3-149
 Production Data 1-19, 1-66, 1-166, 3-16, 3-36
 Edit Shifts 1-26, 1-77, 3-32
 Products
 Add 1-189, 3-9
 Change 1-47, 3-8
 Delete 1-189, 3-9
 Download 1-47, 3-8
 Edit 1-47, 1-189, 3-8, 3-9
 Rename 1-189, 3-9
 Prox 1-94, 2-22, 5-299
 Proximity Sensor 5-299
 Pulley 5-155
 Pump 1-152, 5-127
 Purge 5-196
 Push Button 1-93, 2-21

- Q -

QC Case 1-19, 1-66, 3-16
 Quick Reference 1-55, 4-34

- R -

Radius 5-69
 Rearrange Page 1-194, 3-186
 Reboot 5-106
 Recipe
 C40 1-189, 3-9
 Copy 1-189, 3-9
 Import 1-189, 3-9
 Recovery
 From Backup 5-188
 Refeed Mode 5-124
 Reference 1-55, 4-34
 Actual Position 1-105, 3-53
 Barrel cam 5-21, 5-28, 5-32
 Carton picker servo 5-9
 Direction of Pos Movement 1-105, 3-53
 Home End Pos 1-105, 3-53
 Home Pos 1-105, 3-53
 Image 1-105, 3-53
 Information 6-2
 Page 1-105, 3-53
 Reference Mark Location 1-105, 3-53
 Reference Mark Position 1-105, 3-53
 Routine 1-105, 3-53
 Servo 1-105, 1-108, 2-31, 3-53
 Servo Drive 5-120
 Referencing
 Dir Pos Movement 1-183, 3-153
 Image 1-183, 3-153
 Precision 1-183, 3-153
 Ref Mark Location 1-183, 3-153
 Reference Mark Position 1-183, 3-153
 Referencing Data
 Accel 1-156, 1-180, 3-150
 Decel 1-156, 1-180, 3-150
 End Position 1-156, 1-180, 3-150
 Lag Limit 1-156, 1-180, 3-150
 Low Velocity 1-156, 1-180, 3-150
 Move # 1-156, 1-180, 3-150
 Probe Clear Dist 1-156, 1-180, 3-150
 Ref Verification Type 1-156, 1-180, 3-150
 Reference Position 1-156, 1-180, 3-150

Reference Velocity 1-156, 1-180, 3-150
 Referencing Direction 1-156, 1-180, 3-150
 Referencing Type 1-156, 1-180, 3-150
 Standard Referencing 1-156, 1-180, 3-150
 Torque 1-156, 1-180, 3-150
 Regulator 1-95, 2-23, 5-141, 5-297
 Reinitialize 1-138, 3-141, 5-118
 Reject History 1-69, 1-73, 1-86, 1-158, 1-162,
 1-168, 3-38, 3-42, 3-61
 Remove Aagard Avail for Prod 1-81, 3-56
 Replacing
 MI Drive 5-197
 Parts 5-133
 Replenish 1-30, 1-31, 1-33, 1-34, 1-59, 1-60, 1-62,
 1-63, 2-10, 2-11, 2-12
 Report Generator
 Archive Path 3-189
 Delete Files Older Than 3-189
 Delete Records Older Than 3-189
 Entry Point 3-189
 Generate Detail Rpt 3-189
 Generate Summary Rpt 3-189
 Output Path 3-189
 Report Process Config 3-189
 Report Process DLL 3-189
 Shut Down 3-189
 Test Output 3-189
 Results 5-101
 Resume 5-100
 Retract 5-126
 Rexroth 5-196
 Ring
 Stabilize 5-81
 Unstable 5-81
 Robot 1-231
 Robot Data
 Case Conveyor Height 3-182
 Cube Discharge Conveyor Height 3-182
 Cube Offset Dist 3-182
 Robot Early Release Distance 3-182
 Slip Sheet Score To Accumulation Dist 3-182
 Vertical Nest Dist 3-182
 Rod Ends 5-156
 Roller 5-169
 Rotary Placer 5-307
 Run 5-116

- S -

- S18 5-77
- Safety 1-12, 1-13, 1-225, 1-226, 1-227
- Schedule 5-130
- See Graph For Drop Down Menu 3-167
- See Points For Drop Down Menu 3-168
- Send this cam to another master 3-169
- Sensor 5-298, 5-299
- Sequence 1-36, 2-13
- Sercos
 - Diagnostics 1-138, 1-155, 3-141
 - Errors 1-138, 3-141
 - IDN 1-138, 3-141
 - Initialize 1-138, 3-141
 - Node Status 1-138, 3-141
 - Nodes 1-138, 3-141
 - Reinitialize 1-138, 3-141
 - Req Phase 1-138, 3-141
 - Ring 1-138, 3-141
- Service 1-2
- Servo 1-183, 3-153
 - Accel 1-197, 3-176
 - Advanced 1-180, 3-150
 - Axis Jogging 1-100, 3-46, 5-119
 - Cable 5-205
 - Coupling 5-195
 - Data 1-180, 3-150
 - Decel 1-197, 3-176
 - Default Fields 1-197, 3-176
 - Delete 1-197, 3-176
 - Diagnose 1-197, 3-176
 - Drive 5-197
 - Drive Diagnostics 1-130, 3-123
 - Drive Reference 5-120
 - Drive Status 1-197, 3-176
 - Drive Tuning 1-186
 - Gearbox 5-195, 5-206
 - Help 1-81, 3-56
 - Initialize Options 1-153, 1-155, 3-5
 - Jogging 1-100, 3-46
 - Modulo 1-197, 3-176
 - Motor 1-231
 - Motor with Brake 1-231
 - Move 1-197, 3-176
 - Moves Data 1-197, 3-176
 - New 1-197, 3-176
 - Position Error Limit 1-197, 3-176
 - Reference 1-105, 3-53
 - Reference Positions 1-108, 2-31
 - Rename 1-197, 3-176
 - Servo Axis Move Parameters 1-197, 3-176
 - Standard 1-180, 3-150
 - Torque 1-197, 3-176
 - Velocity 1-197, 3-176
- Servo Diagnostics
 - Act Pos Status 1-130, 3-123
 - Act Torq Status 1-130, 3-123
 - Active Status 1-130, 3-123
 - Display Status 1-130, 3-123
 - Done Status 1-130, 3-123
 - Enabled Status 1-130, 3-123
 - Faulted Status 1-130, 3-123
 - In Use Status 1-130, 3-123
 - Location Status 1-130, 3-123
 - Max Torq Status 1-130, 3-123
 - Negative Direction 1-130, 3-123
 - Positive Direction 1-130, 3-123
 - Ready Status 1-130, 3-123
 - Reset Features 1-130, 3-123
- Servo Drive 1-156, 1-180, 1-197, 3-150, 3-176
 - Initialize 3-7
 - Step 3-7
- Servo Motor 1-95, 2-23, 5-109
- Servo Power 1-93, 2-21
- Servo Reference 1-183, 3-153
- Settings
 - Default 1-235
 - Factory 1-235
- Setup Data
 - Motor Data 3-149
 - Servo Drive Data 3-149
 - Solenoid Data 3-149
- Setup Users
 - Button 1-83, 3-58
- Shaft 5-154
- Sheets 1-30, 1-59, 2-10
- Shifts
 - Begin 1-166, 3-36
 - Edit 1-166, 3-36
 - End 1-166, 3-36
- Shutdown 1-152, 5-127
- Shutting Down 1-14, 1-81, 1-228, 3-56, 5-192
- Sick
 - KT8L 5-294
 - WL12G 5-295
- Side Belts 5-212

- Side seal not aligned 5-44
 - Side seam height 5-18
 - Side to side 5-43
 - Skewed 5-33
 - Skid 1-232
 - Slave Column 3-168
 - Slide-Rite
 - Gearbox 5-207, 5-213
 - Lubrication 5-207, 5-213
 - Slip 5-16
 - Slip Sheet 5-157
 - Roller 5-185
 - Solenoid Diagnostics
 - A Coil 1-130, 3-123
 - A Switch 1-130, 3-123
 - Active Status 1-130, 3-123
 - B Coil 1-130, 3-123
 - B Switch 1-130, 3-123
 - Done Status 1-130, 3-123
 - Faulted Status 1-130, 3-123
 - Input 1-130, 3-123
 - Internal 1-130, 3-123
 - Location Status 1-130, 3-123
 - Not Used Status 1-130, 3-123
 - Output 1-130, 3-123
 - Ready Status 1-130, 3-123
 - Solenoid Valve 1-96, 2-24
 - A Coil 1-100, 3-46
 - A Sensor 1-178, 3-155
 - A Time 1-178, 3-155
 - B Coil 1-100, 3-46
 - B Sensor 1-178, 3-155
 - B Time 1-178, 3-155
 - Cams 3-174
 - Configuration 1-178, 3-155
 - Data 1-178, 3-155
 - DeBounce Time 1-178, 3-155
 - Jam Time 1-178, 3-155
 - Jogging 1-100, 3-46, 5-121
 - Master Pos 3-174
 - Slave Pos 3-174
 - Span 5-163, 5-165
 - Spare 6-2
 - Spare Parts 6-2
 - Specifications 2-2
 - Splice tape 5-47
 - Springs 5-215, 5-220, 5-223
 - Square 5-29
 - Standard 2-3
 - Start 1-13, 1-15, 1-227, 1-229
 - Light 1-16, 1-230
 - Startup 1-15, 1-17, 1-47, 1-57, 1-64, 1-153, 1-155, 1-156, 1-229, 3-4, 3-5, 3-8, 3-13, 3-15
 - States 1-22, 3-24
 - Station address 5-76
 - Stop 1-13, 1-227
 - Storage Temperature 5-270
 - Strings 1-171, 3-118
 - Support 5-110
 - Switch
 - Guard Door 5-289
 - Setup 5-301, 5-314
 - Slip Sheet in Place 5-300
 - Vacuum 5-301, 5-314
 - System
 - Edit 1-189, 3-9
 - Messages 1-86, 1-168, 3-61
 - Notices 1-86, 1-168, 3-61
 - Products 1-47, 1-189, 3-8, 3-9
 - System manager 5-67
- T -**
- Tags
 - Close 5-93
 - Reopen 5-93
 - Tagout 1-12, 1-226
 - Tags 3-122
 - Activity Code 3-122
 - Custom 3-122
 - Deal Code 3-122
 - Rate Code 3-122
 - Temperature 5-143, 5-152, 5-270
 - Tension 5-16, 5-163
 - Tensioner
 - Cylinder Tension 5-178
 - Terms
 - Acceptance 2-4
 - Delivery 2-4
 - Liability 2-4
 - Payment 2-4
 - Warranty 2-4
 - Test cable 5-73
 - Test Carton 1-83, 3-58
 - Test Carton Quantity 1-83, 3-58
 - TJUI-23-12 5-158
 - Top carton guide 5-7, 5-8
 - Top Position 5-134

Torque 5-132
Torque Monitoring
 Torq Warning Threshold % 1-156, 1-180, 3-150
 Torque Averaging Count 1-156, 1-180, 3-150
Tracking running constantly 5-43
Training 1-211
Transformer 1-97, 2-25
Transmission setting 5-71
Transmission settings 5-72
Trigger 5-277
Troubleshoot 1-36, 2-13
Tucker Arm 5-134
Tuning 1-186
 Default 1-100, 3-46
 Position Prop Gain 1-100, 3-46
 Rejection Bandwidth 1-100, 3-46
 Rejection Frequency 1-100, 3-46
 Velocity Integral Action Time 1-100, 3-46
 Velocity Prop Gain 1-100, 3-46
TwinCAT 5-67

- U -

Unitizer Data 3-182
update 1-3
Urethane roller 5-13
User
 Levels 1-17, 1-64, 1-211, 3-15
 Log In 1-17, 1-64, 3-15
 Password 1-17, 1-64, 3-15
 Training 1-211
Users
 Level 3-147
 Password 3-147
 Set Up 1-81, 3-56
 Setup 3-147
 User Name 3-147

- V -

V Roller 5-186
Vacuum 1-152, 5-109, 5-127
 Filter 5-305
 Hoses 5-306
 Sensor 5-313
Vacuum Switch 1-97, 2-25, 5-301, 5-314
Valve Bank 5-241
Velocity Column 3-168
version 1-3

Vertical Cartoner 5-228
Vertical slot guide 5-26
Voltage 1-232
V-Rail 5-169

- W -

Warning 1-12, 1-225, 1-226
Warning Horn 1-15, 1-229
Warped 5-30
Warranty 2-4, 2-7
 Void 1-232
Washdown
 Henkel 5-201, 5-271
 High pressure 5-275
 Loctite 5-201, 5-271
 Recommendations 5-275
 Rexroth 5-201, 5-271
 Sealant 5-201, 5-271
 Sealing Rexroth Servo Drives 5-201, 5-271
 Use of air 5-275
Wear 5-10
Web 5-110
Welded tab 5-25
Wheels 5-15
Wiring 6-2
Wiring Diagram 6-2
Wiring sequence 5-71